

R&S®SMW-K68

TETRA Release 2

User Manual



1175681002
Version 18

ROHDE & SCHWARZ
Make ideas real



This document describes the following software options:

- R&S®SMW-K68 TETRA Release 2 (1413.4439.xx)

This manual describes firmware version FW 5.30.047.xx and later of the R&S®SMW200A.

© 2023 Rohde & Schwarz

Muehldorfstr. 15, 81671 Muenchen, Germany

Phone: +49 89 41 29 - 0

Email: info@rohde-schwarz.com

Internet: www.rohde-schwarz.com

Subject to change – data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

Trade names are trademarks of the owners.

1175.6810.02 | Version 18 | R&S®SMW-K68

The following abbreviations are used throughout this manual: R&S®SMW200A is abbreviated as R&S SMW, R&S®WinIQSIM2™ is abbreviated as R&S WinIQSIM2; the license types 02/03/07/11/13/16/12 are abbreviated as xx.

Contents

1	Welcome to the TETRA2 digital standard.....	5
1.1	Accessing the TETRA dialog.....	5
1.2	What's new.....	6
1.3	Documentation overview.....	6
1.3.1	Getting started manual.....	6
1.3.2	User manuals and help.....	6
1.3.3	Tutorials.....	7
1.3.4	Service manual.....	7
1.3.5	Instrument security procedures.....	7
1.3.6	Printed safety instructions.....	7
1.3.7	Data sheets and brochures.....	7
1.3.8	Release notes and open source acknowledgment (OSA).....	7
1.3.9	Application notes, application cards, white papers, etc.....	8
1.3.10	Videos.....	8
1.4	Scope.....	8
1.5	Notes on screenshots.....	8
2	Required options.....	10
3	TETRA2 configuration and settings.....	11
3.1	General settings.....	11
3.2	Trigger settings.....	16
3.3	Marker settings.....	21
3.4	Clock settings.....	23
3.5	Local and global connectors settings.....	24
3.6	Frame configuration settings.....	25
3.7	Burst editor.....	25
3.8	BSCH / BNCH/T.....	30
3.8.1	TETRA frequency.....	30
3.8.2	Contents settings.....	33
3.8.3	Scrambling.....	36
3.9	Filter / clipping settings.....	38
3.9.1	Filter settings.....	38

3.9.2	Modulation settings.....	40
3.9.3	Clipping settings.....	41
3.10	Power ramp control.....	42
3.10.1	Ramp control.....	43
3.10.2	Slot attenuations.....	44
4	Remote control commands.....	46
4.1	General commands.....	47
4.2	Power ramp commands.....	53
4.3	Slot configuration commands.....	55
4.4	BSCH / BNCH/T commands.....	63
4.5	Filter/clipping commands.....	71
4.6	Trigger commands.....	73
4.7	Marker commands.....	80
4.8	Clock commands.....	83
	List of commands.....	85
	Index.....	88

1 Welcome to the TETRA2 digital standard

The R&S SMW-K68 is a firmware application that adds functionality to generate signals in accordance with the standard Terrestrial Trunked Radio Release 2 (TETRA2).

The R&S SMW-K68 main features:

- Generating of a signal in accordance with ETSI EN 300 392-2.
- The TETRA frame (bit stream) is generated according to the selected burst type, i.e. control burst (CB), normal burst (NB) or synchronization burst (SB).
- The frames are generated for the uplink (mobile station [MS] transmitting) or the downlink (base station [BS] transmitting).
- The channel types AACH, BSCH, BNCH, TCH, STCH, SCH as well as the TETRA Release 2 specific channels like SCH-Q, etc. are generated.
- Channel coding including scrambling with system code, base color code, mobile country code and mobile network code are performed for all channels.
- Frame repetition can be selected via sequence length.
- The T1 test signal is generated for the V+D (voice and data) test on MS and BS DUTs.
- Test channel types can be set for the downlink and for the uplink.
- The bit stream can be generated either from pseudo-random sequences (CCITT O.153) or from user-selectable sequences.
- The R&S SMW calculates the appropriate TETRA2 T1, T2, T3 and T4 signal according to the specification.
- Additionally, user-defined test signal can be generated.

This user manual contains a description of the functionality that the application provides, including remote control operation.

All functions not discussed in this manual are the same as in the base unit and are described in the R&S SMW user manual. The latest version is available at:

www.rohde-schwarz.com/manual/SMW200A

Installation

You can find detailed installation instructions in the delivery of the option or in the R&S SMW service manual.

1.1 Accessing the TETRA dialog

To open the dialog with TETRA settings

- ▶ In the block diagram of the R&S SMW, select "Baseband" > "TETRA".

A dialog box opens that displays the provided general settings.

The signal generation is not started immediately. To start signal generation with the default settings, select "State" > "On".

1.2 What's new

This manual describes firmware version FW 5.30.047.xx and later of the R&S®SMW200A.

Compared to the previous version, it provides the new features listed below:

- Time-based triggering, see "[Time Based Trigger](#)" on page 18 and "[Trigger Time](#)" on page 18.
- Editorial changes

1.3 Documentation overview

This section provides an overview of the R&S SMW user documentation. Unless specified otherwise, you find the documents at:

www.rohde-schwarz.com/manual/smw200a

1.3.1 Getting started manual

Introduces the R&S SMW and describes how to set up and start working with the product. Includes basic operations, typical measurement examples, and general information, e.g. safety instructions, etc. A printed version is delivered with the instrument.

1.3.2 User manuals and help

Separate manuals for the base unit and the software options are provided for download:

- Base unit manual
Contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance, instrument interfaces and error messages. Includes the contents of the getting started manual.
- Software option manual
Contains the description of the specific functions of an option. Basic information on operating the R&S SMW is not included.

The contents of the user manuals are available as help in the R&S SMW. The help offers quick, context-sensitive access to the complete information for the base unit and the software options.

All user manuals are also available for download or for immediate display on the Internet.

1.3.3 Tutorials

The R&S SMW provides interactive examples and demonstrations on operating the instrument in form of tutorials. A set of tutorials is available directly on the instrument.

1.3.4 Service manual

Describes the performance test for checking compliance with rated specifications, firmware update, troubleshooting, adjustments, installing options and maintenance.

The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS):

<https://gloris.rohde-schwarz.com>

1.3.5 Instrument security procedures

Deals with security issues when working with the R&S SMW in secure areas. It is available for download on the internet.

1.3.6 Printed safety instructions

Provides safety information in many languages. The printed document is delivered with the product.

1.3.7 Data sheets and brochures

The data sheet contains the technical specifications of the R&S SMW. It also lists the options and their order numbers and optional accessories.

The brochure provides an overview of the instrument and deals with the specific characteristics.

See www.rohde-schwarz.com/brochure-datasheet/smw200a

1.3.8 Release notes and open source acknowledgment (OSA)

The release notes list new features, improvements and known issues of the current firmware version, and describe the firmware installation.

The software makes use of several valuable open source software packages. An open-source acknowledgment document provides verbatim license texts of the used open source software.

See www.rohde-schwarz.com/firmware/smw200a

1.3.9 Application notes, application cards, white papers, etc.

These documents deal with special applications or background information on particular topics.

See www.rohde-schwarz.com/application/smw200a and www.rohde-schwarz.com/manual/smw200a

1.3.10 Videos

Find various videos on Rohde & Schwarz products and test and measurement topics on YouTube: <https://www.youtube.com/@RohdeundSchwarz>



On the menu bar, search for your product to find related videos.



Figure 1-1: Product search on YouTube

1.4 Scope



Tasks (in manual or remote operation) that are also performed in the base unit in the same way are not described here.

In particular, it includes:

- Managing settings and data lists, like saving and loading settings, creating and accessing data lists, or accessing files in a particular directory.
- Information on regular trigger, marker and clock signals and filter settings, if appropriate.
- General instrument configuration, such as checking the system configuration, configuring networks and remote operation
- Using the common status registers

For a description of such tasks, see the R&S SMW user manual.

1.5 Notes on screenshots

When describing the functions of the product, we use sample screenshots. These screenshots are meant to illustrate as many as possible of the provided functions and

possible interdependencies between parameters. The shown values may not represent realistic usage scenarios.

The screenshots usually show a fully equipped product, that is: with all options installed. Thus, some functions shown in the screenshots may not be available in your particular product configuration.

2 Required options

The basic equipment layout for generating TETRA Release 2 signals includes the:

- Standard or wideband Baseband Generator (R&S SMW-B10/-B9)
- Baseband main module (R&S SMW-B13) or wideband baseband main module (R&S SMW-B13XT)
- Frequency option (e.g. R&S SMW-B1003)
- Digital standard TETRA release 2 (R&S SMW-K68)

You can generate signals via play-back of waveform files at the signal generator. To create the waveform file using R&S WinIQSIM2, you do not need a specific option.

To play back the waveform file at the signal generator, you have two options:

- Install the R&S WinIQSIM2 option of the digital standard, e.g. R&S SMW-K255 for playing LTE waveforms
- If supported, install the real-time option of the digital standard, e.g. R&S SMW-K55 for playing LTE waveforms

For more information, see data sheet.

3 TETRA2 configuration and settings

Access:

- ▶ Select "Baseband" > "TETRA".

The remote commands required to define these settings are described in [Chapter 4, "Remote control commands"](#), on page 46.

Contents


● General settings	11
● Trigger settings	16
● Marker settings	21
● Clock settings	23
● Local and global connectors settings	24
● Frame configuration settings	25
● Burst editor	25
● BSCH / BNCH/T	30
● Filter / clipping settings	38
● Power ramp control	42

3.1 General settings

Access:

- ▶ Select "Baseband > TETRA > General".

This dialog provides access to the default, the "Save/Recall" settings and provides test mode, channel type and link direction selection. The selected test mode and link direction determine the available parameters.



Settings:

State	12
Set to Default	12
Save/Recall	13
Generate Waveform	13
Test Mode	13
Link Direction	14
Channel Type	15
Modulation Type	15
Downlink Burst Type	15
Sequence Length	15
BSCH / BNCH/T	15
Filter / Clipping	15
Power Ramp/Slot Attenuations	15

State

Enables or disables the TETRA standard.

Activates the standard and deactivates all the other digital standards and digital modulation modes in the same path.

Remote command:

[\[:SOURce<hw>\] :BB:TETRA:STATE](#) on page 51

Set to Default

Calls the default settings. The values of the main parameters are listed in the following table.

Parameter	Value
State	Not affected by "Set to Default"
Test Mode	T1

Parameter	Value
Link Direction	Downlink / Forward
Channel Type	0
Sequence Length	1 Multiframe
Power Ramp/Slot Attenuation	cosine/ 2 / 0 / 0sym
Filter/Clipping	Root Cosine / clipping Off
Trigger/Marker	Auto/Int
Clock	Internal

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:PRESet](#) on page 49

Save/Recall

Accesses the "Save/Recall" dialog, that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.

The settings are saved in a file with predefined extension. You can define the filename and the directory, in that you want to save the file.

See also, chapter "File and Data Management" in the R&S SMW user manual.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:SETTING:LOAD](#) on page 50

[\[:SOURce<hw>\] :BB:TETRa:SETTING:STORE](#) on page 51

[\[:SOURce<hw>\] :BB:TETRa:SETTING:CATALOG?](#) on page 50

[\[:SOURce<hw>\] :BB:TETRa:SETTING:DELETE](#) on page 50

Generate Waveform

With enabled signal generation, triggers the instrument to save the current settings of an arbitrary waveform signal in a waveform file with predefined extension *.wv. You can define the filename and the directory, in that you want to save the file.

Using the ARB modulation source, you can play back waveform files and/or process the file to generate multi-carrier or multi-segment signals.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:WAVEform:CREATE](#) on page 52

Test Mode

Selects the test mode.

Several settings depend on the selected test model.

"T1"	<p>Test signal T1 (TETRA wanted signal, phase modulated)</p> <p>This test mode enables the generation of test signals that comply with the TETRA air interface multiframe, frame and slot structure. The T1 test signal is generated according to EN 300 394-1V3.1.1 and is intended to be the wanted signal transmitted by the test system during frames 1 to 17 in all receiver tests.</p> <p>The signal is pi/4-DQPSK or pi/8-D8PSK modulated. Frame 18 transmits information for control purposes.</p> <p>To enable configuration of the T1 signal for different receiver tests, the channel type for the "T1" signal is user-selectable. Channel types 0 to 4, 21, 22 and 25 are available in the Downlink/Forward "Link Direction" and channel types 7 to 11, 21, 23 and 24 for the Uplink/Reverse direction.</p> <p>The burst types Uplink/Reverse and Downlink/Forward are derived from the channel types. The instrument generates the Tx data for complete multiframe for the V+D service (voice and data). The contents of data fields are automatically inserted according to the burst type. The control block (cb), blocks 1 + 2 (bk), the synchronization block (sb) and the broadcast block (bb) for test signal T1 are generated according to the frame number and the channel type.</p>
"T4"	<p>Test signal T4 (TETRA wanted signal, QAM modulated)</p> <p>The test signal T4 complies with the TETRA air interface multiframe, frame and slot structure. The T4 test signal is intended to be the wanted signal transmitted by the test system during frames 1 to 17 in all receiver tests. Except for frame 18, the signal is 4-QAM, 16-QAM or 64-QAM modulated. Frame 18 transmits information for control purposes and is QAM and phase modulated (QAM + pi/4-DQPSK); the frame is generated according to EN 300 394-1.</p>
"User Defined"	Enables the generation of user-defined test signal.
"T2"	<p>Test signal T2 (TETRA interfere)</p> <p>The T2 test signal is phase or QAM modulated, depending on the selected Modulation Type.</p>
"T3"	<p>Test signal T3 (unmodulated interferer)</p> <p>The T3 test signal is an unmodulated continuous sinusoidal out-of-band interfering signal.</p>

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:TMode](#) on page 52

Link Direction

Selects the transmission direction.

This parameter determines the available "Channel Types".

"Downlink/ Forward"	The transmission direction selected is from the base station (BS) to the terminal (MS). The signal corresponds to that of a BS.
"Uplink/ Reverse"	The transmission direction selected is from MS to the BS. The signal corresponds to that of a terminal.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:LDIRection](#) on page 49

Channel Type

(for "Test Model" set to T1 or T4)

Determines the channel type.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:CTYPe](#) on page 48**Modulation Type**

(for "Test Model" set to "User Defined" or "T2")

Determines the modulation type, "Phase" or "QAM."

"Phase"	The T2 test signal is a pi/4-DQPSK modulated continuous radio signal.
---------	---

"QAM"	The T2 test signal is 4-QAM, 16-QAM or 64-QAM modulated and spans a bandwidth of 25kHz, 50kHz, 100kHz or 150kHz.
-------	--

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:MTYPe](#) on page 49**Downlink Burst Type**

(in Downlink "Link Direction" and for "Test Model" set to "T2" or "User Defined")

Determines whether a discontinuous or continuous downlink burst type is used.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:DBTYpe](#) on page 48**Sequence Length**

Selects the sequence length of the arbitrary waveform file in the number of multiframes. One multiframe is the minimum sequence length for a T1 signal.

Remote command:


[\[:SOURce<hw>\]:BB:TETRa:SLENgth](#) on page 51**BSCH / BNCH/T**Accesses the "BSCH / BNCH/T" dialog, used to configure the frequency settings, the scrambling code and the content of the "Broadcast Synchronization Channel (BSCH)" and the "Broadcast Network Channel (BNCH/T)", see [Chapter 3.8, "BSCH / BNCH/T", on page 30](#).**Filter / Clipping**Access to the dialog for setting baseband filtering, clipping and the sequence length of the arbitrary waveform component, see [Chapter 3.9, "Filter / clipping settings", on page 38](#).**Power Ramp/Slot Attenuations**Calls the "Power Ramp Control" dialog. This dialog is used to set the power ramping parameters and for setting values for the level attenuation in dB (see [Chapter 3.10, "Power ramp control", on page 42](#)).

The currently selected ramp function and ramp time are displayed.

3.2 Trigger settings

Access:

- ▶ Select "Baseband" > "TETRA" > "Trigger In".



This tab provides settings to select and configure the trigger, like trigger source, trigger mode and trigger delays, and to arm or trigger an internal trigger manually. The header of the tab displays the status of the trigger signal and trigger mode. As in the tabs "Marker" and "Clock", this tab provides also access to the settings of the related connectors.

Routing and activating a trigger signal

1. Define the effect of a trigger event and the trigger signal source.
 - a) Select "Trigger In" > "Mode".
 - b) Select "Trigger In" > "Source".
2. For external trigger signals, define the connector for signal input. See [Chapter 3.5, "Local and global connectors settings", on page 24](#). You can map trigger signals to one or more USER x or T/M connectors. Local and global connectors settings allow you to configure the signal mapping, the polarity, the trigger threshold and the input impedance of the input connectors.
3. Activate baseband signal generation. In the block diagram, set "Baseband" > "On". The R&S SMW starts baseband signal generation after the configured trigger event.

About baseband trigger signals

This section focuses on the available settings.

For information on how these settings affect the signal, refer to section "Basics on ..." in the R&S SMW user manual.

Settings:

Trigger settings common to all basebands.....	17
Mode.....	17
Signal Duration Unit.....	17
Signal Duration.....	18
Running/Stopped.....	18
Time Based Trigger.....	18
Trigger Time.....	18

Arm.....	18
Execute Trigger.....	19
Source.....	19
Sync. Output to External Trigger/Sync. Output to Trigger.....	19
External Inhibit/Trigger Inhibit.....	20
External Delay/Trigger Delay.....	20

Trigger settings common to all basebands

To enable simultaneous signal generation in all basebands, the R&S SMW couples the trigger settings in the available basebands in any instrument's configuration involving signal routing with signal addition. For example, in MIMO configuration, routing and summing of basebands or of streams.

The icon  indicates that common trigger settings are applied.

You can access and configure the common trigger source and trigger mode settings in any of the basebands. An arm or a restart trigger event applies to all basebands, too. You can still apply different delay to each of the triggers individually.

Mode

Selects trigger mode, i.e. determines the effect of a trigger event on the signal generation.

For more information, refer to chapter "Basics" in the R&S SMW user manual.

- "Auto"
The signal is generated continuously.
- "Retrigger"
The signal is generated continuously. A trigger event (internal or external) causes a restart.
- "Armed Auto"
The signal is generated only when a trigger event occurs. Then the signal is generated continuously.
An "Arm" stops the signal generation. A subsequent trigger event (internal or external) causes a restart.
- "Armed Retrigger"
The signal is generated only when a trigger event occurs. Then the signal is generated continuously. Every subsequent trigger event causes a restart.
An "Arm" stops signal generation. A subsequent trigger event (internal or external) causes a restart.
- "Single"
The signal is generated only when a trigger event occurs. Then the signal is generated once to the length specified at "Signal Duration".
Every subsequent trigger event (internal or external) causes a restart.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:TRIGger:SEQuence](#) on page 78

Signal Duration Unit

Defines the unit for describing the length of the signal sequence to be output in the "Single" trigger mode.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:TRIGger:SLUnit](#) on page 76

Signal Duration

Requires trigger "Mode" > "Single".

Enters the length of the trigger signal sequence.

Use this parameter, for example, for the following applications:

- To output the trigger signal partly.
- To output a predefined sequence of the trigger signal.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:TRIGger:SLENgth](#) on page 76

Running/Stopped

With enabled modulation, displays the status of signal generation for all trigger modes.

- "Running"
The signal is generated; a trigger was (internally or externally) initiated in triggered mode.
- "Stopped"
The signal is not generated and the instrument waits for a trigger event.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:TRIGger:RMODE](#) on page 76

Time Based Trigger

Requires trigger "Mode" > "Armed Auto"/"Single".

Activates time-based triggering with a fixed time reference.

The R&S SMW triggers signal generation when its operating system time ("Current Time") matches a specified time trigger ("Trigger Time"). As trigger source, you can use an internal trigger or an external global trigger.

How to: Chapter "Time-based triggering" in the R&S SMW user manual.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:TRIGger:TIME\[:STATE\]](#) on page 79

Trigger Time

Requires trigger "Mode" > "Armed Auto"/"Single".

Sets date and time for a time-based trigger signal.

Set a trigger time that is later than the "Current Time". The current time is the operating system time of the R&S SMW. If you set an earlier trigger time than the current time, time-based triggering is not possible.

How to: Chapter "Time-based triggering" in the R&S SMW user manual.

"Date" Sets the date of the time-based trigger in format YYYY-MM-DD.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:TRIGger:TIME:DATE](#) on page 78

"Time" Sets the time of the time-based trigger in format hh:mm:ss.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:TRIGger:TIME:TIME](#) on page 79

Arm

Stops the signal generation until subsequent trigger event occurs.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:TRIGger:ARM:EXECute](#) on page 74

Execute Trigger

For internal trigger source, executes trigger manually.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:TRIGger:EXECute](#) on page 75

Source

The following sources of the trigger signal are available:

- "Internal"
The trigger event is executed manually by the "Execute Trigger".
- "Internal (Baseband A/B)"
The trigger event is provided by the trigger signal from the other basebands.
If common trigger settings are applied, this trigger source is disabled.
- "External Global Trigger"
The trigger event is the active edge of an external trigger signal provided and configured at the USER x connectors.
- "External Local Trigger"
The trigger event is the active edge of an external trigger signal provided and configured at the local T/M/C connector.
With coupled trigger settings, the signal has to be provided at the T/M/C1/2/3 connectors.
- "External Local Clock"
The trigger event is the active edge of an external local clock signal provided and configured at the local T/M/C connector.
With coupled trigger settings, the signal has to be provided at the T/M/C1 connector.

How to: ["Routing and activating a trigger signal"](#) on page 16


Remote command:

[\[:SOURce<hw>\]:BB:TETRa:TRIGger:SOURce](#) on page 77

Sync. Output to External Trigger/Sync. Output to Trigger

Enables signal output synchronous to the trigger event.


- "On"
Corresponds to the default state of this parameter.
The signal calculation starts simultaneously with the trigger event. Because of the processing time of the instrument, the first samples are cut off and no signal is output. After elapsing of the internal processing time, the output signal is synchronous to the trigger event.



- "Off"

The signal output begins after elapsing of the processing time. Signal output starts with sample 0. The complete signal is output.

This mode is recommended for triggering of short signal sequences. Short sequences are sequences with signal duration comparable with the processing time of the instrument.



Remote command:

[\[:SOURce<hw>\]:BB:TETRa:TRIGger\[:EXTernal<ch>\]:SYNChronize:OUTPut on page 75](#)

External Inhibit/Trigger Inhibit

Applies for external trigger signal or trigger signal from the other path.

Sets the duration with that any following trigger event is suppressed. In "Retrigger" mode, for example, a new trigger event does not cause a restart of the signal generation until the specified inhibit duration does not expire.

For more information, see chapter "Basics" in the R&S SMW user manual.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:TRIGger\[:EXTernal\]:INHibit on page 78](#)
[\[:SOURce<hw>\]:BB:TETRa:TRIGger:OBASEband:INHibit on page 76](#)

External Delay/Trigger Delay

Delays the trigger event of the signal from:

- The external trigger source
- The other path
- The other basebands (internal trigger), if common trigger settings are used.

Use this setting to:

- Synchronize the instrument with the device under test (DUT) or other external devices
- Postpone the signal generation start in the basebands compared to each other

For more information, see chapter "Basics on ..." in the R&S SMW user manual.


Remote command:

`[:SOURce<hw>] :BB:TETRa:TRIGger[:EXTernal]:DELy` on page 77
`[:SOURce<hw>] :BB:TETRa:TRIGger:OBASEband:DELy` on page 75

3.3 Marker settings

Access:

- ▶ Select "Baseband" > "TETRA" > "Marker".



This tab provides settings to select and configure the marker output signal including marker mode and marker delay.

Routing and activating a marker signal

1. To define the signal shape of an individual marker signal "x", select "Marker" > "Marker x" > "Mode".
2. Optionally, define the connector for signal output. See [Chapter 3.5, "Local and global connectors settings"](#), on page 24.
You can map marker signals to one or more USER x or T/M connectors.
3. Activate baseband signal generation. In the block diagram, set "Baseband" > "On".
The R&S SMW adds the marker signal to the baseband signal. Also, R&S SMW outputs this signal at the configured USER x connector.

About marker output signals

This section focuses on the available settings.

For information on how these settings affect the signal, refer to section "Basics on ..." in the R&S SMW user manual.

Settings:

Mode.....	22
Delay.....	23

Mode

Marker configuration for up to 3 markers. The settings are used to select the marker mode defining the shape and periodicity of the markers. The contents of the dialog change with the selected marker mode.

How to: ["Routing and activating a marker signal"](#) on page 21

"Restart"	A marker signal is generated at the start of each ARB sequence.
"Slot Start"	A marker signal is generated at the start of each slot.
"Frame Start"	A marker signal is generated at the start of each frame.
"Multiframe Start"	A marker signal is generated at the start of each multiframe.
"Hyperframe Start"	A marker signal is generated at the start of each hyperframe.
"Pulse"	A regular marker signal is generated. The frequency is derived by dividing the sample rate by the divider. The input box for the divider opens when "Pulse" is selected, and the resulting pulse frequency is displayed below it. Remote command: [:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PULSe:DIVider on page 82 [:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PULSe:FREQuency? on page 83
"Pattern"	A marker signal that is defined by a bit pattern is generated. The pattern has a maximum length of 64 bits and is defined in an input field which opens when pattern is selected. Remote command: [:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PATTERn on page 82

"On/Off Ratio" A regular marker signal that is defined by an On/Off ratio is generated. A period lasts one On and Off cycle.
The "On Time" and "Off Time" are each expressed as several samples and are set in an input field which opens when On/Off ratio is selected.



Remote command:

`[:SOURce<hw>] :BB:TETRa:TRIGger:OUTPut<ch>:ONTIme`
on page 82

`[:SOURce<hw>] :BB:TETRa:TRIGger:OUTPut<ch>:OFFTime`
on page 82

Remote command:

`[:SOURce<hw>] :BB:TETRa:TRIGger:OUTPut<ch>:MODE` on page 81

Delay

Delays the marker signal at the marker output relative to the signal generation start.

Variation of the parameter "Marker x" > "Delay" causes signal recalculation.


Remote command:

`[:SOURce<hw>] :BB:TETRa:TRIGger:OUTPut<ch>:DELay` on page 81

3.4 Clock settings

Access:

- ▶ Select "Baseband" > "TETRA" > "Clock".



This tab provides settings to select and configure the clock signal, like the clock source and clock mode.

Defining the clock

1. Select "Clock" > "Source" to define the source of clock signal.
2. For external clock signals, define the connector for signal input. See [Chapter 3.5, "Local and global connectors settings"](#), on page 24.
You can map clock signals to one or more USER x or T/M connectors.

Local and global connectors settings allow you to configure the signal mapping, the polarity, the trigger threshold and the input impedance of the input connectors.

3. Activate baseband signal generation. In the block diagram, set "Baseband" > "On".

The R&S SMW starts baseband signal generation with a symbol rate that equals the clock rate.

About clock signals

This section focuses on the available settings.

For information on how these settings affect the signal, refer to section "Basics on ..." in the R&S SMW user manual.

Settings:

Clock Source.....	24
Clock Mode.....	24
Measured External Clock.....	24

Clock Source

Selects the clock source.

- "Internal"
The instrument uses its internal clock reference.
- "External Local Clock"
Option: R&S SMW-B10
The instrument expects an external clock reference at the local T/M/C connector.

How to: ["Defining the clock"](#) on page 23

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:CLOCK:SOURce](#) on page 84

Clock Mode

Sets the type of externally supplied clock.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:CLOCK:MODE](#) on page 83

Measured External Clock

Provided for permanent monitoring of the enabled and externally supplied clock signal.

Remote command:

[CLOCK:INPut:FREQuency?](#)

3.5 Local and global connectors settings

Accesses a dialog to configure local connectors or global connectors.

The button is available in the following dialogs or tabs:

- "Trigger / Marker / Clock" dialog that is accessible via the "TMC" block in the block diagram.

- "Trigger In", "Marker" and "Clock" tabs that are accessible via the "Baseband" block in the block diagram.




See also chapter "Local and global connectors settings" in the user manual.

3.6 Frame configuration settings

Access:

1. Select "Baseband > Tetra > Frame Configuration".



The dialog displays the frames slots graphically.

2. Select the slot to for configuration.

The corresponding burst editor dialog opens, see [Chapter 3.7, "Burst editor", on page 25](#).


3.7 Burst editor

Access:

- Select "Frame Configuration > Frame: Select Slot > Frame".

At the top of the dialog, the structure of the current burst type for the selected slot is displayed. Individual fields of the frame are color-coded:

Field	Color
Data, Fixed, Mixed, Stealing	white
White Training Sequences: TSC, ETSC, SYNC	yellow
Tail, extended Tail	green
Guard, extended Guard	blue



The rest of the dialog displays the data contained in fields predefined by the standard for the current burst type. Data fields with variable content can be edited.

The following sections list all possible settings and displays for the various burst types. If a setting applies only to a particular burst type, it is mentioned for the corresponding parameter.

Settings:

Common.....	27
└ T2 Burst Type.....	27
└ (Sub-) Slot Level.....	27
└ (Sub-) Slot Attenuation.....	27

└ Use Coded T1/T4 Data	27
└ Logical Channel Type	28
└ AACH-Q Mode	28
└ Access-Assign PDU	28
Burst (Downlink/Uplink)	29
└ Data Source	29
└ Scrambling	29
└ Training Sequence	30
└ TSC User Defined	30

Common

Selects the common settings for the selected slot.

T2 Burst Type ← Common

Selects the burst type for "Test Mode T2".

Remote command:

[[:SOURce<hw>\]:BB:TETRa:SCONfiguration:SLOT<st>:LDIRection<ch>:TBType](#) on page 55

(Sub-) Slot Level ← Common

Sets the level for the selected (sub-)slot.

Subslots are used by control bursts only.

- | | |
|--------------|--|
| "Off" | Attenuation is maximum. The (sub-) slot is inactive. |
| "Full" | The level corresponds to the level indicated in the display. |
| "Attenuated" | Level is reduced by the level attenuation set in "(Sub-)Slot Attenuation". |

Remote command:

[[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SLEvel](#) on page 61 for "Slot Level"
[\[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SSLevel](#) on page 62 for "Sub-Slot Level".

(Sub-) Slot Attenuation ← Common

Selects the level attenuation for the "(Sub-)Slot Level" attenuated setting.

Subslots are used by control bursts only.

Use the "Power Ramp Control" > "[Slot Attenuations](#)" dialog to define four different values for level attenuation.

Remote command:

[[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:BSATTenuation](#) on page 57 for "Slot-Attenuation".
[\[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SSATTenuation](#) on page 57 for "Sub-Slot Attenuation".

Use Coded T1/T4 Data ← Common

Enables/disables auto coding of the data.

If enabled, the selection of the data source is disabled.

Remote command:

[:SOURce<hw>] :BB:TETRa:SCONfiguration:SLOT<st>:UBBNch on page 56

Logical Channel Type ← Common

Selects the logical channel type.

The available channels depend on the selected [Test Mode](#) and [Link Direction](#).

Remote command:

[:SOURce<hw>] :BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:LCTYpe on page 59

AACH-Q Mode ← Common

(enabled for Frame 1- 17)

Sets the AACH-Q mode element that indicates whether the "Access-Assign PDU" follows in the AACH-Q.

The AACH-Q ("Access Assignment Channel, QAM") channel is present on all transmitted downlink slots (except slots containing BLCH-Q). It is used to indicate on each QAM physical channel the assignment of the uplink and downlink slots.

"Access- Assign PDU" The value of the AACH-Q mode element is set to 0, i.e. contents of "Access-Assign PDU" are present.

The "Access-Assign PDU" is used to convey information about the downlink slot in which it appears and also the access rights for the corresponding (same-numbered) uplink slot.

The fields of the "Access-Assign PDU" are defined with the corresponding parameters.

"Reserved Element" The value must be set to all zeros.

Remote command:

[:SOURce<hw>] :BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:AMODE on page 56

Access-Assign PDU ← Common

(enabled for Frame 1- 17)

Enables configuration of the "Access-Assign PDU" content.

"Header" Sets the value for the information element Header.

Remote command:

[:SOURce<hw>] :BB:TETRa:SCONfiguration:TMODe<di>:
SLOT<st>:LDIRection<ch>:APHeader on page 57

"Field1" Sets the value for the information element Field 1.

Remote command:

[:SOURce<hw>] :BB:TETRa:SCONfiguration:TMODe<di>:
SLOT<st>:LDIRection<ch>:APF1 on page 56

"Field2" Sets the value for the information element "Field2".

Remote command:

[:SOURce<hw>] :BB:TETRa:SCONfiguration:TMODe<di>:
SLOT<st>:LDIRection<ch>:APF2 on page 57

Burst (Downlink/Uplink)

Selects the settings for the "Logical Channel Type" of the selected burst "Link Direction".

Data Source ← Burst (Downlink/Uplink)

Selects a data source for the "Data" field.

The data source for both channels can be defined separately, i.e. each (sub-)slot has its own data source.

If a burst contains multiple "Data" fields, they are treated as a continuous field. For instance, a pseudo-random sequence is continued without interruption from one "Data" field to the next.

The following standard data sources are available:

- "All 0, All 1"
An internally generated sequence containing 0 data or 1 data.
- "PNxx"
An internally generated pseudo-random noise sequence.
- "Pattern"
An internally generated sequence according to a bit pattern.
Use the "Pattern" box to define the bit pattern.
- "Data List/Select DList"
A binary data from a data list, internally or externally generated.
Select "Select DList" to access the standard "Select List" dialog.
 - Select the "Select Data List > navigate to the list file *.dm_iqd > Select" to select an existing data list.
 - Use the "New" and "Edit" functions to create internally new data list or to edit an existing one.
 - Use the standard "File Manager" function to transfer external data lists to the instrument.

See also:

- Section "Modulation Data" in the R&S SMW user manual.
- Section "File and Data Management" in the R&S SMW user manual.
- Section "Data List Editor" in the R&S SMW user manual

Remote command:

```
[ :SOURce<hw> ] :BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:  
LDIRection<ch>:DATA on page 58  
[ :SOURce<hw> ] :BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:  
LDIRection<ch>:SDATA on page 60  
[ :SOURce<hw> ] :BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:  
LDIRection<ch>:DATA:DSELECTION on page 59  
[ :SOURce<hw> ] :BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:  
LDIRection<ch>:SDATA:SDSELECTION on page 61  
[ :SOURce<hw> ] :BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:  
LDIRection<ch>:DATA:DPattern on page 58  
[ :SOURce<hw> ] :BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:  
LDIRection<ch>:SDATA:SDPattern on page 60
```

Scrambling ← Burst (Downlink/Uplink)

Enables/disables auto scrambling.

Remote command:

[**:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:SCRambling** on page 59

Training Sequence ← Burst (Downlink/Uplink)

Determines whether the default or a user-defined training sequence (TSC) is used.

A user-defined training sequence can be created in the field "TSC User Defined".

Remote command:

[**:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:TSOurce** on page 62

TSC User Defined ← Burst (Downlink/Uplink)

Enters a user-defined TSC. The length of the training sequences depends on the burst type. The first user bit is equivalent to the first bit of the training sequence. All further sequences are inserted successively.

Remote command:

[**:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:TPATtern** on page 62

3.8 BSCH / BNCH/T

Access:

- ▶ Select "General > BSCH/BNCH/T".

In the "BSCH / BNCH/T" dialog, the contents of the broadcast synchronization channel (BSCH) and the broadcast network channel (BNCH/T) are configured. The BSCH and the BNCH are the two possible broadcast control channels (BCCH) that are transmitted in downlink direction only.


Contents

● TETRA frequency	30
● Contents settings	33
● Scrambling	36

3.8.1 TETRA frequency

Access:

- ▶ Select "General > BSCH/BNCH/T > TETRA Frequency"



This section comprises the parameters necessary to set the carrier bandwidth and the frequency band.

Settings:

Carrier Bandwidth	31
Main Carrier Number	31
Frequency Band	31
Offset	32
Duplex Spacing	32
Reverse Operation	32
Coded RF Frequency	32

Carrier Bandwidth

Selects the carrier bandwidth, i.e. determines the carrier spacing.

The default value for all standard test modes is 25kHz. The carrier spacing of 50 kHz, 100 kHz and 150 kHz is enabled for "Test Mode" set to "User Defined" or "T4".

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:CBANdwidth](#) on page 64

Main Carrier Number

The "Main Carrier Number" divides the TETRA band into carriers with a spacing as set with the parameter "Carrier Bandwidth". The range is 0 to 4095 (12 bits).

The main carrier frequency is calculated as follows:

Main Carrier Frequency, kHz = "Main Carrier Number" * "Carrier Bandwidth"

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:MCNumber](#) on page 67

Frequency Band

Sets the "Frequency Band".

This setting affects the calculation of the transmission frequency. The frequency band information is inserted only in the TETRA BSCH protocol channel.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:FBAND](#) on page 66

Offset

Set the "Offset" to shift the center frequency in the channel spacing. The allowed offsets are +6.25, 0, -6.25 kHz and +12.50 kHz.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:OFFSet](#) on page 68

Duplex Spacing

(for Uplink direction only)

The "Duplex Spacing" and "Reverse Operation" parameters in the BNCH/T indicate the required uplink frequency with respect to the indicated downlink frequency. These parameters are defined in ETSI 300 392-2.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:DSPacing](#) on page 65

Reverse Operation

(for Uplink direction only)

Enables reverse operation.

Reverse operation is used to fix the uplink frequency relative to the downlink frequency. In normal operation, the uplink frequency is lower than the downlink frequency and in reverse operation, the uplink frequency is higher than the downlink frequency.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:ROperation](#) on page 68

Coded RF Frequency

Displays the resulting RF frequency, calculated from the previous settings. The frequency is calculated from the "Frequency Band", "Main Carrier Number", "Offset", "Duplex Spacing" and "Reverse Operation" and transmitted in message channel BNCH/T when "Downlink MS V+D Testing" is selected.

The "Coded RF Frequency" is calculated as described in [Table 3-1](#).

Table 3-1: Calculation of coded RF frequency

"Link Direction"	"Reverse Operation"	"Coded RF Frequency", MHz
Downlink	-	Downlink coded RF Frequency = "Frequency Band" + ("Main Carrier Number" * "Carrier Bandwidth") + "Offset"
Uplink	Off (Normal operation)	Uplink coded RF Frequency = Downlink coded RF Frequency - "Duplex Spacing"
	On	Uplink coded RF Frequency = Downlink coded RF Frequency + "Duplex Spacing"


Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:CRFFrequency?](#) on page 64

3.8.2 Contents settings

Access:

1. Select "General > Link Direction > Downlink/ Forward".
2. Select "BSCH/BNCH/T > Contents Settings".



This dialog is enabled for downlink direction only. In the downlink mode, a synchronization burst is used to control the MS messages. In this burst, protocol elements are transmitted in BSCH and BNCH. The parameters are used to form the commands for the mobile station. This section comprises the parameters necessary to set the carrier bandwidth and the frequency band.

Settings:

System Code.....	33
TS reserved frames.....	34
Frame 18 extension.....	34
Sharing Mode.....	34
U-plane DTX.....	34
D-NWRK-BROADCAST broadcast.....	34
D-NWRK-BROADCAST enquiry.....	34
Cell service level.....	34
MS_TXPWR_MAX_CELL.....	35
Tx_on.....	35
T1_T4_Burst_Type.....	35
Error Correction.....	35
Late Entry.....	35
ACCESS_PARAMETER.....	35
Tx_burst_type.....	36
Loop Back.....	36

System Code

Indicates whether the system is a TETRA V+D system or whether it is a "Direct Mode" transmission.

Remote command:

[:SOURce<hw>] :BB:TETRa:BBNcht:SCODE on page 69

TS reserved frames

Determines the number of frames reserved over two multiframe period.

The way this field is processed, depends on the selected "Sharing Mode" on page 34. If MCCH sharing is indicated, the TS reserved frames field indicates which frames are reserved in this mode of operation. For the other values of sharing mode, the contents of the TS reserved frames field are ignored.

Remote command:

[:SOURce<hw>] :BB:TETRa:BBNcht:TRFRAMES on page 70

Frame 18 extension

Enables the frame 18 extension element, i.e. indicates whether an MS is allowed to receive downlink information on all slots of the frame 18. If extension is allowed, only MSs which can receive consecutive slots are able to perform this function.

Remote command:

[:SOURce<hw>] :BB:TETRa:BBNcht:FEEExtension on page 66

Sharing Mode

The sharing mode field indicates whether the BS is using continuous transmission, carrier sharing, MCCH sharing or traffic carrier sharing.

Remote command:

[:SOURce<hw>] :BB:TETRa:BBNcht:SMODE on page 69

U-plane DTX

The "U-plane DTX" element indicates whether the BS supports discontinuous traffic transmission by the MS.

Remote command:

[:SOURce<hw>] :BB:TETRa:BBNcht:UPDTx on page 71

D-NWRK-BROADCAST broadcast

Enables the support of the D-NWRK-BROADCAST PDU.

Remote command:

[:SOURce<hw>] :BB:TETRa:BBNcht:DNBBroadcast on page 65

D-NWRK-BROADCAST enquiry

Enables the support of the D-NWRK-BROADCAST inquiry.

Remote command:

[:SOURce<hw>] :BB:TETRa:BBNcht:DNBenquiry on page 65

Cell service level

Sets the cell service level information element, i.e. define the level of service an MS can receive in a cell. It can relate to the traffic loading in a cell.

The following service levels are supported:

- "Cell load unknown"
- "Low cell load"

- "Medium cell load"
- "High cell load"

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:CSLevel](#) on page 65

MS_TXPWR_MAX_CELL

Sets the protocol information on the maximum transmission power for the mobile station. Allowed are values from 15 dBm to 45 dBm in 5 dB steps.

The MS_TXPWR_MAX_CELL parameter is used for cell selection and reselection, and for power adjustments.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:MTMCell](#) on page 68

Tx_on

Determines the value of the Tx_on parameter, i.e. selects the test mode the MS operates in, "Reception ON" or "Transmission ON".

This parameter is necessary for the generation of test signal T1 or T4 transmitted by the test system.

"Transmission ON" The mobile station is requested to transmit.

"Reception ON" The mobile station is requested to receipt.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:TXON](#) on page 70

T1_T4_Burst_Type

Sets the value of the special parameter T1_T4_Burst_Type, i.e. determines the logical channel the BS is expecting to receive.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:TTBType](#) on page 70

Error Correction

Enables error correction.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:ECORrection](#) on page 66

Late Entry

Sets the value of the late entry supported information element, used to indicate to the MS whether late entry can be supported by the cell.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:LENTry](#) on page 67

ACCESS_PARAMETER

Sets the value of the ACCESS_PARAMETER information field. This parameter is used for subsequent power adjustments for the mobile station.

This protocol information field can have values from -53 dBm to -23 dBm in 2 dB steps.

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:APARameter](#) on page 63

Tx_burst_type

Sets the parameter Tx_burst_type and determines whether the MS under test transmit either a normal uplink burst or control uplink burst.

"Normal uplink" The mobile station transmits using normal uplink burst.
burst"

"Control uplink" The mobile station transmits using control uplink burst.
burst"

Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:TBTYpe](#) on page 69

Loop Back

Enables the loop back for test purposes.

If enabled, the mobile station sets up a loop and returns the data when requested by the Tx_burst_type.


Remote command:

[\[:SOURce<hw>\]:BB:TETRa:BBNcht:LBACK](#) on page 66

3.8.3 Scrambling

Access:

- ▶ Select "General > BSCH/BNCH/T > Scrambling".



The "Scrambling" section contains of the parameters necessary to configure the scrambling sequence.

The scrambling code is a 24-bit field composed of the "Mobile Country Code" (MCC) and "Mobile Network Code" (MNC) and is calculated as defined in EN 300 392. The MCC and MNC is a part of the MLE information contained within the SYNC PDU broadcast by the BS on the BSCH. The upper MAC adds a 6-bit color code which is

contained in the SYNC PDU. The combination of MCC, MNC and color code make up the scrambling code which the upper MAC passes to the lower MAC via the TMV-SAP. This scrambling code corresponds to the extended color code used for scrambling and descrambling in the lower MAC. The scrambling code corresponds to the 30-bit extended color code e(1), e(2),..., e(30).

Table 3-2: Building of scrambling code

"Mobile Country Code (MCC)"	"Mobile Network Code (MNC)"	"Colour Code"
10 bits	14 bits	6 bits
e(1) - e(10)	e(11) - e(24)	e(25) - e(30)
e(1) = msb ¹⁾ of MCC	e(11) = msb of MNC	e(25) = msb of colour code
¹⁾ Most Significant Bit		

Settings:

Base Colour Code	37
Mobile Network Code	37
Mobile Country Code	37

Base Colour Code

Sets the colour code.

The base color code is the number of subscriber groups in a network.

See [Table 3-2](#) for information on how the scrambling code is calculated.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:BBNcht:BCCode](#) on page 64

Mobile Network Code

Sets the mobile network code (MNC).

The MNC is the number of the TETRA network operator.

See [Table 3-2](#) for information on how the scrambling code is calculated.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:BBNcht:MNCode](#) on page 68

Mobile Country Code

Sets the mobile country code.

The MCC is the number of the country in which the unit is operated.

See [Table 3-2](#) for information on how the scrambling code is calculated.

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:BBNcht:MCCode](#) on page 67

3.9 Filter / clipping settings

Access:

- ▶ Select "General > Filter/Clipping/ARB/IQ Settings".

The dialog contains the settings required to configure the baseband filter and to enable clipping.


Settings:

● Filter settings	38
● Modulation settings	40
● Clipping settings	41

3.9.1 Filter settings

Access:

- ▶ Select "General > Filter/Clipping".



Settings:

Filter	39
Roll Off Factor or BxT	39
Cut Off Frequency Shift	39
Cut Off Frequency Factor	39
Impulse Length	39

Filter

Selects the baseband filter.

Remote command:

[**:SOURce<hw>**] :BB:TETRa:FILTer:TYPE on page 73

Roll Off Factor or BxT

Sets the filter parameter.

The filter parameter ("Roll off Factor" or "BxT") depends on the currently selected filter type. This parameter is preset to the default for each of the predefined filters.

Remote command:

[**:SOURce<hw>**] :BB:TETRa:FILTer:PARAmeter:COSine on page 72
 [**:SOURce<hw>**] :BB:TETRa:FILTer:PARAmeter:RCOSine on page 72
 [**:SOURce<hw>**] :BB:TETRa:FILTer:PARAmeter:PGauss on page 72
 [**:SOURce<hw>**] :BB:TETRa:FILTer:PARAmeter:GAUss on page 72
 [**:SOURce<hw>**] :BB:TETRa:FILTer:PARAmeter:SPHase on page 72
 [**:SOURce<hw>**] :BB:TETRa:FILTer:PARAmeter:APCO25 on page 72

Cut Off Frequency Shift

(available for filter parameter "Cosine" only)

Sets the value for the cut off frequency shift. The cut off frequency of the cosine filter can be adjusted to reach spectrum mask requirements.

The value range is -1.0 to 1.0.

Remote command:

[**:SOURce<hw>**] :BB:TETRa:FILTer:PARAmeter:COSine:COFS on page 73

Cut Off Frequency Factor

Sets the value for the cutoff frequency factor. The cutoff frequency of the filter can be adjusted to reach spectrum mask requirements.

Remote command:

[**:SOURce<hw>**] :BB:TETRa:FILTer:PARAmeter:LPASSs on page 72
 [**:SOURce<hw>**] :BB:TETRa:FILTer:PARAmeter:LPASSEVM on page 72

Impulse Length

Sets the number of filter tabs.


Remote command:

[**:SOURce<hw>**] :BB:TETRa:FILTer:ILENgth on page 72

3.9.2 Modulation settings

Access:

- Select "General > Filter/Clipping > Modulation".



This tab displays the used modulation type.

Settings:

Modulation Type.....40

Modulation Type

Displays the modulation type as selected with the parameter "Modulation Type".


Remote command:

[:SOURce<hw>] :BB:TETRa:MTYPE on page 49

3.9.3 Clipping settings

Access:

- Select "General > Filter/Clipping > Clipping".



This tab contains the settings necessary to configure the clipping.

Settings:

Clipping State.....	41
Clipping Level.....	42
Clipping Mode.....	42

Clipping State

Switches baseband clipping on and off.

Baseband clipping is a simple and effective way of reducing the crest factor of the signal. Since clipping is done before filtering, the procedure does not influence the spectrum. The EVM however increases.

Remote command:

`[:SOURce<hw>] :BB:TETRa:CLIPping:STATE` on page 72

Clipping Level

Sets the limit for clipping.

This value indicates at what point the signal is clipped. It is specified as a percentage, relative to the highest level. 100% indicates that clipping does not take place.

Remote command:

[:SOURce<hw>] :BB:TETRa:CLIPping:LEVel on page 71

Clipping Mode

Selects the clipping method. The dialog displays a graphical illustration on how this two methods work.

- "Vector $| i + jq |$ "

The limit is related to the amplitude $| i + q |$. The I and Q components are mapped together, the angle is retained.

- "Scalar $| i |, | q |$ "

The limit is related to the absolute maximum of all the I and Q values $| i | + | q |$.

The I and Q components are mapped separately, the angle changes.


Remote command:

[:SOURce<hw>] :BB:TETRa:CLIPping:MODE on page 72

3.10 Power ramp control

Access:

- Select "General > Power Ramp/Slot Attenuations".



The dialog contains the settings for configuring the power ramping and level attenuation. The "Slot Attenuations" (used in "Frame Editor") section is used to define four possible values for level attenuation. You can select these values from the frame editor for the slot currently being edited.

This dialog provides access to the settings for power ramping and slot attenuation.


Contents

● Ramp control.....	43
● Slot attenuations.....	44

3.10.1 Ramp control

Access:

- ▶ Select "General > Power Ramp/Slot Attenuations > Ramp Control".



The dialog contains the settings for configuring the power ramping.

Settings:

Ramp Function.....	43
Ramp Time.....	44
Rise Offset.....	44
Fall Offset.....	44

Ramp Function

Selects the form of the transmitted power, i.e. the shape of the rising and falling during power ramp control.

- | | |
|----------|--|
| "Linear" | The transmitted power rises and falls linear fashion. |
| "Cosine" | The transmitted power rises and falls with a cosine-shaped edge.
This setting causes a more favorable spectrum than the "Linear" setting. |

Remote command:

[\[:SOURce<hw>\] :BB:TETRa:PRAMPing:RFUNction](#) on page 53

Ramp Time

Sets the power ramping rise time and fall time for a frame. The setting is expressed in symbols.

Do not switch the transmitted power abruptly at the end or the start of a frame, since the switching operation generates excessively strong non-harmonics. The switching operation is therefore stretched over several symbol clocks.

Remote command:

[[:SOURce<hw>](#)] :BB:TETRa:PRAMping:RTIMe on page 54

Rise Offset

Sets the offset in the rising edge of the envelope at the start of a frame. A positive value causes a delay and a negative value causes an advance. The setting is expressed in symbols.

Remote command:

[[:SOURce<hw>](#)] :BB:TETRa:PRAMping:ROFFset on page 53

Fall Offset

Sets the offset in the falling edge of the envelope at the end of a frame. A positive value causes a delay and a negative value causes an advance. The setting is expressed in symbols.

Remote command:

[[:SOURce<hw>](#)] :BB:TETRa:PRAMping:FOFFset on page 53

3.10.2 Slot attenuations

Access:

- ▶ Select "General > Power Ramp/Slot Attenuations > Slot Attenuations".

Ramp Control	Slot Attenuations
Slot Attenuations(Used In Burst Editors)	
A1	0.0 dB
A2	0.0 dB
A3	0.0 dB
A4	0.0 dB

The dialog contains the settings for level attenuation. The "Slot Attenuations" (used in "Frame Editor") section is used to define four possible values for level attenuation. You can select these values from the frame editor for the slot currently being edited.

"Slot Level > Full" setting in the frame editor corresponds to 0 dB attenuation.

See "[\(Sub-\) Slot Level](#)" on page 27.

Settings

Slot Attenuation A1 to A4	45
---	----

Slot Attenuation A1 to A4

Sets the four different values for level attenuation.

The frame editor can be used to set the level attenuation for the four slots to one of these predefined values independently of one another.

The set value determines the slot output power (slot power = RF power - attenuation). 0 dB attenuation corresponds to "Slot Level = Full".

This feature is provided to set a sequence of slots to different levels in order to measure transmission stability.

The frame editor is likewise used to assign the "Slot Level" attribute "Attenuated" to individual slots.

Remote command:

[[:SOURce<hw>](#)] :BB:TETRa:SATTenuation<ch> on page 54

4 Remote control commands

The following commands are required to perform signal generation with the TETRA options in a remote environment. We assume that the R&S SMW has already been set up for remote operation in a network as described in the R&S SMW documentation. A knowledge about the remote control operation and the SCPI command syntax are assumed.



Conventions used in SCPI command descriptions

For a description of the conventions used in the remote command descriptions, see section "Remote Control Commands" in the R&S SMW user manual.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
ENTity<ch>	1 .. 4	entity in a multiple entity configuration with separate baseband sources ENTity3 4 require option R&S SMW-K76
SOURce<hw>	[1] to 4	available baseband signals only SOURce1 possible, if the keyword ENTity is used
OUTPut<ch>	1 to 3	available markers
TMODe<di>	1...4	The numeric suffix to TMODe distinguishes between the test modes: <ul style="list-style-type: none"> • TMODE1 = Test Mode 1 • TMODE2 = Test Mode 4 • TMODE3 = User Defined • TMODE4 = Test Mode 2
SLOT<st>	1...8	The numeric suffix to SLOT distinguishes between the slot numbers: <ul style="list-style-type: none"> • SLOT<1..4> = Slots#1 to Slot#4 in Frame 1..17 • SLOT<5..8> = Slots#1 to Slot#4 in Frame 18
LDIRection<ch>	1...2	The numeric suffix to LDIRection distinguishes between the link directions: <ul style="list-style-type: none"> • LDIRection1 = Downlink • LDIRection2 = Uplink



Using SCPI command aliases for advanced mode with multiple entities

You can address multiple entities configurations by using the SCPI commands starting with the keyword `SOURce` or the alias commands starting with the keyword `ENTity`.

Note that the meaning of the keyword `SOURce<hw>` changes in the second case.

For details, see section "SCPI Command Aliases for Advanced Mode with Multiple Entities" in the R&S SMW user manual.

Programming examples

This description provides simple programming examples. The purpose of the examples is to present **all** commands for a given task. In real applications, one would rather reduce the examples to an appropriate subset of commands.

The programming examples have been tested with a software tool which provides an environment for the development and execution of remote tests. To keep the example as simple as possible, only the "clean" SCPI syntax elements are reported. Non-executable command lines (e.g. comments) start with two // characters.

At the beginning of the most remote control program, an instrument (p)reset is recommended to set the instrument to a definite state. The commands *RST and SYSTem:PRESet are equivalent for this purpose. *CLS also resets the status registers and clears the output buffer.

The following commands specific to the TETRA are described here:

● General commands.....	47
● Power ramp commands.....	53
● Slot configuration commands.....	55
● BSCH / BNCH/T commands.....	63
● Filter/clipping commands.....	71
● Trigger commands.....	73
● Marker commands.....	80
● Clock commands.....	83

4.1 General commands

Example: Selecting test mode, link direction and channel type

```
// set to default and query the TETRA standard version
SOURCE1:TETRa:PRESet
SOURCE:BB:TETRa:VERSION?
// Response: "ETSI EN 300 392-2 V3.2.1."

SOURCE1:BB:TETRa:TMODe T1
SOURCE1:BB:TETRa:LDIRection DOWN
SOURCE1:BB:TETRa:CTYPe CH0
// setting parameters for user and T2 test modes
// SOURCE1:BB:TETRa:TMODe USER
// SOURCE1:BB:TETRa:MTYPe PHASE
// SOURCE1:BB:TETRa:DBTYpe CONT
SOURCE1:BB:TETRa:SLENgth 1

// Save the configuration in a waveform file
SOURCE1:BB:TETRa:WAVEform:CREAtE 'tetra_waveform_t1_dl'

// activate signal generation
SOURCE1:BB:TETRa:STATE 1
```

Example: Saving current configuration

```
SOURCE1:BB:TETRa:SETTING:STORe '/var/user/tetra_t1_dl'
*RST
SOURCE1:BB:TETRa:SETTING:CATalog?
// Response: tetra_t1_dl, tetra_user_dl
SOURCE1:BB:TETRa:SETTING:LOAD '/var/user/tetra_t1_dl'
SOURCE1:BB:TETRa:SETTING:DELetE 'tetra_user_dl'
```

[:SOURce<hw>]:BB:TETRa:CTYPe.....	48
[:SOURce<hw>]:BB:TETRa:DBTYpe.....	48
[:SOURce<hw>]:BB:TETRa:LDIRection.....	49
[:SOURce<hw>]:BB:TETRa:MTYPe.....	49
[:SOURce<hw>]:BB:TETRa:PRESet.....	49
[:SOURce<hw>]:BB:TETRa:SETTING:CATalog?.....	50
[:SOURce<hw>]:BB:TETRa:SETTING:DELetE.....	50
[:SOURce<hw>]:BB:TETRa:SETTING:LOAD.....	50
[:SOURce<hw>]:BB:TETRa:SETTING:STORe.....	51
[:SOURce<hw>]:BB:TETRa:SLENgth.....	51
[:SOURce<hw>]:BB:TETRa:SRATe:VARiation.....	51
[:SOURce<hw>]:BB:TETRa:STATe.....	51
[:SOURce<hw>]:BB:TETRa:TMODe.....	52
[:SOURce<hw>]:BB:TETRa:VERSion?.....	52
[:SOURce<hw>]:BB:TETRa:WAveform:CREate.....	52

[:SOURce<hw>]:BB:TETRa:CTYPe <CType>

(for "Test Model" set to T1 or T4)

Determines the channel type.

Parameters:

<CType> CH0 | CH1 | CH2 | CH3 | CH4 | CH7 | CH8 | CH9 | CH10 |
 CH11 | CH21 | CH22 | CH23 | CH24 | CH25 | CH26 | CH27
 *RST: CH0

Example: See [Example"Selecting test mode, link direction and channel type" on page 47](#)

Manual operation: See ["Channel Type" on page 15](#)

[:SOURce<hw>]:BB:TETRa:DBTYpe <DBType>

(in Downlink "Link Direction" and for "Test Model" set to T2 or User Defined)

Determines the downlink burst type.

Parameters:

<DBType> CONTInuous | DCONtinuous
 *RST: CONTInuous

Example: See [Example"Selecting test mode, link direction and channel type" on page 47](#)

Manual operation: See "[Downlink Burst Type](#)" on page 15

[[:SOURce<hw>](#)]:BB:TETRa:LDIRection <LDirection>

Selects the transmission direction.

This parameter determines the available "Channel Types".

Parameters:

<LDirection> DOWN | UP

DOWN

The transmission direction selected is from the base station (BS) to the terminal (MS). The signal corresponds to that of a BS.

UP

The transmission direction selected is from MS to the BS. The signal corresponds to that of a terminal.

*RST: DOWN

Example: See [Example"Selecting test mode, link direction and channel type"](#) on page 47

Manual operation: See "[Link Direction](#)" on page 14

[[:SOURce<hw>](#)]:BB:TETRa:MTYPE <MTYPE>

(for "Test Model" set to User Defined)

Determines the modulation type, "Phase" or "QAM."

Parameters:

<MTYPE> PHASE | QAM

PHASE

The T2 test signal is a pi/4-DQPSK modulated continuous radio signal.

QAM

The T2 test signal is 4-QAM, 16-QAM or 64-QAM modulated and spans a bandwidth of 25kHz, 50kHz, 100kHz or 150kHz.

*RST: PHASE

Example: See [Example"Selecting test mode, link direction and channel type"](#) on page 47

Manual operation: See "[Modulation Type](#)" on page 15

See "[Modulation Type](#)" on page 40

[[:SOURce<hw>](#)]:BB:TETRa:PRESet

Sets the parameters of the digital standard to their (*RST values specified for the commands).

Not affected is the state set with the command [[:SOURce<hw>](#)] :BB:TETRa:STATE.

Example: See [Example "Selecting test mode, link direction and channel type" on page 47](#)

Usage: Event

Manual operation: See ["Set to Default" on page 12](#)

[:SOURce<hw>]:BB:TETRa:SETTING:CATalog?

Queries the files with settings in the default directory. Listed are files with the file extension *.tetra.

Return values:

<Catalog> <filename1>,<filename2>,...

Returns a string of file names separated by commas.

Example: See [Example "Saving current configuration" on page 48](#).

Usage: Query only

Manual operation: See ["Save/Recall" on page 13](#)

[:SOURce<hw>]:BB:TETRa:SETTING:DELetE <Filename>

Deletes the selected file in the specified directory. Deleted are files with the file extension *.tetra.

Setting parameters:

<Filename> <file name>

file name or complete file path

Example: See [Example "Saving current configuration" on page 48](#)

Usage: Setting only

Manual operation: See ["Save/Recall" on page 13](#)

[:SOURce<hw>]:BB:TETRa:SETTING:LOAD <Filename>

Loads the selected file from the default or the specified directory. Loaded are files with extension *.tetra.

Setting parameters:

<Filename> string

file name or complete file path

Example: See [Example "Saving current configuration" on page 48](#)

Usage: Setting only

Manual operation: See ["Save/Recall" on page 13](#)

[:SOURce<hw>]:BB:TETRa:SETTING:STORe <Filename>****

Stores the current settings into the selected file; the file extension (*.tetra) is assigned automatically.

Setting parameters:

<Filename> string
file name or complete file path

Example: See [Example "Saving current configuration" on page 48](#)

Usage: Setting only

Manual operation: See "[Save/Recall](#)" on page 13

[:SOURce<hw>]:BB:TETRa:SLength <SLength>****

Selects the sequence length of the arbitrary waveform file in the number of multiframes. One multiframe is the minimum sequence length for a T1 signal.

Parameters:

<SLength> integer
Range: 1 to depends on carrier bandwidth
*RST: 1

Example: See [Example "Selecting test mode, link direction and channel type" on page 47](#)

Manual operation: See "[Sequence Length](#)" on page 15

[:SOURce<hw>]:BB:TETRa:SRATe:VARiation <Variation>****

Sets the symbol rate of the signal. A variation of this parameter only affects the ARB clock rate; all other signal parameters remain unchanged.

Parameters:

<Variation> float
Range: 400 to 15E6
Increment: 0.001
*RST: 18000

Example: BB:TETR:SRAT:VAR?
queries the symbol rate of the signal.

[:SOURce<hw>]:BB:TETRa:STATe <State>****

Activates the standard and deactivates all the other digital standards and digital modulation modes in the same path.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Selecting test mode, link direction and channel type" on page 47](#)

Manual operation: See ["State"](#) on page 12

[:SOURce<hw>]:BB:TETRa:TMODE <Tmode>

Selects the test mode.

Several settings depend on the selected test mode.

Parameters:

<Tmode> T1 | T4 | USER | T2 | T3
*RST: T1

Example: See [Example "Selecting test mode, link direction and channel type" on page 47](#)

Manual operation: See ["Test Mode"](#) on page 13

[:SOURce<hw>]:BB:TETRa:VERSion?

Queries the tetra standard version.

Return values:

<Version> string

Example: See [Example "Selecting test mode, link direction and channel type" on page 47](#)

Usage: Query only

[:SOURce<hw>]:BB:TETRa:WAVEform:CREate <Filename>

Saves the current settings as an ARB signal in a waveform file (*.wv).

Setting parameters:

<Filename> string
file name or complete file path; file extension is assigned automatically

Example: See [Example "Selecting test mode, link direction and channel type" on page 47](#)

Usage: Setting only

Manual operation: See ["Generate Waveform"](#) on page 13

4.2 Power ramp commands

[:SOURce<hw>]:BB:TETRa:PRAMPing:FOFFset.....	53
[:SOURce<hw>]:BB:TETRa:PRAMPing:RFUNction.....	53
[:SOURce<hw>]:BB:TETRa:PRAMPing:ROFFset.....	53
[:SOURce<hw>]:BB:TETRa:PRAMPing:RTIME.....	54
[:SOURce<hw>]:BB:TETRa:SATTenuation<ch>.....	54

[:SOURce<hw>]:BB:TETRa:PRAMPing:FOFFset <FOffset>

Sets the offset in the falling edge of the envelope at the end of a frame. A positive value gives rise to a delay and a negative value causes an advance. The setting is expressed in symbols.

Parameters:

<FOffset>	integer
	Range: 0 to 4
	*RST: 0

Example: BB:TETR:PRAM:FOFF 10

Manual operation: See "[Fall Offset](#)" on page 44

[:SOURce<hw>]:BB:TETRa:PRAMPing:RFUNction <RFunction>

Enters the form of the transmitted power during the switching operation, i.e. the shape of the rising and falling edges of the envelope.

Parameters:

<RFunction>	LINear COSine
	LINear
	The transmitted power rises and falls linear fashion.
	COSine
	The transmitted power rises and falls with a cosine-shaped edge. This gives rise to a more favorable spectrum than the "Linear" setting.
	*RST: COSine

Example: BB:TETR:PRAM:RFUN LIN

Manual operation: See "[Ramp Function](#)" on page 43

[:SOURce<hw>]:BB:TETRa:PRAMPing:ROFFset <ROffset>

Sets the offset in the rising edge of the envelope at the start of a frame. A positive value gives rise to a delay and a negative value causes an advance. The setting is expressed in symbols.

Parameters:

<ROffset> integer
 Range: -4 to 0
 *RST: 0

Example: BB:TETR:PRAM:ROFF 6

Manual operation: See "[Rise Offset](#)" on page 44

[:SOURce<hw>]:BB:TETRa:PRAMPing:RTIMe <Rtime>

Enters the power ramping rise time and fall time for a frame. The setting is expressed in symbols.

The transmitted power must not be switched abruptly at the start and end of a frame, because the switching operation would otherwise generate excessively strong non-harmonics; the switching operation is therefore stretched over several symbol clocks.

Parameters:

<Rtime> integer
 Range: 1 to 13|16, depends on test mode
 *RST: 2

Example: BB:TETR:PRAM:RTIM 25

Manual operation: See "[Ramp Time](#)" on page 44

[:SOURce<hw>]:BB:TETRa:SATTenuation<ch> <Sattenuation>

Enters four different values for level attenuation.

The frame editor can be used to set the level attenuation for the four slots to one of these predefined values independently of one another.

The entered value determines the slot output power (slot power = RF power - attenuation). 0 dB attenuation corresponds to "Slot Level" = Full.

This feature is provided to set a sequence of slots to different levels in order to measure transmission stability.

The frame editor is likewise used to assign the "Slot Level" attribute Attenuated to individual slots.

Parameters:

<Sattenuation> float
 Range: 0 to 50
 Increment: 0.1
 *RST: 0

Example: BB:TETR:SATT1 30

Manual operation: See "[Slot Attenuation A1 to A4](#)" on page 45

4.3 Slot configuration commands

[:SOURce<hw>]:BB:TETRa:SCONfiguration:SLOT<st>:LDIRection<ch>:TBType.....	55
[:SOURce<hw>]:BB:TETRa:SCONfiguration:SLOT<st>:UBBNch.....	56
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
AMODE.....	56
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:APF1.....	56
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:APF2.....	57
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
APHeader.....	57
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
BSATtenuation.....	57
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
SSATtenuation.....	57
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
DATA:DPATtern.....	58
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
DATA:DSELection.....	59
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
LCType.....	59
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
SCRambling.....	59
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
SDATA:SDPattern.....	60
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
SDATA:SDSelection.....	61
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
SLEvel.....	61
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
SSLevel.....	62
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
TPATtern.....	62
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:	
TSOurce.....	62

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:SLOT<st>:LDIRection<ch>:TBType
 <TbType>**

Selects the burst type for "Test Mode T2".

Parameters:

<TbType>	NCDB SCDB NDDB SDDB ND4 ND16 ND64 NUB CUB NU4 NU16 NU64 CU4 CU16 CU64 RAB
*RST:	NCDB

Example:

BB:TETR:SCON:SLOT3:LDIR1:TBTY NCDB

Manual operation: See "T2 Burst Type" on page 27

[:SOURce<hw>]:BB:TETRa:SCONfiguration:SLOT<st>:UBBNch <Ubbnch>

Enables/disables auto coding of the data.

If enabled, the selection of the data source is disabled.

Parameters:

<Ubbnch>	1 ON 0 OFF
	*RST: 0

Example:

```
SOURce:BB:TETRa:TMODE USER
SOURce:BB:TETRa:LDIRection DOWN
SOURce:BB:TETRa:SCONfiguration:SLOT1:UBBNch ON
```

Manual operation: See "[Use Coded T1/T4 Data](#)" on page 27

[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:AMODe <AMode>

(enabled for Frame 1- 17)

Sets the AACH-Q Mode element that indicates whether the Access-Assign PDU follows in the AACH-Q.

The AACH-Q (Access Assignment Channel, QAM) channel is present on all transmitted downlink slots (except slots containing BLCH-Q) and is used to indicate on each QAM physical channel the assignment of the uplink and downlink slots.

Parameters:

<AMode>	AAPDu REElement
---------	-------------------

AAPDu

The value of the AACH-Q Mode element is set to 0, i.e. contents of Access-Assign PDU are present.

The Access-Assign PDU is used to convey information about the downlink slot in which it appears and also the access rights for the corresponding (same-numbered) uplink slot.

The fields of the "Access-Assign PDU" are defined with the corresponding parameters.

REElement

The value shall be set to all zeros.

*RST:	AAPDu
-------	-------

Example:

```
BB:TETR:SCON:TMOD1:SLOT2:LDIR1:AMOD REL
```

Manual operation: See "[AACH-Q Mode](#)" on page 28

[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:APF1 <Apf1>

Sets the value for the information element Field 1 of the Access-Assign PDU.

Parameters:

<Apf1>	8 bits
--------	--------

Example: BB:TETR:SCON:TMOD2:SLOT3:LDIR1:APF1 #B000000,6

Manual operation: See "[Access-Assign PDU](#)" on page 28

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:APF2 <Apf2>**

Sets the value for the information element Field 2 of the Access-Assign PDU.

Parameters:

<Apf2> 8 bits

Example: BB:TETR:SCON:TMOD2:SLOT3:LDIR1:APF2 #B000000,6

Manual operation: See "[Access-Assign PDU](#)" on page 28

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:APHeader <ApHeader>**

Sets the value for the information element Header Of the Access-Assign PDU.

Parameters:

<ApHeader> 8 bits

Example: BB:TETR:SCON:TMOD3:SLOT5:LDIR1:APH #B01,2

Manual operation: See "[Access-Assign PDU](#)" on page 28

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:BSATtenuation <BsAttenuation>**

Selects the level attenuation for the "Slot Level" Attenuated setting.

Parameters:

<BsAttenuation> A1 | A2 | A3 | A4

*RST: A1

Example: BB:TETR:SCON:TMOD1:SLOT3:LDIR1:BSAT A1

Manual operation: See "[\(Sub-\) Slot Attenuation](#)" on page 27

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:SSATtenuation <SSATtenuation>**

Sets the attenuation for the second sub-slot in a control burst.

Parameters:

<SSATtenuation> A1 | A2 | A3 | A4

*RST: A1

Example: BB:TETR:SCON:TMOD1:SLOT3:LDIR2:SSAT A1

Example:

```
BB:TETR:LDIR UP
BB:TETR:CTYP CH11
Selects a control burst.
BB:TETR:SCON:TMOD1:SLOT3:LDIR2:BSAT A1
BB:TETR:SCON:TMOD1:SLOT3:LDIR2:SSAT A1
Sets the attenuation of the first and second sub-slot.
```

Manual operation: See "[\(Sub-\) Slot Attenuation](#)" on page 27

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:
LDIRection<ch>:DATA <Data>**

Defines the data source for the DATA fields in the burst.

Parameters:

<Data> PATTern | PN11 | PN15 | PN16 | PN20 | PN21 | PN23 | DLISt |
ALL0 | ALL1 | PN09

ALL0|ALL1|

Internal 0 or 1 data is used.

PATT

Internal data is used. The bit pattern for the data is defined with the aid of command [\[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:
LDIRection<ch>:DATA:DPattern](#) on page 58.

PNxx

The pseudo-random sequence generator is used as the data source. There is a choice of different lengths of random sequence.

DLISt

A data list is used. The data list is selected with the aid of command [\[:SOURce<hw>\]:BB:TETRa:SCONfiguration:
TMODE<di>:SLOT<st>:LDIRection<ch>:DATA:DSElection](#) on page 59.

*RST: PN09

Example: BB:TETR:SCON:TMOD1:SLOT2:LDIR1:DATA PN23

Manual operation: See "[Data Source](#)" on page 29

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:
LDIRection<ch>:DATA:DPattern, <BitCount>**

Selects the data pattern for data source pattern ([\[:SOURce<hw>\]:BB:TETRa:
SCONfiguration:TMODE<di>:SLOT<st>:LDIRection<ch>:DATA](#) on page 58).

Parameters:

<DPattern> numeric

*RST: #H0

<BitCount>	integer Range: 1 to 64 *RST: 1
Example:	BB:TETR:SCON:TMOD1:SLOT2:LDIR1:DATA PATT BB:TETR:SCON:TMOD1:SLOT2:LDIR1:DATA:DPAT #H3F,8
Manual operation:	See " Data Source " on page 29

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:
LDIRection<ch>:DATA:DSELection <DSelction>**

Selects a data list. This command is only valid for bursts with DATA fields. This data list is only used if it is set as the data source with the aid of command [\[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:LDIRection<ch>:DATA:DSELection <DSelction>](#) on page 58.

Parameters:

<DSelction> <data list name>

Example:	BB:TETR:SCON:TMOD1:SLOT2:LDIR1:DATA DLIS BB:TETR:SCON:TMOD1:SLOT2:LDIR1:DATA:DSEL 'dl_tetra_t2_ul'
-----------------	--

Manual operation: See "[Data Source](#)" on page 29

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:
LDIRection<ch>:LCTYpe <LcType>**

Selects the logical channel type.

The available channels depend on the selected test mode and link direction.

Parameters:

<LcType> T72 | T48 | T24 | TCHF | TCHH | STCH | SSTCh | SCHF | T108 | SP8F | SSHD | BSHD | SBNCh | BBNCh | S8HD | D4H | D16H | D64H | D64M | D16U | D64U | B4H | B16H | B64H | B64M | B16U | B64U | SSHU | S8HU | S4S8 | S8S4 | U4H | U16H | U64H | U64M | U16U | U64U | H4H | H16H | H64H | H64M | H16U | H64U | SQRA | D4U | U4U
*RST: T72|D4H

Example:	BB:TETR:SCON:TMOD2:SLOT3:LDIR1:LCTY T72
-----------------	---

Manual operation: See "[Logical Channel Type](#)" on page 28

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:
LDIRection<ch>:SCRambling <Scrambling>**

Enables/disables auto scrambling.

Parameters:

<Scrambling> 1 | ON | 0 | OFF
 *RST: 1

Example:

BB:TETR:SCON:TMOD2:SLOT3:LDIR1:SCR ON

Manual operation: See "[Scrambling](#)" on page 29

[[:SOURce<hw>](#)]:BB:TETRa:[SCONfiguration:TMODe<di>:SLOT<st>](#):
LDIRection<ch>:[SDATa <SDATA>](#)

Defines the data source for the DATA fields in the burst.

Parameters:

<SDATA> PATTern | PN11 | PN15 | PN16 | PN20 | PN21 | PN23 | DLISt |
 ALL0 | ALL1 | PN09

PATT

Internal data is used. The bit pattern for the data is defined with the aid of command [\[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SDATa:SDPattern](#) on page 60.

PNxx

The pseudo-random sequence generator is used as the data source. There is a choice of different lengths of random sequence.

DLISt

A data list is used. The data list is selected with the aid of command [\[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SDATa:SDSelection](#) on page 61.

*RST: PN09

Example:

BB:TETR:SCON:TMOD4:SLOT2:LDIR2:SDAT PN23

Manual operation: See "[Data Source](#)" on page 29

[[:SOURce<hw>](#)]:BB:TETRa:[SCONfiguration:TMODe<di>:SLOT<st>](#):
LDIRection<ch>:[SDATa:SDPattern <SDPattern>, <BitCount>](#)

Selects the data pattern for data source pattern ([\[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SDATa](#) on page 60).

Parameters:

<SDPattern> numeric
 *RST: #H0

<BitCount> integer
 Range: 1 to 64
 *RST: 1

Example: BB:TETR:SCON:TMOD4:SLOT2:LDIR2:SDAT PATT
 BB:TETR:SCON:TMOD4:SLOT2:LDIR2:SDAT:SDP #H3F,8

Manual operation: See "[Data Source](#)" on page 29

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:
 LDIRection<ch>:SDATa:SDSelection <SdSelection>**

Selects a data list. This command is only valid for bursts with DATA fields. This data list is only used if it is set as the data source with the aid of command [\[:SOURce<hw>\]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:LDIRection<ch>:SDATa](#) on page 60.

Parameters:

<SdSelection> <data list name>

Example: BB:TETR:SCON:TMOD4:SLOT2:LDIR2:SDAT DLIS
 BB:TETR:SCON:TMOD4:SLOT2:LDIR2:SDAT:SDS
 'dl_tetra_t4_ul_2'

Manual operation: See "[Data Source](#)" on page 29

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODE<di>:SLOT<st>:
 LDIRection<ch>:SLEVel <SLevel>**

Sets the level for the selected slot.

Parameters:

<SLevel> OFF | ATTenuated | FULL

OFF

Attenuation is maximum. The slot is inactive.

ATT

Level is reduced by the level attenuation set in "Slot Attenuation".

FULL

The level corresponds to the level indicated in the display.

*RST: FULL

Example: BB:TETR:SCON:TMOD1:SLOT3:LDIR1:SLEV FULL

Manual operation: See "[\(Sub-\) Slot Level](#)" on page 27

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:SSLevel <SSLevel>**

Sets the level for the second sub-slot.

Parameters:

<SSLevel>	OFF ATTenuated FULL OFF Attenuation is maximum. The slot is inactive. ATT Level is reduced by the level attenuation set in "Slot Attenuation". FULL The level corresponds to the level indicated in the display. *RST: FULL
-----------	--

Example:

```
BB:TETR:LDIR UP
BB:TETR:CTYP CH11
Selects a control burst.
BB:TETR:SCON:TMOD1:SLOT3:LDIR2:SLEV FULL
BB:TETR:SCON:TMOD1:SLOT3:LDIR2:SSLevel FULL
Sets the level of the first and second sub-slot.
```

Manual operation: See "[\(Sub-\) Slot Level](#)" on page 27

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:TPATtern <TPattern>, <BitCount>**

Enters a user-defined TSC. The length of the training sequences depends on the burst type. The first user bit is equivalent to the first bit of the training sequence. All further will be inserted successively.

Parameters:

<TPattern>	numeric *RST: #H00000000000000000000000000000000
<BitCount>	integer Range: 1 to 96 *RST: 96

Example:

```
BB:TETR:SCON:TMOD1:SLOT2:LDIR1:TPAT
#H00000000000000000000000000000000, 96
```

Manual operation: See "[TSC User Defined](#)" on page 30

**[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:
LDIRection<ch>:TSOurce <TSource>**

Determines whether the default or a user-defined training sequence (TSC) is used.

A user-defined training sequence can be created in the field "TSC User Defined".

Parameters:

<TSource> DEFault | UDEFined
 *RST: DEFault

Example: BB:TETR:SCON:TMOD1:SLOT2:LDIR1:TSO DEF

Manual operation: See "Training Sequence" on page 30

4.4 BSCH / BNCH/T commands

[:SOURce<hw>]:BB:TETRa:BBNcht:APARameter.....	63
[:SOURce<hw>]:BB:TETRa:BBNcht:BCCode.....	64
[:SOURce<hw>]:BB:TETRa:BBNcht:CBANDwidth.....	64
[:SOURce<hw>]:BB:TETRa:BBNcht:CRFREquency?.....	64
[:SOURce<hw>]:BB:TETRa:BBNcht:CSLevel.....	65
[:SOURce<hw>]:BB:TETRa:BBNcht:DNBroadcast.....	65
[:SOURce<hw>]:BB:TETRa:BBNcht:DNBenquiry.....	65
[:SOURce<hw>]:BB:TETRa:BBNcht:DSPacing.....	65
[:SOURce<hw>]:BB:TETRa:BBNcht:ECORrection.....	66
[:SOURce<hw>]:BB:TETRa:BBNcht:FBAND.....	66
[:SOURce<hw>]:BB:TETRa:BBNcht:FEEXtension.....	66
[:SOURce<hw>]:BB:TETRa:BBNcht:LBACK.....	66
[:SOURce<hw>]:BB:TETRa:BBNcht:LENTRY.....	67
[:SOURce<hw>]:BB:TETRa:BBNcht:MCCode.....	67
[:SOURce<hw>]:BB:TETRa:BBNcht:MCNumber.....	67
[:SOURce<hw>]:BB:TETRa:BBNcht:MNCode.....	68
[:SOURce<hw>]:BB:TETRa:BBNcht:MTMCell.....	68
[:SOURce<hw>]:BB:TETRa:BBNcht:OFFSet.....	68
[:SOURce<hw>]:BB:TETRa:BBNcht:ROperation.....	68
[:SOURce<hw>]:BB:TETRa:BBNcht:SCODE.....	69
[:SOURce<hw>]:BB:TETRa:BBNcht:SMODE.....	69
[:SOURce<hw>]:BB:TETRa:BBNcht:TBTYpe.....	69
[:SOURce<hw>]:BB:TETRa:BBNcht:TRFRAMES.....	70
[:SOURce<hw>]:BB:TETRa:BBNcht:TTBType.....	70
[:SOURce<hw>]:BB:TETRa:BBNcht:TXON.....	70
[:SOURce<hw>]:BB:TETRa:BBNcht:UPDTx.....	71

[:SOURce<hw>]:BB:TETRa:BBNcht:APARameter <AParameter>

Sets the value of the ACCESS_PARAMETER information field. This parameter is used for subsequent power adjustments for the mobile station.

This protocol information field can takes values from -53 dBm to -23 dBm in 2 dB steps.

Parameters:

<AParameter> AP53 | AP51 | AP49 | AP47 | AP45 | AP43 | AP41 | AP39 |
 AP37 | AP35 | AP33 | AP31 | AP29 | AP27 | AP25 | AP23
 *RST: AP53

Example: BB:TETR:BBNC:APAR AP31

Manual operation: See "[ACCESS_PARAMETER](#)" on page 35

[:SOURce<hw>]:BB:TETRa:BBNcht:BCCode <Bccode>

Sets the colour code.

The base color code is the number of subscriber group in a network.

See [Table 3-2](#) for information on how the scrambling code is calculated.

Parameters:

<Bccode> integer

Range: 1 to 63

*RST: 1

Example: BB:TETR:BBNC:BCC 55

Manual operation: See "[Base Colour Code](#)" on page 37

[:SOURce<hw>]:BB:TETRa:BBNcht:CBANdwidth <CBandwidth>

Selects the carrier bandwidth, i.e. determines the carrier spacing.

The default value for all standard test modes is 25kHz; carrier spacing of 50, 100 and 150 kHz is enabled for "Test Mode" set to User Defined or T4.

Parameters:

<CBandwidth> C25 | C50 | C100 | C150

*RST: C25

Example: BB:TETR:BBNC:CBAN C25

Manual operation: See "[Carrier Bandwidth](#)" on page 31

[:SOURce<hw>]:BB:TETRa:BBNcht:CRFRequency?

Displays the resulting RF frequency, calculated from the previous settings. The frequency is calculated from the "Frequency Band", "Main Carrier Number", "Offset", "Duplex Spacing" and "Reverse Operation" and transmitted in message channel BNCH/T when Downlink MS V+D Testing is selected.

The "Coded RF Frequency" is calculated as described in [Table 3-1](#).

Return values:

<CrFrequency> float

Range: 0 to 1000

Example: BB:TETR:BBNC:CRFR?

Usage: Query only

Manual operation: See "[Coded RF Frequency](#)" on page 32

[:SOURce<hw>]:BB:TETRa:BBNcht:CSLevel <CSLevel>

Sets the cell service level information element, i.e. define the level of service a MS may receive in a cell. It may relate to the traffic loading in a cell.

Parameters:

<CSLevel>	CLUNknown LCLoad MCLoad HCLoad
	CLUNknown
	Cell load unknown
	LCLoad
	Low cell load
	MCLoad
	Medium cell load
	HCLoad
	High cell load
	*RST: CLUNknown

Example: BB:TETR:BBNC:CSL LCL

Manual operation: See "[Cell service level](#)" on page 34

[:SOURce<hw>]:BB:TETRa:BBNcht:DNBroadcast <DnbBroadcast>

Enables/disables support of the D-NWRK-BROADCAST PDU.

Parameters:

<DnbBroadcast>	1 ON 0 OFF
	*RST: OFF

Example: BB:TETR:BBNC:DNBB ON

Manual operation: See "[D-NWRK-BROADCAST broadcast](#)" on page 34

[:SOURce<hw>]:BB:TETRa:BBNcht:DNBenquiry <DnbEnquiry>

Enables/disables support of the D-NWRK-BROADCAST enquiry.

Parameters:

<DnbEnquiry>	1 ON 0 OFF
	*RST: OFF

Example: BB:TETR:BBNC:DNB ON

Manual operation: See "[D-NWRK-BROADCAST enquiry](#)" on page 34

[:SOURce<hw>]:BB:TETRa:BBNcht:DSPacing <DSpacing>

(for Uplink direction only)

The "Duplex Spacing" and "Reverse Operation" parameters in the BNCH/T indicate the required uplink frequency with respect to the indicated downlink frequency. These parameters are defined in ETSI 300 392-2.

Parameters:

<DSpacing> DS0 | DS1 | DS2 | DS3 | DS4 | DS5 | DS6 | DS7
 *RST: DS0

Example:

BB:TETR:BBNC:DSP DS2

Manual operation: See "[Duplex Spacing](#)" on page 32**[:SOURce<hw>]:BB:TETRa:BBNcht:ECORrection <ECorrection>**

Enables/disables error correction.

Parameters:

<ECorrection> 1 | ON | 0 | OFF
 *RST: ON

Example:

BB:TETR:BBNC:ECOR ON

Manual operation: See "[Error Correction](#)" on page 35**[:SOURce<hw>]:BB:TETRa:BBNcht:FBAND <FBand>**

Sets the Frequency Band.

This setting has an effect on the calculation of the transmission frequency. The Frequency Band Information is inserted only in the TETRA BSCH protocol channel.

Parameters:

<FBand> F100 | F200 | F300 | F400 | F500 | F600 | F700 | F800 | F900
 *RST: F100

Example:

BB:TETR:BBNC:FBAN F700

Manual operation: See "[Frequency Band](#)" on page 31**[:SOURce<hw>]:BB:TETRa:BBNcht:FEEExtension <FeExtension>**

Enables/disables the frame 18 extension element, i.e. indicates whether an MS is allowed to receive downlink information on all slots of the frame 18. If extension is allowed, only MSs which are capable of receiving consecutive slots are able to perform this function.

Parameters:

<FeExtension> 1 | ON | 0 | OFF
 *RST: OFF

Example:

BB:TETR:BBNC:FEEX ON

Manual operation: See "[Frame 18 extension](#)" on page 34**[:SOURce<hw>]:BB:TETRa:BBNcht:LBACK <LBack>**

Enables/disables loop back for test purposes.

If enabled, the mobile station should set up a loop and return the data when requested by the Tx_burst_type.

Parameters:

<LBack>	1 ON 0 OFF
	*RST: OFF

Example: BB:TETR:BBNC:LBAC ON

Manual operation: See "[Loop Back](#)" on page 36

[:SOURce<hw>]:BB:TETRa:BBNcht:LENtry <LEntry>

Sets the value of the late entry supported information element, used to indicate to the MS whether or not late entry can be supported by the cell.

Parameters:

<LEntry>	1 ON 0 OFF
	*RST: OFF

Example: BB:TETR:BBNC:LENT ON

Manual operation: See "[Late Entry](#)" on page 35

[:SOURce<hw>]:BB:TETRa:BBNcht:MCCode <Mccode>

Sets the Mobile Country Code.

The MCC is the number of the country in which the unit is operated.

See [Table 3-2](#) for information on how the scrambling code is calculated.

Parameters:

<Mccode>	integer
	Range: 0 to 1023
	*RST: 262

Example: BB:TETR:BBNC:MCC 900

Manual operation: See "[Mobile Country Code](#)" on page 37

[:SOURce<hw>]:BB:TETRa:BBNcht:MCNumber <Mcnumber>

The "Main Carrier Number" divides the TETRA band into carriers with a spacing as set with the parameter "Carrier Bandwidth". The range is 0 to 4095 (12 bits).

The Main Carrier Frequency is calculated as follow:

Main Carrier Frequency, kHz = "Main Carrier Number" * "Carrier Bandwidth"

Parameters:

<Mcnumber>	integer
	Range: 0 to 4095
	*RST: 0

Example: BB:TETR:BBNC:MCN 2300

Manual operation: See "[Main Carrier Number](#)" on page 31

[*:SOURce<hw>*]:BB:TETRa:BBNcht:MNCode <MnCode>

Sets the Mobile Network Code (MNC).

The MNC is the number of the TETRA network operator.

See [Table 3-2](#) for information on how the scrambling code is calculated.

Parameters:

<MnCode> integer

Range: 0 to 16383

*RST: 5519

Example: BB:TETR:BBNC:MNC 230

Manual operation: See "[Mobile Network Code](#)" on page 37

[*:SOURce<hw>*]:BB:TETRa:BBNcht:MTMCell <MtMCell>

Sets the protocol information on the maximum transmission power for the mobile station. Allowed are values from 15 dBm to 45 dBm in 5 dB steps.

The MS_TXPWR_MAX_CELL parameter is used for cell selection and reselection, and for power adjustments.

Parameters:

<MtMCell> M15 | M20 | M25 | M30 | M35 | M40 | M45

*RST: M15

Example: BB:TETR:BBNC:MTMC M25

Manual operation: See "[MS_TXPWR_MAX_CELL](#)" on page 35

[*:SOURce<hw>*]:BB:TETRa:BBNcht:OFFSet <Offset>

Set the "Offset" to shift the center frequency in the channel spacing. The allowed offsets are +6.25, 0, -6.25 and +12.50 kHz.

Parameters:

<Offset> ZERO | P625 | M625 | P125

*RST: ZERO

Example: BB:TETR:BBNC:OFFS P125

Manual operation: See "[Offset](#)" on page 32

[*:SOURce<hw>*]:BB:TETRa:BBNcht:ROperation <ROperation>

(for Uplink direction only)

Enables/disables reverse operation.

Reverse operation is used to fix the uplink frequency relative to the downlink frequency. In normal operation, the uplink frequency is lower than the downlink frequency and in reverse operation, the uplink frequency is higher than the downlink frequency.

Parameters:

<ROperation>	1 ON 0 OFF
	*RST: OFF

Example: BB:TETR:BBNC:ROP ON

Manual operation: See "[Reverse Operation](#)" on page 32

[:SOURce<hw>]:BB:TETRa:BBNCh:SCODe <SCode>

Indicate whether the system is a TETRA V+D system or whether this is a Direct Mode transmission.

Parameters:

<SCode>	S0 S1 S2 S3 S4 S5 S6 S7
	*RST: S4

Example: BB:TETR:BBNC:SCOD S3

Manual operation: See "[System Code](#)" on page 33

[:SOURce<hw>]:BB:TETRa:BBNCh:SMODe <SMode>

The sharing mode field indicates whether the BS is using continuous transmission, carrier sharing, MCCH sharing or traffic carrier sharing.

Parameters:

<SMode>	CTRansmission CSHaring MSHaring TCSHaring
	*RST: CTRansmission

Example: BB:TETR:BBNC:SMOD CSHaring

Manual operation: See "[Sharing Mode](#)" on page 34

[:SOURce<hw>]:BB:TETRa:BBNCh:TBTYpe <TbType>

Sets the parameter Tx_burst_type and determines whether the MS under test transmit either a normal uplink burst or control uplink burst.

Parameters:

<TbType>	NUB CUB
----------	-----------

NUB

The mobile station should transmit using normal uplink burst.

CUB

The mobile station should transmit using control uplink burst.

*RST: NUB

Example: BB:TETR:BBNC:TBTY NUB

Manual operation: See "[Tx_burst_type](#)" on page 36

[:SOURce<hw>]:BB:TETRa:BBNcht:TRFRames <TrFrames>

Determines the number of frames reserved over two multiframe period.

The way this field is processed, depends on the selected [\[:SOURce<hw>\]:BB:TETRa:BBNcht:SMODE](#). If MCCH sharing is indicated, the TS reserved frames field shall indicate which frames are reserved in this mode of operation. For the other values of sharing mode, the contents of the TS reserved frames field shall be ignored.

Parameters:

<TrFrames>	F1 F2 F3 F4 F6 F9 F12 F18
	*RST: F1

Example: BB:TETR:BBNC:TRFR F2

Manual operation: See "[TS reserved frames](#)" on page 34

[:SOURce<hw>]:BB:TETRa:BBNcht:TTBType <TtbType>

Sets the value of the special parameter T1_T4_Burst_Type, i.e. determines the logical channel the BS is expecting to receive.

Parameters:

<TtbType>	T72F T72S SFD BSHD T24D RSV1 RSV2 T72U SFU SSTCh T24U SSCH RSV3 RSburst RSSburst TPTD TPTU T48D T48U TSCD TSCU T108 SPHD SPHU SPF SQHU SQU SQD SQRA
	*RST: T72F

Example: BB:TETR:BBNC:TTBT T48D

Manual operation: See "[T1_T4_Burst_Type](#)" on page 35

[:SOURce<hw>]:BB:TETRa:BBNcht:TXON <TxOn>

Determines the value of the Tx_on parameter, i.e. selects the test mode the MS operates in, "Reception ON" or "Transmission ON".

This parameter is necessary for the generation of test signal T1 or T4 transmitted by the test system.

Parameters:

<TxOn>	RON TON
	RON
	The mobile station is requested to recept.
	TON
	The mobile station is requested to transmit.
	*RST: RON

Example: BB:TETR:BBNC:TXON RON

Manual operation: See "[Tx_on](#)" on page 35

[**:SOURce<hw>]:BB:TETRa:BBNcht:UPDTx <UpDtx>**

The "U-plane DTX" element indicates whether or not the BS supports discontinuous traffic transmission by the MS.

Parameters:

<UpDtx>	1 ON 0 OFF
	*RST: OFF

Example: BB:TETR:BBNC:UPDT ON

Manual operation: See "[U-plane DTX](#)" on page 34

4.5 Filter/clipping commands

[:SOURce<hw>]:BB:TETRa:CLIPping:LEVel	71
[:SOURce<hw>]:BB:TETRa:CLIPping:MODE	72
[:SOURce<hw>]:BB:TETRa:CLIPping:STATe	72
[:SOURce<hw>]:BB:TETRa:FILTer:ILENGTH	72
[:SOURce<hw>]:BB:TETRa:FILTter:PARameter:COSine	72
[:SOURce<hw>]:BB:TETRa:FILTter:PARameter:GAUSS	72
[:SOURce<hw>]:BB:TETRa:FILTter:PARameter:LPASS	72
[:SOURce<hw>]:BB:TETRa:FILTter:PARameter:LPASSEVM	72
[:SOURce<hw>]:BB:TETRa:FILTter:PARameter:PGauss	72
[:SOURce<hw>]:BB:TETRa:FILTter:PARameter:RCOSine	72
[:SOURce<hw>]:BB:TETRa:FILTter:PARameter:SPHase	72
[:SOURce<hw>]:BB:TETRa:FILTter:PARameter:APCO25	72
[:SOURce<hw>]:BB:TETRa:FILTter:PARameter:COSine:COFS	73
[:SOURce<hw>]:BB:TETRa:FILTter:TYPE	73

[**:SOURce<hw>]:BB:TETRa:CLIPping:LEVel <Level>**

Sets the limit for clipping.

Parameters:

<Level>	integer
	Range: 1 to 100
	*RST: 100
	Default unit: PCT

Example: BB:TETR:CLIP:LEV 25

Manual operation: See "[Clipping Level](#)" on page 42

[:SOURce<hw>]:BB:TETRa:CLIPping:MODE <Mode>

Selects the clipping method.

Parameters:

<Mode>	VECTor SCALar
*RST:	VECTor

Example: BB:TETR:CLIP:MODE SCAL

Manual operation: See "[Clipping Mode](#)" on page 42

[:SOURce<hw>]:BB:TETRa:CLIPping:STATe <State>

Switches baseband clipping on and off.

Parameters:

<State>	1 ON 0 OFF
*RST:	OFF

Example: BB:TETR:CLIP:STAT ON

Manual operation: See "[Clipping State](#)" on page 41

[:SOURce<hw>]:BB:TETRa:FILTer:ILENGTH <ILength>

Sets the impulse length (number of filter tabs).

Parameters:

<ILength>	integer
Range:	2 to 100
*RST:	40

Example: BB:TETR:FILT:ILEN 20

Manual operation: See "[Impulse Length](#)" on page 39

[:SOURce<hw>]:BB:TETRa:FILTer:PARameter:COSine <Cosine>

[:SOURce<hw>]:BB:TETRa:FILTer:PARameter:GAUss <Gauss>

[:SOURce<hw>]:BB:TETRa:FILTer:PARameter:LPASs <LPass>

[:SOURce<hw>]:BB:TETRa:FILTer:PARameter:LPASSEVM <LPassEvm>

[:SOURce<hw>]:BB:TETRa:FILTer:PARameter:PGauss <PGauss>

[:SOURce<hw>]:BB:TETRa:FILTer:PARameter:RCOSine <RCosine>

[:SOURce<hw>]:BB:TETRa:FILTer:PARameter:SPhase <SPhase>

[:SOURce<hw>]:BB:TETRa:FILTer:PARameter:APCO25 <ApcO25>

Sets the filter parameter.

Parameters:

<ApcO25>	float
Range:	0.05 to 0.99
Increment:	0.01
*RST:	0.2

Example: BB:TETR:FILT:TYPE APCO25
BB:TETR:FILT:PAR:APCO25 0.1

Manual operation: See "[Roll Off Factor or BxT](#)" on page 39

[**:SOURce<hw>]:BB:TETRa:FILTer:PARameter:COSine:COFS <Cofs>**

Sets the value for the cut off frequency shift. The cut off frequency of the cosine filter can be adjusted to reach spectrum mask requirements.

Parameters:

<Cofs>	float
	Range: -1 to 1
	Increment: 0.01
	*RST: -0.1

Example: BB:TETR:FILT:TYPE COS
BB:TETR:FILT:PAR:COS:COFS 0.5

Manual operation: See "[Cut Off Frequency Shift](#)" on page 39

[**:SOURce<hw>]:BB:TETRa:FILTer:TYPE <Type>**

Sets the baseband filter.

Parameters:

<Type>	RCOSine COSine GAUSS LGauss CONE COF705 COEqualizer COFequalizer C2K3x APCO25 SPHase RECTangle PGAuss LPASs DIRac ENPShape EWPSshape
*RST:	RCOSine

Example: SOURce1:BB:TETRa:FILTer:TYPE GAUS

Manual operation: See "[Filter](#)" on page 39

4.6 Trigger commands

Example: Configuring trigger signals

```
SOURce1:BB:TETRa:TRIGger:SEQUence AREtrigger
SOURce1:BB:TETRa:TRIGger:SOURce EGT1
SOURce1:BB:TETRa:TRIGger:EXTernal:SYNChronize:OUTPut 1
SOURce1:BB:TETRa:TRIGger:EXTernal:INHibit 100
SOURce1:BB:TETRa:TRIGger:EXTernal:DELay 10
```

```
SOURce1:BB:TETRa:TRIGger:SEQUence SING
SOURce1:BB:TETRa:TRIGger:SLUNit SEQ
```

```

// SOURce1:BB:TETRa:TRIGger:SLUNit MFR
SOURce1:BB:TETRa:TRIGger:SLENgth 2

SOURce1:BB:TETRa:TRIGger:SOURce INTernal
SOURce1:BB:TETRa:TRIGger:SEQuence ARETrigger
SOURce1:BB:TETRa:STATE ON
SOURce1:BB:TETRa:TRIGger:EXECute
// executes a trigger, signal generation starts
SOURce1:BB:TETRa:TRIGger:ARM:EXECute
// signal generation stops
SOURce1:BB:TETRa:TRIGger:EXECute
// executes a trigger, signal generation starts again
SOURce1:BB:TETRa:TRIGger:RMODE?
// queries the current signal generation status
// 1 (running)

BB:TETRa:TRIG:SOUR OBAS
// sets triggering by the other path
BB:TETRa:TRIG:INH 200
// sets a restart inhibit for 200 chips following a trigger event
BB:TETRa:TRIG:OBAS:DEL 50
// sets a delay of 50 symbols for the trigger

```

Commands:

[:SOURce<hw>]:BB:TETRa:TRIGger:ARM:EXECute.....	74
[:SOURce<hw>]:BB:TETRa:TRIGger:EXECute.....	75
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal<ch>]:SYNChronize:OUTPut.....	75
[:SOURce<hw>]:BB:TETRa:TRIGger:OBASEband:DELay.....	75
[:SOURce<hw>]:BB:TETRa:TRIGger:OBASEband:DELay.....	75
[:SOURce<hw>]:BB:TETRa:TRIGger:OBASEband:INHibit.....	76
[:SOURce<hw>]:BB:TETRa:TRIGger:RMODE.....	76
[:SOURce<hw>]:BB:TETRa:TRIGger:SLENgth.....	76
[:SOURce<hw>]:BB:TETRa:TRIGger:SLUNit.....	76
[:SOURce<hw>]:BB:TETRa:TRIGger:SOURce.....	77
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal<ch>]:DELay.....	77
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal]:DELay.....	77
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal<ch>]:INHibit.....	78
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal]:INHibit.....	78
[:SOURce<hw>]:BB:TETRa:TRIGger:SEQuence.....	78
[:SOURce<hw>]:BB:TETRa:TRIGger:TIME:DATE.....	78
[:SOURce<hw>]:BB:TETRa:TRIGger:TIME:TIME.....	79
[:SOURce<hw>]:BB:TETRa:TRIGger:TIME[:STATe].....	79

[:SOURce<hw>]:BB:TETRa:TRIGger:ARM:EXECute

Stops signal generation; a subsequent trigger event restarts signal generation.

Example: See [Example "Configuring trigger signals"](#) on page 73

Usage: Event

Manual operation: See "Arm" on page 18

[:SOURce<hw>]:BB:TETRa:TRIGger:EXECute****

Executes a trigger manually. A manual trigger can be executed only when an internal trigger source and a trigger mode other than "Auto" have been selected.

Example: See [Example"Configuring trigger signals" on page 73](#)

Usage: Event

Manual operation: See ["Execute Trigger" on page 19](#)

[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal<ch>]:SYNChronize:OUTPut <Output>****

Enables signal output synchronous to the trigger event.

Parameters:

<Output> 1 | ON | 0 | OFF

*RST: 1

Example: See [Example"Configuring trigger signals" on page 73](#)

Manual operation: See ["Sync. Output to External Trigger/Sync. Output to Trigger" on page 19](#)

[:SOURce<hw>]:BB:TETRa:TRIGger:OBASeband:DELay <Delay>****

Sets the trigger delay (expressed as a number of samples) for triggering by the trigger signal from the second path.

Parameters:

<Delay> float

Range: 0 to 2147483647

Increment: 0.01

*RST: 0

Example: See [Example"Configuring trigger signals" on page 73](#)

Manual operation: See ["External Delay/Trigger Delay" on page 20](#)

[:SOURce<hw>]:BB:TETRa:TRIGger:OBASeband:DELay <Delay>****

Sets the trigger delay (expressed as a number of samples) for triggering by the trigger signal from the second path.

Parameters:

<Delay> float

Range: 0 to 65535

Increment: 0.01

*RST: 0

[:SOURce<hw>]:BB:TETRa:TRIGger:OBASeband:INHibit <Inhibit>

For triggering via the other path, specifies the duration by which a restart is inhibited.

Parameters:

<Inhibit>	integer
	Range: 0 to 67108863
	*RST: 0

Example: See [Example "Configuring trigger signals" on page 73](#)

Manual operation: See ["External Inhibit/Trigger Inhibit"](#) on page 20

[:SOURce<hw>]:BB:TETRa:TRIGger:RMODE <RMode>

Queries the status of signal generation for all trigger modes.

Parameters:

<RMode>	STOP RUN
	*RST: STOP

Example: See [Example "Configuring trigger signals" on page 73](#)

Manual operation: See ["Running/Stopped"](#) on page 18

[:SOURce<hw>]:BB:TETRa:TRIGger:SLENGth <Slength>

Defines the length of the signal sequence that is output in the SINGLE trigger mode.

Parameters:

<Slength>	integer
	Range: 1 to 7000
	*RST: 1

Example: See [Example "Configuring trigger signals" on page 73](#)

Manual operation: See ["Signal Duration"](#) on page 18

[:SOURce<hw>]:BB:TETRa:TRIGger:SLUNit <SIUnit>

Defines the unit of the signal sequence length that is output in the SINGLE trigger mode.

Parameters:

<SIUnit>	SEQUence MFRAme
	*RST: SEQuence

Example: See [Example "Configuring trigger signals" on page 73](#)

Manual operation: See ["Signal Duration Unit"](#) on page 17

[:SOURce<hw>]:BB:TETRa:TRIGger:SOURce <Source>

Selects the trigger signal source and determines the way the triggering is executed.
 Provided are:

- Internal triggering by a command (`INTERNAL`)
- External trigger signal via one of the local or global connectors
 - `EGT1 | EGT2`: External global trigger
 - `EGC1 | EGC2`: External global clock
 - `ELTRigger`: External local trigger
 - `ELClock`: External local clock
- Internal triggering by a signal from the other basebands (`INTA | INTB`)
- `OBASEband | BEXTernal | EXTernal`: Setting only
 Provided only for backward compatibility with other Rohde & Schwarz signal generators.

The R&S SMW accepts these values and maps them automatically as follows:

`EXTernal` = `EGT1`, `BEXTernal` = `EGT2`, `OBASEband` = `INTA` or `INTB`
 (depending on the current baseband)

Parameters:

<Source> `INTB|INTernal|OBASEband|EGT1|EGT2|EGC1|EGC2|ELTRigger|INTA|ELClock|BEXTernal|EXTernal`
 *RST: `INTERNAL`

Example: See [Example "Configuring trigger signals"](#) on page 73

Manual operation: See ["Source"](#) on page 19

[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal<ch>]:DELay <Delay>

Sets the trigger delay.

Parameters:

<Delay>	float
	Range: 0.0 to 65535
	Increment: 0.01
	*RST: 0.0

[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal]:DELay <Delay>

Sets the trigger delay.

Parameters:

<Delay>	float
	Range: 0 to 2147483647
	Increment: 0.01
	*RST: 0
	Default unit: samples

Example: See [Example "Configuring trigger signals"](#) on page 73

Manual operation: See "[External Delay/Trigger Delay](#)" on page 20

[[:SOURce<hw>](#)]:BB:TETRa:TRIGger[:EXternal<ch>]:INHibit <Inhibit>

Specifies the duration by which a restart is inhibited.

Parameters:

<Inhibit>	integer
	Range: 0 to 67108863
	*RST: 0

[[:SOURce<hw>](#)]:BB:TETRa:TRIGger[:EXternal]:INHibit <Inhibit>

Specifies the number of samples by which a restart is to be inhibited following an external trigger event.

Parameters:

<Inhibit>	integer
	Range: 0 to 21.47*symRate(=18E3)
	*RST: 0

Example: See [Example"Configuring trigger signals"](#) on page 73

Manual operation: See "[External Inhibit/Trigger Inhibit](#)" on page 20

[[:SOURce<hw>](#)]:BB:TETRa:TRIGger:SEQuence <Sequence>

Selects the trigger mode:

- AUTO = auto
- RETRigger = retrigger
- AAUTo = armed auto
- ARETrigger = armed retrigger
- SINGle = single

Parameters:

<Sequence>	AUTO RETRigger AAUTo ARETrigger SINGle
	*RST: AUTO

Example: See [Example"Configuring trigger signals"](#) on page 73

Manual operation: See "[Mode](#)" on page 17

[[:SOURce<hw>](#)]:BB:TETRa:TRIGger:TIME:DATE <Year>, <Month>, <Day>

Sets the date for a time-based trigger signal. For trigger modes single or armed auto, you can activate triggering at this date via the following command:

SOURce<hw>:BB:<DigStd>:TRIGger:TIME:STATE

<DigStd> is the mnemonic for the digital standard, for example, ARB. Time-based triggering behaves analogously for all digital standards that support this feature.

Parameters:

<Year>	integer Range: 1980 to 9999
<Month>	integer Range: 1 to 12
<Day>	integer Range: 1 to 31

Example:

See example "Configure a time-based trigger signal" in the sub-chapter "Trigger Commands" of the chapter "SOURce:BB:ARB subsystem" in the R&S SMW user manual.

Manual operation: See "[Trigger Time](#)" on page 18

[:SOURce<hw>]:BB:TETRa:TRIGger:TIME:TIME <Hour>, <Minute>, <Second>

Sets the time for a time-based trigger signal. For trigger modes single or armed auto, you can activate triggering at this time via the following command:

SOURce<hw>:BB:<DigStd>:TRIGger:TIME:STATE

<DigStd> is the mnemonic for the digital standard, for example, ARB. Time-based triggering behaves analogously for all digital standards that support this feature.

Parameters:

<Hour>	integer Range: 0 to 23
<Minute>	integer Range: 0 to 59
<Second>	integer Range: 00 to 59

Example:

See example "Configure a time-based trigger signal" in the sub-chapter "Trigger Commands" of the chapter "SOURce:BB:ARB subsystem" in the R&S SMW user manual.

Manual operation: See "[Trigger Time](#)" on page 18

[:SOURce<hw>]:BB:TETRa:TRIGger:TIME[:STATe] <State>

Activates time-based triggering with a fixed time reference. If activated, the R&S SMW triggers signal generation when its operating system time matches a specified time.

Specify the trigger date and trigger time with the following commands:

SOURce<hw>:BB:<DigStd>:TRIGger:TIME:DATE

SOURce<hw>:BB:<DigStd>:TRIGger:TIME:TIME

<DigStd> is the mnemonic for the digital standard, for example, ARB. Time-based triggering behaves analogously for all digital standards that support this feature.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See example "Configure a time-based trigger signal" in the sub-chapter "Trigger Commands" of the chapter "SOURce:BB:ARB subsystem" in the R&S SMW user manual.

Manual operation: See "[Time Based Trigger](#)" on page 18

4.7 Marker commands

Example: Configuring marker signals

```
SOURCE1:BB:TETRa:TRIGger:OUTPut1:MODE RESTart
// sets a marker at ARB sequence start
// SOURCE1:BB:TETRa:TRIGger:OUTPut1:MODE SSTart
// SOURCE1:BB:TETRa:TRIGger:OUTPut1:MODE FSTart
// SOURCE1:BB:TETRa:TRIGger:OUTPut1:MODE MFSTart
// SOURCE1:BB:TETRa:TRIGger:OUTPut1:MODE HFSTart

SOURCE1:BB:TETRa:TRIGger:OUTPut1:MODE PULSE
// sets a pulse marker
SOURCE1:BB:TETRa:TRIGger:OUTPut1:PULSe:DIVider 2
SOURCE1:BB:TETRa:TRIGger:OUTPut1:PULSe:FREQuency?
// 500000

SOURCE1:BB:TETRa:TRIGger:OUTPut1:MODE PATTern
// sets a bit pattern marker
SOURCE1:BB:TETRa:TRIGger:OUTPut1:PATTern #H2,2

SOURCE1:BB:TETRa:TRIGger:OUTPut1:MODE RAT
SOURCE1:BB:TETRa:TRIGger:OUTPut1:ONTime 40
SOURCE1:BB:TETRa:TRIGger:OUTPut1:OFFTime 20
// defines the on/off ratio
```

Example: Configuring marker delay

```
SOURCE1:BB:TETRa:TRIGger:OUTPut2:DELay 1600
// delays the marker signal output
```

Commands:

[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:DELay.....	81
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:MODE.....	81
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:ONTIme.....	82
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:OFFTime.....	82

[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PATtern	82
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PULSe:DIVider	82
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PULSe:FREQuency?	83

[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:DELay <Delay>

Defines the delay between the signal at the marker outputs and the start of the signals.

Parameters:

<Delay>	float
	Range: 0 to 16777215
	Increment: 1E-3
	*RST: 0

Example: See [Example "Configuring marker delay"](#) on page 80.

Manual operation: See "[Delay](#)" on page 23

[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:MODE <Mode>

Defines the signal for the selected marker output.

Parameters:

<Mode>	RESTart SSTart FSTart MFSTart HFSTart PULSe PATtern RATio
--------	---

RESTart

A marker signal is generated at the start of each ARB sequence.

SSTart

A marker signal is generated at the start of each slot.

FSTart

A marker signal is generated at the start of each frame.

MFSTart

A marker signal is generated at the start of each multiframe.

HFSTart

A marker signal is generated at the start of each hyperframe.

PULSe

A regular marker signal is generated. The pulse frequency is defined by entering a divider. The frequency is derived by dividing the sample rate by the divider.

PATtern

A marker signal that is defined by a bit pattern is generated. The pattern has a maximum length of 64 bits and is defined with the command [\[:SOURce<hw>\]:BB:TETRa:TRIGger:OUTPut<ch>:PATtern](#) on page 82.

RATIo

A marker signal corresponding to the Time Off / Time On specifications in the commands [:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:ONTIme on page 82 and [:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:OFFTime on page 82 is generated.

*RST: RESTart

Example: See [Example "Configuring marker signals"](#) on page 80.

Manual operation: See ["Mode"](#) on page 22

[**:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:ONTIme <Ontime>**
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:OFFTime <Offtime>

Sets the duration during which the marker output is on or off.

*) If R&S SMW-B9 is installed, the minimum marker duration depends on the sample/symbol rate.

See chapter "Basics on ..." in the R&S SMW user manual.

Parameters:

<Offtime>	integer
Range:	1 (R&S SMW-B10) / 1* (R&S SMW-B9) to 16777215
*RST:	1

Example: See [Example "Configuring marker signals"](#) on page 80

Manual operation: See ["Mode"](#) on page 22

[**:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PATTern <Pattern>, <BitCount>**

Sets a data pattern.

Parameters:

<Pattern>	numeric
*RST:	#H2
<BitCount>	integer
Range:	1 to 64
*RST:	2

Example: See [Example "Configuring marker signals"](#) on page 80.

Manual operation: See ["Mode"](#) on page 22

[**:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PULSe:DIVider <Divider>**

Sets the divider for the clock frequency.

^{*)} If R&S SMW-B9 is installed, the minimum marker duration depends on the sample/symbol rate.

See chapter "Basics on ..." in the R&S SMW user manual.

Parameters:

<Divider>	integer Range: 2 (R&S SMW-B10) / 2* (R&S SMW-B9) to 1024 *RST: 2
-----------	--

Example: See [Example "Configuring marker signals"](#) on page 80.

Manual operation: See ["Mode"](#) on page 22

[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PULSe:FREQuency?

Queries the marker pulse frequency.

Return values:

<Frequency>	float Increment: 0.001
-------------	---------------------------

Example: See [Example "Configuring marker signals"](#) on page 80.

Usage: Query only

Manual operation: See ["Mode"](#) on page 22

4.8 Clock commands

This section lists the remote control commands to configure the clock.

Example: Configuring the clock

```
SOURCE:BB:TETRa:CLOCK:SOURce INTernal
// selects internal clock

SOURCE1:BB:TETRa:CLOCK:SOURce ELCL
// selects and configures the external clock signal
SOURCE1:BB:TETRa:CLOCK:MODE SAMP

[:SOURce<hw>]:BB:TETRa:CLOCK:MODE..... 83
[:SOURce<hw>]:BB:TETRa:CLOCK:SOURce..... 84
```

[:SOURce<hw>]:BB:TETRa:CLOCK:MODE <Mode>

Sets the type of externally supplied clock.

Parameters:

<Mode>	SAMPLE *RST: SAMPLE
--------	------------------------

Example: SOURCE1:BB:TETRa:CLOCK:MODE SAMPLE

Options: R&S SMW-B10

Manual operation: See "[Clock Mode](#)" on page 24

[:SOURce<hw>]:BB:TETRa:CLOCk:SOURce <Source>

Selects the clock source.

Parameters:

<Source> INTernal | ELClock | EXTernal

INTernal

The instrument uses its internal clock reference

ELClock

External local clock

EXTernal

EXTernal = EGC1

Setting only; provided for backward compatibility with other Rohde & Schwarz signal generators.

*RST: INTernal

Example: BB:TETR:CLOC:SOUR INT

selects the nternal clock reference.

Options: ELClock requires R&S SMW-B10

Manual operation: See "[Clock Source](#)" on page 24

List of commands

[:SOURce<hw>]:BB:TETRa:BBNcht:APARameter.....	63
[:SOURce<hw>]:BB:TETRa:BBNcht:BCCode.....	64
[:SOURce<hw>]:BB:TETRa:BBNcht:CBANDwidth.....	64
[:SOURce<hw>]:BB:TETRa:BBNcht:CRFRfrequency?.....	64
[:SOURce<hw>]:BB:TETRa:BBNcht:CSLevel.....	65
[:SOURce<hw>]:BB:TETRa:BBNcht:DNNBroadcast.....	65
[:SOURce<hw>]:BB:TETRa:BBNcht:DNBenquiry.....	65
[:SOURce<hw>]:BB:TETRa:BBNcht:DSPacing.....	65
[:SOURce<hw>]:BB:TETRa:BBNcht:ECORrection.....	66
[:SOURce<hw>]:BB:TETRa:BBNcht:FBAND.....	66
[:SOURce<hw>]:BB:TETRa:BBNcht:FEEExtension.....	66
[:SOURce<hw>]:BB:TETRa:BBNcht:LBACK.....	66
[:SOURce<hw>]:BB:TETRa:BBNcht:LENTRY.....	67
[:SOURce<hw>]:BB:TETRa:BBNcht:MCCode.....	67
[:SOURce<hw>]:BB:TETRa:BBNcht:MCNumber.....	67
[:SOURce<hw>]:BB:TETRa:BBNcht:MNCode.....	68
[:SOURce<hw>]:BB:TETRa:BBNcht:MTMCell.....	68
[:SOURce<hw>]:BB:TETRa:BBNcht:OFFSet.....	68
[:SOURce<hw>]:BB:TETRa:BBNcht:ROperation.....	68
[:SOURce<hw>]:BB:TETRa:BBNcht:SCODE.....	69
[:SOURce<hw>]:BB:TETRa:BBNcht:SMODE.....	69
[:SOURce<hw>]:BB:TETRa:BBNcht:TBTYpe.....	69
[:SOURce<hw>]:BB:TETRa:BBNcht:TRFRAMES.....	70
[:SOURce<hw>]:BB:TETRa:BBNcht:TTBType.....	70
[:SOURce<hw>]:BB:TETRa:BBNcht:TXON.....	70
[:SOURce<hw>]:BB:TETRa:BBNcht:UPDTx.....	71
[:SOURce<hw>]:BB:TETRa:CLIPping:LEVel.....	71
[:SOURce<hw>]:BB:TETRa:CLIPping:MODE.....	72
[:SOURce<hw>]:BB:TETRa:CLIPping:STATe.....	72
[:SOURce<hw>]:BB:TETRa:CLOCK:MODE.....	83
[:SOURce<hw>]:BB:TETRa:CLOCK:SOURce.....	84
[:SOURce<hw>]:BB:TETRa:CTYPe.....	48
[:SOURce<hw>]:BB:TETRa:DBTYpe.....	48
[:SOURce<hw>]:BB:TETRa:FITer:ILENGTH.....	72
[:SOURce<hw>]:BB:TETRa:FITer:PARameter:APCO25.....	72
[:SOURce<hw>]:BB:TETRa:FITer:PARameter:COSSine.....	72
[:SOURce<hw>]:BB:TETRa:FITer:PARameter:COSSine:COFS.....	73
[:SOURce<hw>]:BB:TETRa:FITer:PARameter:GAUSS.....	72
[:SOURce<hw>]:BB:TETRa:FITer:PARameter:LPASS.....	72
[:SOURce<hw>]:BB:TETRa:FITer:PARameter:LPASSEVM.....	72
[:SOURce<hw>]:BB:TETRa:FITer:PARameter:PGauss.....	72
[:SOURce<hw>]:BB:TETRa:FITer:PARameter:RCOSine.....	72
[:SOURce<hw>]:BB:TETRa:FITer:PARameter:SPHase.....	72
[:SOURce<hw>]:BB:TETRa:FITer:TYPE.....	73
[:SOURce<hw>]:BB:TETRa:LDIRection.....	49
[:SOURce<hw>]:BB:TETRa:MTYPe.....	49
[:SOURce<hw>]:BB:PRAMPing:FOFFset.....	53

[:SOURce<hw>]:BB:TETRa:PRAMping:RFUNction.....	53
[:SOURce<hw>]:BB:TETRa:PRAMping:ROFFset.....	53
[:SOURce<hw>]:BB:TETRa:PRAMping:RTIME.....	54
[:SOURce<hw>]:BB:TETRa:PRESet.....	49
[:SOURce<hw>]:BB:TETRa:SATTenuation<ch>.....	54
[:SOURce<hw>]:BB:TETRa:SCONfiguration:SLOT<st>:LDIRection<ch>:TBTYpe.....	55
[:SOURce<hw>]:BB:TETRa:SCONfiguration:SLOT<st>:UBBNch.....	56
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:AMODE.....	56
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:APF1.....	56
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:APF2.....	57
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:APHeader.....	57
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:BSATtenuation.....	57
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:DATA.....	58
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:DATA:DPATtern.....	58
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:DATA:DSELection.....	59
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:LCTYpe.....	59
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SCRambling.....	59
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SDATA.....	60
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SDATA:SDPattern....	60
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SDATA:SDSelection.	61
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SLEVel.....	61
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SSATtenuation.....	57
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:SSLevel.....	62
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:TPATtern.....	62
[:SOURce<hw>]:BB:TETRa:SCONfiguration:TMODe<di>:SLOT<st>:LDIRection<ch>:TSOrce.....	62
[:SOURce<hw>]:BB:TETRa:SETTing:CATalog?.....	50
[:SOURce<hw>]:BB:TETRa:SETTing:DELete.....	50
[:SOURce<hw>]:BB:TETRa:SETTing:LOAD.....	50
[:SOURce<hw>]:BB:TETRa:SETTing:STORe.....	51
[:SOURce<hw>]:BB:TETRa:SLENgth.....	51
[:SOURce<hw>]:BB:TETRa:SRATe:VARiation.....	51
[:SOURce<hw>]:BB:TETRa:STATe.....	51
[:SOURce<hw>]:BB:TETRa:TMODe.....	52
[:SOURce<hw>]:BB:TETRa:TRIGger:ARM:EXECute.....	74
[:SOURce<hw>]:BB:TETRa:TRIGger:EXECute.....	75
[:SOURce<hw>]:BB:TETRa:TRIGger:OBASEband:DELay.....	75
[:SOURce<hw>]:BB:TETRa:TRIGger:OBASEband:DELay.....	75
[:SOURce<hw>]:BB:TETRa:TRIGger:OBASEband:INHibit.....	76
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:DELay.....	81
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:MODE.....	81
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:OFFTime.....	82
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:ONTime.....	82
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PATTERn.....	82
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PULSE:DIVider.....	82
[:SOURce<hw>]:BB:TETRa:TRIGger:OUTPut<ch>:PULSE:FREQuency?.....	83
[:SOURce<hw>]:BB:TETRa:TRIGger:RMODe.....	76
[:SOURce<hw>]:BB:TETRa:TRIGger:SEQUence.....	78
[:SOURce<hw>]:BB:TETRa:TRIGger:SLENgth.....	76
[:SOURce<hw>]:BB:TETRa:TRIGger:SLUnit.....	76
[:SOURce<hw>]:BB:TETRa:TRIGger:SOURce.....	77

[:SOURce<hw>]:BB:TETRa:TRIGger:TIME:DATE.....	78
[:SOURce<hw>]:BB:TETRa:TRIGger:TIME:TIME.....	79
[:SOURce<hw>]:BB:TETRa:TRIGger:TIME[:STATE].....	79
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal]:DELay.....	77
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal]:INHibit.....	78
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal<ch>]:DELay.....	77
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal<ch>]:INHibit.....	78
[:SOURce<hw>]:BB:TETRa:TRIGger[:EXTernal<ch>]:SYNChronize:OUTPut.....	75
[:SOURce<hw>]:BB:TETRa:VERSion?.....	52
[:SOURce<hw>]:BB:TETRa:WAveform:CREate.....	52

Index

A

AACH configuration	28
AACH-Q mode	28
ACCESS_PARAMETER	35
Application cards	8
Application notes	8
Arm	
Trigger	18
Armed	
Auto, trigger mode	17
Retrigger, trigger mode	17
Auto	
Trigger mode	17

B

B x T	39
Base colour code	37
Baseband clipping	41
Baseband filter	39
BNCH/T	15
Brochures	7
BSCH	15

C

Carrier bandwidth	31
Cell service level	34
Channel type	15
Clipping	38
Level	41
Mode	41
Settings	41
State	41
Clipping Level	42
Clipping Mode	42
Clock	
Mode	24
Source	24
Clock settings	23
Coded RF Frequency	32
Common trigger settings	17
Conventions	
SCPI commands	46
Coupled trigger settings	17
Crest factor	41
Current range without recalculation	23
Cut Off Frequency factor	39
Cut Off Frequency Shift	39

D

D-NWRK-BROADCAST broadcast	34
D-NWRK-BROADCAST inquiry	34
Data sheets	7
Data source	29
Default settings	12
Delay	
Marker	23
Trigger	20
Documentation overview	6
Downlink Burst Type	15
Duplex spacing	32

E

Error Correction	35
Execute	
Trigger	19
External trigger	
Delay	20
Inhibit	20

F

Fall offset	44
Filter	
Settings	38
Type	39
Filter parameter	39
Frame 18 extension	34
Frequency band	31

G

Generate	
Waveform file	13
Getting started	6

H

Help	6
------------	---

I

Impulse Length	39
Installation	5
Instrument help	6
Instrument security procedures	7

L

Late entry	35
Logical Channel Type	28
Loop back	36

M

Main carrier number	31
Marker	
Delay	23
Mode	22
Settings	21
Measured external clock	24
Mobile country code	37
Mobile network code	37
Mode	
Clock	24
Marker	22
Modulation	
Settings	40
Type	40
Modulation type	15
MS_TXPWR_MAX_CELL	35

N

Nyquist filter	39
----------------------	----

O

Offset	32
Open source acknowledgment (OSA)	7

P

Power Ramp Control	15
--------------------------	----

R

Raised cosine filter	
see Cosine filter	39
Ramp function	43
Ramp time	44
Release notes	7
Retrigger	
Trigger mode	17
Reverse operation	32
Rise offset	44
Roll Off	39
Root raised cosine filter	
see Root Cosine	39
RRC filter	
see Root Cosine filter	39

S

Safety instructions	7
Save/Recall	
Tetra	13
Scrambling	29
Security procedures	7
Sequence Length	15
Service manual	7
Set to default	12
Settings	
Clipping	41
Clock	23
Filter	38
Modulation	40
Sharing mode	34
Signal duration	18
Signal duration unit	17
Signal generation status	18
Single	
Trigger	17
Slot attenuation	45
Subslot attenuation	27
Slot Attenuations	15
Slot level	
Subslot level	27
Source	
Clock	24
Trigger	19
Standard settings	12
State	
Tetra	12
System code	33

T

T1_T4_Burst_Type	35
T2 burst type	27
Tetra	
cut off frequency LP EVM	72
State	12

Time-based trigger

Date	18
State	18
Time	18
Training sequence	30
Transmission direction	14
Trigger	
Arm	18
Delay	20
Execute	19
External	20
External, inhibit	20
Mode	17
Running/Stopped	18
Signal duration	18
Source	19
Synchronize output	19
TS reserved frames	34
Tutorials	7
Tx_burst_type	36
Tx_on	35

U

U-plane DTX	34
Use coded T1/T4 data	27
User manual	6

V

Videos	8
--------------	---

W

Waveform file	
Create	13
White papers	8