

R&S®FSWP-K30

Noise Figure Measurements

User Manual



1177567902
Version 10



This manual describes the following R&S®FSWP models with firmware version 3.02 or higher:

- R&S®FSWP8 (1322.8003K08)
- R&S®FSWP8 (1322.8003K09)
- R&S®FSWP26 (1322.8003K26)
- R&S®FSWP26 (1322.8003K27)
- R&S®FSWP50 (1322.8003K50)
- R&S®FSWP50 (1322.8003K51)

The following firmware applications are described:

- R&S FSWP-K30 (1325.4244.02) (requires R&S FSWP-B1)

© 2024 Rohde & Schwarz

Muehldorfstr. 15, 81671 Muenchen, Germany

Phone: +49 89 41 29 - 0

Email: info@rohde-schwarz.com

Internet: www.rohde-schwarz.com

Subject to change – data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

All other trademarks are the properties of their respective owners.

1177.5679.02 | Version 10 | R&S®FSWP-K30

Throughout this manual, products from Rohde & Schwarz are indicated without the ® symbol , e.g. R&S®FSWP is indicated as R&S FSWP.

Contents

1	Preface	9
1.1	About this manual	9
1.2	Documentation overview	10
1.2.1	Getting started manual.....	10
1.2.2	User manuals and help.....	10
1.2.3	Service manual.....	10
1.2.4	Instrument security procedures.....	10
1.2.5	Printed safety instructions.....	11
1.2.6	Specifications and brochures.....	11
1.2.7	Release notes and open source acknowledgment (OSA).....	11
1.2.8	Application notes, application cards, white papers, etc.....	11
1.2.9	Videos.....	11
1.3	Conventions used in the documentation	11
1.3.1	Typographical conventions.....	11
1.3.2	Conventions for procedure descriptions.....	12
1.3.3	Notes on screenshots.....	12
2	Welcome to the noise figure measurement application	13
2.1	Starting the noise application	13
2.2	Understanding the display information	14
3	Measurements and result displays	17
4	Measurement basics	28
4.1	Tuning modes	28
4.1.1	Swept measurements.....	29
4.1.2	Frequency table measurements.....	29
4.1.3	Single frequency measurements.....	29
4.2	Measurement modes	30
4.3	DUT types	32
4.3.1	Measurements on linear DUTs (direct measurement).....	32
4.3.2	Measurements on frequency converting DUTs.....	32
4.4	External generator control	33

4.5	Image frequency rejection.....	35
4.6	Calibration (2nd stage correction).....	37
4.7	Separating signals by selecting an appropriate resolution bandwidth.....	40
4.8	Analyzing several traces - trace mode.....	41
4.9	Using markers.....	42
5	Configuration.....	45
5.1	Configuration overview.....	45
5.2	Defining the measurement frequency.....	47
5.2.1	Defining a frequency set.....	47
5.2.2	Configuring single frequency measurements.....	50
5.2.3	Using a frequency table.....	51
5.3	Selecting DUT characteristics.....	54
5.4	Configuring the noise source.....	55
5.4.1	Defining the noise source characteristics.....	55
5.4.2	Using an ENR or temperature table.....	59
5.5	Configuring additional loss.....	63
5.5.1	Defining loss.....	63
5.5.2	Using a loss table.....	66
5.6	Configuring the analyzer.....	68
5.7	Using the uncertainty calculator.....	72
5.7.1	Configuring noise source characteristics.....	73
5.7.2	Configuring DUT characteristics.....	75
5.7.3	Configuring analyzer characteristics.....	76
5.7.4	Guidelines and results.....	77
5.8	Trigger and gate configuration.....	78
5.8.1	Trigger settings.....	78
5.8.2	Gate settings.....	82
5.8.3	Continuous gate settings.....	83
5.9	Performing measurements.....	84
5.10	Configuring inputs and outputs of the R&S FSWP.....	86
5.10.1	Radio frequency (RF) input.....	86
5.10.2	External generator.....	88
5.10.2.1	Interface configuration settings.....	88

5.10.2.2	Measurement configuration.....	89
5.10.3	DC power output configuration.....	92
5.10.4	Signal source output configuration.....	92
6	Analysis.....	93
6.1	Configuring the display.....	93
6.1.1	Configuring graphical results.....	93
6.1.2	Configuring numerical results.....	95
6.2	Working with traces.....	96
6.3	Trace / data export configuration.....	98
6.4	Using markers.....	101
6.4.1	Marker configuration.....	101
6.4.2	Marker positioning.....	104
6.5	Limit line settings and functions.....	106
6.5.1	Limit line management.....	106
6.5.2	Limit line details.....	108
7	Remote control commands for noise figure measurements.....	111
7.1	Common suffixes.....	112
7.2	Introduction.....	112
7.2.1	Conventions used in descriptions.....	113
7.2.2	Long and short form.....	113
7.2.3	Numeric suffixes.....	114
7.2.4	Optional keywords.....	114
7.2.5	Alternative keywords.....	114
7.2.6	SCPI parameters.....	115
7.2.6.1	Numeric values.....	115
7.2.6.2	Boolean.....	116
7.2.6.3	Character data.....	116
7.2.6.4	Character strings.....	117
7.2.6.5	Block data.....	117
7.3	Controlling the noise figure measurement channel.....	117
7.4	Working with windows in the display.....	121
7.5	General window commands.....	128
7.6	Retrieving measurement results.....	128

7.7	Defining the measurement frequency	130
7.8	Selecting DUT characteristics	135
7.9	Configuring the noise source	137
7.10	Configuring additional loss	145
7.11	Configuring the analyzer	152
7.12	Configuring triggered and gated measurements	158
7.12.1	Configuring the triggering conditions	159
7.12.2	Configuring gated measurements	162
7.12.3	Configuring the trigger output	165
7.13	Using the uncertainty calculator	167
7.14	Performing measurements	177
7.15	Configuring the inputs and outputs	182
7.15.1	Radio frequency (RF) input	182
7.15.2	External mixer	183
7.15.3	External generator	194
7.16	Configuring the display	198
7.17	Working with traces	201
7.18	Working with limit lines	206
7.18.1	Defining general characteristics of a limit line	207
7.18.2	Defining horizontal data points	209
7.18.3	Controlling lower limit lines	210
7.18.4	Controlling upper limit lines	211
7.18.5	Managing limit lines	212
7.18.6	Controlling limit checks	213
7.19	Working with markers	216
7.19.1	Using markers	216
7.19.2	Using delta markers	219
7.19.3	Configuring markers	222
7.19.4	Positioning markers	223
7.19.5	Positioning delta markers	225
7.20	Using the status register	227
7.20.1	Status registers for noise figure measurements	227
7.20.1.1	STATus:OPERation register	229

7.20.1.2	STATus:QUEStionable register.....	229
7.20.1.3	STATus:QUEStionable:LIMit register.....	230
7.20.1.4	STATus:QUEStionable:CORRection register.....	230
7.20.1.5	Status register remote commands.....	231
7.21	Deprecated remote commands for noise figure measurements.....	233
7.22	Programming example: measuring a noise figure.....	234
	Annex.....	235
A	Reference: frequency table file format.....	235
	List of Remote Commands (Noise Figure).....	236
	Index.....	243

1 Preface

1.1 About this manual

This Spurious Measurements User Manual provides all the information **specific to the application**. All general instrument functions and settings common to all applications and operating modes are described in the main R&S FSWP User Manual.

The main focus in this manual is on the measurement results and the tasks required to obtain them. The following topics are included:

- **Welcome to the noise measurement application**
Introduction to and getting familiar with the application
- **About the measurement**
General concept of the noise measurement and typical applications
- **Measurements and Result Displays**
Details on supported measurements and their result types
- **Measurement Basics**
Background information on basic terms and principles in the context of the measurement
- **Configuration + Analysis**
A concise description of all functions and settings available to configure measurements and analyze results with their corresponding remote control command
- **How to Perform Measurements in the noise measurement application**
Step-by-step instructions to perform a basic noise measurement
- **Measurement Examples**
Detailed measurement examples to guide you through typical measurement scenarios and allow you to try out the application immediately
- **Optimizing and Troubleshooting the Measurement**
Hints and tips on how to handle errors and optimize the test setup
- **Remote Commands for noise Measurements**
Remote commands required to configure and perform noise measurements in a remote environment, sorted by tasks
(Commands required to set up the environment or to perform common tasks on the instrument are provided in the main R&S FSWP User Manual)
Programming examples demonstrate the use of many commands and can usually be executed directly for test purposes
- **Annex**
Reference material
- **List of remote commands**
Alphabetical list of all remote commands described in the manual
- **Index**

1.2 Documentation overview

This section provides an overview of the R&S FSWP user documentation. Unless specified otherwise, you find the documents at:

www.rohde-schwarz.com/manual/FSWP

1.2.1 Getting started manual

Introduces the R&S FSWP and describes how to set up and start working with the product. Includes basic operations, typical measurement examples, and general information, e.g. safety instructions, etc.

A printed version is delivered with the instrument. A PDF version is available for download on the Internet.

1.2.2 User manuals and help

The user manual contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance, instrument interfaces and error messages. Includes the contents of the getting started manual.

The contents of the user manual are available as help in the R&S FSWP. The help offers quick, context-sensitive access to the complete information for the instrument and its firmware.

The user manual is also available for download or for immediate display on the Internet.

1.2.3 Service manual

Describes the performance test for checking the rated specifications, module replacement and repair, firmware update, troubleshooting and fault elimination, and contains mechanical drawings and spare part lists.

The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS):

<https://gloris.rohde-schwarz.com>

1.2.4 Instrument security procedures

Deals with security issues when working with the R&S FSWP in secure areas. It is available for download on the internet.

1.2.5 Printed safety instructions

Provides safety information in many languages. The printed document is delivered with the product.

1.2.6 Specifications and brochures

The specifications document, also known as the data sheet, contains the technical specifications of the R&S FSWP. It also lists the firmware applications and their order numbers, and optional accessories.

The brochure provides an overview of the instrument and deals with the specific characteristics.

See www.rohde-schwarz.com/brochure-datasheet/FSWP

1.2.7 Release notes and open source acknowledgment (OSA)

The release notes list new features, improvements and known issues of the current software version, and describe the software installation.

The software uses several valuable open source software packages. An open source acknowledgment document provides verbatim license texts of the used open source software.

See www.rohde-schwarz.com/firmware/FSWP

1.2.8 Application notes, application cards, white papers, etc.

These documents deal with special applications or background information on particular topics.

See www.rohde-schwarz.com/application/FSWP

1.2.9 Videos

Find various videos on Rohde & Schwarz products and test and measurement topics on YouTube: <https://www.youtube.com/@RohdeundSchwarz>

1.3 Conventions used in the documentation

1.3.1 Typographical conventions

The following text markers are used throughout this documentation:

Convention	Description
"Graphical user interface elements"	All names of graphical user interface elements on the screen, such as dialog boxes, menus, options, buttons, and softkeys are enclosed by quotation marks.
[Keys]	Key and knob names are enclosed by square brackets.
Filenames, commands, program code	Filenames, commands, coding samples and screen output are distinguished by their font.
<i>Input</i>	Input to be entered by the user is displayed in italics.
Links	Links that you can click are displayed in blue font.
"References"	References to other parts of the documentation are enclosed by quotation marks.

1.3.2 Conventions for procedure descriptions

When operating the instrument, several alternative methods may be available to perform the same task. In this case, the procedure using the touchscreen is described. Any elements that can be activated by touching can also be clicked using an additionally connected mouse. The alternative procedure using the keys on the instrument or the on-screen keyboard is only described if it deviates from the standard operating procedures.

The term "select" may refer to any of the described methods, i.e. using a finger on the touchscreen, a mouse pointer in the display, or a key on the instrument or on a keyboard.

1.3.3 Notes on screenshots

When describing the functions of the product, we use sample screenshots. These screenshots are meant to illustrate as many as possible of the provided functions and possible interdependencies between parameters. The shown values may not represent realistic usage scenarios.

The screenshots usually show a fully equipped product, that is: with all options installed. Thus, some functions shown in the screenshots may not be available in your particular product configuration.

2 Welcome to the noise figure measurement application

The R&S FSWP-K30 is a firmware application that adds functionality to perform "noise figure" measurements to the R&S FSWP.



Availability of "Noise Figure" measurements

The "Noise Figure" measurements application becomes available when you equip the R&S FSWP with the optional Spectrum Analyzer hardware (R&S FSWP-B1) and firmware application R&S FSWP-K30.

This user manual contains a description of the functionality that the application provides, including remote control operation.

Functions that are not discussed in this manual are the same as in the Spectrum application and are described in the R&S FSWP user manual.

The latest versions of the manuals are available for download at the product homepage.

<http://www.rohde-schwarz.com/product/FSWP.html>.

Installation

Find detailed installing instructions in the getting started or the release notes of the R&S FSWP.

- [Starting the noise application](#)..... 13
- [Understanding the display information](#)..... 14

2.1 Starting the noise application


The "noise figure" measurement application adds a new type of measurement to the R&S FSWP.

To activate the noise measurement application

1. Select [MODE].

A dialog box opens that contains all operating modes and applications currently available on your R&S FSWP.

2. Select the "Noise Figure" item.



The R&S FSWP opens a new measurement channel for the "noise figure" measurement application.


All settings specific to "noise figure" measurements are in their default state.

Multiple Channels and Sequencer Function

When you activate an application, a new channel is created which determines the measurement settings for that application ("Channel"). The same application can be activated with different measurement settings by creating several "Channel"s for the same application.

The number of channels that can be configured at the same time depends on the available memory on the instrument.

Only one measurement can be performed at any time, namely the one in the currently active channel. However, to perform the configured measurements consecutively, a Sequencer function is provided.

If activated, the measurements configured in the currently defined "Channel"s are performed one after the other in the order of the tabs. The currently active measurement is indicated by a  symbol in the tab label.

The result displays of the individual channels are updated in the tabs (as well as the "MultiView") as the measurements are performed. Sequential operation itself is independent of the currently *displayed* tab.

For details on the Sequencer function, see the R&S FSWP user manual.

2.2 Understanding the display information

The following figure shows the display as it looks for "noise figure" measurements. All different information areas are labeled. They are explained in more detail in the following sections.



Figure 2-1: Screen layout of the noise figure measurement application

- 1 = Toolbar
- 2 = Channel bar
- 3 = Diagram header
- 4 = Result display
- 5 = Softkey bar
- 6 = Status bar

Channel bar information

In the noise measurement application, the R&S FSWP shows the following settings:

Ref Level	Reference level of the R&S FSWP.
Att	Attenuation of the R&S FSWP.
RBW	Resolution bandwidth
SWT	Sweep time
AVG	Number of averages
ENR	Excess noise ratio
2nd Stage Corr	State of the 2nd stage correction.
Calibration Data	Date and time of the current calibration data.
Mode	Currently selected measurement mode.

Window title bar information

For each diagram, the header provides the following information:



Figure 2-2: Window title bar information for the noise measurement application

- 1 = Window number
- 2 = Window type
- 3 = Trace color and number
- 4 = Trace mode

Status bar information

Global instrument settings, the instrument status and any irregularities are indicated in the status bar beneath the diagram. Furthermore, the progress of the current operation is displayed in the status bar.

NOTICE

Risk of damaging the instrument

Make sure not to overload the input mixer during calibration and the measurement. An overload condition can damage or destroy the input mixer.


If an overload condition occurs, the R&S FSWP shows a corresponding message in the status line ("RF OVLD" or "IF OVLD").

To avoid an overload during calibration or measurement, do one or more of the following:

- Check and adjust the DUT "gain" settings
 - Check and adjust the ENR settings
 - Increase the reference level.
-

3 Measurements and result displays

The R&S FSWP-K30 measures the "Noise Figure" of a DUT and displays the results graphically and numerically. Each graphical result display shows the "Noise Figure" from a different perspective. In the default configuration, the application shows the "Noise Figure" of the DUT, the "Gain" of the DUT and the corresponding "Y-Factor". In addition, it shows the numerical results of the measurement.



The scale of the horizontal axis depends on the tuning mode.

Frequency list and swept measurements

In all graphical result displays, the horizontal axis represents the frequency. The displayed frequency is either the RF (radio frequency) or the IF (intermediate frequency). The range depends on the frequency set you have currently defined. Because the application only measures selected frequencies, it connects the results to draw a trace.



Negative "Noise Figure" and "Temperature"

From a physical point of view, the "Noise Figure" and the "Temperature" levels have a positive range (including zero).

Due to the mathematical operations the application performs, the results can be negative. Sometimes this happens due to incorrect calibration or variance of measurement values.

Single frequency measurements

In all graphical result displays, the horizontal axis represents a chronological order of measurement results for the frequency you are testing. The axis has no unit, but is made up out of several index values that represent time. Each index value represents one measurement point and therefore one measurement on the single frequency you are analyzing. The size of the index (and thus number of results) depends on the number of **(Measurement) Points** that you have defined. Because the application only measures at certain points in time, it connects the results to draw a trace.

The right diagram border represents the present (index = 0), values to the left represent past measurement results (index = -<x>). As soon as the application finishes a single measurement, the measurement points are moved to the left, the new result is added on the right. All other measurement points are moved down one position with the most obsolete result falling out of the diagram (like in the roll mode of an oscilloscope).

Selecting the result display

- ▶ Select the  icon in the toolbar or press [MEAS].

The application enters the SmartGrid configuration mode.

For more information on the SmartGrid functionality, see the R&S FSWP Getting Started.

Noise Figure.....	18
Gain.....	19
Temperature.....	19
Y-Factor.....	20
ENR Measured.....	21
Level (Hot).....	22
Level (Cold).....	22
Cal Y-Factor.....	23
Cal Level (Hot).....	24
Cal Level (Cold).....	24
P Hot.....	25
P Cold.....	25
Result Table.....	26
Current Values.....	26
Marker Table.....	26


Noise Figure

Shows the "Noise Figure" of the DUT.

The "Noise Figure" is the ratio of the signal-to-noise ratio at the DUT input to the signal-to-noise ratio at the DUT output.

$$\text{Noise Figure} = \frac{SNR_{in}}{SNR_{out}}$$

The vertical axis shows the level of the "Noise Figure" in dB. The scale depends on the settings in the "Display Configuration" dialog box.



Remote command:


LAY:ADD:WIND? '2',RIGH,NOIS see [LAYout:ADD\[:WINDOW\]?](#) on page 121

Results:TRACe<t>[:DATA]? <Trace>,NOISe

Gain

Shows the "Gain" characteristics of the DUT.

The vertical axis shows the level of the "Gain" in dB. The scale depends on the settings in the "Display Configuration" dialog box.



Remote command:

LAY:ADD:WIND? '2',RIGH,GAIN see [LAYout:ADD\[:WINDOW\]?](#) on page 121

Results:TRACe<t>[:DATA]? <Trace>,GAIN

Temperature

Shows the "Temperature" characteristics of the DUT.

$$\text{Noise Temperature} = \frac{P}{B \cdot k}$$


with

P = Power

B = Bandwidth

k = Boltzmann constant

The vertical axis shows the "Temperature" in Kelvin. The scale depends on the settings in the "Display Configuration" dialog box.



Remote command:

LAY:ADD:WIND? '2', RIGH, TEMP see [LAYout:ADD\[:WINDow\]?](#) on page 121

Results: [TRACe<t>\[:DATA\]? <Trace>, TEMPerature](#)

Y-Factor

Shows the ratio of the hot and the cold power of the DUT.

The "Y-factor" indicates the quality of measurement tolerances and uncertainties. To get the result, the application measures the DUT power with the noise source turned on (hot power) and the noise source turned off (cold power).


$$\text{Y-Factor} = \frac{N_{on}}{N_{off}}$$

with

N_{on} = Noise power [dB] with noise source on

N_{off} = Noise power [dB] with noise source off

The vertical axis shows the linear relation. The scale depends on the settings in the "Display Configuration" dialog box.



Remote command:


LAY:ADD:WIND? '2',RIGH,YFAC see [LAYout:ADD\[:WINDow\]?](#) on page 121

Results: [TRACe<t>\[:DATA\]?](#) <Trace>,YFACTOR

ENR Measured

Shows the results of the ENR measurement.

To measure the ENR of a noise source, first attach a noise source with known ENR to the device, enter the ENR of this noise source to the calibration ENR table and calibrate using this one. Then, attach the unknown noise source to the device and perform a measurement ("Run Single") with this one. The graph shown in the ENR Measured display and the results for ENR Measured in the Result Summary will be the ENR of the noise source at the measured frequencies. The vertical axis shows the level of the measured ENR in dB. The scale depends on the settings in the "Display Configuration" dialog box.



Remote command:


LAY:ADD:WIND? '2', RIGH, ENR see LAYout:ADD[:WINDOW]? on page 121

Results: TRACe<t>[:DATA]? <Trace>, ENR

Level (Hot)

Shows the absolute power characteristics at the instrument input. The noise source is turned on.

The vertical axis shows the power in dBm. The scale depends on the settings in the "Display Configuration" dialog box.



Remote command:


LAY:ADD:WIND? '2', RIGH, PHOT see LAYout:ADD[:WINDOW]? on page 121

Results: TRACe<t>[:DATA]? <Trace>, PHOT

Level (Cold)

Shows the absolute power characteristics at the instrument input. The noise source is turned off.

The vertical axis shows the power in dBm. The scale depends on the settings in the "Display Configuration" dialog box.




Remote command:

LAY:ADD:WIND? '2', RIGH, PCOL see [LAYout:ADD\[:WINDOW\]?](#) on page 121

Results: [TRACe<t>\[:DATA\]? <Trace>, PCOLd](#)

Cal Y-Factor

Shows the ratio of the hot and the cold power measured during calibration.



The "Y-factor" indicates the quality of measurement tolerances and uncertainties. To get the result, the application measures the power with the noise source turned on (hot power) and the noise source turned off (cold power), but without the DUT inserted.

$$Y\text{-Factor} = \frac{N_{on}}{N_{off}}$$

with

N_{on} = Noise power [dB] with noise source on

N_{off} = Noise power [dB] with noise source off

The vertical axis shows the linear relation. The scale depends on the settings in the "Display Configuration" dialog box.


Remote command:

LAY:ADD:WIND? '2', RIGH, CYF see [LAYout:ADD\[:WINDOW\]?](#) on page 121

Results: [TRACe<t>\[:DATA\]? <Trace>, CYFactor](#)

Cal Level (Hot)

Shows the absolute power characteristics at the instrument input during the calibration measurement. The noise source is turned on, the DUT is not inserted.



The vertical axis shows the power in dBm. The scale depends on the settings in the "Display Configuration" dialog box.


Remote command:

LAY:ADD:WIND? '2',RIGH,CPH see [LAYout:ADD\[:WINDow\]?](#) on page 121

Results: [TRACe<t>\[:DATA\]? <Trace>,CPHot](#)

Cal Level (Cold)

Shows the absolute power characteristics at the instrument input during the calibration measurement. The noise source is turned off, the DUT is not inserted.



The vertical axis shows the power in dBm. The scale depends on the settings in the "Display Configuration" dialog box.

Remote command:


LAY:ADD:WIND? '2',RIGH,CPC see LAYout:ADD[:WINDow]? on page 121

Results: TRACe<t>[:DATA]? <Trace>,CPCold

P Hot

Shows the relative power with a hot noise source in dB.

The scale depends on the settings in the "Display Configuration" dialog box.



Remote command:


LAY:ADD? '1',RIGH,DPH, see LAYout:ADD[:WINDow]? on page 121

Results: TRACe<t>[:DATA]? <Trace>,DPHot

P Cold

Shows the relative power with a cold noise source in dB.

The scale depends on the settings in the "Display Configuration" dialog box.



Remote command:

LAY:ADD? '1', RIGH, DPC, see [LAYout:ADD\[:WINDow\]?](#) on page 121

Results: [TRACe<t>\[:DATA\]?](#) <Trace>, DPCold

Result Table

Shows the measurement results in numerical form in a table.

The contents of the table depend on the "Display Settings". By default it shows the "Noise Figure", "Gain" and "Y-Factor" results. Each row represents one measurement point. Each column represents one result type. The first column shows the measurement frequency.

If you display the uncertainty result, it is displayed in the "Noise" column next to the "Noise Figure" result. Note that the uncertainty is displayed only after you have turned on the uncertainty calculation and also include the result in the display.

The result table shows either the RF or the IF, depending on your selection.

For more information, see [Chapter 6.1.2, "Configuring numerical results"](#), on page 95.

4 Result Table [T1]					
RF Freq	Noise Figure	Gain	Y-Factor		
3.000 GHz	3.83 dB	17.00 dB	10.39 dB		
3.020 GHz	3.91 dB	16.85 dB	10.33 dB		
3.040 GHz	3.96 dB	17.11 dB	10.28 dB		
3.060 GHz	4.05 dB	16.88 dB	10.20 dB		
3.080 GHz	3.99 dB	17.08 dB	10.27 dB		
3.100 GHz	3.91 dB	16.94 dB	10.33 dB		
3.120 GHz	3.91 dB	16.98 dB	10.32 dB		
3.140 GHz	3.97 dB	16.96 dB	10.29 dB		
3.160 GHz	4.07 dB	16.91 dB	10.22 dB		
3.180 GHz	4.14 dB	17.11 dB	10.14 dB		
3.200 GHz	4.11 dB	17.14 dB	10.17 dB		
3.220 GHz	3.98 dB	17.38 dB	10.31 dB		
3.240 GHz	3.88 dB	17.20 dB	10.38 dB		
3.260 GHz	3.97 dB	17.26 dB	10.32 dB		
3.280 GHz	4.04 dB	17.10 dB	10.26 dB		

Remote command:

LAY:ADD:WIND? '2', RIGH, RES see [LAYout:ADD\[:WINDow\]?](#) on page 121

Results: [TRACe<n>\[:DATA\]?](#) on page 129

Table items: [DISPlay\[:WINDow<n>\]:TABLE:ITEM](#) on page 198

Current Values

Shows the result at the current measurement point.

The contents of the "Current" result display are updated as soon as a new measurement point is analyzed.

The result types shown in the table depend on the "Display Settings". By default it shows the results for the "Noise Figure", "Gain" and "Y-Factor" result type. Each row represents one result type. The first column shows the result type, the second column shows the result.

For more information, see [Chapter 6.1.2, "Configuring numerical results"](#), on page 95.

Marker Table

Shows the marker characteristics in numerical form in a table.

The size of the table depends on the number of active markers and the way you have configured the table in the "Result Config" dialog box. For more information, see [Chapter 6.4, "Using markers"](#), on page 101 and [Chapter 6.1.2, "Configuring numerical results"](#), on page 95.

4 Marker Table					
Type	Ref	Trc	Stimulus	Noise	Gain
N1		1	400.00 MHz	3.24 dB	21.72 dB
D2	N1	1	100.00 MHz	-0.01 dB	-0.84 dB
D3	N1	1	200.00 MHz	-0.08 dB	-0.12 dB

The first four columns of the table are fix.

- Type
Shows the marker type. 'M' represents a normal marker, 'D' represents a delta marker.
- Ref
Shows the reference marker for relative delta markers.
- Trc
Shows the trace that the marker is positioned on.
- X-value
Shows the horizontal position (frequency) of the marker.
For normal markers, the position is an absolute value. The position of delta markers is relative to another marker.
- <Result>
Shows the measurement result at the marker position.
For normal markers, the result is an absolute value. Results for delta markers are relative to another marker.

Remote command:

LAY:ADD:WIND? '2', RIGH, MTAB see [LAYout:ADD\[:WINDow\]?](#) on page 121

Results:

[CALCulate<n>:MARKer<m>:Y?](#) on page 218

[CALCulate<n>:DELTAmarker<m>:Y?](#) on page 221

4 Measurement basics

The measurement basics contain background information on the terminology and principles of "noise figure" measurements.


"Noise figure" measurements determine the noise that a device under test (DUT) adds to a signal as that signal passes through the DUT.

- [Tuning modes](#)..... 28
- [Measurement modes](#)..... 30
- [DUT types](#)..... 32
- [External generator control](#)..... 33
- [Image frequency rejection](#)..... 35
- [Calibration \(2nd stage correction\)](#)..... 37
- [Separating signals by selecting an appropriate resolution bandwidth](#)..... 40
- [Analyzing several traces - trace mode](#)..... 41
- [Using markers](#)..... 42

4.1 Tuning modes

Basically, the application calculates the "noise figure" of a DUT based on the characteristics of the DUT that have been measured and a noise source whose properties are known. Therefore, the Noise Source Control connector on the R&S FSWP is a prerequisite for the noise measurement application.

In addition to the noise characteristics of a DUT, the application is also able to determine several more DUT characteristics like its "gain" or its "noise temperature" characteristics.



The application provides several measurement modes or **tuning modes**.

- [Swept measurements](#)..... 29
- [Frequency table measurements](#)..... 29
- [Single frequency measurements](#)..... 29

4.1.1 Swept measurements

The **sweep** tuning mode performs measurements on a set of discrete frequencies based on the frequency parameters. Each measurement analyzes the noise characteristics of the corresponding frequency or measurement point.

For swept measurements, the application automatically determines the measurement frequencies and combines them in a frequency list.

Such a frequency set is the result of the frequency and span information that you have provided. The frequency and span information is made up out of the center frequency, the span, the start and the stop frequency. In combination with the measurement points or the frequency table step size, the application calculates the contents of the frequency table.

The **center frequency** is the frequency in the center of the frequency band that you are measuring. Thus, it is defined either by the span, or the start and stop frequencies.

The **measurement points** is the number of entries in a frequency list and thus the number of measurements that the application performs during a "noise figure" measurement.

The **stepsize** defines the distance between two measurement points. It is constant for all measurement points.



If the stepsize is larger than the distance between start and stop frequency, the frequency table consists of the start and stop frequencies only.

4.1.2 Frequency table measurements

The **frequency table** tuning mode also performs measurements on a set of frequencies based on the contents of a frequency list. Each measurement analyzes the noise characteristics of the corresponding frequency.

Compared to a swept measurement, you can customize the contents of the frequency list. Thus, you can add frequencies that are independent of the frequency stepsize and the number of measurement points.

Frequency tables also allow you to define a variable RBW and sweep time, depending on the current frequency of the sweep point (see ["Variable RBW and sweep time for low-frequency measurements"](#) on page 41 and [Chapter 5.2.3, "Using a frequency table"](#), on page 51).

4.1.3 Single frequency measurements

The **single frequency** tuning mode performs one or several consecutive measurements on a single frequency. You can perform the measurement on any frequency that is supported by the hardware you are using.

Single frequency measurements are a way to facilitate manual adjustments for "noise figure" measurements. They also allow you to get an idea about how the "noise figure" at a particular frequency change over time.

Note that sweep lists or frequency tables are not considered in this measurement mode.

Single frequency measurement results

For single frequency measurements, the same set of graphical result displays is available as for frequency list measurements ("Noise Figure", "Gain" etc.). Note, however, that the x-axis has no unit, but shows a series of results taken for a single frequency. The number of displayed results depends on the number of measurement points you have defined.

For more information, see [Chapter 3, "Measurements and result displays"](#), on page 17.

In addition, you can also view the results in the Result Table in numerical form.

Single frequency measurements are not available when you are using a resistor as a noise source.

4.2 Measurement modes

In some cases, the "Level (Hot)" and "Level (Cold)" results require two different noise sources with different temperature characteristics (cold and hot). Measurements with a resistor noise source are such a case.

Usually, noise sources with diode characteristics are used for "Noise Figure" measurements. These noise sources have two states, on and off. When they are supplied with power (state = on), the application measures the hot power, when they are not supplied with power (state = off), it measures the cold power. Turning the noise source on and off is automatically done by the application, so that you can get the hot and cold power characteristics in a single step.


This **automatic measurement mode** is the default measurement mode of the noise measurement application.

A resistor noise source, however, requires two resistors, one hot and one cold. You have to substitute the hot resistor by the cold resistor to measure first the hot and then the cold power. For these cases, the application provides a **manual measurement mode**. This measurement mode is automatically selected when you select a ["Noise Source"](#) on page 57 with resistor characteristics, but is not restricted to those cases.

The manual measurement mode is available for measurements and the calibration stage.

Performing a manual measurement

In manual measurement mode, you have to measure (or calibrate) the hot and cold power characteristics of the DUT separately. When you start the measurement, the application opens a dialog box that allows you to select the type of measurement to perform next.




Recommended order of measurements

Note that it is recommended that you begin with the hot power measurement.


Furthermore, calibration always begins with the hot power measurement.

In case the hot power has to be measured first, the cold power measurement is unavailable:



When the first measurement is done, you can change the test setup by connecting the other resistor. Then start the second measurement.

In the dialog box, the measurement stage that is already done is labeled green.



In addition, the application shows the missing calibration and measurement steps in the channel bar.

Noise		X	
ENR (THot, TCold)	296.50 K, 77.00 K	Mode	Direct
2nd Stage Corr	On (No Cal)		
Calibration	PCold required	Meas	PHot & PCold required

Clearing results

To replace the previous calibration or measurement results, clear the currently stored data using the "Clear Calibration Results" or "Clear Measurement Results" function.



Returning to automatic measurement mode

When you are in automatic measurement mode and select a noise source with resistor characteristics, the application automatically selects the manual measurement mode.

When you are in manual measurement mode and select a noise source with diode characteristics, you have to select the automatic measurement mode deliberately in the "Sweep" menu.

4.3 DUT types

"Noise figure" measurements are possible on DUTs with a wide variety of characteristics. The DUT characteristics not only affect the test setup, but also determine the way the application populates the frequency list for swept measurements.

The noise measurement application supports measurements on DUTs that work on a fixed frequency as well as measurements on frequency-converting DUTs.

- [Measurements on linear DUTs \(direct measurement\)](#).....32
- [Measurements on frequency converting DUTs](#)..... 32

4.3.1 Measurements on linear DUTs (direct measurement)

For a linear DUT, the RF frequency remains the same between its input and output. For measurements on such DUTs, it is sufficient to measure the signal's RF frequency without any additional equipment (like a local oscillator). A typical linear DUT is an amplifier, for example.

The test setup for measurements on such DUTs usually consists of the noise source, the DUT and an analyzer. If necessary, the measurement also considers loss that occurs somewhere in the measurement path.

For linear DUTs, the contents and layout of the "Overview" dialog box represents the configuration of a typical test setup.




4.3.2 Measurements on frequency converting DUTs

A frequency converting DUT converts the RF frequency to an intermediate frequency (IF) using the local oscillator (LO). A frequency-converting DUT either converts the RF frequency to a lower IF (down-conversion) or a higher IF (up-conversion).

The conversion process requires a local oscillator in the test setup. You can generate the LO signal in two ways.

- An external generator controlled by the analyzer via IEC bus.
- A VCO controlled by a voltage source.

If you have selected a frequency-converting DUT measurement mode, the layout of the "Overview" dialog box adds the local oscillator to the test setup.



The local oscillator can have a fixed or a variable frequency. If the LO frequency is fixed, the intermediate frequency (IF) resulting from the conversion process is variable (depending on the input signal). If the LO frequency is variable, the IF has to be fixed.

The noise measurement application provides measurement for both measurement scenarios.

Fixed intermediate frequency

If you select one of the fixed IF measurement modes, the IF is the same for all entries in the frequency list. The LO frequency for each entry is variable and is the result of the equation the selected mode is based on.

- $f_{RF} - f_{IF}$ for up-converters
- $f_{RF} + f_{IF}$ for down-converters

The fixed IF measurement modes are, for example, useful for measurements on mixers.

Note that fixed IF measurements are only possible if the R&S FSWP is equipped with the optional External Generator Control hardware. For more information, see [Chapter 4.4, "External generator control"](#), on page 33.

Fixed LO frequency

If you select one of the fixed LO measurement modes, the LO frequency is the same for all entries in the frequency list. The IF frequency for each entry is variable and is the result of the equation the selected mode is based on.

- $f_{RF} + f_{LO}$ for up-converters
- $f_{RF} - f_{LO}$ for down-converters

The fixed LO measurement modes are, for example, required for measurements on satellite converters.

4.4 External generator control

To perform fixed IF measurements with the noise measurement application, you have to install the optional External Generator Control hardware. This option allows you to control an external generator and the type of signal it generates.

The typical measurement setup for such measurements includes the R&S FSWP equipped with the optional noise measurement application, a signal generator and the DUT. The signal generator is controlled either via the LAN connection or the GPIB interface. The GPIB interface is part of the optional External Generator Control hardware.

To enhance the measurement accuracy, it is recommended to use a common reference frequency for both R&S FSWP and signal generator in the measurement setup.

If you have no 10 MHz reference frequency on hand, you can use the internal reference signal of the R&S FSWP or signal generator. For more information, see the documentation of the R&S FSWP or the signal generator.

Signal generator support

The R&S FSWP-B10 supports various signal generators. A list is available in the user interface (see [Generator Type](#)) and in the documentation of the R&S FSWP.

Note that you have to select the generator specifically for the noise measurement application. It does not inherit the generator settings from other applications.

It is also possible to add new signal generators to that list. To do so, you have to copy a custom signal generator setup file with the file extension `.gen` to the R&S FSWP. The setup file defines the frequency and power ranges supported by the generator, as well as information required for communication. You can use a setup file of the signal generators already supported as a template. After you copy it to the R&S FSWP, the new generator model is added to the dropdown menu.

The existing setup files can be displayed in an editor in read-only mode directly from the [Interface Configuration](#) dialog box.

Make sure to adhere to the required syntax and commands and only change the values of the parameters. Errors are only detected and displayed when you try to use the custom generator.

Error and status messages

The following status and error messages can occur during external generator control.

Message	Description
"Ext. Generator GPIB Handshake Error!" / "Ext. Generator TCPIP Handshake Error!" / "Ext. Generator TTL Handshake Error!"	Connection to the generator is not possible, e.g. due to a cable damage or loose connection or wrong address.
"Ext. Generator Limits Exceeded!"	The allowed frequency or power ranges for the generator were exceeded.
"Reverse Sweep via min. Ext. Generator Frequency!"	Reverse sweep is performed; frequencies are reduced to the minimum frequency, then increased again.
"Ext. Generator File Syntax Error!"	Syntax error in the generator setup file.
"Ext. Generator Command Error!"	Missing or wrong command in the generator setup file.
"Ext. Generator Visa Error!!"	Error with Visa driver provided with installation (very unlikely).

NOTICE**Risk of damage to the instrument**

To allow for highest sensitivity during the measurement, the noise measurement application automatically sets the input attenuation to 0 dB.

Because this configuration minimizes the overrange reserve, make sure that the signal you apply does not cause an overload condition. In particular, consider the LO feedthrough. An overload condition can damage or destroy the input mixer.

The R&S FSWP shows a corresponding message in the status line if an overload occurs ("RF OVLD" or "IF OVLD").

To avoid an overload, do one of the following:

- Reduce the LO feedthrough of the mixer device.
- Increase the reference level.

4.5 Image frequency rejection

Frequency converting DUTs convert a radio frequency (RF) to an intermediate frequency (IF). The IF is lower than the RF for down-converting DUTs, and higher than the RF for up-converting DUTs.

In a basic test setup, the image frequency of the RF signal is also converted to the IF. Depending on the DUT, this effect can be wanted or even necessary, or not. To avoid measurement errors of the "noise figure" and "gain" of up to 3 dB, make sure to use the appropriate measurement configuration.


Basically, you can distinguish between single sideband (SSB) mixers, double sideband (DSB) mixers, and mixers that partly suppress a sideband. If a sideband is not needed or only partly needed, you can reject the image frequency. If you do so, the application activates a filter that suppresses the image frequency to a certain extent.

The following illustrations help you configure the measurement correctly.

For more information on how to configure image rejection, see ["Image Rejection"](#) on page 55.

Double sideband measurements

Double sideband mixers use both sidebands to the same extent. Both RF and image frequency are converted. In that case, turn off image rejection.




f_{LO} = frequency of the local oscillator
 f_{IF} = intermediate frequency = $f_{RF} \pm f_{LO}$
 f_{RF} = lower sideband = $f_{LO} - f_{IF}$
 f_{image} = upper sideband = $f_{LO} + f_{IF}$

If image rejection is on, the results have a 3 dB error. That means "noise figure" results are 3 dB lower than they should be. "Gain" results are 3 dB higher.

Single sideband measurements

Single sideband mixers use a single sideband only. In that case, you have to suppress the sideband that is not required. If you do so, the measurement is like on an amplifier.




To suppress a sideband completely, it is best to set the image rejection to the maximum amount possible (999.99 dB).

Partial sideband suppression


For measurements on mixers with a low image frequency rejection, there are two test scenarios.

- Mixers whose image rejection is known.
- Mixers whose image rejection is unknown.



For mixers whose image rejection is known, define the magnitude of image rejection in dB as accurately as possible. Otherwise, measurement results ("noise figure" and "gain") deviate between 0 dB to 3 dB.

If you do not know the image rejection characteristics of a mixer, use a custom test setup including an additional filter. You also have to know the "gain" characteristics of the DUT.



- (1) = Test setup for calibration
 (2) = Test setup for "noise figure" measurement

In the test setup shown above, a lowpass filter prevents unwanted noise from being fed in at the image frequency.

Depending on the position of the frequency bands, you might need a highpass or bandpass filter for the RF frequency instead of the lowpass filter. The important point is that unwanted noise is not converted by a further receive path of the mixer. The unwanted noise at the received frequency must not be reduced. The insertion loss must be considered, if applicable.

With this test setup, the measurement on a mixer without sideband suppression is the same as SSB measurements.

To take the characteristics of the filter into account, include the insertion loss of the filter at the RF. To consider the actual filter suppression at the image frequency, include the actual attenuation for the image rejection.

Harmonics mixer measurement

For a harmonics mixer, the input signals are not only converted to the IF by the wanted harmonic. The harmonic of the LO signal produced in the mixer is also converted. Often, the mixer even features a lower conversion loss for unwanted harmonics. For measurements on this type of mixer, you have to use a bandpass filter. The filter ensures that there is only noise at the desired frequency at the input of the DUT. This measurement is similar to measurements on a mixer with an average sideband suppression.

4.6 Calibration (2nd stage correction)

The calibration procedure of the application measures the inherent noise of the R&S FSWP you are using. Performing calibration is therefore recommended, as it increases the accuracy of measurement results. The results get more accurate because the application takes the inherent noise of the analyzer into account while it calculates the results.

Calibration for "noise figure" measurements is also known as 2nd stage correction. This term is used because in a typical "noise figure" test setup, the DUT represents the first stage and the analyzer the second stage in the test setup.



The 2nd stage correction is a calibration that is specific to "noise figure" measurements. It is independent of the overall calibration state of the analyzer and does not calibrate the analyzer.

For successful calibration, you need additional equipment.

- Noise source
The noise source is like a calibration standard. It provides a reference with known noise characteristics that allows the application to determine the inherent noise of the analyzer you are using.

During the calibration, the application measures the inherent noise characteristics of the analyzer at the set of measurement frequencies.

Thus, the 2nd stage correction is valid for a particular instrument configuration, the room temperature and the instrument temperature. As long as this configuration stays the same, calibration data remains valid.



Calibrating single frequency measurements

Like for all other measurements of the noise measurement application, perform a calibration before a single frequency measurement for increased accuracy.

There is an easy way to calibrate single frequency measurements, if you already calibrated the application for swept or list measurements. If the single frequency is part of the frequency list, the measurement is already calibrated for that frequency and no further steps are necessary. The application recalls the last calibration values when you switch back to sweep mode or frequency table mode.

Only if you use a single frequency that is not part of the frequency list, you must calibrate this frequency point first.

- Interpolation
If you change the frequency, while the frequency span stays the same or is reduced, the application interpolates the correction data for the new measurement points. A new calibration is not required.
However, measurements based on interpolated data can result in an increased measurement uncertainty. Highly accurate measurements that conform to the values specified in the specifications document are only possible at calibrated measurement points.
Note that useful interpolation is possible only if essential calibration parameters (e.g. impedance or attenuation) change only slightly. This is the case if the distance between the original calibration points is sufficiently small.
If the span increases compared to the span during calibration, a new calibration is necessary.
If the application interpolates the calibration data, it shows a corresponding label in the channel bar and a warning message in the status bar.
- Invalid calibration
If you change one of the amplitude parameters (e.g. the attenuation), calibration is labeled invalid. In that case, calibration is not accurate, because the settings are not in line with the settings at the time the R&S FSWP has been calibrated. If cali-

bration is invalid, repeat the calibration or restore the settings as they were during the calibration.



Saving calibration data

If you save the current configuration or measurement results to a data set, calibration data is part of that data set.

For more information on saving and restoring data sets, see the "Storing and Recalling Instrument Settings and Measurement Data" chapter in the R&S FSWP user manual.

The picture below shows a typical calibration setup that includes a noise source.




Figure 4-1: Noise figure calibration setup

1. Connect the noise source directly and without a cable to the RF input of the analyzer.
2. Connect the noise source to the +28 V voltage supply (Noise Source Control connector) on the back of the R&S FSWP.
To connect the noise source to the voltage supply, you need a coaxial cable.

After you have set up calibration, there are several ways to start calibration.

- In the "Noise Overview" dialog box, press "Calibrate".
- In the "Sweep" menu, press "Calibrate".

Calibration Save



If the user has performed a valid calibration on the instrument, the calibration results can be saved by using "Calibration Save" in the "Export" dialog. This provides the possibility to use once stored calibration results at a later point.

Remote command:


[SENSe:]CORRection:SAVE on page 154

Calibration Recall



Calibration results that have been stored once on the instrument can be recalled by using "Calibration Recall" in the "Import" dialog.

To achieve a valid calibration by importing a saved one, all parameters of R&S FSWP-K30 must match exactly to the ones that have been used for the calibration. At the import of a calibration, a preview dialog is shown which contains all relevant parameters of the calibration to be imported and an indication (green / red) if they match to the current instrument and option settings. Only if the calibration context summary is green, the calibration import can be done. If the calibration context summary is red, importing the calibration results would lead to an invalid calibration status for the current settings. Thus the calibration results cannot be imported in this case. If the calibration context summary is green but some of the individual entries are red (i.e. they differ from the current settings), the calibration results still can be imported. The import will then overwrite the red marked settings with the ones from the stored calibration to ensure the settings match.



Remote command:

`[SENSe:]CORRection:RECall` on page 154

4.7 Separating signals by selecting an appropriate resolution bandwidth

The resolution bandwidth defines the 3 dB bandwidth of the resolution filter to be used. An RF sinusoidal signal is displayed according to the passband characteristic of the resolution filter (RBW), i.e. the signal display reflects the shape of the filter.

The highest sensitivity is obtained at the smallest bandwidth (1 Hz). If the bandwidth is increased, the reduction in sensitivity is proportional to the change in bandwidth. Increasing the bandwidth by a factor of 3 increases the displayed noise by approx. 5 dB (4.77 dB precisely). If the bandwidth is increased by a factor of 10, the displayed noise increases by a factor of 10, i.e. 10 dB.

The higher spectral resolution with smaller bandwidths is won by longer sweep times for the same span. The sweep time has to allow the resolution filters to settle during a sweep at all signal levels and frequencies to be displayed.

If the RBW is too large, signal parts that are very far away (e.g. from a different signal) are considered in the measurement and distort the results. The displayed noise increases.

If the RBW is too small, the measurement time increases.

Variable RBW and sweep time for low-frequency measurements

Usually, a constant RBW and sweep time is used for the entire measurement. However, for low-frequency measurements (under 10 MHz), smaller bandwidths and longer sweep times are required to improve accuracy of the results. Using a small RBW and long sweep time for the entire span would increase measurement time significantly. In this case, a variable RBW and sweep time can be defined for lower frequencies, depending on the current frequency of the sweep point. The variable RBW and sweep times are defined in the frequency table (see [Chapter 5.2.3, "Using a frequency table"](#), on page 51). The defined RBW and sweep times are also included in a table export. In the channel bar, the bandwidth and sweep time range of the variable values is indicated.

4.8 Analyzing several traces - trace mode

The trace mode determines the way the data is processed and displayed. The application provides the following trace modes.

Table 4-1: Overview of available trace modes


Trace Mode	Description
Blank	Hides the selected trace.
Clear Write	Overwrite mode: the trace is overwritten by each sweep. This is the default setting.
View	The current contents of the trace memory are frozen and displayed.



Each time the trace mode is changed, the selected trace memory is cleared.

The default trace mode for the first trace is Clear/Write. For trace 2-4, the default trace mode is "Blank". If you require another mode, you have to set it manually.

As you can have up to four traces simultaneously, you can compare the results with different measurement configurations. For example, freeze a trace and use it as a reference trace.



If you change the scaling of the y-axis, the R&S FSWP automatically adapts the trace data to the changed display range. Thus, you can perform an amplitude zoom after the measurement to show details of the trace.

4.9 Using markers

Markers are used to mark points on traces, to read out the results of a particular measurement point or compare results of different traces. The noise application provides four markers.

When you activate a marker, the application automatically positions it on the first measurement point (left border of the diagram) of trace 1, regardless of how many traces are active. A marker is always positioned on the same horizontal position in all active measurement windows. If you change the position of a marker in one window, the application adjusts the position of that marker in all other measurement windows. Thus, the marker results for a specific marker are always for the same frequency, which makes it easier to compare results.




Markers in single frequency mode

When you use a marker for single frequency measurements, the marker is positioned on a particular index value and not a particular measurement point. This means that during continuous measurements, the marker remains on the index value you have put it on. It does not move down the line with the results.


To move a marker, you can use several methods.

- Enter a particular measurement frequency in the input field that opens when you activate a marker.
- Move the marker around with the rotary knob or the cursor keys.
- Drag the marker around using the touchscreen.

All markers can be used either as normal markers or delta markers. A normal marker indicates the absolute signal value at the defined position in the diagram. A delta marker indicates the value of the marker relative to the specified reference marker (by default marker 1).



The application always positions the marker on the trace with the lowest number that is in Clear/Write trace mode. To set the marker on another trace, use the "Marker to Trace" function. With this function, you can also position a marker on a trace that is in "View" trace mode, e.g. to compare measurement results. Note that at least one active marker has to be a normal marker.



The application shows the results at the marker position directly in the diagram area (up to two markers) or in the marker table (if you use more than two markers).

Marker information in diagram area

By default, the results of the last two markers or delta markers that were activated are displayed in the diagram area.



The following information is displayed there:

- The marker type (M for normal, D for delta, or special function name)
- The marker number (1 to 4)
- The assigned trace number in square brackets []
- The marker value on the y-axis
- The marker position on the x-axis

Marker information in marker table

In addition to the marker information displayed within the diagram area, a marker table can be displayed in a separate window. For more information on the contents of the marker table, see "[Marker Table](#)" on page 26.

5 Configuration

"Noise figure" measurements require a special application on the R&S FSWP, which you activate using [MODE].



The Noise Source Control connector on the R&S FSWP is also a prerequisite for the noise measurement application. Without this connector, no measurement can be performed.

When you activate a measurement channel in the noise measurement application, a measurement for the input signal is defined with the default configuration. The "Noise Figure" menu is displayed and provides access to the most important configuration functions.



Unavailable hardkeys


Note that the [AMPT], [AUTO SET], [BW], [TRIG] and [MKR FUNC] keys have no contents and no function in the noise measurement application.

• Configuration overview	45
• Defining the measurement frequency	47
• Selecting DUT characteristics	54
• Configuring the noise source	55
• Configuring additional loss	63
• Configuring the analyzer	68
• Using the uncertainty calculator	72
• Trigger and gate configuration	78
• Performing measurements	84
• Configuring inputs and outputs of the R&S FSWP	86

5.1 Configuration overview



Throughout the measurement channel configuration, an overview of the most important currently defined settings is provided in the "Overview". The "Overview" is displayed when you select the "Overview" icon, which is available at the bottom of all softkey menus.



In addition to the main measurement settings, the "Overview" provides quick access to the main settings dialog boxes. The individual configuration steps are displayed in the order of the data flow. Thus, you can easily configure an entire measurement channel from input over processing to output and analysis by stepping through the dialog boxes as indicated in the "Overview".

In particular, the "Overview" provides quick access to the following configuration dialog boxes (listed in the recommended order of processing):

To perform a calibration

1. Noise Source
See [Chapter 5.4, "Configuring the noise source"](#), on page 55.
2. Spectrum Analyzer
See [Chapter 5.6, "Configuring the analyzer"](#), on page 68.
3. Calibration
See ["Calibrate"](#) on page 85

To perform a measurement

1. Noise Source
See [Chapter 5.4, "Configuring the noise source"](#), on page 55.
2. Input and output losses
See [Chapter 5.5, "Configuring additional loss"](#), on page 63.
3. DUT configuration
See [Chapter 5.3, "Selecting DUT characteristics"](#), on page 54
4. Spectrum Analyzer
See [Chapter 5.6, "Configuring the analyzer"](#), on page 68.
5. Display Configuration

See [Chapter 6.1, "Configuring the display"](#), on page 93

To configure settings

- ▶ Select any button in the "Overview" to open the corresponding dialog box. Select a setting in the channel bar (at the top of the measurement channel tab) to change a specific setting.

Preset Channel

Select "Preset Channel" in the lower left-hand corner of the "Overview" to restore all measurement settings *in the current channel* to their default values.

Note: Do not confuse "Preset Channel" with the [Preset] key, which restores the entire instrument to its default values and thus closes *all channels* on the R&S FSWP (except for the default channel)!

Remote command:

`SYSTem:PRESet:CHANnel[:EXEC]` on page 120

Specific Settings for

The channel can contain several windows for different results. Thus, the settings indicated in the "Overview" and configured in the dialog boxes vary depending on the selected window.

Select an active window from the "Specific Settings for" selection list that is displayed in the "Overview" and in all window-specific configuration dialog boxes.

The "Overview" and dialog boxes are updated to indicate the settings for the selected window.

5.2 Defining the measurement frequency

- [Defining a frequency set](#)..... 47
- [Configuring single frequency measurements](#).....50
- [Using a frequency table](#)..... 51

5.2.1 Defining a frequency set

Access: "Overview" > "DUT" > "Frequency Config"

These settings define the frequency characteristics for the measurement.

The information in this tab is also the basis for an automatic population of the frequency table. All parameters of this dialog are interdependent. If you change one parameter, at least one other parameter is changed by the application.



If you change a frequency set, perform a new calibration to ensure accurate results.



Preamplifier

If a preamplifier is used, make sure the defined (and possibly upconverted) IF frequencies for the measurement stay below the maximum frequency the preamplifier supports. For the R&S FSWP-B22 option, the maximum frequency is 7 GHz. However, the preamplifier can be activated or deactivated individually for different tuning modes. For example, for a sweep mode which requires a span above 7 GHz it is deactivated, while for a single frequency measurement at 1 GHz it can be activated.

Tuning Mode.....	48
Center.....	49
Span.....	49
Start and Stop Frequency.....	49
(Measurement) Points.....	49
Step.....	50

Tuning Mode

Selects the tuning or measurement mode.

For more information, see [Chapter 4.1, "Tuning modes"](#), on page 28.

Tuning mode selection is also available via softkeys ("Sweep Mode", "Frequency Table Mode", "Single Frequency Mode") in the "Sweep" menu.

Note: A preamplifier can be activated or deactivated individually for different tuning modes. When you switch tuning modes, the defined preamplifier state is adapted.

"Sweep"	The measurement is based on an automatically generated frequency set.
"Frequency Table"	The measurement is based on a customized frequency table. For more information, see Chapter 5.2.3, "Using a frequency table" , on page 51.
"Single Frequency"	The measurement measures a single frequency only. For more information, see Chapter 5.2.2, "Configuring single frequency measurements" , on page 50.

Remote command:

Frequency sweep measurement:

[\[SENSe:\]CONFigure:LIST:CONTinuous](#) on page 131

[\[SENSe:\]CONFigure:LIST:SINGle](#) on page 131

[INITiate<n>\[:IMMediate\]](#) on page 179

Single frequency measurement:

[\[SENSe:\]CONFigure:FREQuency:CONTinuous](#) on page 131

[\[SENSe:\]CONFigure:FREQuency:SINGle](#) on page 131

[INITiate<n>\[:IMMediate\]](#) on page 179

Center

Defines the center of the measurement frequency range.

If you change the center frequency, the application changes the start and stop frequency according to the span you have set.

The "Center" setting is also available via [FREQ].

Remote command:

Frequency list measurement:

[\[SENSe:\]FREQuency:CENTer](#) on page 132

Single frequency measurement:

[\[SENSe:\]FREQuency:SINGle](#) on page 133

Span

Defines the measurement span.

If you change the span, the application changes the start frequency, the stop frequency and the stepsize according to the center frequency and the measurement points.

The "Span" setting is also available via [SPAN].

Remote command:

[\[SENSe:\]FREQuency:SPAN](#) on page 134

Start and Stop Frequency

Defines the start and stop frequencies.

If you change the start or stop frequency, the application changes the center frequency, the span and the measurement points according to the new values and the stepsize.

The "Start" and "Stop" settings are also available via [FREQ].

Remote command:

Start frequency:

[\[SENSe:\]FREQuency:START](#) on page 134

Stop frequency:

[\[SENSe:\]FREQuency:STOP](#) on page 135

(Measurement) Points

Defines the measurement points.

For frequency list measurements, the number of measurement points corresponds to the number of entries in the frequency table. The number of points displayed in the graphical results is also the same.

If you change the measurement points, the application changes the stepsize according to the span.

The "Points" setting is also available via [SPAN].

Remote command:

[SENSe:] FREQuency: POINTs on page 133

Step

Defines the frequency step size in the frequency table.

The stepsize corresponds to the distance between two consecutive measurement points.

If you change the stepsize, the application changes the measurement point according to the span.

The "Stepsize" setting is also available via [FREQ].

Remote command:

[SENSe:] FREQuency: STEP on page 135


5.2.2 Configuring single frequency measurements

Access: "Overview" > "DUT" > "Frequency Config" > "Tuning Mode: Single Frequency"

These settings define the frequency characteristics for the measurement.



If you change the frequency, perform a new calibration to ensure accurate results.



Single (Frequency).....	50
Coupled to Sweep List.....	51
(Measurement) Points.....	51

Single (Frequency)

Defines the frequency that the single frequency measurement is performed on.

The "Single" setting is also available via [FREQ].

Remote command:

[SENSe:]FREQuency:SINGle on page 133

Coupled to Sweep List

Couples or decouples frequency selection to the contents of a sweep list.

If you couple the frequency to the sweep list, the application allows you to select only the frequencies currently part of the frequency list. If you enter another frequency, the application automatically selects the nearest frequency of the frequency list. If the frequency list has been calibrated previously, calibration remains valid for those frequencies when you change the tuning mode.

If you turn off the coupling, you can define any frequency for single frequency measurements. Note, however, that you have to calibrate the measurement for that frequency.

Remote command:

[SENSe:]FREQuency:SINGle:COUPled on page 134

(Measurement) Points

Defines the number of measurement points for single frequency measurements.

For single frequency measurements, the number of measurement points corresponds to the number of measurements (index values) performed on a single frequency.

For more information, see "[Single frequency measurements](#)" on page 18.

The "Points" setting is also available via [SPAN].

Remote command:

[SENSe:]FREQuency:POINTs on page 133


5.2.3 Using a frequency table

Access: "Overview" > "DUT" > "Frequency Config" > "Frequency Table"

The "Frequency Table" tab in the "Frequency Settings" dialog box contains functionality to manage the measurement frequencies.

The application populates the table according to the information you entered in the "Frequency Config" tab when you select "Populate Table".

Note that changes to the frequency table take effect only if you select the "Frequency Table" tuning mode.



Frequency Table.....	52
Clear Table.....	53
Populate Table.....	53
Insert.....	53
Delete.....	53
Import / Export.....	53

Frequency Table

Shows the current measurement points.

The table is made up of one column that represents the measurement frequency. Each frequency corresponds to one measurement point. The length of the table is variable (up to a maximum of 10001 points).

When you perform measurements in "Sweep" or "Single Frequency" tuning mode, the contents of the table have no effect on the measurement.

When you select a table entry in "Frequency Table" tuning mode, you can edit it or add a new frequency below the selected frequency. A new frequency has to be higher than the last table entry and lower than the next table entry.

If the RBW and sweep time settings are set to "variable" in the measurement settings (see [Resolution Bandwidth \(RBW\)](#) and ["Sweep Time"](#) on page 69), you can also define those values in the frequency table.

Select [Populate Table](#) to predefine the RBW and sweep times to be used. For each sweep point with a frequency under 10 MHz in the table, suitable settings are defined. For higher frequencies, the values provided in the measurement settings are used (indicated by "--" as they are automatically updated if the measurement settings change.) All predefined values in the table can be overwritten manually.

The defined RBW and sweep times are also included in a table export.

See also "[Variable RBW and sweep time for low-frequency measurements](#)" on page 41.

Clear Table

Deletes the contents of the table.

Populate Table

Populates or restores the measurement frequencies based on the center frequency, the start and stop frequencies, the span, the stepsize and the number of measurement points.

If the RBW and sweep time settings are set to "variable" in the measurement settings (see [Resolution Bandwidth \(RBW\)](#) and "[Sweep Time](#)" on page 69), those values are also predefined. For each sweep point with a frequency under 10 MHz in the table, suitable settings are defined. For higher frequencies, the values provided in the measurement settings are used (indicated by "--" as they are automatically updated if the measurement settings change.) All predefined values in the table can be overwritten manually.

See also "[Variable RBW and sweep time for low-frequency measurements](#)" on page 41.

Remote command:

`[SENSe:] FREQuency: TABLE: DATA` on page 132

`[SENSe:] FREQuency: LIST: DATA` on page 132

RBW and sweep time set to variable: `[SENSe:] BANDwidth: LIST: DATA` on page 133

Insert

Inserts a new measurement point above the one you have selected.

Delete

Deletes the currently selected measurement point.

Import / Export

Opens a dialog box to select a frequency table to import or export.

An import copies the frequency table into the default frequency table directory. An export copies the table to a location outside the default frequency table directory, e.g. a memory stick. The file extension has to be `*.freq`.

If variable RBW and sweep times are enabled, they are also included in a table export (see "[Frequency Table](#)" on page 52).

For details on the required file format, see [Chapter A, "Reference: frequency table file format"](#), on page 235.

5.3 Selecting DUT characteristics

Access: "Overview" > "DUT" > "DUT Settings"

The "DUT" button opens a dialog box to configure the characteristics of the DUT you are testing. The dialog box contains a schematic overview of the DUT input and output characteristics and the way it is integrated into the test setup.

The screenshot shows the 'Frequency Settings' dialog box with the 'DUT Settings' tab selected. The 'Mode' is set to 'Fixed IF, Down Conv'. Under 'Mixer Settings', the 'IF fixed' value is 0.0 Hz and the 'Image Rejection' is 999.99 dB. A schematic diagram illustrates the mixer configuration: an RF input with a frequency range from 10.0 MHz to 26.5 GHz and a LO input with the same frequency range are combined in a multiplier (represented by a circle with an 'X') to produce a fixed IF output of 0.0 Hz.

Mode.....	54
LO Fixed.....	55
IF Fixed.....	55
Image Rejection.....	55

Mode

Selects the measurement mode.

The required measurement mode depends on the type of DUT you are testing. For more information, see [Chapter 4.3, "DUT types"](#), on page 32.

Note: For upconverting measurements, if a preamplifier is used, make sure the upconverted frequencies for the measurement stay below the maximum frequency the preamplifier supports.

Remote command:

DUT type: `[SENSe:]CONFigure:MODE:DUT` on page 137

LO type: `[SENSe:]CONFigure:MODE:SYSTem:LO` on page 136

LO Fixed

Defines a fixed LO frequency for measurements on frequency-converting DUTs with a fixed LO.

After you have defined the LO frequency, the application updates the frequency list accordingly.

The "LO" setting is also available via [FREQ].

Remote command:

[\[SENSe:\]CONFigure:MODE:SYSTem:LO:FREQuency](#) on page 136

IF Fixed

Defines a fixed intermediary frequency (IF) for measurements on frequency-converting DUTs with a fixed IF.

After you have defined the intermediary frequency, the application updates the frequency list accordingly.

The "IF" setting is also available via [FREQ].

Remote command:

[\[SENSe:\]CONFigure:MODE:SYSTem:IF:FREQuency](#) on page 135

Image Rejection

Turns image rejection of the DUT on and off.

If you set an image rejection of 0 dB, the image frequency passes completely. If you set a high image rejection (up to 999.99 dB), the image frequency is suppressed completely. For DUTs that have a partial image rejection, define the amount of suppression.

For more information, see [Chapter 4.5, "Image frequency rejection"](#), on page 35.

Remote command:

[\[SENSe:\]CORRection:IREJection](#) on page 137

5.4 Configuring the noise source

The noise source characteristics are used to calculate the effective noise temperature of the noise source. The more accurate the specified characteristics of the noise source you are using, the more accurate the measurement results. The noise source characteristics must be supplied by its manufacturer.

- [Defining the noise source characteristics](#).....55
- [Using an ENR or temperature table](#)..... 59

5.4.1 Defining the noise source characteristics

Access: "Overview" > "Noise Source" > "ENR / Temp Settings"

The noise characteristics of noise sources with diode characteristics are usually defined by their ENR (Excess Noise Ratio). The noise characteristics of noise sources with resistor characteristics are defined by their noise (or ambient) temperatures (T_{hot} and T_{cold}). T_{cold} is typically at a very low temperature of liquid nitrogen or liquid helium.

Both noise source types can have different ENR values during the calibration and the measurement stage. You can use either the same type of noise source for both calibration and measurement, or use different types of noise sources for calibration and measurement.


ENR/TEMP Settings	
ENR/TEMP Settings	Table Settings
Auto Select SNS	<input checked="" type="checkbox"/> On <input type="checkbox"/> Off
Measurement	
Noise Source	Noise Diode ▾
<input checked="" type="radio"/> Constant	15.0 dB
<input type="radio"/> Table	DEFAULT ▾
Common Noise Source	<input checked="" type="checkbox"/> On <input type="checkbox"/> Off
Calibration	
Noise Source	Noise Diode ▾
<input type="radio"/> Constant	15.0 dB
<input type="radio"/> Table	DEFAULT ▾
Temperature	23.35 C

Auto Select SNS.....	56
Noise Source.....	57
Measurement.....	57
Common Noise Source.....	58
Calibration.....	58
Temperature.....	59

Auto Select SNS

If enabled (default), the noise measurement application automatically recognizes a connected smart noise source and uses it for the noise measurement. The provided ENR and uncertainty tables and temperature are loaded and used for the measurement. The recognized serial number of the SNS is indicated in the channel bar and dialogs of the noise measurement application.

If "Auto Select SNS" is ON and a SNS is connected, a green message with information about the connected SNS is displayed:



If no SNS is connected, a red "No SNS connected" warning is displayed:



If "Auto Select SNS" is disabled, you must manually change the noise source to SNS and select the required tables, if necessary (see "Frequency Table" on page 52).

Noise Source

Access: "Overview" > "Noise Source" > "ENR / Temp Settings" > "Noise Source"

You can select the type of noise source and its characteristics independently for the [Calibration](#) and the [Measurement](#).

- | | |
|----------------------|--|
| "Diode" | Selects a noise source with diode characteristics. The frequency characteristics of the noise source are defined by the Excess Noise ratio (ENR). |
| "Resistor" | Selects a test setup that uses two resistors which act as a noise source. One of the resistors has a low noise or ambient temperature (a cold resistor), the other has a high noise or ambient temperature (a hot resistor). The noise characteristics of the resistor are defined by its noise temperatures T_{hot} and T_{cold} .
When you select the resistor noise source, the application automatically starts the manual measurement mode, which is indicated in a message at the bottom of the dialog box. |
| "Smart Noise Source" | Selects a smart noise source, which provides its own ENR and uncertainty tables. The serial number of the connected noise source is automatically recognized and indicated. Otherwise, enter the number of a noise source to continue preconfiguring the measurement. |

Remote command:

Measurement: `[SENSe:]CORRection:ENR[:MEASurement]:TYPE` on page 143

`[SENSe:]CORRection:ENR[:MEASurement]:SNS:SRNumber` on page 145

Calibration: `[SENSe:]CORRection:ENR:CALibration:TYPE` on page 140

`[SENSe:]CORRection:ENR:CALibration:SNS:SRNumber` on page 145

Measurement

Selects the source of the ENR or temperature values.

The frequency characteristics can be approximated by a constant or be based on an ENR or temperature table.

If the ENR or temperature is a constant, the same values are used for all frequencies in the frequency table. If you have selected a constant ENR, you have to define its magnitude in the input field next to the radio button. If you have selected a constant temperature, you have to define the temperatures of the resistor in the input fields next to the radio button. T_{hot} is the temperature of a resistor with a low noise or ambient temperature; T_{cold} is the temperature of a resistor with a high noise or ambient temperature.

If the noise characteristics are based on a table, the ENR level and temperatures typically depend on the measurement frequency. You can select an existing table from the dropdown menu next to the radio button, if it is active. For more information on ENR and temperature tables, see [Chapter 5.4.2, "Using an ENR or temperature table"](#), on page 59.

When "Common Noise Source" is on, the ENR is used for both measurement and calibration.

Remote command:

ENR mode: `[SENSe:]CORRection:ENR[:MEASurement]:MODE` on page 143

Constant ENR: `[SENSe:]CORRection:ENR[:MEASurement]:SPOT` on page 143

Select table: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:SElect`
on page 141

Constant temperature: `[SENSe:]CORRection:ENR[:MEASurement]:SPOT:COLD`
on page 144

Constant temperature: `[SENSe:]CORRection:ENR[:MEASurement]:SPOT:HOT`
on page 144

Common Noise Source

Turns the use of a common ENR on and off.

Common ENRs have the same characteristics for the measurement and calibration. If you turn off common ENR, you can define an additional ENR to be used during calibration.

Define additional ENR for measurements on frequency converting DUTs, if one noise source does not cover the frequency range at the DUT input (RF) and for calibration (IF).

Remote command:

`[SENSe:]CORRection:ENR:COMMon` on page 140

Calibration

Selects the source of the ENR or temperature values used during calibration.

The frequency characteristics can be a constant or be based on an ENR or temperature table.

If the ENR or temperature is a constant, the same value is used for all frequencies in the frequency table. If you have selected a constant ENR, you can also define its value in the input field next to the radio button. If you have selected a constant temperature, you have to define the temperatures of the resistor in the input fields next to the radio button. T_{hot} is the temperature of a resistor with a low noise or ambient temperature; T_{cold} is the temperature of a resistor with a high noise or ambient temperature.

If the noise source characteristics are based on a table, the ENR level and temperature depend on the measurement frequency. In that case, the values are interpolated to the measurement points. You can select a table from the dropdown menu next to the radio button, if it is active. For more information on ENR tables, see [Chapter 5.4.2, "Using an ENR or temperature table"](#), on page 59.

The calibration settings are available if the "Common Noise Source" is off.

Remote command:

ENR mode: `[SENSe:]CORRection:ENR:CALibration:MODE` on page 139

Constant ENR: `[SENSe:]CORRection:ENR:CALibration:SPOT` on page 139

Select table: `[SENSe:]CORRection:ENR:CALibration:TABLE:SElect`
on page 139

Constant temperature: `[SENSe:]CORRection:ENR:CALibration:SPOT:COLD`
on page 138

Constant temperature: `[SENSe:]CORRection:ENR:CALibration:SPOT:HOT`
on page 138

Temperature

Defines the absolute room temperature in degree Celsius or Fahrenheit.

The room temperature is required for the calculation of the real ENR of the noise source, because an ENR table is based on a temperature of 290K.

For smart noise sources, the temperature is provided automatically by the connected SNS itself. If no SNS is connected, the most recently loaded value is indicated. The provided temperature is used for all noise sources throughout the measurement.

To change the unit of the temperature from Celsius to Fahrenheit, change the date format from "DE" to "US" in the "General" display settings.

- Press [SETUP].
- Select "Display".
- Select the "General" tab.
- Select "DE" for Celsius or "US" for Fahrenheit.

Note: If you define the temperature via remote control, the unit is degree Kelvin.

Remote command:

`[SENSe:]CORRection:TEMPerature` on page 144

5.4.2 Using an ENR or temperature table

Access: "Overview" > "Noise Source" > "Table Settings"

The "Table Settings" tab in the "ENR/TEMP Settings" dialog box contains the functionality to create and edit ENR or temperature tables.

ENR or temperature tables contain the noise source characteristics for particular frequencies. If the table does not contain ENR or temperature values for one of the measurement frequencies, the application interpolates between the values.

The "Table Settings" tab contains a list of ENR and temperature tables currently available on the R&S FSWP and shows the table currently in use if the "ENR/TEMP Settings" are enabled.

In addition, the tab contains functionality to create new tables and modify existing ones.

Noise Source.....	60
New.....	60
Edit.....	60
Delete.....	61
Copy To.....	61
Import / Export Table.....	61
Edit Table.....	61

Noise Source

Selects the type of noise source you are using for the measurement. The type of noise source selected in the "ENR/TEMP Settings" > "Noise Source" dialog is adopted automatically.

The noise source type affects the data type that the table contains. For a "Noise Diode", the table contains the ENR values of the noise source you are using. For a "Resistor", the table contains the noise temperatures of the resistors (T_{hot} and T_{cold}).

For a smart noise source, the table contains the provided ENR and uncertainty table. The table for the connected noise source is automatically recognized and highlighted. The name of the ENR table contains the serial number of the SNS. The "default" table also contains the data for the most recently connected smart noise source. The tables for all previously connected noise sources, whose ENR tables remain stored on the instrument, are also listed. Smart noise source tables are for reference only and cannot be edited.

For more information on the noise source types, see "Noise Source" on page 57.

Remote command:

`[SENSe:]CORRection:ENR[:MEASurement]:TYPE` on page 143

New

Opens the [Edit Table](#) dialog box to create a new table.

The contents of the dialog box are empty.

Smart noise source tables are shown for reference only and cannot be edited. A message indicates whether the SNS with the selected serial number is currently connected to the R&S FSWP or not. If it is connected, the table data reflects the most recent data provided by the SNS.

Remote command:

Table selection: `[SENSe:]CORRection:ENR:CALibration:TABLE:SElect`
on page 139

and: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:SElect` on page 141

Diode: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE[:DATA]` on page 140

Resistor: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature[:DATA]` on page 142

Edit

Opens the [Edit Table](#) dialog box to modify the selected table.

Smart noise source tables are for reference only and cannot be edited.

Remote command:

Table selection: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:SElect`
on page 141

and: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:SElect` on page 141

Diode: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE[:DATA]` on page 140

Resistor: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature[:DATA]`
on page 142

Delete

Deletes the selected table.

Smart noise source tables cannot be deleted.

Remote command:

Diode: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:DElete` on page 141

Resistor: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature:DElete`
on page 142

Copy To

Opens the [Edit Table](#) dialog box to modify the selected table and save it under a new name.

Import / Export Table

Opens a dialog box to select a table to import or export.

Smart noise source tables can be exported, but not re-imported. Tables for smart noise sources are always loaded directly from the SNS itself. However, you can edit and use the SNS tables for other noise sources, such as noise diodes.

Edit Table

Defines the noise source characteristics or the loss characteristics of additional measurement equipment.

The noise source and loss tables are made up of up to 10001 data points. A data point consists of a frequency and its corresponding ENR, temperature or loss value. The ENR and temperature values must be supplied by the manufacturer of the noise source or resistor. The loss characteristics of measurement equipment must also be supplied by the manufacturer.

Frequency	Value
1.00000000 MHz	1.00 dB
10.00000000 MHz	10.00 dB

"Name"	Name of the ENR, temperature or loss table.
"Comment"	Comment for the ENR, temperature or loss table.
"Frequency"	Frequency of a particular ENR, temperature or loss value.
"Value"	ENR value or loss in dB. For a resistor, the characteristics of the resistor are defined by the noise temperatures T_{hot} and T_{cold} instead of a single value. The unit in that case is Kelvin (degrees).
"Clear Table"	Deletes the contents of the table (frequencies and values) or the loss table.
"Insert"	Inserts a new data point above the selected one.
"Delete"	Deletes the selected data point.
"Save"	Saves the table.
"Cancel"	Exits the "Edit Table" dialog box and returns to the result diagram.

Remote command:

Edit ENR table: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE[:DATA]`
on page 140

Edit temperature table: `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature[:DATA]`
on page 142

Edit input loss table: [\[SENSe:\]CORRection:LOSS:INPut:TABLE\[:DATA\]](#)
on page 148

Edit output loss table: [\[SENSe:\]CORRection:LOSS:OUTPut:TABLE\[:DATA\]](#)
on page 150

5.5 Configuring additional loss

These settings configure the loss characteristics of additional equipment in the test setup, such as cables or attenuators at the DUT input or output. The characteristics of such equipment must be supplied by the manufacturer.

Note that loss is only considered during the measurement and not during calibration because the noise source is connected directly to the analyzer input.



Treatment of losses in resistor noise sources

For resistor noise sources, it is not possible to change the loss characteristics.

When you change back to using a diode as a noise source, the previous loss settings are **not** restored. In that case, store loss settings in a loss table for later use.


- [Defining loss](#).....63
- [Using a loss table](#).....66

5.5.1 Defining loss

Access: "Overview" > "Loss Input" / "Loss Output" > "Loss Settings"

The "Loss Settings" tab in the "Loss Settings" dialog box contains settings to define the loss characteristics of miscellaneous equipment in the test setup.

You can define the loss characteristics of the signal path to the DUT input and the signal path from the DUT output to the analyzer.



Furthermore, you can define the loss characteristics of the signal path from the noise source directly to the analyzer for the calibration measurement.

Input Loss	64
Output Loss	65
Calibration Loss	65

Input Loss

Defines losses between the noise source and the DUT input.

The input loss is the sum of all losses caused by the measurement equipment. The loss can be constant or based on a loss table.

If the loss is constant, the same loss is used for all frequencies in the frequency table. If you have selected a constant loss, you can also define its value in the input field next to the radio button.

If the loss is based on a table, the loss values are interpolated to the measurement frequencies. You can select a table from the dropdown menu next to the radio button, if it is active. For more information on loss tables, see [Chapter 5.5.2, "Using a loss table"](#), on page 66.

The specified temperature at the time of measurement can be considered in the loss calculation.

Remote command:

Loss mode:

[\[SENSe:\]CORRection:LOSS:INPut:MODE](#) on page 148

Constant loss:

[\[SENSe:\]CORRection:LOSS:INPut:SPOT](#) on page 148

Select loss table:

[\[SENSe:\]CORRection:LOSS:INPut:TABLE:SElect](#) on page 149

Temperature:

[\[SENSe:\]CORRection:LOSS:INPut:TEMPerature](#) on page 150

Output Loss

Selects the loss between the DUT output and the RF input of the analyzer.

The output loss is the sum of all losses caused by the measurement equipment (e.g. connectors, cables or attenuators). The loss can be constant or be based on a loss table.

If the loss is constant, the same loss is used for all frequencies in the frequency table. If you have selected a constant loss, you can also define its value in the input field next to the radio button.

If the loss is based on a table, the loss values are interpolated to the measurement frequencies. You can select a table from the dropdown menu next to the radio button, if it is active. For more information on loss tables, see [Chapter 5.5.2, "Using a loss table"](#), on page 66.

The current temperature at the time of measurement can be considered in the loss calculation.

Remote command:

Loss mode:

[\[SENSe:\]CORRection:LOSS:OUTPut:MODE](#) on page 150

Constant loss:

[\[SENSe:\]CORRection:LOSS:OUTPut:SPOT](#) on page 150

Select loss table:

[\[SENSe:\]CORRection:LOSS:OUTPut:TABLE:SElect](#) on page 151

Temperature:

[\[SENSe:\]CORRection:LOSS:OUTPut:TEMPerature](#) on page 151

Calibration Loss

Selects the loss between the noise source and the RF input of the analyzer for the calibration measurement.

The loss is the sum of all losses caused by the measurement equipment (e.g. connectors, cables or attenuators). The loss can be constant or be based on a loss table.

If the loss is constant, the same loss is used for all frequencies in the frequency table. If you have selected a constant loss, you can also define its value in the input field next to the radio button.

If the loss is based on a table, the loss values are interpolated to the measurement frequencies. You can select a table from the dropdown menu next to the radio button, if it is active. For more information on loss tables, see [Chapter 5.5.2, "Using a loss table"](#), on page 66.

The current temperature at the time of measurement can be considered in the loss calculation.

Remote command:

Loss mode:

[\[SENSe:\]CORRection:LOSS:CALibration:MODE](#) on page 146

Constant loss:

[\[SENSe:\]CORRection:LOSS:CALibration:SPOT](#) on page 146

Select loss table:

[\[SENSe:\]CORRection:LOSS:CALibration:TABLE:SElect](#) on page 147


Temperature:

[\[SENSe:\]CORRection:LOSS:CALibration:TEMPerature](#) on page 147

5.5.2 Using a loss table

Access: "Overview" > "Loss Input" / "Loss Output" > "Table Settings"

The "Table Settings" tab in the "Loss Settings" dialog box contains the functionality to create and edit loss tables.



Loss tables contain the loss characteristics of additional frequency-dependent equipment in the test setup. If you are using a loss table, the loss values can be different on

each frequency that is measured. If the table does not contain a loss for one of the measurement frequencies, the application interpolates between values.

The "Table Settings" tab contains a list of loss tables currently available on the R&S FSWP. It shows the table currently selected in the "Loss Settings" tab.

In addition, the tab contains functionality to create new tables and modify existing ones.

New	67
Edit	67
Delete	67
Copy To	67
Import / Export Table	68

New

Opens the [Edit Table](#) dialog box to create a new loss table.

The contents of the dialog box are empty.

Remote command:

Create input loss table:

[\[SENSe:\]CORRection:LOSS:INPut:TABLE\[:DATA\]](#) on page 148

Create output loss table:

[\[SENSe:\]CORRection:LOSS:OUTPut:TABLE\[:DATA\]](#) on page 150

Create calibration loss table:

[\[SENSe:\]CORRection:LOSS:CALibration:TABLE\[:DATA\]](#) on page 147

Edit

Opens the [Edit Table](#) dialog box to modify the selected table.

Remote command:

Edit input loss table:

[\[SENSe:\]CORRection:LOSS:INPut:TABLE\[:DATA\]](#) on page 148

Edit output loss table:

[\[SENSe:\]CORRection:LOSS:OUTPut:TABLE\[:DATA\]](#) on page 150

Edit calibration loss table:

[\[SENSe:\]CORRection:LOSS:CALibration:TABLE\[:DATA\]](#) on page 147

Delete

Deletes the selected table.

Remote command:

Delete input loss table:

[\[SENSe:\]CORRection:LOSS:INPut:TABLE:DELeTe](#) on page 149

Delete output loss table:

[\[SENSe:\]CORRection:LOSS:OUTPut:TABLE:DELeTe](#) on page 151

Delete calibration loss table:

[\[SENSe:\]CORRection:LOSS:CALibration:TABLE:DELeTe](#) on page 146

Copy To

Opens the [Edit Table](#) dialog box to modify the selected table and save it under a new name.

Import / Export Table

Opens a dialog box to select a loss table to import or export.

An import copies the loss table into the default loss table directory. The file extension can be *.loss or *.s2p. In case the file extension is *.s2p, the S21 vector is parsed out of the *.s2p file. The magnitude of this vector is written to a file with ending *.loss into the default loss directory. This file then can be used like conventional loss files.

An export copies the table to a location outside the default loss table directory, e.g. a memory stick. The file extension will be *.loss.

5.6 Configuring the analyzer

Access: "Overview" > "Spectrum Analyzer"

Or: [MEAS CONFIG] > "Meas Settings"

The measurement settings include parameters related to the second stage correction measurement.

Meas Settings

Measurement Settings

2nd Stage Correction On Off

RBW and Sweep Settings

RBW Variable Constant RBW 3.0 MHz

Sweep Time Variable Constant Sweep Time 30.0 ms

The RBW and Sweep Time 'Variable' selections are used to improve measurements at frequency < 10MHz

Settling Time 50.0 ms

Average 1

Level and Range Settings

Ref Level Auto Manual Ref Level -30.0 dBm

Auto Level Range 30.0 dB

RF Atten 0.0 dB

Preamplifier On Off

2nd Stage Correction.....	69
Resolution Bandwidth (RBW).....	69
Sweep Time.....	69
Settling Time.....	70
Average.....	70
Ref Level.....	70

Auto Level Range.....	71
RF Attenuation.....	71
Preamplifier.....	71

2nd Stage Correction

Turns 2nd stage correction on and off.

If enabled, the application uses the calibration data to compensate for the inherent noise of the analyzer when calculating the measurement results.

If disabled, the application does not correct the measurement results, even if a valid calibration has been performed. Note that correction data is not deleted if you turn off the 2nd stage correction.

For more information, see [Chapter 4.6, "Calibration \(2nd stage correction\)"](#), on page 37.

Remote command:

State: `[SENSe:]CORRection[:STATe]` on page 154

Calibration measurement selection: `[SENSe:]CONFigure:CORRection` on page 153

Resolution Bandwidth (RBW)

Defines the resolution bandwidth for the measurement.

For more information on the resolution bandwidth, see [Chapter 4.7, "Separating signals by selecting an appropriate resolution bandwidth"](#), on page 40.

"Constant"	Uses a constant RBW for the entire measurement span
"Variable"	Uses a variable RBW, depending on the current frequency of the sweep point, as defined in the frequency table (see Chapter 5.2.3, "Using a frequency table" , on page 51); In the channel bar, the bandwidth and sweep time range of the variable values is indicated.

Remote command:

`[SENSe:]BANDwidth:RESolution:AUTO` on page 153

`[SENSe:]BANDwidth[:RESolution]` on page 152

Sweep Time

Defines the sweep time for the measurement.

The sweep time is the time it takes the analyzer to perform a measurement at one measurement frequency.

Note that "noise figure" measurements perform two measurements during one sweep. One with the noise source turned on, one with the noise source turned off.

Frequency tables allow you to define a variable RBW and sweep time, depending on the current frequency of the sweep point (see ["Variable RBW and sweep time for low-frequency measurements"](#) on page 41 and [Chapter 5.2.3, "Using a frequency table"](#), on page 51).

"Constant"	Uses a constant sweep time for the entire measurement span
------------	--

"Variable" Uses a variable sweep time, depending on the current frequency of the sweep point, as defined in the frequency table (see [Chapter 5.2.3, "Using a frequency table"](#), on page 51); In the channel bar, the bandwidth and sweep time range of the variable values is indicated.

Remote command:

[\[SENSe:\] SWEEp:TIME:AUTO](#) on page 155

[\[SENSe:\] SWEEp:TIME](#) on page 155

Settling Time

Defines the settling time of the DUT and the noise source.

Most noise sources need a certain amount of time to settle after you turn them on. Low-frequency DUTs can require a certain time until their coupling capacitors have been charged or discharged. Both are defined as the settling time. For details on the settling time, refer to the datasheet of the noise source.

Remote command:

[SYSTem:CONFIgure:DUT:STIME](#) on page 158

Average

Defines the number of measurements that are used to average the results.

The more measurements you include in the averaging, the more accurate and stable the results are. However, accuracy and stability come at the price of measurement speed.

Remote command:

[\[SENSe:\] SWEEp:COUNT](#) on page 155

Ref Level

Turns automatic determination of the reference level on and off.

The reference level is the power level the R&S FSWP expects at the RF input. Keep in mind that the noise signal has a high crest factor. To avoid an instrument overload, set the reference level to the peak envelope power of the noise signal, not to the mean power.

Set the reference level to approximately 5 dB to 15 dB above the noise display that occurs with the DUT connected and the noise source activated.

To get the best dynamic range, set the reference level as low as possible. At the same time, make sure that the maximum signal level does not exceed the reference level. If it does, it can overload the RF and IF stages of the analyzer, regardless of the signal power. Measurement results can deteriorate.

Note that the signal level at the A/D converter can be stronger than the level the R&S FSWP displays because the resolution bandwidths are implemented digitally after the A/D converter.

If automatic detection of the reference level is on, the application performs a measurement to determine the ideal reference level. The time of this measurement depends on the state of the "2nd Stage Correction".

- "2nd Stage Correction" is enabled

The application determines the reference level before the calibration starts. The reference level is based on several test measurements on the start frequency. For more information, see ["Auto Level Range"](#) on page 71.

- "2nd Stage Correction" is disabled
The application determines the reference level before the measurement begins. The reference level is based on the measurement of the first frequency that is measured. After this measurement is done, the application resumes the measurement.

If manual selection of the reference level is on, you can define the reference level in the corresponding input field.

Note: Reference level. Even for DUTs with a high-ripple frequency response it can be useful to define the reference level manually. Determining the reference level automatically does not always result in optimal settings.

Remote command:

Manual reference level:

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel` on page 156

Automatic reference level:

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:AUTO` on page 156

Auto Level Range

Defines the maximum expected "gain" of the DUT.

The application uses the auto level range to determine the reference level automatically if the 2nd stage correction is on.

Make sure the range does not exceed the actual "gain" of the DUT by more than 10 dB.

Remote command:

`SYSTem:CONFIgure:DUT:GAIN` on page 158

RF Attenuation

Defines the RF attenuation of the analyzer.

The attenuation is applied to the signal at the RF input.

Attenuation affects the quality of the "noise figure" measurement results. For a low "noise figure" of the analyzer (and thus more accurate measurement results), keep the attenuation as low as possible. No attenuation is best. However, some high-power DUTs require attenuation to avoid an overload of the analyzer. An attenuation of 10 dB provides a better input VSWR of the analyzer, but results in a deteriorating "noise figure".

Remote command:

`INPut:ATTenuation` on page 156

Preamplifier

If the (optional) internal preamplifier hardware is installed on the R&S FSWP, a preamplifier can be activated for the RF input signal.

Turn on the preamplifier for a low inherent noise of the analyzer.

Note: If an optional external preamplifier is activated, the internal preamplifier is automatically disabled, and vice versa.

"Off" Deactivates the preamplifier.

"On" The RF input signal is amplified by about 30 dB.

Remote command:

`INPut:GAIN:STATe` on page 157

`INPut:GAIN[:VALue]` on page 157

5.7 Using the uncertainty calculator

Access: [MEAS CONFIG] > "Uncertainty Calculation"

"Noise figure" measurements are subject to uncertainty. The "noise figure" measurement is meaningless if the measurement uncertainty is too large. Knowing the uncertainty of the "noise figure" measurement adds value especially when comparing measurement results.

Note that the "noise figure" uncertainty is not calculated for frequencies above 67 GHz because input VSWR values are not specified.

Uncertainty Calculation				Analyzer	
Measurement Noise Source		DUT		Analyzer	
Output Match		Input Match		SA Input Match (Typical)	
Use SNS Values	On Off	VSWR RL 1.0	VSWR RL 1.0	VSWR RL 1.87	PA On
VSWR RL 1.15		Use Meas Values	On Off	SA NF Uncert 0.05 dB	
ENR Uncert 0.1 dB		DUT NF 0.0 dB		SA Gain Uncert 0.15 dB	
		DUT Gain 0.0 dB		SA NF 11.22 dB	
		Frequency (IF) 1.0 GHz		Ext PA On Off	
				PA NF 5.0 dB	
				PA Gain 20.0 dB	
				Net SA NF 11.22 dB	
Guidelines (repeatability)	ENR - SA NF	[> 3 dB]	3.78 dB	NF Uncert +/-	1.91 dB
	ENR - DUT NF	[> 5 dB]	15.0 dB	Meas Offset	
	DUT (NF+Gain) - SA NF	[> 1 dB]	-11.22 dB		



Uncertainty values and systematic error recognition

Note that the uncertainty calculation only takes systematic measurement inaccuracies into account.

The most significant inaccuracies are:

- Uncertainties of the noise source and the analyzer
- Input and output matching
- "Noise figure" and "gain" of the DUT
- "Noise figure" of the analyzer

The accuracy of the measurement can also be affected by insufficient repeatability during calibration or measurement.

The repeatability is mainly affected by:

- Signal-to-noise ratio during calibration and measurement
- Measurement time (if it is too short)
- Environmental conditions (e.g. a change in the temperature between measurements)
- Mechanical stability of the test setup

For more background information on "noise figure" measurement uncertainty, refer to the application note "The "Y-Factor" Technique for "Noise Figure" Measurement" available for download on the Rohde & Schwarz homepage (http://www.rohde-schwarz.com/en/applications/the-y-factor-technique-for-noise-figure-measurements-application-note_56280-15484.html).

In addition to the parameters described here, the application also considers several parameters from the general measurement configuration when calculating the uncertainty.

- [Measurement mode](#)
- [2nd Stage Correction](#)
If 2nd stage correction is on, but no calibration data is available, uncertainty is calculated without the 2nd stage correction data.
- [Internal preamplification](#)
- [RF Attenuation](#)
- [Temperature](#)
- [ENR values](#)

5.7.1 Configuring noise source characteristics

Access: [MEAS CONFIG] > "Uncertainty Calculation"

The Uncertainty Calculator supports individual characteristics for a noise source used during calibration and the measurement.

If you are using a Common ENR, the application assumes that the [Output Match](#) and [ENR Uncert\(ainty\)](#) are the same during calibration and measurement. Only the "Measurement Noise Source" parameters are displayed.

If you are using a different noise source during calibration and measurement, the Uncertainty Calculator adds an **Output Match** and **ENR Uncert(ainty)** required for uncertainty calculation during calibration.

Note that you have to turn off the **Common Noise Source** if you have to define the values of the noise source used during calibration.

Common Source for Meas and Cal	74
Output Match	74
ENR Uncert(ainty)	74
Temperature Uncert(ainty)	74

Common Source for Meas and Cal

Controls the way the application calculates the uncertainty for the noise source.

Turn on the switch when you use the same noise source during calibration and measurement. Only one set of fields to define the noise source characteristics is available. The application calculates the uncertainty according to the values you have entered in there.

Turn the switch off when you use different noise sources during calibration and measurement. The application shows an additional set of fields to define the noise source characteristics. The uncertainty calculation also includes these values.

The switch is available if you have turned on **Common Noise Source**.

Remote command:

`CALCulate<n>:UNCertainty:COMMon` on page 168

Output Match

Defines the output match of the noise source you are using.

You can define the output match either as the VSWR or as the return loss (RL).

Refer to the datasheet of the noise source for these values.

Remote command:

`CALCulate<n>:UNCertainty:MATCH:SOURce:CALibration:RL` on page 174

`CALCulate<n>:UNCertainty:MATCH:SOURce:RL` on page 174

`CALCulate<n>:UNCertainty:MATCH:SOURce:CALibration[:VSWR]`
on page 174

`CALCulate<n>:UNCertainty:MATCH:SOURce:CALibration:RL` on page 174

ENR Uncert(ainty)

Defines the uncertainty of the excess noise ratio of the noise source you are using.

Refer to the datasheet of the noise source for this value.

Available for noise sources with diode characteristics.

Remote command:

`CALCulate<n>:UNCertainty:ENR:UNCertainty` on page 171

`CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty` on page 170

Temperature Uncert(ainty)

Defines the uncertainty of the hot and cold temperatures of the noise source you are using.

Refer to the datasheet of the noise source for these values.

Available for resistor noise sources.

Remote command:

`CALCulate<n>:UNCertainty:ENR:UNCertainty:COLD` on page 171

`CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty:HOT`

on page 170

`CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty:COLD`

on page 170

`CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty:HOT`

on page 170

5.7.2 Configuring DUT characteristics

Access: [MEAS CONFIG] > "Uncertainty Calculation"

Input / Output Match	75
Use Measurement Values	75

Input / Output Match

Defines the match at the DUT input and output.

You can define the match either as the VSWR or as the return loss (RL). If you define the VSWR or the return loss, the application automatically calculates the other.

If these values are not defined in the DUT datasheet, determine these values, for example, with a network analyzer.

Note: For the system down converter modes, please add the matches for the system mixer to the output match.

Remote command:

`CALCulate<n>:UNCertainty:MATCH:DUT:IN[:VSWR]` on page 172

`CALCulate<n>:UNCertainty:MATCH:DUT:IN:RL` on page 172

`CALCulate<n>:UNCertainty:MATCH:DUT:OUT[:VSWR]` on page 173

`CALCulate<n>:UNCertainty:MATCH:DUT:OUT:RL` on page 173

Use Measurement Values

Turns automatic determination of the DUT characteristics used for the uncertainty calculation on and off.

If on, the application calculates the uncertainty with the DUT characteristics ("noise figure", "gain" and frequency) resulting from the "noise figure" measurement. For this method, the application calculates the uncertainty for each measurement point (or frequency) based on the "noise figure" and "gain" results of the last measurement.

If you have selected automatic determination of the DUT characteristics, the application does not show a result in the "NF Uncertainty +/-" field in the dialog box. Instead, to view the uncertainty at all measurement points, use the "Result Table".

If off, define the "gain", "noise figure" and frequency of the DUT manually for a single frequency. With this manual determination of the DUT characteristics, the application only calculates the uncertainty for that frequency and shows the result in the "NF Uncertainty +/-" field in the dialog box.

- "Noise Figure" of the DUT
- "Gain" of the DUT
- Frequency of the DUT

Remote command:

Control automatic DUT characteristics determination:

`CALCulate<n>:UNCertainty[:RESult]?` on page 176

Manual definition of DUT characteristics:

`CALCulate<n>:UNCertainty:DATA:NOISe` on page 169

`CALCulate<n>:UNCertainty:DATA:GAIN` on page 169

`CALCulate<n>:UNCertainty:DATA:FREQuency` on page 168

5.7.3 Configuring analyzer characteristics

Access: [MEAS CONFIG] > "Uncertainty Calculation"

For the analyzer characteristics, the application always uses the data specified in the datasheet of the R&S FSWP model you are using. Thus, it is not possible to change or adjust the analyzer characteristics in any way. The uncertainty calculation takes several analyzer characteristics into account, of which the following are shown as read-only fields in the user interface.

- "SA Input Match:" Input match (VSWR or return loss) of the analyzer
- "SA NF Uncert:" Noise figure uncertainty of the analyzer
- "SA Gain Uncert:" Gain uncertainty of the analyzer
- "SA NF:" Noise figure of the analyzer

However, if you are using an external preamplifier in the test setup, you have to specify its characteristics to get a valid uncertainty result.

Remote commands:

`CALCulate<n>:UNCertainty:SANalyzer:GAIN:UNCertainty?` on page 176

`CALCulate<n>:UNCertainty:SANalyzer:NOISe:UNCertainty?` on page 177

External Preamplifier (Ext PA).....	76
L Preamplifier noise figure (PA NF).....	76
L Preamplifier Gain (PA Gain).....	77
L Net spectrum analyzer noise figure (Net SA NF).....	77

External Preamplifier (Ext PA)

If enabled, the application automatically calculates and updates the analyzer characteristics based on the characteristics of the external preamplifier defined here.

Refer to the datasheet of the preamplifier you are using for the values you have to enter.

Remote command:

`CALCulate<n>:UNCertainty:PREamp:STATe` on page 176

Preamplifier noise figure (PA NF) ← External Preamplifier (Ext PA)

Defines the "noise figure" of the preamplifier.

Remote command:

`CALCulate<n>:UNCertainty:PREamp:NOISe` on page 175

Preamplifier Gain (PA Gain) ← External Preamplifier (Ext PA)

Defines the "gain" of the preamplifier.

Remote command:

`CALCulate<n>:UNCertainty:PREamp:GAIN` on page 175

Net spectrum analyzer noise figure (Net SA NF) ← External Preamplifier (Ext PA)

Shows the "noise figure" of the analyzer.

If you are using an external preamplifier, the application calculates the "noise figure" of the analyzer including the "noise figure" of the preamplifier and shows the result here.

If you do not use an external preamplifier, this value is the same as the "noise figure" of the analyzer shown in the "SA NF" field.

5.7.4 Guidelines and results

Access: [MEAS CONFIG] > "Uncertainty Calculation"

The lower part of the dialog box contains measurement guidelines that provide information on the quality of measurement and the actual "noise figure" uncertainty.




Guidelines

The guidelines are an indicator of the quality of the measurement and an indicator the repeatability of the measurement.

The three guidelines are:

- Make sure that the "noise figure" of the DUT and the "gain" of the DUT is greater than the "noise figure" of the analyzer plus 1 dB.
- Make sure that the ENR of the noise source is greater than the "noise figure" of the DUT plus 5 dB.
- Make sure that the ENR of the noise source is greater than the "noise figure" of the analyzer plus 3 dB.

A short form of these guidelines is indicated in the "Uncertainty Calculation" dialog box. The dialog box also indicates if the guidelines have been met or not by a colored dot.

- Green light : guideline condition met.
- Yellow light : guideline condition not met, but within 1 dB of being met.
- Red light : guideline condition not met.

Note that the guidelines have no effect on the actual uncertainty that has been calculated and that they are only considered for measurements with 2nd Stage Correction.

Uncertainty

The "Uncertainty" result is shown only if you define the "noise figure" and "gain" characteristics of the DUT manually on a single frequency. In that case, the uncertainty

shown in the "Uncertainty Calculation" dialog box is valid only for the DUT frequency you have defined.

The "Measurement Offset" evaluates the internal noise of the R&S FSWP that is added to the "noise figure" results. The measurement offset result is displayed when 2nd stage correction is turned off. When you turn on 2nd stage correction, the internal noise is automatically removed from the uncertainty results, so the measurement offset is not shown.

If you are using the "noise figure" and "gain" that has been determined during a measurement, the uncertainty is displayed only in the result table.

For more information, see ["Use Measurement Values"](#) on page 75.

SCPI command:

`CALCulate<n>:UNCertainty[:RESult]?` on page 176

5.8 Trigger and gate configuration

Triggering means to capture the interesting part of the signal. Choosing the right trigger type and configuring all trigger settings correctly allows you to detect various incidents in your signals.

Gating allows you to restrict measurement analysis to the important part or parts of the signal, for example bursts.



Trigger only available with gating

In the noise measurement application, triggering is only available if gating is active. If gating is disabled, the trigger source is automatically set to "Free Run".



Noise source for trigger preview

As long as the trigger and gate preview is displayed, a "Noise Source State" function is available in the "Trigger" menu. This function turns on the noise source temporarily so that you can see the effects of the trigger and gate settings with the noise source on. See ["Noise Source State"](#) on page 82.


- [Trigger settings](#)..... 78
- [Gate settings](#)..... 82
- [Continuous gate settings](#)..... 83

5.8.1 Trigger settings

Access: "Overview" > "Trigger/Gate"



External triggers from one of the trigger connectors on the R&S FSWP are configured in a separate tab of the dialog box.



Preview.....	79
L Frequency.....	80
L RBW.....	80
L Sweep Time.....	80
Trigger Source.....	80
L Free Run.....	80
L Ext. Trigger 1/2.....	80
Trigger Level.....	81
Drop-Out Time.....	81
Trigger Offset.....	81
Hysteresis.....	81
Trigger Holdoff.....	81
Slope.....	82
Noise Source State.....	82

Preview

The preview mode allows you to try out trigger and gate settings before actually applying them to the current measurement.

The preview diagram displays a zero span measurement at the center frequency with the defined RBW and sweep time. This is useful when analyzing bursts, for example, to determine the required gate settings.

The trigger and gate settings are applied to the measurement when the dialog box is closed.

Note: The zero span settings refer only to the preview diagram. The main diagram remains unchanged.

If preview mode is switched off, any changes to the settings in this dialog box are applied to the measurement diagram directly. In this case, the zero span settings for the preview diagram are not displayed.

Frequency ← Preview

Defines the center frequency for the preview diagram.

Remote command:

[\[SENSe:\]FREQuency:CENTer](#) on page 132

RBW ← Preview

Defines the resolution bandwidth for the preview diagram. The available resolution bandwidths are specified in the specifications document. Numeric input is always rounded to the nearest possible bandwidth.

Remote command:

[\[SENSe:\]BANDwidth\[:RESolution\]](#) on page 152

Sweep Time ← Preview

Defines the sweep time for the preview diagram. Allowed values depend on the ratio of span to RBW and RBW to VBW. For details refer to the specifications document. Numeric input is always rounded to the nearest possible sweep time.

Trigger Source

Selects the trigger source. If a trigger source other than "Free Run" is set, "TRG" is displayed in the channel bar and the trigger source is indicated.

Remote command:

[TRIGger\[:SEQuence\]:SOURce](#) on page 161

Free Run ← Trigger Source

No trigger source is considered. Data acquisition is started manually or automatically and continues until stopped explicitly.

Remote command:

[TRIG:SOUR IMM](#), see [TRIGger\[:SEQuence\]:SOURce](#) on page 161

Ext. Trigger 1/2 ← Trigger Source

Data acquisition starts when the TTL signal fed into the specified input connector meets or exceeds the specified trigger level.

Note: "External Trigger 1" automatically selects the trigger signal from the "Trigger Input / Output" connector on the front panel.

For details, see the "Instrument Tour" chapter in the R&S FSWP Getting Started manual.

"External Trigger 1"

Trigger signal from the "Trigger Input / Output" connector.
(front panel)

"External Trigger 2"

Trigger signal from the "Sync Trigger Input / Output" connector.
(rear panel)

Note: Connector must be configured for "Input" in the "Output" configuration

(See the R&S FSWP base unit user manual).

Remote command:

TRIG:SOUR EXT, TRIG:SOUR EXT2

See [TRIGger\[:SEquence\]:SOURce](#) on page 161

Trigger Level

Defines the trigger level for the specified trigger source.

For details on supported trigger levels, see the instrument specifications document.

Remote command:

[TRIGger\[:SEquence\]:LEVel\[:EXternal<port>\]](#) on page 160

Drop-Out Time

Defines the time that the input signal must stay below the trigger level before triggering again.

Remote command:

[TRIGger\[:SEquence\]:DTIME](#) on page 159

Trigger Offset

Defines the time offset between the trigger event and the start of the measurement.

Offset > 0:	Start of the measurement is delayed
Offset < 0:	Measurement starts earlier (pretrigger)

Remote command:

[TRIGger\[:SEquence\]:HOLDoff\[:TIME\]](#) on page 159

Hysteresis

Defines the distance in dB to the trigger level that the trigger source must exceed before a trigger event occurs. Setting a hysteresis avoids unwanted trigger events caused by noise oscillation around the trigger level.

This setting is only available for "IF Power" trigger sources. The range of the value is between 3 dB and 50 dB with a step width of 1 dB.

Remote command:

[TRIGger\[:SEquence\]:IFPower:HYSteresis](#) on page 160

Trigger Holdoff

Defines the minimum time (in seconds) that must pass between two trigger events. Trigger events that occur during the holdoff time are ignored.

Remote command:

`TRIGger [:SEquence] :IFPower:HOLDoff` on page 160

Slope

For all trigger sources except time, you can define whether triggering occurs when the signal rises to the trigger level or falls down to it.

Remote command:

`TRIGger [:SEquence] :SLOPe` on page 161

Noise Source State

Access: [TRIG]

Temporarily turns on the noise source so that you can see the effects of the trigger and gate settings with the noise source on.

This function is only available as long as the trigger and gate preview is displayed.

5.8.2 Gate settings

Access: "Overview" > "Trigger" > "Trigger / Gate Config." > "Gate Settings"

Gate settings define one or more extracts of the signal to be measured.

Gate Settings	Cont. Gate
Gated Trigger	<input checked="" type="radio"/> On <input type="radio"/> Off
Gate Mode	<input type="radio"/> Level <input checked="" type="radio"/> Edge
Gate Delay	0.0 s
Gate Length	400.0 μ s



Gating is not available for measurements on I/Q-based data.

Gated Trigger.....	82
Gate Mode.....	83
Gate Delay.....	83
Gate Length.....	83

Gated Trigger

Switches gated triggering on or off.

If the gate is switched on, a gate signal applied to one of the TRIGGER INPUT connectors or the internal IF power trigger controls the measurement.

Remote command:

[\[SENSe:\] SWEEp:EGATe](#) on page 162

Gate Mode

Sets the gate mode.

"Edge"	The trigger event for the gate to open is the detection of the signal edge. After the gate signal has been detected, the gate remains open until the gate length is over.
"Level"	The trigger event for the gate to open is a particular power level. After the gate signal has been detected, the gate remains open until the signal disappears.

Remote command:

[\[SENSe:\] SWEEp:EGATe:TYPE](#) on page 165

Gate Delay

Defines the delay time between the gate signal and the continuation of the measurement.

In the Spectrum application, the delay position on the time axis in relation to the measurement is indicated by a line labeled "GD".

Remote command:

[\[SENSe:\] SWEEp:EGATe:HOLDoff](#) on page 164

Gate Length

Defines how long the gate is open when it is triggered.

The gate length can only be set in the edge-triggered gate mode. In the level-triggered mode the gate length depends on the level of the gate signal.

The gate length in relation to the sweep is indicated by a line labeled "GL".

In the Spectrum application, the gate length in relation to the measurement is indicated by a line labeled "GL".

Remote command:

[\[SENSe:\] SWEEp:EGATe:LENGth](#) on page 164

5.8.3 Continuous gate settings

Access: "Overview" > "Trigger" > "Trigger / Gate Config." > "Cont. Gate" tab

Continuous gating allows you to perform a continuous gated sweep after a single external trigger is received.

Gate Settings	Cont. Gate
Continuous Gate	<input checked="" type="radio"/> On <input type="radio"/> Off
Gate Period Length	5.0 ms
Gate Period Count	100

Continuous Gate.....	84
Gate Period Length.....	84
Gate Period Count.....	84

Continuous Gate

Activates or deactivates continuous gating.

This setting is only available if **Gated Trigger** is "On".

Remote command:

[\[SENSe:\]SWEep:EGATe:CONTInuous\[:STATe\]](#) on page 163

Gate Period Length

Defines the length in seconds of a single gate period in continuous gating. The length is determined from the beginning of one gate measurement to the beginning of the next one.

Remote command:

[\[SENSe:\]SWEep:EGATe:CONTInuous:PLENgtH](#) on page 163

Gate Period Count

Defines the number of gate periods to be measured after a single trigger event in continuous gating.

Remote command:

[\[SENSe:\]SWEep:EGATe:CONTInuous:PCOunt](#) on page 163

5.9 Performing measurements

Access: [SWEEP]

Access (calibration): "Overview" > "Calibrate"

This chapter contains all functionality necessary to control and perform "noise figure" measurements.

Continuous Sweep / Run Cont.....	85
Single Sweep / Run Single.....	85
Calibrate.....	85
Sweep Time.....	86
Meas Mode (Auto Manual).....	86

Continuous Sweep / Run Cont

Initiates a measurement and repeats it continuously until stopped. If necessary, the application automatically determines the reference level before starting the actual measurement.

While the measurement is running, "Continuous Sweep" and [RUN CONT] are highlighted. The running measurement can be aborted by selecting the highlighted softkey or key again. The results are not deleted until a new measurement is started.

Note: Sequencer. Furthermore, [RUN CONT] controls the Sequencer, not individual sweeps. [RUN CONT] starts the Sequencer in continuous mode.

For details on the Sequencer, see the R&S FSWP base unit user manual.

Remote command:

`INITiate<n>:CONTInuous` on page 178

Single Sweep / Run Single

Initiates a single measurement. The measurement is finished after all frequencies in the frequency list have been measured. If necessary, the application automatically determines the reference level before starting the actual measurement.

After triggering, initiates a single measurement. The measurement is finished after all frequencies in the frequency list have been measured. If necessary, the application automatically determines the reference level before starting the actual measurement.

While the measurement is running, "Single Sweep" and [RUN SINGLE] are highlighted. The running measurement can be aborted by selecting the highlighted softkey or key again.

Note: Sequencer. Furthermore, [RUN SINGLE] controls the Sequencer, not individual sweeps. [RUN SINGLE] starts the Sequencer in single mode.

If the Sequencer is off, only the evaluation for the currently displayed channel is updated.

For details on the Sequencer, see the R&S FSWP base unit user manual.

Remote command:

`INITiate<n>[:IMMEDIATE]` on page 179

Calibrate

Initiates a calibration measurement.

For interpolation purposes, R&S FSWP-K30 will internally add additional measurement points at the band switching frequencies. This may increase the time needed to complete the calibration.

For more information see [Chapter 4.6, "Calibration \(2nd stage correction\)"](#), on page 37.

Remote command:

`INITiate<n>[:IMMediate]` on page 179

when `[SENSe:]CONFigure:CORRection` is on.

Sweep Time

Defines the sweep time.

For more information see "Sweep Time" on page 69.

Meas Mode (Auto Manual)

Selects the measurement mode for the hot and cold power measurements.

For more information about the measurement modes see Chapter 4.2, "Measurement modes", on page 30.

In manual measurement mode, the application opens a dialog box when you start a measurement. For more information about its contents see "Performing a manual measurement" on page 30.

Remote command:

`[SENSe:]CONFigure:CONTRol` on page 180

`[SENSe:]CONFigure:MEASurement` on page 181

5.10 Configuring inputs and outputs of the R&S FSWP



Further input sources

The noise measurement application application can also process input from the following optional sources:

- External mixer
- External generator
- Active modular probes

For details, see the R&S FSWP I/Q Analyzer and I/Q Input User Manual.

• Radio frequency (RF) input	86
• External generator	88
• DC power output configuration	92
• Signal source output configuration	92

5.10.1 Radio frequency (RF) input

Access: `[INPUT/OUTPUT] > "Input Source Config" > "Input Source" > "Radio Frequency"`

The RF input is the default input of the R&S FSWP.

Input Coupling.....	87
Impedance.....	87
High Pass Filter 1 to 3 GHz.....	87
YIG-Preselector.....	87

Input Coupling

The RF input of the R&S FSWP can be coupled by alternating current (AC) or direct current (DC).

AC coupling blocks any DC voltage from the input signal. AC coupling is activated by default to prevent damage to the instrument. Very low frequencies in the input signal can be distorted.

However, some specifications require DC coupling. In this case, you must protect the instrument from damaging DC input voltages manually. For details, refer to the specifications document.

Remote command:

`INPut:COUPling` on page 182

Impedance

For some measurements, the reference impedance for the measured levels of the R&S FSWP can be set to 50 Ω or 75 Ω .

Select 75 Ω if the 50 Ω input impedance is transformed to a higher impedance using a 75 Ω adapter of the RAZ type. (That corresponds to 25 Ω in series to the input impedance of the instrument.) The correction value in this case is 1.76 dB = 10 log (75 Ω /50 Ω).

This value also affects the unit conversion.

Remote command:

`INPut:IMPedance` on page 182

High Pass Filter 1 to 3 GHz

Activates an additional internal highpass filter for RF input signals from 1 GHz to 3 GHz. This filter is used to remove the harmonics of the analyzer to measure the harmonics for a DUT, for example.

This function requires an additional hardware option.

Note: For RF input signals outside the specified range, the high-pass filter has no effect. For signals with a frequency of approximately 4 GHz upwards, the harmonics are suppressed sufficiently by the YIG-preselector, if available.)

Remote command:

`INPut:FILTer:HPASs[:STATe]` on page 183

YIG-Preselector

Enables or disables the YIG-preselector.

This setting requires an additional option on the R&S FSWP.

An internal YIG-preselector at the input of the R&S FSWP ensures that image frequencies are rejected. However, image rejection is only possible for a restricted bandwidth. To use the maximum bandwidth for signal analysis you can disable the YIG-preselector at the input of the R&S FSWP, which can lead to image-frequency display.

Note: Note that the YIG-preselector is active only on frequencies greater than 8 GHz. Therefore, switching the YIG-preselector on or off has no effect if the frequency is below that value.

Remote command:

`INPut:FILTer:YIG[:STATe]` on page 183


5.10.2 External generator

Access: [INPUT/OUTPUT] > "Input Source Config" > "External Generator"

- [Interface configuration settings](#)..... 88
- [Measurement configuration](#).....89

5.10.2.1 Interface configuration settings

Access: "Overview" > "Local Oscillator" > "External Generator" > "Measurement Configuration"



- [Generator Type](#)..... 88
- [Interface](#)..... 89
- [TTL Handshake](#).....89
- [GPIB Address/TCPIP Address / Computer Name](#)..... 89
- [Reference](#).....89
- [Edit Generator Setup File](#).....89
- [Frequency Min/ Frequency Max](#).....89
- [Level Min/ Level Max](#)..... 89

Generator Type

Selects the generator type and thus defines the generator setup file to use.

Remote command:

[SYSTem:COMMunicate:RDEvice:GENerator<gen>:TYPE](#) on page 196

Interface

Type of interface connection used.

For details on which signal generators support which interfaces, see the documentation of the corresponding signal generator.

- GPIB
- TCP/IP

Remote command:

[SYSTem:COMMunicate:RDEvice:GENerator<gen>:INTerface](#) on page 196

TTL Handshake

Turning the TTL handshake on and off has no effect for "Noise Figure" measurements.

GPIB Address/TCP/IP Address / Computer Name

For LAN connections: TCP/IP address of the signal generator

For GPIB connections: GPIB address of the signal generator.

Remote command:

[SYSTem:COMMunicate:GPIB:RDEvice:GENerator<gen>:ADDRess](#) on page 196

[SYSTem:COMMunicate:TCPIP:RDEvice:GENerator<gen>:ADDRess](#)
on page 197

Reference

Selects the internal R&S FSWP or an external frequency reference to synchronize the R&S FSWP with the generator (default: internal).

Remote command:

[SOURce<si>:EXTernal<gen>:ROSCillator\[:SOURce\]](#) on page 195

Edit Generator Setup File

Displays the setup file for the currently selected [Generator Type](#) in read-only mode in an editor.

Although the existing setup files are displayed in read-only mode in the editor, they can be saved under a different name (using "File > SaveAs").

For more information, see [Chapter 4.4, "External generator control"](#), on page 33.

Frequency Min/ Frequency Max


For reference only: Lower and upper frequency limit for the generator.

Level Min/ Level Max

For reference only: Lower and upper power limit for the generator.

5.10.2.2 Measurement configuration

Access: "Overview" > "Local Oscillator" > "External Generator" > "Measurement Configuration"



Automatic Control.....90
 Init Before Meas.....90
 Auto Switch Off.....91
 Source Power.....91
 Frequency Coupling.....91
 Init External Generator.....92

Automatic Control

Turns automatic control of the external generator on and off.

If on, the application controls the configuration of the external generator during measurements by transmitting the required remote commands. The connection is established automatically before a measurement if **Init Before Meas** is on. To establish the connection manually at any time, use the **Init External Generator** function.

Otherwise, you have to control the generator manually. The application assumes that the generator is configured correctly for the measurement. The remote connection to the generator is automatically terminated.

Turn on automatic control to perform Fixed IF measurements with the LO frequency tuned to the current measurement (RF) frequency. Manual control is recommended only for measurements whose generator settings remain the same during the measurement.

Remote command:

[SYSTem:CONFigure:GENerator:CONTRol:STATe](#) on page 197

Init Before Meas

Turns automatic transmission of the external generator configuration on and off.

If enabled, the application transmits a sequence of remote commands that configures the generator and turns on its RF output before each measurement. Thus, the generator runs with the required configuration and can still receive remote control commands during a measurement. Automatic initialization requires a slightly longer measurement time because of the time required to transmit the commands and configure the generator.

If disabled, you have to initialize the generator manually with [Init External Generator](#).

Note that you have to establish the connection before you can perform a measurement with the external generator.

Remote command:

[SYSTem:CONFIgure:GENerator:INITialise:AUTO](#) on page 197

Auto Switch Off

Turns automatic deactivation of the generator's RF output on and off.

If enabled, the application transmits a sequence of remote commands to turn off the RF output of the generator when a measurement is over. A measurement is over after a single sweep or if the measurement is aborted. The sequence of commands also ends the remote control session.

If disabled, you have to turn off the RF output and remote control session manually.

Note that when you close the noise measurement application, the generator's RF output is turned off and the remote session is terminated.

Remote command:

[SYSTem:CONFIgure:GENerator:SWITCh:AUTO](#) on page 198

Source Power

Defines the output power of the external generator.

The range depends on the generator you are using and is defined in its specifications document.

Remote command:

[SOURce<si>:EXTernal<gen>:POWER\[:LEVel\]](#) on page 195

Frequency Coupling

Defines frequency correction characteristics.

The generator frequency is calculated as follows.

$$f_{\text{Generator}} = \left[(f_{\text{LO}} + \text{Offset} < 1 >) * \frac{\text{Numerator}}{\text{Denominator}} \right] + \text{Offset} < 2 >$$

With:

- $f_{\text{Generator}}$ = generator frequency
- f_{LO} = frequency of the analyzer's LO
- $f_{\text{offset}<1>}$ = offset frequency of the analyzer
- $f_{\text{offset}<2>}$ = offset frequency of other components

Use the factors and offsets to compensate one or more components in the test setup which change the frequency between the generator and the DUT. Make sure, however, that the result does not exceed the frequency range of the generator.

The application calculates the resulting start and stop frequency based on the values you apply and displays them below the equation.

Remote command:

`SOURce:EXTernal:FREQuency[:FACTor]:DENominator` on page 195

`SOURce:EXTernal:FREQuency[:FACTor]:NUMerator` on page 195

`SOURce:EXTernal:FREQuency:OFFSet<of>` on page 195

Init External Generator

Establishes a connection to generator and turns on its RF output.

You can establish the connection automatically before a measurement if [Init Before Meas](#) is on.

Note that you have to establish the connection before you can perform a measurement with the external generator.

Remote command:

`SYSTem:CONFigure:GENerator:INITialise[:IMMediate]` on page 198

5.10.3 DC power output configuration

The configuration of the DC Power supply is the same as in the Phase Noise application.

For a comprehensive description, please refer to the R&S FSWP user manual.

5.10.4 Signal source output configuration

The configuration of the optional signal source is the same as in the Phase Noise application.

For a comprehensive description, please refer to the R&S FSWP user manual.

6 Analysis

This chapter contains all settings and parameters that the application provides to analyze and evaluate measurement results.

- [Configuring the display](#).....93
- [Working with traces](#).....96
- [Trace / data export configuration](#)..... 98
- [Using markers](#)..... 101
- [Limit line settings and functions](#)..... 106

6.1 Configuring the display

Access: [MEAS CONFIG] > "Result Config"

Display configuration settings configure the way the results are displayed in the diagram.

The contents depend on whether you want to configure a graphical result display or a numerical result display.

Specifics for


The settings you make apply to the results you have selected in the "Specifics for" dropdown menu. If more than one window is active, "Specifics for" also puts the focus on the corresponding window.

- [Configuring graphical results](#).....93
- [Configuring numerical results](#).....95

6.1.1 Configuring graphical results

Access: [MEAS CONFIG] > "Result Config" > "Graph"

When configuring graphical results, the dialog box contains functionality to scale and set up the diagram axes.



Y-Axis.....	94
Auto Scale / Min / Max.....	94
Symbols.....	95
Uncertainty.....	95
X-Axis.....	95

Y-Axis

Selects the result display and thus the scaling of the vertical axis.

For more information, see [Chapter 3, "Measurements and result displays"](#), on page 17.

Auto Scale / Min / Max

Turns automatic scaling of the vertical axis on and off.

If on, the application optimizes the scaling of the vertical axis after each measurement for ideal viewing of the results.

If off, you can define the scaling manually. The "Min" and "Max" input fields become available. These two input fields define the values at the top and bottom of the vertical axis.

Remote command:

Automatic scaling:

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALE]:AUTO` on page 200

Manual minimum value:

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALE]:BOTTom` on page 200

Manual maximum value

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALE]:TOP` on page 201

Symbols


Turns symbols that represent a measurement point on the trace on and off.

Remote command:

`DISPlay[:WINDow<n>]:TRACe<t>:SYMBOLs` on page 199

Uncertainty

Displays an additional trace indicating the measured trace values \pm the uncertainty values determined by the uncertainty calculator. Thus, you obtain a range of minimum and maximum result values. This trace is only useful for "noise figure" measurements.



Remote command:

`DISPlay[:WINDow<n>]:TRACe<t>:UNCertainty` on page 199

X-Axis

Selects the frequency data that is displayed on the x-axis.

For measurements on frequency converting DUTs with a variable intermediate frequency, you can display either the RF frequency or the IF frequency.

Note that a change of the x-axis scale applies to all result displays, and also determines which value is output for trace export.

The "Frequency Axis" scale is also available via [FREQ].

Remote command:


`DISPlay[:WINDow<n>]:TRACe<t>:X[:SCALE]` on page 199

6.1.2 Configuring numerical results

When configuring numerical results, the dialog box selects the type of results you want to display in the result table. The results in the table are based on a particular trace that you can select in the corresponding input field.

You can add an aspect of the measurement by placing a checkmark in front of the corresponding result on and remove it by removing the checkmark.

For more information on each result, see [Chapter 3, "Measurements and result displays"](#), on page 17.



Remote command:

`DISPlay[:WINDOW<n>]:TABLE:ITEM` on page 198


6.2 Working with traces

Access (trace configuration): [TRACE] > "Trace Config" > "Traces"

Access (trace export): [TRACE] > "Trace Config" > "Trace / Data Export"

Access (copy trace): [TRACE] > "Trace Config" > "Trace Copy"

A trace is the graphical representation of a set of measurement results in a diagram. Each measurement window that contains graphical results supports up to four individual traces. Each trace has a different color. Trace settings determine how the measured data is analyzed and displayed on the screen. The trace information, including a color map and trace mode is summarized in the diagram header.



Traces..... 97
 Smoothing..... 97
 Preset Traces..... 98
 Copy Trace..... 98

Traces

The "Trace 1 to 4" softkeys open the "Traces" tab of the "Trace Configuration" dialog box.

The "Traces" tab contains functionality to configure a trace.

"Trace Selection" The "Trace 1" to "Trace 4" buttons select a trace. If a trace is selected, it is highlighted orange. Note that you cannot select a trace if its trace mode is "Blank".

"Trace Mode" Selects the trace mode for the corresponding trace. For more information, see Chapter 4, "Measurement basics", on page 28.

Remote command:

Trace mode:

DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:MODE on page 202

Smoothing

If enabled, the trace is smoothed by the specified value (between 1 % and 50 %). The smoothing value is defined as a percentage of the display width. The larger the smoothing value, the greater the smoothing effect.

Remote command:

`DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:SMOothing[:STATe]`
on page 203

`DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:SMOothing:APERture`
on page 203

Preset Traces

Restores the default configuration for all traces in a window.

Copy Trace

Access: "Overview" > "Analysis" > "Traces" > "Copy Trace"

Or: [TRACE] > "Copy Trace"

Copies trace data to another trace.

The first group of buttons (labeled "Trace 1" to "Trace 4") selects the source trace. The second group of buttons (labeled "Copy to Trace 1" to "Copy to Trace 4") selects the destination.

Remote command:

`TRACe<n>:COPY` on page 206


6.3 Trace / data export configuration

Or: [TRACE] > "Trace Config" > "Trace / Data Export"



The standard data management functions (e.g. saving or loading instrument settings) that are available for all R&S FSWP applications are not described here.

See the R&S FSWP base unit user manual for a description of the standard functions.



Export all Traces and all Table Results.....	99
Include Instrument & Measurement Settings.....	99
Trace to Export.....	99
Decimal Separator.....	99
Export Trace to ASCII File.....	99
L File Type.....	100
L Decimal Separator.....	101
L File Explorer.....	101
Export Trace to ASCII File.....	101

Export all Traces and all Table Results

Selects all displayed traces and result tables (e.g. "Result Summary", marker table etc.) in the current application for export to an ASCII file.

Alternatively, you can select one specific trace only for export (see [Trace to Export](#)).

The results are output in the same order as they are displayed on the screen: window by window, trace by trace, and table row by table row.

Remote command:

`FORMat:DEXPort:TRACes` on page 205

Include Instrument & Measurement Settings

Includes additional instrument and measurement settings in the header of the export file for result data.

Remote command:

`FORMat:DEXPort:HEADer` on page 205

Trace to Export

Defines an individual trace to be exported to a file.

This setting is not available if [Export all Traces and all Table Results](#) is selected.

Decimal Separator

Defines the decimal separator for floating-point numerals for the data export/import files. Evaluation programs require different separators in different languages.


Remote command:

`FORMat:DEXPort:DSEParator` on page 204

Export Trace to ASCII File

Saves the selected trace or all traces in the currently active result display to the specified file and directory in the selected ASCII format.

"File Explorer": Instead of using the file manager of the R&S FSWP firmware, you can also use the Microsoft Windows File Explorer to manage files.



Note: Secure user mode.

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see "Protecting Data Using the Secure User Mode" in the "Data Management" section of the R&S FSWP base unit user manual.

Remote command:

[MMEMory:STORe<n>:TRACe](#) on page 205

File Type ← Export Trace to ASCII File

Determines the format of the ASCII file to be imported or exported.

Depending on the external program in which the data file was created or is evaluated, a comma-separated list (CSV) or a plain data format (DAT) file is required.

Remote command:

[FORMat:DEXPort:FORMat](#) on page 205

Decimal Separator ← Export Trace to ASCII File

Defines the decimal separator for floating-point numerals for the data export/import files. Evaluation programs require different separators in different languages.

Remote command:

[FORMat:DEXPort:DSEParator](#) on page 204

File Explorer ← Export Trace to ASCII File

Opens the Microsoft Windows File Explorer.

Remote command:

not supported

Export Trace to ASCII File

Opens a file selection dialog box and saves the selected trace in ASCII format (.dat) to the specified file and directory.

The results are output in the same order as they are displayed on the screen: window by window, trace by trace, and table row by table row.

The column headers are provided as the first row. Whether the frequency value represents the RF or IF frequency depends on the [X-Axis](#) setting.

Note: Secure user mode.

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see "Protecting Data Using the Secure User Mode" in the "Data Management" section of the R&S FSWP base unit user manual.

Remote command:

[MMEMory:STORe<n>:TRACe](#) on page 205

6.4 Using markers

Markers help you to read out measurement results for particular frequencies or mark a particular point on a trace. The "noise figure" application features four markers. Markers in the "noise figure" application are linked. If you use more than one measurement window and activate a marker in one window, it also appears in all other measurement windows on the same horizontal position.

- [Marker configuration](#)..... 101
- [Marker positioning](#)..... 104

6.4.1 Marker configuration


Access (marker configuration): [MKR] > "Marker Config" > "Marker"

Access (marker settings): [MKR] > "Marker Config" > "Marker Settings"


The "Marker Configuration" dialog box and the "Marker" menu contain all functionality necessary to control markers.

The "Marker Configuration" dialog box consists of two tabs.

The "Markers" tab contains functionality to define characteristics for each marker.



The "Marker Settings" tab contains general marker functionality.



Marker (1...4).....	103
Marker Type.....	103
Marker to Trace.....	103
All Markers Off.....	103
Marker Config.....	103
Marker Table Display.....	104
Marker Info.....	104

Marker (1...4)

Selects or turns the corresponding marker on and off.

Turning on a marker also opens an input field to define the horizontal position of the marker.

By default, the first marker you turn on is a normal marker, all others are delta markers.

Marker Type

Toggles the marker type.

The type for marker 1 is always "Normal", the type for delta marker 1 is always "Delta". These types cannot be changed.

Note: If normal marker 1 is the active marker, switching the "Mkr Type" activates an additional delta marker 1. For any other marker, switching the marker type does not activate an additional marker, it only switches the type of the selected marker.

"Normal" A normal marker indicates the absolute value at the defined position in the diagram.

"Delta" A delta marker defines the value of the marker relative to the specified reference marker (marker 1 by default).

Remote command:

[CALCulate<n>:MARKer<m>\[:STATe\]](#) on page 217

[CALCulate<n>:DELTAmarker<m>\[:STATe\]](#) on page 220

Marker to Trace

Opens an input field to assign the marker to a particular trace if you are using more than one trace.

All Markers Off

Deactivates all markers in one step.

Remote command:

[CALCulate<n>:MARKer<m>:AOFF](#) on page 216

Marker Config

Opens the "Marker Configuration" dialog box.

The "Marker Configuration" dialog box contains all marker functions necessary to set up the four markers supported by the application.

- Selected
Highlights the currently selected marker.
- State
Turns a marker on and off.
- X-value

Defines the marker position on the horizontal axis.

- Type
Selects the marker type. For more information see "[Marker Type](#)" on page 103.
- Trace
Selects the trace the marker is positioned on.

Marker Table Display

Defines how the marker information is displayed.

"On" Displays the marker information in a table in a separate area beneath the diagram.

"Off" No separate marker table is displayed.
If [Marker Info](#) is active, the marker information is displayed within the diagram area.

Remote command:

`DISPlay[:WINDow<n>]:MTABLE` on page 222

Marker Info

Turns the marker information displayed in the diagram on and off.

1AP Clrw	
M1[1]	81.13 dBµV 177.610 MHz
D2[1]	-22.18 dB -28.980 MHz

Remote command:

`DISPlay[:WINDow<n>]:MINFo[:STATe]` on page 222

6.4.2 Marker positioning

If you are using more than one measurement window, the application performs the peak search in the currently selected measurement window. The currently selected measurement window has a blue border. Because the markers are linked in the "noise figure" application, the frequency position of the marker in the other window is updated accordingly, even if it means that the marker is on a peak in one window only.

Select Marker <x>.....	104
Peak Search.....	105
Search Next Peak.....	105
Search Minimum.....	105
Search Next Minimum.....	106
Marker to Single Frequency.....	106

Select Marker <x>

Opens a dialog box to select and activate or deactivate one or more markers.

The number in the softkey label (<x>) shows the number of the currently selected marker.



Remote command:

Marker selected via suffix <m> in remote commands.

Peak Search

Sets the selected marker/delta marker to the maximum of the trace. If no marker is active, marker 1 is activated.

Remote command:

[CALCulate<n>:MARKer<m>:MAXimum\[:PEAK\]](#) on page 223

[CALCulate<n>:DELTamarker<m>:MAXimum\[:PEAK\]](#) on page 226

Search Next Peak

Sets the selected marker/delta marker to the next (lower) maximum of the assigned trace. If no marker is active, marker 1 is activated.

Remote command:

[CALCulate<n>:MARKer<m>:MAXimum:NEXT](#) on page 223

[CALCulate<n>:MARKer<m>:MAXimum:RIGHT](#) on page 224

[CALCulate<n>:MARKer<m>:MAXimum:LEFT](#) on page 223

[CALCulate<n>:DELTamarker<m>:MAXimum:NEXT](#) on page 225

[CALCulate<n>:DELTamarker<m>:MAXimum:RIGHT](#) on page 226

[CALCulate<n>:DELTamarker<m>:MAXimum:LEFT](#) on page 225

Search Minimum

Sets the selected marker/delta marker to the minimum of the trace. If no marker is active, marker 1 is activated.

Remote command:

[CALCulate<n>:MARKer<m>:MINimum\[:PEAK\]](#) on page 224

[CALCulate<n>:DELTamarker<m>:MINimum\[:PEAK\]](#) on page 226

Search Next Minimum

Sets the selected marker/delta marker to the next (higher) minimum of the selected trace. If no marker is active, marker 1 is activated.

Remote command:

`CALCulate<n>:MARKer<m>:MINimum:NEXT` on page 224

`CALCulate<n>:MARKer<m>:MINimum:LEFT` on page 224

`CALCulate<n>:MARKer<m>:MINimum:RIGHT` on page 224

`CALCulate<n>:DELTamarker<m>:MINimum:NEXT` on page 226

`CALCulate<n>:DELTamarker<m>:MINimum:LEFT` on page 226

`CALCulate<n>:DELTamarker<m>:MINimum:RIGHT` on page 227

Marker to Single Frequency

Starts a single frequency measurement on the current marker position.

When you use this function, the application changes the tuning mode and automatically adjusts the single frequency to that of the current marker position.

For more information see [Chapter 4.1.3, "Single frequency measurements"](#), on page 29.

6.5 Limit line settings and functions

Access: [LINES]

The "noise figure" measurement application supports up to eight active limit lines in each active measurement window.

**Stored limit line settings**

When storing and recalling limit line settings, consider the information provided in the Data Management chapter of the R&S FSWP User Manual.

- [Limit line management](#)..... 106
- [Limit line details](#)..... 108

6.5.1 Limit line management

Access: "Overview" > "Analysis" > "Lines" > "Limit Lines"

or: [LINES] > "Line Config" > "Limit Lines"

For the limit line overview, the R&S FSWP searches for all stored limit lines with the file extension `.LIN` in the `limits` subfolder of the main installation folder. The overview allows you to determine which limit lines are available and can be used for the current measurement.

For details on settings for individual lines see [Chapter 6.5.2, "Limit line details"](#), on page 108.

Name.....	107
Unit.....	107
Compatibility.....	107
Visibility.....	107
Traces to be Checked.....	107
Comment.....	107
Show Compatible Limit Lines.....	107
Show Lines for Noise.....	108
Create New Line.....	108
Edit Line.....	108
Copy Line.....	108
Delete Line.....	108
Disable All Lines.....	108

Name

The name of the stored limit line.

Unit

The unit in which the y-values of the data points of the limit line are defined.

Compatibility

Indicates whether the limit line definition is compatible with the current measurement settings.

Visibility

Displays or hides the limit line in the diagram. Up to 8 limit lines can be visible at the same time. Inactive limit lines can also be displayed in the diagram.

Remote command:

`CALCulate<n>:LIMit:LOWer:STATe` on page 211

`CALCulate<n>:LIMit:UPPer:STATe` on page 212

`CALCulate<n>:LIMit:ACTive?` on page 212

Traces to be Checked

Defines which traces are automatically checked for conformance with the limit lines. As soon as a trace to be checked is defined, the assigned limit line is active. One limit line can be activated for several traces simultaneously. If any of the "Traces to be Checked" violate any of the active limit lines, a message is indicated in the diagram.

Remote command:

`CALCulate<n>:LIMit:TRACe<t>:CHECK` on page 215

Comment

An optional description of the limit line.

Show Compatible Limit Lines

Defines which of the stored limit lines are included in the overview.

If active, only limit lines that are compatible to the result display currently in focus are displayed.

Show Lines for Noise

If activated (default), only limit lines created for "noise figure" measurements are displayed. Otherwise, all limit lines are displayed.

Create New Line

Creates a new limit line.

Edit Line

Edit an existing limit line configuration.

Copy Line

Copy the selected limit line configuration to create a new line.

Remote command:

[CALCulate<n>:LIMit:COPY](#) on page 213

Delete Line

Delete the selected limit line configuration.

Remote command:

[CALCulate<n>:LIMit:DELete](#) on page 213

Disable All Lines

Disable all limit lines in one step.


Remote command:

[CALCulate<n>:LIMit:STATe](#) on page 214

6.5.2 Limit line details

Access: "Overview" > "Analysis" > "Lines" > "Limit Lines" > "New" / "Edit" / "Copy To"

or: [LINES] > "Line Config" > "Limit Lines" > "New" / "Edit" / "Copy To"



Name..... 109

Comment..... 109

Y-Axis..... 109

Data Points..... 110

Insert Value..... 110

Delete Value..... 110

Shift x..... 110

Shift y..... 110

Save..... 110

Name

Defines the limit line name. All names must be compatible with Windows conventions for file names. The limit line data is stored under this name (with a .LIN extension).

Remote command:

[CALCulate<n>:LIMit:NAME](#) on page 208

Comment

Defines an optional comment for the limit line.

Remote command:

[CALCulate<n>:LIMit:COMMENT](#) on page 208

Y-Axis

Describes the vertical axis on which the data points of the limit line are defined.

You can select the type of limit line (upper or lower) for each type of result. From that information, the application sets the level unit and y-axis scaling. Both are then fix parameters because the unit depends on the result and the scaling is always absolute in case of "noise figure" measurements.

Data Points

Each limit line is defined by a minimum of 2 and a maximum of 200 data points. Each data point is defined by its position (x-axis) and value (y-value). Data points must be defined in ascending order. The same position can have two different values.

Remote command:

[CALCulate<n>:LIMit:CONTRol\[:DATA\]](#) on page 209

[CALCulate<n>:LIMit:LOWer\[:DATA\]](#) on page 210

[CALCulate<n>:LIMit:UPPer\[:DATA\]](#) on page 211

Insert Value

Inserts a data point in the limit line above the selected one in the "Edit Limit Line" dialog box.

Delete Value

Deletes the selected data point in the "Edit Limit Line" dialog box.

Shift x

Shifts the x-value of each data point horizontally by the defined shift width.

Remote command:

[CALCulate<n>:LIMit:CONTRol:SHIFt](#) on page 209

Shift y

Shifts the y-value of each data point vertically by the defined shift width.

Remote command:

[CALCulate<n>:LIMit:LOWer:SHIFt](#) on page 210

[CALCulate<n>:LIMit:UPPer:SHIFt](#) on page 212

Save

Saves the currently edited limit line under the name defined in the "Name" field.

7 Remote control commands for noise figure measurements

The following remote control commands are required to configure and perform "noise figure" measurements in a remote environment. The R&S FSWP must already be set up for remote operation in a network as described in the base unit manual.



Common functionality

Note that basic tasks that are also performed in the base unit in the same way are not described here. For a description of such tasks, see the R&S FSWP User Manual.

In particular, this includes:

- Managing Settings and Results, i.e. storing and loading settings and result data.
- Basic instrument configuration, e.g. checking the system configuration, customizing the screen layout, or configuring networks and remote operation.
- Using the common status registers (specific status registers for Pulse measurements are not used).

Channel-specific commands

Apart from a few general commands on the R&S FSWP, most commands refer to the currently active channel. Thus, always remember to activate a "Noise Figure" channel before starting a remote program for a "noise figure" measurement.

• Common suffixes	112
• Introduction	112
• Controlling the noise figure measurement channel	117
• Working with windows in the display	121
• General window commands	128
• Retrieving measurement results	128
• Defining the measurement frequency	130
• Selecting DUT characteristics	135
• Configuring the noise source	137
• Configuring additional loss	145
• Configuring the analyzer	152
• Configuring triggered and gated measurements	158
• Using the uncertainty calculator	167
• Performing measurements	177
• Configuring the inputs and outputs	182
• Configuring the display	198
• Working with traces	201
• Working with limit lines	206
• Working with markers	216
• Using the status register	227
• Deprecated remote commands for noise figure measurements	233
• Programming example: measuring a noise figure	234

7.1 Common suffixes

In the noise measurement application, the following common suffixes are used in remote commands:

Table 7-1: Common suffixes used in remote commands in the noise measurement application

Suffix	Value range	Description
<m>	1 to 4	Marker (or spot noise marker)
<n>	1 to 16	Window (in the currently selected channel)
<t>	1 to 4	Trace
	1 to 8	Limit line
<j>	1..10	Selects an integrated measurement range.
<k>	1..8 (Limit line) 1 2 (Display line)	Selects a limit or display line.
<r>	1..x	Selects a half decade. The value range depends on the number of half decades. The first half decade in the measurement always has the value "1". For subsequent half decades, add "1" to get the value "x" (the fourth half decade, for example, would have the value "4").
<s>	1..6	Selects a (user defined) spot noise marker.
<x>	1..2	Selects a mixer in the test setup.



Selecting windows in multiple channels

Note that the suffix <n> always refers to a window in the currently selected channel.

7.2 Introduction

Commands are program messages that a controller (e.g. a PC) sends to the instrument or software. They operate its functions ('setting commands' or 'events') and request information ('query commands'). Some commands can only be used in one way, others work in two ways (setting and query). If not indicated otherwise, the commands can be used for settings and queries.

The syntax of a SCPI command consists of a header and, usually, one or more parameters. To use a command as a query, you have to append a question mark after the last header element, even if the command contains a parameter.

A header contains one or more keywords, separated by a colon. Header and parameters are separated by a "white space" (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank). If there is more than one parameter for a command, they are separated by a comma from one another.

Only the most important characteristics that you need to know when working with SCPI commands are described here. For a more complete description, refer to the user manual of the R&S FSWP.



Remote command examples

Note that some remote command examples mentioned in this general introduction are possibly not supported by this particular application.

7.2.1 Conventions used in descriptions

The following conventions are used in the remote command descriptions:

- *Command usage*
If not specified otherwise, commands can be used both for setting and for querying parameters.
If a command can be used for setting or querying only, or if it initiates an event, the usage is stated explicitly.
- *Parameter usage*
If not specified otherwise, a parameter can be used to set a value, and it is the result of a query.
Parameters required only for setting are indicated as "Setting parameters".
Parameters required only to refine a query are indicated as "Query parameters".
Parameters that are only returned as the result of a query are indicated as "Return values".
- *Conformity*
Commands that are taken from the SCPI standard are indicated as "SCPI confirmed". All commands used by the R&S FSWP follow the SCPI syntax rules.
- *Asynchronous commands*
A command which does not automatically finish executing before the next command starts executing (overlapping command) is indicated as an "Asynchronous command".
- *Reset values (*RST)*
Default parameter values that are used directly after resetting the instrument (*RST command) are indicated as "*RST" values, if available.
- *Default unit*
The default unit is used for numeric values if no other unit is provided with the parameter.
- *Manual operation*
If the result of a remote command can also be achieved in manual operation, a link to the description is inserted.

7.2.2 Long and short form

The keywords have a long and a short form. You can use either the long or the short form, but no other abbreviations of the keywords.

The short form is emphasized in uppercase letters. Note however, that this emphasis only serves the purpose to distinguish the short from the long form in the manual. For the instrument, the case does not matter.

Example:

`SENSe:FREQuency:CENTer` is the same as `SENS:FREQ:CENT`.

7.2.3 Numeric suffixes

Some keywords have a numeric suffix if the command can be applied to multiple instances of an object. In that case, the suffix selects a particular instance (e.g. a measurement window).

Numeric suffixes are indicated by angular brackets (<n>) next to the keyword.

If you do not quote a suffix for keywords that support one, a 1 is assumed.

Example:

`DISPlay[:WINDow<1...4>]:ZOOM:STATe` enables the zoom in a particular measurement window, selected by the suffix at `WINDow`.

`DISPlay:WINDow4:ZOOM:STATe ON` refers to window 4.

7.2.4 Optional keywords

Some keywords are optional and are only part of the syntax because of SCPI compliance. You can include them in the header or not.



If an optional keyword has a numeric suffix and you need to use the suffix, you have to include the optional keyword. Otherwise, the suffix of the missing keyword is assumed to be the value 1.

Optional keywords are emphasized with square brackets.

Example:

Without a numeric suffix in the optional keyword:

`[SENSe:]FREQuency:CENTer` is the same as `FREQuency:CENTer`

With a numeric suffix in the optional keyword:

`DISPlay[:WINDow<1...4>]:ZOOM:STATe`

`DISPlay:ZOOM:STATe ON` enables the zoom in window 1 (no suffix).

`DISPlay:WINDow4:ZOOM:STATe ON` enables the zoom in window 4.

7.2.5 Alternative keywords

A vertical stroke indicates alternatives for a specific keyword. You can use both keywords to the same effect.

Example:

```
[SENSe:]BANDwidth|BWIDth[:RESolution]
```

In the short form without optional keywords, `BAND 1MHZ` would have the same effect as `BWID 1MHZ`.

7.2.6 SCPI parameters

Many commands feature one or more parameters.

If a command supports more than one parameter, they are separated by a comma.

Example:

```
LAYout:ADD:WINDow Spectrum,LEFT,MTABLE
```

Parameters can have different forms of values.

- [Numeric values](#)..... 115
- [Boolean](#)..... 116
- [Character data](#)..... 116
- [Character strings](#)..... 117
- [Block data](#)..... 117

7.2.6.1 Numeric values

Numeric values can be entered in any form, i.e. with sign, decimal point or exponent. For physical quantities, you can also add the unit. If the unit is missing, the command uses the basic unit.

Example:

With unit: `SENSe:FREQuency:CENTer 1GHZ`

Without unit: `SENSe:FREQuency:CENTer 1E9` would also set a frequency of 1 GHz.

Values exceeding the resolution of the instrument are rounded up or down.

If the number you have entered is not supported (e.g. for discrete steps), the command returns an error.

Instead of a number, you can also set numeric values with a text parameter in special cases.

- **MIN/MAX**
Defines the minimum or maximum numeric value that is supported.
- **DEF**
Defines the default value.
- **UP/DOWN**
Increases or decreases the numeric value by one step. The step size depends on the setting. Sometimes, you can customize the step size with a corresponding command.

Querying numeric values

When you query numeric values, the system returns a number. For physical quantities, it applies the basic unit (e.g. Hz for frequencies). The number of digits after the decimal point depends on the type of numeric value.

Example:

Setting: `SENSe:FREQuency:CENTer 1GHZ`

Query: `SENSe:FREQuency:CENTer?` would return `1E9`

Sometimes, numeric values are returned as text.

- `INF/NINF`
Infinity or negative infinity. Represents the numeric values `9.9E37` or `-9.9E37`.
- `NAN`
Not a number. Represents the numeric value `9.91E37`. `NAN` is returned if errors occur.

7.2.6.2 Boolean

Boolean parameters represent two states. The "on" state (logically true) is represented by `"ON"` or the numeric value `1`. The "off" state (logically untrue) is represented by `"OFF"` or the numeric value `0`.

Querying Boolean parameters

When you query Boolean parameters, the system returns either the value `1` (`"ON"`) or the value `0` (`"OFF"`).

Example:

Setting: `DISPlay:WINDow:ZOOM:STATe ON`

Query: `DISPlay:WINDow:ZOOM:STATe?` would return `1`

7.2.6.3 Character data

Character data follows the syntactic rules of keywords. You can enter text using a short or a long form. For more information, see [Chapter 7.2.2, "Long and short form"](#), on page 113.

Querying text parameters

When you query text parameters, the system returns its short form.

Example:

Setting: `SENSe:BANDwidth:RESolution:TYPE NORMal`

Query: `SENSe:BANDwidth:RESolution:TYPE?` would return `NORM`

7.2.6.4 Character strings

Strings are alphanumeric characters. They have to be in straight quotation marks. You can use a single quotation mark (') or a double quotation mark (").

Example:

```
INSTRument:DELeTe 'Spectrum'
```

7.2.6.5 Block data

Block data is a format which is suitable for the transmission of large amounts of data.

The ASCII character # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. The data bytes follow. During the transmission of these data bytes, all end or other control signs are ignored until all bytes are transmitted. #0 specifies a data block of indefinite length. The use of the indefinite format requires an NL^END message to terminate the data block. This format is useful when the length of the transmission is not known or if speed or other considerations prevent segmentation of the data into blocks of definite length.

7.3 Controlling the noise figure measurement channel

The following commands are necessary to control the measurement channel.

INSTRument:CREate:DUPLicate.....	117
INSTRument:CREate[:NEW].....	118
INSTRument:CREate:REPLace.....	118
INSTRument:DELeTe.....	118
INSTRument:LIST?.....	119
INSTRument:REName.....	119
INSTRument[:SELeCt].....	120
SYSTem:PRESet:CHANnel[:EXEC].....	120

INSTRument:CREate:DUPLicate

Duplicates the currently selected channel, i.e. creates a new channel of the same type and with the identical measurement settings. The name of the new channel is the same as the copied channel, extended by a consecutive number (e.g. "IQAnalyzer" -> "IQAnalyzer 2").

The channel to be duplicated must be selected first using the `INST:SEL` command.

Example:

```
INST:SEL 'PhaseNoise'
INST:CRE:DUPL
```

Duplicates the channel named 'PhaseNoise' and creates a new channel named 'PhaseNoise 2'.

Usage:

Event

INSTrument:CREate[:NEW] <ChannelType>, <ChannelName>

Adds a measurement channel. You can configure up to 10 measurement channels at the same time (depending on available memory).

Parameters:

- <ChannelType> Channel type of the new channel.
For a list of available channel types, see [INSTrument:LIST?](#) on page 119.
- <ChannelName> String containing the name of the channel.
Note that you cannot assign an existing channel name to a new channel. If you do, an error occurs.

Example: `INST:CRE SAN, 'Spectrum 2'`
Adds a spectrum display named "Spectrum 2".

INSTrument:CREate:REPLace <ChannelName1>, <ChannelType>, <ChannelName2>

Replaces a channel with another one.

Setting parameters:

- <ChannelName1> String containing the name of the channel you want to replace.
- <ChannelType> Channel type of the new channel.
For a list of available channel types, see [INSTrument:LIST?](#) on page 119.
- <ChannelName2> String containing the name of the new channel.
Note: If the specified name for a new channel already exists, the default name, extended by a sequential number, is used for the new channel (see [INSTrument:LIST?](#) on page 119).
Channel names can have a maximum of 31 characters, and must be compatible with the Windows conventions for file names. In particular, they must not contain special characters such as ":", "*", "?".

Example: `INST:CRE:REPL 'PhaseNoise', PNO, 'PNO2'`
Replaces the channel named "PhaseNoise" by a new channel of type "Phase Noise" named "PNO2".

Usage: Setting only

INSTrument:DELeTe <ChannelName>

Deletes a channel.

If you delete the last channel, the default "Phase Noise" channel is activated.

Setting parameters:

- <ChannelName> String containing the name of the channel you want to delete.
A channel must exist to delete it.

Example: `INST:DEL 'PhaseNoise'`
Deletes the channel with the name 'PhaseNoise'.

Usage: Setting only

INSTrument:LIST?

Queries all active channels. The query is useful to obtain the names of the existing channels, which are required to replace or delete the channels.

Return values:

<ChannelType>, For each channel, the command returns the channel type and
<ChannelName> channel name (see tables below).

Tip: to change the channel name, use the [INSTrument:REName](#) command.

Example: `INST:LIST?`
Result for 2 channels:
'PNO', 'PhaseNoise', 'PNO', 'Phase Noise 2'

Usage: Query only

Table 7-2: Available channel types and default channel names

Application	<ChannelType> Parameter	Default Channel Name*)
Phase Noise	PNOise	Phase Noise
Spectrum Monitor	SMONitor	Spectrum Monitor
Spectrum (R&S FSWP-B1)	SANalyzer	Spectrum
I/Q Analyzer (R&S FSWP-B1)	IQ	IQ Analyzer
Pulse Measurements (R&S FSWP-K6)	PULSe	Pulse
Analog Modulation Analysis (R&S FSWP-K7)	ADEMod	Analog Demod
Noise Figure Measurements (R&S FSWP-K30)	NOISe	Noise
Fast Spur Search (R&S FSWP-K50)	SPUR	Spurious
Transient Analysis (R&S FSWP-K60)	TA	Transient Analysis
Vector Signal Analysis (R&S FSWP-K70)	DDEM	VSA

Note: the default channel name is also listed in the table. If the specified name for a new channel already exists, the default name, extended by a sequential number, is used for the new channel.

INSTrument:REName <ChannelName1>, <ChannelName2>

Renames a channel.

Setting parameters:

<ChannelName1> String containing the name of the channel you want to rename.

<ChannelName2> String containing the new channel name.

Note that you cannot assign an existing channel name to a new channel. If you do, an error occurs.

Channel names can have a maximum of 31 characters, and must be compatible with the Windows conventions for file names. In particular, they must not contain special characters such as ":", "*", "?".

Example:

```
INST:REN 'PhaseNoise', 'PNO'
```

Renames the channel with the name 'PhaseNoise' to 'PNO'.

Usage:

Setting only

INSTrument[:SElect] <ChannelType> | <ChannelName>

Activates a new channel with the defined channel type, or selects an existing channel with the specified name.

Also see

- [INSTrument:CREate\[:NEW\]](#) on page 118

Parameters:

<ChannelType> Channel type of the new channel.

For a list of available channel types see [INSTrument:LIST?](#) on page 119.

<ChannelName> String containing the name of the channel.

Example:

```
INST IQ
```

Activates a channel for the I/Q Analyzer application (evaluation mode).

```
INST 'MyIQSpectrum'
```

Selects the channel named 'MyIQSpectrum' (for example before executing further commands for that channel).

SYSTem:PRESet:CHANnel[:EXEC]

Restores the default instrument settings in the current channel.

Use `INST:SEL` to select the channel.

Example:

```
INST:SEL 'Spectrum2'
```

Selects the channel for "Spectrum2".

```
SYST:PRESet:CHAN:EXEC
```

Restores the factory default settings to the "Spectrum2" channel.

Usage:

Event

Manual operation: See ["Preset Channel"](#) on page 47

7.4 Working with windows in the display

The following commands are required to change the evaluation type and rearrange the screen layout for a channel as you do using the SmartGrid in manual operation. Since the available evaluation types depend on the selected application, some parameters for the following commands also depend on the selected channel.

Note that the suffix <n> always refers to the window *in the currently selected channel*.

LAYout:ADD[:WINDow]?	121
LAYout:CATalog[:WINDow]?	123
LAYout:IDENtify[:WINDow]?	123
LAYout:MOVE[:WINDow]	123
LAYout:REMove[:WINDow]	124
LAYout:REPLace[:WINDow]	124
LAYout:SPLitter	125
LAYout:WINDow<n>:ADD?	126
LAYout:WINDow<n>:IDENtify?	126
LAYout:WINDow<n>:REMove	127
LAYout:WINDow<n>:REPLace	127

LAYout:ADD[:WINDow]? <WindowName>, <Direction>, <WindowType>

Adds a window to the display in the active channel.

Is always used as a query so that you immediately obtain the name of the new window as a result.

To replace an existing window, use the `LAYout:REPLace[:WINDow]` command.

Query parameters:

<WindowName>	String containing the name of the existing window the new window is inserted next to. By default, the name of a window is the same as its index. To determine the name and index of all active windows, use the <code>LAYout:CATalog[:WINDow]?</code> query.
<Direction>	LEFT RIGHT ABOVE BELOW Direction the new window is added relative to the existing window.
<WindowType>	text value Type of result display (evaluation method) you want to add. See the table below for available parameter values.

Return values:

<NewWindowName>	When adding a new window, the command returns its name (by default the same as its number) as a result.
-----------------	---

- Example:** LAY:ADD? '1', LEFT, MTAB
 Result:
 '2'
 Adds a new window named '2' with a marker table to the left of window 1.
- Usage:** Query only
- Manual operation:** See ["Noise Figure"](#) on page 18
 See ["Gain"](#) on page 19
 See ["Temperature"](#) on page 19
 See ["Y-Factor"](#) on page 20
 See ["ENR Measured"](#) on page 21
 See ["Level \(Hot\)"](#) on page 22
 See ["Level \(Cold\)"](#) on page 22
 See ["Cal Y-Factor"](#) on page 23
 See ["Cal Level \(Hot\)"](#) on page 24
 See ["Cal Level \(Cold\)"](#) on page 24
 See ["P Hot"](#) on page 25
 See ["P Cold"](#) on page 25
 See ["Result Table"](#) on page 26
 See ["Marker Table"](#) on page 26

Table 7-3: <WindowType> parameter values for Noise Figure application

Parameter value	Window type
CPCold	"Cal Level (Cold)"
CPHot	"Cal Level (Hot)"
CYFactor	"Cal Y-Factor"
DPC	"P Cold"
DPH	"P Hot"
ENR	"ENR Measured"
GAIN	"Gain"
MTABle	"Marker table"
NOISe	"Noise figure"
PCOLd	"Level (cold)"
PHOT	"Level (hot)"
RESults	"Result table"
TEMPerature	"Temperature"
YFACtor	"Y-Factor"

LAYout:CATalog[:WINDow]?

Queries the name and index of all active windows in the active channel from top left to bottom right. The result is a comma-separated list of values for each window, with the syntax:

<WindowName_1>,<WindowIndex_1>..<WindowName_n>,<WindowIndex_n>

Return values:

<WindowName> string
Name of the window.
In the default state, the name of the window is its index.

<WindowIndex> **numeric value**
Index of the window.

Example:

LAY:CAT?

Result:

'2',2,'1',1

Two windows are displayed, named '2' (at the top or left), and '1' (at the bottom or right).

Usage: Query only

LAYout:IDENtify[:WINDow]? <WindowName>

Queries the **index** of a particular display window in the active channel.

Note: to query the **name** of a particular window, use the [LAYout:WINDow<n>:IDENtify?](#) query.

Query parameters:

<WindowName> String containing the name of a window.

Return values:

<WindowIndex> Index number of the window.

Example:

LAY:IDEN:WIND? '2'

Queries the index of the result display named '2'.

Response:

2

Usage: Query only

LAYout:MOVE[:WINDow] <WindowName>, <WindowName>, <Direction>**Setting parameters:**

<WindowName> String containing the name of an existing window that is to be moved.

By default, the name of a window is the same as its index. To determine the name and index of all active windows in the active channel, use the [LAYout:CATalog\[:WINDow\]?](#) query.

<WindowName>	String containing the name of an existing window the selected window is placed next to or replaces. By default, the name of a window is the same as its index. To determine the name and index of all active windows in the active channel, use the LAYout:CATalog[:WINDow]? query.
<Direction>	LEFT RIGHT ABOVE BELOW REPLACE Destination the selected window is moved to, relative to the reference window.
Example:	<code>LAY:MOVE '4', '1', LEFT</code> Moves the window named '4' to the left of window 1.
Example:	<code>LAY:MOVE '1', '3', REPL</code> Replaces the window named '3' by window 1. Window 3 is deleted.
Usage:	Setting only

LAYout:REMOve[:WINDow] <WindowName>

Removes a window from the display in the active channel.

Setting parameters:

<WindowName> String containing the name of the window. In the default state, the name of the window is its index.

Example: `LAY:REM '2'`
Removes the result display in the window named '2'.

Usage: Setting only

LAYout:REPLace[:WINDow] <WindowName>, <WindowType>

Replaces the window type (for example from "Diagram" to "Result Summary") of an already existing window in the active channel while keeping its position, index and window name.

To add a new window, use the [LAYout:ADD\[:WINDow\]?](#) command.

Setting parameters:

<WindowName> String containing the name of the existing window.
By default, the name of a window is the same as its index. To determine the name and index of all active windows in the active channel, use the [LAYout:CATalog\[:WINDow\]?](#) query.

<WindowType> Type of result display you want to use in the existing window.
See [LAYout:ADD\[:WINDow\]?](#) on page 121 for a list of available window types.

Example: `LAY:REPL:WIND '1', MTAB`
Replaces the result display in window 1 with a marker table.

Usage: Setting only

LAYout:SPLitter <Index1>, <Index2>, <Position>

Changes the position of a splitter and thus controls the size of the windows on each side of the splitter.

Compared to the `DISPlay[:WINDow<n>]:SIZE` on page 128 command, the `LAYout:SPLitter` changes the size of all windows to either side of the splitter permanently, it does not just maximize a single window temporarily.

Note that windows must have a certain minimum size. If the position you define conflicts with the minimum size of any of the affected windows, the command does not work, but does not return an error.




Figure 7-1: SmartGrid coordinates for remote control of the splitters

Setting parameters:

<Index1> The index of one window the splitter controls.

<Index2> The index of a window on the other side of the splitter.

<Position> New vertical or horizontal position of the splitter as a fraction of the screen area (without channel and status bar and softkey menu).

The point of origin ($x = 0$, $y = 0$) is in the lower left corner of the screen. The end point ($x = 100$, $y = 100$) is in the upper right corner of the screen. (See Figure 7-1.)

The direction in which the splitter is moved depends on the screen layout. If the windows are positioned horizontally, the splitter also moves horizontally. If the windows are positioned vertically, the splitter also moves vertically.

Range: 0 to 100

Example: `LAY:SPL 1,3,50`
 Moves the splitter between window 1 ('Frequency Sweep') and 3 ('Marker Table') to the center (50%) of the screen, i.e. in the figure above, to the left.

Example: `LAY:SPL 1,4,70`
 Moves the splitter between window 1 ('Frequency Sweep') and 3 ('Marker Peak List') towards the top (70%) of the screen. The following commands have the exact same effect, as any combination of windows above and below the splitter moves the splitter vertically.

`LAY:SPL 3,2,70`

`LAY:SPL 4,1,70`

`LAY:SPL 2,1,70`

Usage: Setting only

LAYout:WINDow<n>:ADD? <Direction>,<WindowType>

Adds a measurement window to the display. Note that with this command, the suffix <n> determines the existing window next to which the new window is added. Unlike [LAYout:ADD\[:WINDow\]?](#), for which the existing window is defined by a parameter.

To replace an existing window, use the [LAYout:WINDow<n>:REPLace](#) command.

Is always used as a query so that you immediately obtain the name of the new window as a result.

Suffix:

<n> [Window](#)

Query parameters:

<Direction> LEFT | RIGHT | ABOVE | BELOW

<WindowType> Type of measurement window you want to add.
 See [LAYout:ADD\[:WINDow\]?](#) on page 121 for a list of available window types.

Return values:

<NewWindowName> When adding a new window, the command returns its name (by default the same as its number) as a result.

Example: `LAY:WIND1:ADD? LEFT,MTAB`
 Result:
 '2'
 Adds a new window named '2' with a marker table to the left of window 1.

Usage: Query only

LAYout:WINDow<n>:IDENTify?

Queries the **name** of a particular display window (indicated by the <n> suffix) in the active channel.

Note: to query the **index** of a particular window, use the `LAYout:IDENTify[:WINDow]?` command.

Suffix:

<n> [Window](#)

Return values:

<WindowName> String containing the name of a window.
In the default state, the name of the window is its index.

Example:

`LAY:WIND2:IDEN?`
Queries the name of the result display in window 2.
Response:
'2'

Usage: Query only

LAYout:WINDow<n>:REMove

Removes the window specified by the suffix <n> from the display in the active channel.
The result of this command is identical to the `LAYout:REMove[:WINDow]` command.

Suffix:

<n> [Window](#)

Example:

`LAY:WIND2:REM`
Removes the result display in window 2.

Usage: Event

LAYout:WINDow<n>:REPLace <WindowType>

Changes the window type of an existing window (specified by the suffix <n>) in the active channel.

The effect of this command is identical to the `LAYout:REPLace[:WINDow]` command.

To add a new window, use the `LAYout:WINDow<n>:ADD?` command.

Suffix:

<n> [Window](#)

Setting parameters:

<WindowType> Type of measurement window you want to replace another one with.
See `LAYout:ADD[:WINDow]?` on page 121 for a list of available window types.

Example:

`LAY:WIND2:REPL MTAB`
Replaces the result display in window 2 with a marker table.

Usage: Setting only

7.5 General window commands

The following commands are required to configure general window layout, independent of the application.

DISPlay:FORMat	128
DISPlay[:WINDow<n>]:SIZE	128

DISPlay:FORMat <Format>

Determines which tab is displayed.

Parameters:

<Format>

SPLit

Displays the MultiView tab with an overview of all active channels

SINGle

Displays the measurement channel that was previously focused.

*RST: SING

Example:

DISP:FORM SPL

DISPlay[:WINDow<n>]:SIZE <Size>

Maximizes the size of the selected result display window *temporarily*. To change the size of several windows on the screen permanently, use the `LAY:SPL` command (see [LAYout:SPLitter](#) on page 125).

Suffix:

<n>

Window

Parameters:

<Size>

LARGe

Maximizes the selected window to full screen. Other windows are still active in the background.

SMALI

Reduces the size of the selected window to its original size. If more than one measurement window was displayed originally, these are visible again.

*RST: SMALI

Example:

DISP:WIND2:SIZE LARG

7.6 Retrieving measurement results

The following commands are necessary to query measurement results.

TRACe<n>[:DATA]?	129
--	-----

TRACe<n>[:DATA]? <Trace>[, <Result>]

Queries the "Noise Figure" measurement results.

Suffix:

<n> 1..n
[Window](#)

Query parameters:

<Trace> TRACe1 | TRACe2 | TRACe3 | TRACe4

Selects the trace to be read out.

TRACE1

TRACE2

TRACE3

TRACE4

<Result> NOISe | GAIN | TEMPerature | YFACTOR | ENR | PHOT |
 PCOLd | CYFactor | CPHot | CPCold | DPHot | DPCold |
 NUNCertainty | X | ALL

Selects the result display to be read out.

ALL

Queries all available results for the measurement.

CPCold

Queries "Cal Level (cold)" results.

CPHot

Queries "Cal Level (hot)" results.

CYFactor

Queries calibration "Y-Factor" results.

DPC

Queries "P Cold" results

DPH

Queries "P Hot" results

ENR

Queries "ENR" measured results.

GAIN

Queries "Gain" results.

NOISe

Queries "Noise Figure" results.

NUNCertainty

Queries "Noise Figure" uncertainty results.

PCOLd

Queries "Level (cold)" results.

PHOT

Queries "Level (hot)" results.

TEMPerature

Queries "Temperature" results.

X

Queries the x-values (frequency).

YFACTOR

Queries "Y-Factor" results.

Return values:

<TraceData>

For any graphical result display, the command returns one result for each measurement point.

The unit depends on the result you are querying.

Example:

TRAC? TRACE1, GAIN

Queries the "gain" results for the first trace.

Usage:

Query only

Manual operation:

See ["Noise Figure"](#) on page 18

See ["Gain"](#) on page 19

See ["Temperature"](#) on page 19

See ["Y-Factor"](#) on page 20

See ["ENR Measured"](#) on page 21

See ["Level \(Hot\)"](#) on page 22

See ["Level \(Cold\)"](#) on page 22

See ["Cal Y-Factor"](#) on page 23

See ["Cal Level \(Hot\)"](#) on page 24

See ["Cal Level \(Cold\)"](#) on page 24

See ["P Hot"](#) on page 25

See ["P Cold"](#) on page 25

See ["Result Table"](#) on page 26

7.7 Defining the measurement frequency

The following commands are necessary to define the frequency characteristics of the "noise figure" measurement.

[SENSe:]CONFigure:FREQuency:CONTInuous.....	131
[SENSe:]CONFigure:FREQuency:SINGle.....	131
[SENSe:]CONFigure:LIST:CONTInuous.....	131
[SENSe:]CONFigure:LIST:SINGle.....	131
[SENSe:]FREQuency:CENTer.....	132
[SENSe:]FREQuency:TABLe:DATA.....	132
[SENSe:]FREQuency:LIST:DATA.....	132
[SENSe:]BANDwidth:LIST:DATA.....	133
[SENSe:]FREQuency:POINts.....	133
[SENSe:]FREQuency:SINGle.....	133
[SENSe:]FREQuency:SINGle:COUPled.....	134
[SENSe:]FREQuency:SPAN.....	134
[SENSe:]FREQuency:STARt.....	134
[SENSe:]FREQuency:STEP.....	135
[SENSe:]FREQuency:STOP.....	135

[SENSe:]CONFigure:FREQuency:CONTInuous

Configures the software to perform a single frequency measurement in continuous sweep mode.

Example: FREQ:SING 20MHz
 Defines a measurement frequency of 20 MHz.
 CONF:FREQ:CONT
 INIT
 Selects and initiates a single frequency measurement.

Usage: Event

Manual operation: See "[Tuning Mode](#)" on page 48

[SENSe:]CONFigure:FREQuency:SINGle

Configures the software to perform a single frequency measurement in single sweep mode.

Example: FREQ:SING 20MHz
 Defines a measurement frequency of 20 MHz.
 CONF:FREQ:SING
 INIT
 Selects and initiates a single frequency measurement.

Usage: Event

Manual operation: See "[Tuning Mode](#)" on page 48

[SENSe:]CONFigure:LIST:CONTInuous

Configures the software to perform a frequency list measurement in continuous sweep mode.

Example: CONF:LIST:CONT
 INIT
 Selects and initiates a frequency list measurement.

Usage: Event

Manual operation: See "[Tuning Mode](#)" on page 48

[SENSe:]CONFigure:LIST:SINGle

Configures the software to perform a measurement in single frequency tuning mode.

Example: CONF:LIST:SING
 INIT
 Selects and initiates a single frequency measurement.

Example: See [Chapter 7.22, "Programming example: measuring a noise figure"](#), on page 234

Usage: Event

Manual operation: See ["Tuning Mode"](#) on page 48

[SENSe:]FREQuency:CENTer <Frequency>

Defines the center frequency.

CW, pulsed and VCO measurements:

This command defines or queries (in case of automatic frequency search) the current signal frequency.

Transient measurement:

This command defines the center frequency of the transient measurement.

Parameters:

<Frequency> For the allowed range and f_{max} , refer to the specifications document.

*RST: $f_{max}/2$

Default unit: Hz

Example:

FREQ:CENT 100 MHz

FREQ:CENT:STEP 10 MHz

FREQ:CENT UP

Sets the center frequency to 110 MHz.

Manual operation: See ["Center"](#) on page 49
See ["Frequency"](#) on page 80

[SENSe:]FREQuency:TABLE:DATA <Frequency>...

Defines the contents of the frequency table.

The command overwrites the current contents of the frequency table.

Parameters:

<Frequency> Defines a frequency for each entry in the frequency table. A frequency table can contain up to 10001 entries.

Range: 0 Hz to f_{max}

Default unit: HZ

Example:

FREQ:TABL:DATA 100MHZ,200MHZ,300MHZ,400MHZ,
500MHZ

Creates a frequency table with five entries.

Manual operation: See ["Populate Table"](#) on page 53

[SENSe:]FREQuency:LIST:DATA {<RFFrequency>, <LOFrequency>, <IFFrequency>}...

Queries the RF, LO and IF frequency.

Parameters:

<RFFrequency> Default unit: Hz

<LOFrequency> Default unit: Hz

<IFFrequency> Default unit: Hz

Example: SENS:FREQ:LIST:DATA?

Manual operation: See "[Populate Table](#)" on page 53

[SENSe:]BANDwidth:LIST:DATA {<Frequency>, <Bandwidth>, <SweepTime>}...

Queries the RF, RBW and sweep time.

Parameters:

<Frequency> <numeric value>

Default unit: Hz

<Bandwidth> <numeric value>

Default unit: Hz

<SweepTime> <numeric value>

Default unit: s

Example: SENS:BAND:LIST:DATA?

Manual operation: See "[Populate Table](#)" on page 53

[SENSe:]FREQUENCY:POINTs <SweepPoints>

Defines the number of measurement points analyzed during a sweep.

Parameters:

<SweepPoints> Range: 1 to 10001

*RST: 20

Example: SWE:POIN 100

Defines 100 measurement points.

Example: See [Chapter 7.22, "Programming example: measuring a noise figure"](#), on page 234

Manual operation: See "[\(Measurement\) Points](#)" on page 49

See "[\(Measurement\) Points](#)" on page 51

[SENSe:]FREQUENCY:SINGLE <Frequency>

Defines the frequency for single frequency measurements.

Parameters:

<Frequency> The minimum and maximum frequency depend on the hardware. Refer to the datasheet for details.

*RST: 100 MHz

Default unit: HZ

Example: `FREQ:SING 200MHZ`
Defines a measurement frequency of 200 MHz.

Manual operation: See ["Center"](#) on page 49
See ["Single \(Frequency\)"](#) on page 50

[SENSe:]FREQuency:SINGle:COUPlEd <State>

Couples or decouples frequency selection to the contents of a sweep list.

Parameters:

<State> ON | OFF | 0 | 1
OFF | 0
 Decouples frequency selection
ON | 1
 Couples frequency selection
 *RST: 0

Example: `SENS:FREQ:SING:COUP ON`

Manual operation: See ["Coupled to Sweep List"](#) on page 51

**[SENSe:]FREQuency:SPAN **

Defines the frequency span.

If you change the span, the application creates a new frequency list.

Parameters:

 Default unit: Hz

Example: `FREQ:SPAN 500MHZ`
Defines a span of 500 MHz.

Manual operation: See ["Span"](#) on page 49

[SENSe:]FREQuency:STARt <Frequency>

Defines the start frequency.

If you change the start frequency, the application creates a new frequency list.

Parameters:

<Frequency> *RST: RST value
 Default unit: HZ

Example: `FREQ:STAR 900MHZ`
Defines a start frequency of 900 MHz.

Example: See [Chapter 7.22, "Programming example: measuring a noise figure"](#), on page 234

Manual operation: See ["Start and Stop Frequency"](#) on page 49

[SENSe:]FREQuency:STEP <Stepsize>

Defines the frequency stepsize in the frequency table.

The stepsize corresponds to the distance from one measurement point to another.

If you change the stepsize, the application creates a new frequency list.

Parameters:

<Stepsize> Range: 0 Hz to span
 *RST: 100 MHz
 Default unit: HZ

Example: `FREQ:STEP 100MHZ`
 Defines a stepsize of 100 MHz.

Manual operation: See ["Step"](#) on page 50

[SENSe:]FREQuency:STOP <Frequency>

Defines the stop frequency.

If you change the stop frequency, the application creates a new frequency list.

Parameters:

<Frequency> *RST: RST value
 Default unit: HZ

Example: `FREQ:STOP 900MHZ`
 Defines a stop frequency of 900 MHz.

Example: See [Chapter 7.22, "Programming example: measuring a noise figure"](#), on page 234

Manual operation: See ["Start and Stop Frequency"](#) on page 49

7.8 Selecting DUT characteristics

The following commands are necessary to define DUT characteristics.

[SENSe:]CONFigure:MODE:SYSTem:IF:FREQuency	135
[SENSe:]CONFigure:MODE:SYSTem:LO	136
[SENSe:]CONFigure:MODE:SYSTem:LO:FREQuency	136
[SENSe:]CONFigure:MODE:DUT	137
[SENSe:]CORRection:IREJection	137

[SENSe:]CONFigure:MODE:SYSTem:IF:FREQuency <Frequency>

Defines the frequency for DUTs with a fixed IF.

[SENSe:]CONFigure:MODE:DUT <DUTType>

Selects the type of DUT you are testing.

Note that you have to use `[SENSe:]CONFigure:MODE:SYSTem:LO` to select if the LO or IF are fixed.

Parameters:

<DUTType> AMPLifier | DDOWnconv | DOWNconv | SDConverter |
UPConv | SDConverter

AMPLifier

Measurements on fixed frequency DUTs.

DOWNconv

Measurements on down-converting DUTs.

SDConv

Measurement on system downconverting DUTs.

UPConv

Measurements on up-converting DUTs.

*RST: AMPLifier

Example:

CONF:MODE:DUT DOWN

Selects the measurement mode for a down-converting DUT.

Manual operation: See "[Mode](#)" on page 54

[SENSe:]CORRection:IREJection <ImageRejection>

Defines the image frequency rejection for the DUT.

Parameters:

<ImageRejection> Range: 0 to 999.99
*RST: 999.99
Default unit: DB

Example:

CORR:IREJ 0

Turns image rejection off.

Manual operation: See "[Image Rejection](#)" on page 55

7.9 Configuring the noise source

The following commands are necessary to define the noise source characteristics.

[SENSe:]CORRection:ENR:CALibration:SPOT:COLD	138
[SENSe:]CORRection:ENR:CALibration:SPOT:HOT	138
[SENSe:]CORRection:ENR:CALibration:MODE	139
[SENSe:]CORRection:ENR:CALibration:SPOT	139
[SENSe:]CORRection:ENR:CALibration:TABLE:SElect	139
[SENSe:]CORRection:ENR:CALibration:TYPE	140
[SENSe:]CORRection:ENR:COMMon	140

[SENSe:]CORRection:ENR[:MEASurement]:TABLE[:DATA].....	140
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:DELeTe.....	141
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:LIST?.....	141
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:SELeCt.....	141
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature[:DATA].....	142
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature:DELeTe.....	142
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature:LIST?.....	142
[SENSe:]CORRection:ENR[:MEASurement]:MODE.....	143
[SENSe:]CORRection:ENR[:MEASurement]:SPOT.....	143
[SENSe:]CORRection:ENR[:MEASurement]:TYPE.....	143
[SENSe:]CORRection:ENR[:MEASurement]:SPOT:COLD.....	144
[SENSe:]CORRection:ENR[:MEASurement]:SPOT:HOT.....	144
[SENSe:]CORRection:TEMPerature.....	144
[SENSe:]CORRection:ENR[:MEASurement]:SNS:SRNumber.....	145
[SENSe:]CORRection:ENR:CALibration:SNS:SRNumber.....	145

[SENSe:]CORRection:ENR:CALibration:SPOT:COLD <Temperature>

Defines a constant temperature of a resistor not supplied with power (T_{cold}) used during calibration.

The command is available when you have selected a noise source with resistor characteristics with [SENSe:]CORRection:ENR:CALibration:TYPE.

Parameters:

<Temperature> Temperature in degrees Kelvin.
 *RST: 77 K
 Default unit: K

Example:

```
CORR:ENR:CAL:TYPE RES
CORR:ENR:CAL:SPOT:COLD 100
Defines a cold temperature of 100 K.
```

Manual operation: See "Calibration" on page 58

[SENSe:]CORRection:ENR:CALibration:SPOT:HOT <Temperature>

Defines a constant temperature of a resistor supplied with power (T_{hot}) used during calibration.

The command is available when you have selected a noise source with resistor characteristics with [SENSe:]CORRection:ENR:CALibration:TYPE.

Parameters:

<Temperature> Temperature in degrees Kelvin.
 *RST: 77 K
 Default unit: K

Example:

```
CORR:ENR:TYPE RES
CORR:ENR:CAL:SPOT:HOT 300
Defines a cold temperature of 300 K.
```

Manual operation: See "Calibration" on page 58

[SENSe:]CORRection:ENR:CALibration:MODE <Mode>

Selects the ENR mode for the calibration.

Is available when you use different noise sources for calibration and measurement (`[SENSe:]CORRection:ENR:COMMon OFF`).

Parameters:

<Mode>

SPOT | TABLE

SPOT

Uses a constant ENR value for all measurement points (see `[SENSe:]CORRection:ENR:CALibration:SPOT`).

TABLE

Uses the contents of the ENR table.

*RST: SPOT

Example:

CORR:ENR:CAL:MODE SPOT

Uses a constant ENR value for all measurement points.

Manual operation: See "[Calibration](#)" on page 58

[SENSe:]CORRection:ENR:CALibration:SPOT <ENR>

Defines the constant ENR for all measurement points during calibration.

Is available when you use different noise sources for calibration and measurement (`[SENSe:]CORRection:ENR:COMMon OFF`).

Parameters:

<ENR>

Range: -999.99 to 999.99

*RST: 15

Default unit: DB

Example:

CORR:ENR:CAL:MODE SPOT

CORR:ENR:CAL:SPOT 30

Selects constant ENR value mode and defines an ENR of 30 dB for all measurement points.

Manual operation: See "[Calibration](#)" on page 58

[SENSe:]CORRection:ENR:CALibration:TABLE:SElect <TableName>

Selects an ENR or temperature table for calibration.

Note that the contents of the table are independent of whether you use it for calibration or the actual measurement. When you want to edit a table, regardless if you want to use it later for a measurement or for calibration, you have to use `[SENSe:]CORRection:ENR[:MEASurement]:TABLE:SElect`. This command only selects a table for calibration.

Is available when you use different noise sources for calibration and measurement (`[SENSe:]CORRection:ENR:COMMon OFF`).

Parameters:

<TableName> String containing the table name.

Example:

CORR:ENR:MEAS:TABL:SEL 'ENRTable'
Selects a table called 'ENRTable'.

Manual operation:

See "[Calibration](#)" on page 58
See "[New](#)" on page 60

[SENSe:]CORRection:ENR:CALibration:TYPE <Type>

Selects the type of noise source you are using for the calibration.

Parameters:

<Type>

DIODe

Selects a noise source with diode characteristics.

RESistor

Selects a noise source with resistor characteristics.

When you select this noise source type, the application automatically selects the manual measurement mode (see [[SENSe:\]CONFigure:CONTRol](#)).

SMART

Selects a smart noise source.

*RST: DIODe

Example:

CORR:ENR:CAL:TYPE RES

Selects a noise source with resistor characteristics.

Manual operation:

See "[Noise Source](#)" on page 57

[SENSe:]CORRection:ENR:COMMOn <State>

Turns the use of a common ENR on or off.

For more information see "[Common Noise Source](#)" on page 58.

Parameters:

<State>

ON | OFF | 1 | 0

Example:

CORR:ENR:COMM ON

Turns the use of a common ENR on.

Manual operation:

See "[Common Noise Source](#)" on page 58

[SENSe:]CORRection:ENR[:MEASurement]:TABLe[:DATA] {<FrequencyENR>, <ENR>}...

Defines the contents of the currently selected ENR table.

Define an ENR for all measurement points.

Each entry of the ENR table consists of one measurement point and the corresponding ENR. The individual values are separated by commas or spaces. The table can contain up to 10001 entries.

If you create a new table with this command, it overwrites the current entries of the frequency list.

To select the ENR table to edit, use `[SENSe:]CORRection:ENR[:MEASurement]:TABLE[:DATA]`.

Parameters:

<FrequencyENR> Frequency of the measurement point.

Range: 0 Hz to 999.99 GHz

Default unit: HZ

<ENR> Default unit: DB

Example:

`CORR:ENR:MEAS:TABL:DATA 1MHZ,10,2MHZ,12`

Defines a new ENR table with two measurement points.

Example:

See [Chapter 7.22, "Programming example: measuring a noise figure"](#), on page 234

Manual operation:

See "New" on page 60

See "Edit" on page 60

See "Edit Table" on page 61

`[SENSe:]CORRection:ENR[:MEASurement]:TABLE:DELeTe <TableName>`

Deletes a temperature table.

Setting parameters:

<TableName> String containing the name of the table.

Example:

`CORR:ENR:MEAS:TABL:TEMP:DEL 'TemperatureTable'`

Deletes the table with the name 'TemperatureTable'.

Usage:

Setting only

Manual operation:

See "Delete" on page 61

`[SENSe:]CORRection:ENR[:MEASurement]:TABLE:LIST?`

Return values:

<Tables> <list>

Usage:

Query only

`[SENSe:]CORRection:ENR[:MEASurement]:TABLE:SELeCt <TableName>`

Selects an ENR or temperature table for the actual measurement.

When you want to edit a table, regardless if you want to use it later for a measurement or for calibration, you have to use this command. `[SENSe:]CORRection:ENR:CALibration:TABLE:SElect` only selects a table for calibration.

Parameters:

<TableName>

Manual operation: See "Measurement" on page 57
 See "New" on page 60
 See "Edit" on page 60

`[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature[:DATA]`
 {<Frequency>, <Thot>, <Tcold>}...

Parameters:

<Frequency> Default unit: HZ

<Thot> Default unit: K

<Tcold> Default unit: K

Manual operation: See "New" on page 60
 See "Edit" on page 60
 See "Edit Table" on page 61

`[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature:DElete`
 <TableName>

Deletes a temperature table.

Setting parameters:

<TableName> String containing the name of the table.

Example: `CORR:ENR:MEAS:TABL:TEMP:DEL 'TemperatureTable'`
 Deletes the table with the name 'TemperatureTable'.

Usage: Setting only

Manual operation: See "Delete" on page 61

`[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature:LIST?`

Queries all temperature tables available in the application.

Return values:

<Tables> <list>

String containing the names of the tables as a comma separated list.

Example: `CORR:ENR:TABL:TEMP:LIST`
 would return, e.g.
 'Table1,Table2,Table3'

Usage: Query only

[SENSe:]CORRection:ENR[:MEASurement]:MODE <Mode>

Selects the ENR mode for the actual measurement.

Parameters:

<Mode> SPOT | TABLE

SPOT

Uses a constant ENR value for all measurement points (see [\[SENSe:\]CORRection:ENR\[:MEASurement\]:SPOT](#)).

TABLE

Uses the contents of the ENR table.

*RST: SPOT

Example:

CORR:ENR:MODE SPOT

Uses a constant ENR value for all measurement points.

Example:

See [Chapter 7.22, "Programming example: measuring a noise figure"](#), on page 234

Manual operation: See ["Measurement"](#) on page 57

[SENSe:]CORRection:ENR[:MEASurement]:SPOT <ENR>

Defines the constant ENR for all measurement points during the actual measurement.

Parameters:

<ENR> *RST: 15
Default unit: DB

Example:

CORR:ENR:MODE SPOT

CORR:ENR:SPOT 30

Selects constant ENR value mode and defines an ENR of 30 dB for all measurement points.

Manual operation: See ["Measurement"](#) on page 57

[SENSe:]CORRection:ENR[:MEASurement]:TYPE <Type>

Selects the type of noise source you are using for the measurement.

Parameters:

<Type>

DIODE

Selects a noise source with diode characteristics.

RESistor

Selects a noise source with resistor characteristics.

When you select this noise source type, the application automatically selects the manual measurement mode (see [\[SENSe:\]CONFigure:CONTRol](#)).

SMART

Selects a smart noise source.

*RST: DIODE

Example: `CORR:ENR:TYPE RES`
Selects a noise source with resistor characteristics.

Manual operation: See "Noise Source" on page 57
See "Noise Source" on page 60

[SENSe:]CORRection:ENR[:MEASurement]:SPOT:COLD <Temperature>

Defines a constant temperature of a resistor not supplied with power (T_{cold}) used during measurements.

The command is available when you have selected a noise source with resistor characteristics with `[SENSe:]CORRection:ENR[:MEASurement]:TYPE`.

Parameters:

<Temperature> Temperature in degrees Kelvin.
*RST: 77 K
Default unit: K

Example: `CORR:ENR:TYPE RES`
`CORR:ENR:SPOT:COLD 100`
Defines a cold temperature of 100 K.

Manual operation: See "Measurement" on page 57

[SENSe:]CORRection:ENR[:MEASurement]:SPOT:HOT <Temperature>

Defines a constant temperature of a resistor supplied with power (T_{hot}) used during measurements.

The command is available when you have selected a noise source with resistor characteristics with `[SENSe:]CORRection:ENR[:MEASurement]:TYPE`.

Parameters:

<Temperature> Temperature in degrees Kelvin.
*RST: 77 K
Default unit: K

Example: `CORR:ENR:TYPE RES`
`CORR:ENR:SPOT:HOT 300`
Defines a cold temperature of 300 K.

Manual operation: See "Measurement" on page 57

[SENSe:]CORRection:TEMPerature <Temperature>

Defines the room temperature of the measurement environment. The temperature is taken into account when calculating noise results.

Parameters:

<Temperature> Range: 278.15 to 318.15
*RST: 293
Default unit: K

Example: CORR:TEMP 291.50
 Specifies a room temperature of 291.50 Kelvin (18.5 C).

Manual operation: See "[Temperature](#)" on page 59

[SENSe:]CORRection:ENR[:MEASurement]:SNS:SRNumber <SerialNumber>

Sets and queries the measurement noise source smart noise source serial number.

Parameters:

<SerialNumber>

Manual operation: See "[Noise Source](#)" on page 57

[SENSe:]CORRection:ENR:CALibration:SNS:SRNumber <SerialNumber>

Sets and queries the calibration noise source smart noise source serial number.

Parameters:

<SerialNumber>

Manual operation: See "[Noise Source](#)" on page 57

7.10 Configuring additional loss

The following commands are necessary to define loss resulting from equipment in the measurement setup.

[SENSe:]CORRection:LOSS:CALibration:MODE.....	146
[SENSe:]CORRection:LOSS:CALibration:SPOT.....	146
[SENSe:]CORRection:LOSS:CALibration:TABLE:DELeTe.....	146
[SENSe:]CORRection:LOSS:CALibration:TABLE:LIST?.....	147
[SENSe:]CORRection:LOSS:CALibration:TABLE:SELeCt.....	147
[SENSe:]CORRection:LOSS:CALibration:TABLE[:DATA].....	147
[SENSe:]CORRection:LOSS:CALibration:TEMPerature.....	147
[SENSe:]CORRection:LOSS:INPut:MODE.....	148
[SENSe:]CORRection:LOSS:INPut:SPOT.....	148
[SENSe:]CORRection:LOSS:INPut:TABLE[:DATA].....	148
[SENSe:]CORRection:LOSS:INPut:TABLE:DELeTe.....	149
[SENSe:]CORRection:LOSS:INPut:TABLE:LIST?.....	149
[SENSe:]CORRection:LOSS:INPut:TABLE:SELeCt.....	149
[SENSe:]CORRection:LOSS:INPut:TEMPerature.....	150
[SENSe:]CORRection:LOSS:OUTPut:MODE.....	150
[SENSe:]CORRection:LOSS:OUTPut:SPOT.....	150
[SENSe:]CORRection:LOSS:OUTPut:TABLE[:DATA].....	150
[SENSe:]CORRection:LOSS:OUTPut:TABLE:DELeTe.....	151
[SENSe:]CORRection:LOSS:OUTPut:TABLE:LIST?.....	151
[SENSe:]CORRection:LOSS:OUTPut:TABLE:SELeCt.....	151
[SENSe:]CORRection:LOSS:OUTPut:TEMPerature.....	151

[SENSe:]CORRection:LOSS:CALibration:MODE <Mode>

Selects the input loss mode.

Parameters:

<Mode> SPOT | TABLE

SPOT

Uses a constant calibration loss value for all measurement points (see [SENSe:]CORRection:LOSS:CALibration:SPOT on page 146).

TABLE

Uses the contents of the calibration loss table.

*RST: SPOT

Example:

```
CORR:LOSS:INP:MODE SPOT
CORR:LOSS:INP:SPOT 10
```

Selects constant calibration loss mode and defines an input loss of 10 dB for all measurement points.

Manual operation: See "Calibration Loss" on page 65

[SENSe:]CORRection:LOSS:CALibration:SPOT <Loss>

Defines a constant calibration loss for all measurement points.

Parameters:

<Loss> Range: -999.99 to 999.99
*RST: 0 dB
Default unit: dB

Example:

```
CORR:LOSS:INP:MODE SPOT
CORR:LOSS:INP:SPOT 10
```

Selects constant calibration loss mode and defines an input loss of 10 dB for all measurement points.

Manual operation: See "Calibration Loss" on page 65

[SENSe:]CORRection:LOSS:CALibration:TABLE:DELeTe <TableName>

Deletes a calibration loss table.

Setting parameters:

<TableName> String containing the name of the table.

Example:

```
CORR:LOSS:CAL:TABL:DEL 'CalibrationLoss'
```

Deletes the table with the name 'CalibrationLoss'.

Usage: Setting only

Manual operation: See "Delete" on page 67

[SENSe:]CORRection:LOSS:CALibration:TABLE:LIST?

Queries all calibration loss tables available in the application.

Example: CORR:LOSS:CAL:TABL:LIST?
Result:
 'Table1, Table2, Table3'

Usage: Query only

[SENSe:]CORRection:LOSS:CALibration:TABLE:SElect <TableName>

Selects a calibration loss table.

Parameters:

<TableName> String containing the table name.

Example: CORR:LOSS:CAL:TABL:SEL 'CalibrationLoss'
 Selects a table called CalibrationLoss'.

Manual operation: See "[Calibration Loss](#)" on page 65

[SENSe:]CORRection:LOSS:CALibration:TABLE[:DATA] {<Frequency>, <Loss>}...

Defines the contents of the currently selected calibration loss table.

Each entry of the loss table consists of one measurement point and the corresponding loss. The table can contain up to 10001 entries.

If you create a new table with this command, it overwrites the current entries of the loss table.

Parameters:

<Frequency> Frequency of the measurement point.

Range: 0 Hz to 999.99 GHz
 Default unit: HZ

<Loss> Loss of the measurement point.

Range: -999.99 GHz to 999.99 GHz
 Default unit: DB

Example: CORR:LOSS:CAL:TABL 1MHz, 10, 2MHz, 12
 Defines a new calibration loss table with two measurement points.

Manual operation: See "[New](#)" on page 67
 See "[Edit](#)" on page 67

[SENSe:]CORRection:LOSS:CALibration:TEMPerature <Temperature>

The specified temperature at the time of measurement is considered in the loss calculation.

Parameters:

<Temperature> Default unit: K

Example:

```
SENS:CORR:LOSS:CAL:TEMP 296.5
```

Calibration loss is corrected for a temperature of 296.5 K (23.35° C).

Manual operation: See "[Calibration Loss](#)" on page 65

[SENSe:]CORRection:LOSS:INPut:MODE <Mode>

Selects the input loss mode.

Parameters:

<Mode> SPOT | TABLE

SPOT

Uses a constant input loss value for all measurement points (see [\[SENSe:\]CORRection:LOSS:INPut:SPOT](#) on page 148).

TABLE

Uses the contents of the input loss table.

*RST: SPOT

Example:

```
CORR:LOSS:INP:MODE SPOT
```

Selects constant input loss.

Manual operation: See "[Input Loss](#)" on page 64

[SENSe:]CORRection:LOSS:INPut:SPOT <Loss>

Defines a constant input loss for all measurement points.

Parameters:

<Loss> Range: -999.99 to 999.99
*RST: 0 dB
Default unit: DB

Example:

```
CORR:LOSS:INP:MODE SPOT
```

```
CORR:LOSS:INP:SPOT 10
```

Selects constant input loss mode and defines an input loss of 10 dB for all measurement points.

Manual operation: See "[Input Loss](#)" on page 64

[SENSe:]CORRection:LOSS:INPut:TABLE[DATA] {<Frequency>, <Loss>}...

Defines the contents of the currently selected input loss table.

Each entry of the loss table consists of one measurement point and the corresponding loss. The table can contain up to 10001 entries.

The table should contain an input loss for all measurement points.

If you create a new table with this command, it will overwrite the current entries of the loss table.

Parameters:

<Frequency> Frequency of the measurement point.

Range: 0 dB to 999.99 dB

Default unit: HZ

<Loss> Loss of the measurement point.

Range: -999.99 dB to 999.99 dB

Default unit: DB

Example:

`CORR:LOSS:INP:TABL 1MHz,10,2MHz,12`

Defines a new input loss table with two measurement points.

Manual operation:

See ["Edit Table"](#) on page 61

See ["New"](#) on page 67

See ["Edit"](#) on page 67

[SENSe:]CORRection:LOSS:INPut:TABLE:DELeTe <TableName>

Deletes an input loss table.

Setting parameters:

<TableName> String containing the name of the table.

Example:

`CORR:LOSS:INP:TABL:DEL 'InputLoss'`

Deletes the table with the name 'InputLoss'.

Usage:

Setting only

Manual operation:

See ["Delete"](#) on page 67

[SENSe:]CORRection:LOSS:INPut:TABLE:LIST?

Queries all input loss tables available in the application.

Example:

`CORR:LOSS:INP:TABL:LIST?`

Result:

`'Table1,Table2,Table3'`

Usage:

Query only

[SENSe:]CORRection:LOSS:INPut:TABLE:SELeCt <TableName>

Selects an input loss table.

Parameters:

<TableName> String containing the table name.

Example:

`CORR:LOSS:INP:TABL:SEL 'InputLoss'`

Selects a table called 'InputLoss'.

Manual operation:

See ["Input Loss"](#) on page 64

[SENSe:]CORRection:LOSS:INPut:TEMPerature <Temperature>

The specified temperature at the time of measurement is considered in the loss calculation.

Parameters:

<Temperature> Default unit: K

Example:

SENS:CORR:LOSS:INP:TEMP 296.5

Input loss is corrected for a temperature of 296.5 K (23.35° C).

Manual operation: See "[Input Loss](#)" on page 64

[SENSe:]CORRection:LOSS:OUTPut:MODE <Mode>

Selects the output loss mode.

Parameters:

<Mode> SPOT | TABLE

SPOT

Uses a constant output loss value for all measurement points (see [\[SENSe:\]CORRection:LOSS:OUTPut:SPOT](#) on page 150).

TABLE

Uses the contents of the output loss table.

*RST: SPOT

Example:

CORR:LOSS:OUTP:MODE SPOT

Selects constant output loss.

Manual operation: See "[Output Loss](#)" on page 65

[SENSe:]CORRection:LOSS:OUTPut:SPOT <Loss>

Defines a constant output loss for all measurement points.

Parameters:

<Loss> Range: -999.99 to 999.99

*RST: 0 dB

Default unit: DB

Example:

CORR:LOSS:OUTP:MODE SPOT

CORR:LOSS:OUTP:SPOT 10

Selects constant output loss mode and defines an output loss of 10 dB for all measurement points.

Manual operation: See "[Output Loss](#)" on page 65

[SENSe:]CORRection:LOSS:OUTPut:TABLE[:DATA] {<Frequency>, <Loss>}...

Defines the contents of the currently selected output loss table.

The table should contain an output loss for all measurement points.

Each entry of the loss table consists of one measurement point and the corresponding loss. The table can contain up to 10001 entries.

If you create a new table with this command, it will overwrite the current entries of the frequency list.

Parameters:

<Frequency>	Frequency of the measurement point. Range: 0 dB to 999.99 dB Default unit: HZ
<Loss>	Loss of the measurement point. Range: -999.99 dB to 999.99 dB Default unit: DB

Example: `CORR:LOSS:OUTP:TABL 1MHz,10,2MHz,12`
Defines a new output loss table with two measurement points.

Manual operation: See ["Edit Table"](#) on page 61
See ["New"](#) on page 67
See ["Edit"](#) on page 67

[SENSe:]CORRection:LOSS:OUTPut:TABLE:DELeTe <TableName>

Setting parameters:

<TableName>

Usage: Setting only

Manual operation: See ["Delete"](#) on page 67

[SENSe:]CORRection:LOSS:OUTPut:TABLE:LIST?

Queries all output loss tables available in the application.

Example: `CORR:LOSS:OUTP:TABLE:LIST?`
Result:
'Table1,Table2,Table3'

Usage: Query only

[SENSe:]CORRection:LOSS:OUTPut:TABLE:SELeCt <TableName>

Parameters:

<TableName>

Manual operation: See ["Output Loss"](#) on page 65

[SENSe:]CORRection:LOSS:OUTPut:TEMPerature <Temperature>

The specified temperature at the time of measurement is considered in the loss calculation.

Parameters:

<Temperature> numeric value
 Default unit: K

Example:

SENS:CORR:LOSS:OUTP:TEMP 296.5
 Output loss is corrected for a temperature of 296.5 K (23.35° C).

Manual operation: See "[Output Loss](#)" on page 65

7.11 Configuring the analyzer

The following commands are necessary to configure the analyzer.

[SENSe:]BWIDth[:RESolution].....	152
[SENSe:]BANDwidth[:RESolution].....	152
[SENSe:]BWIDth:RESolution:AUTO.....	153
[SENSe:]BANDwidth:RESolution:AUTO.....	153
[SENSe:]CONFigure:CORRection.....	153
[SENSe:]CORRection[:STATe].....	154
[SENSe:]CORRection:RECall.....	154
[SENSe:]CORRection:SAVE.....	154
[SENSe:]SWEep:COUNT.....	155
[SENSe:]SWEep:TIME.....	155
[SENSe:]SWEep:TIME:AUTO.....	155
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel.....	156
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:AUTO.....	156
INPut:ATTenuation.....	156
INPut:SElect.....	157
INPut:TYPE.....	157
INPut:GAIN:STATe.....	157
INPut:GAIN[:VALue].....	157
SYSTem:CONFigure:DUT:GAIN.....	158
SYSTem:CONFigure:DUT:STIME.....	158

[SENSe:]BWIDth[:RESolution] <Bandwidth>

[SENSe:]BANDwidth[:RESolution] <Bandwidth>

Defines the resolution bandwidth and decouples the resolution bandwidth from the span.

Example:

BAND 1 MHz
 Sets the resolution bandwidth to 1 MHz

Manual operation:

See "[Resolution Bandwidth \(RBW\)](#)" on page 69
 See "[RBW](#)" on page 80

[SENSe:]BWiDth:RESolution:AUTO <State>

[SENSe:]BANDwidth:RESolution:AUTO <State>

If enabled, the resolution bandwidth is selected automatically, depending on the current frequency of the sweep point, as defined in the frequency table (see [Chapter 5.2.3, "Using a frequency table"](#), on page 51).

If disabled, the RBW defined by `[SENSe:]BANDwidth[:RESolution]` is used.

Parameters:

<State>

ON | OFF | 0 | 1

OFF | 0

Switches the function off

ON | 1

Switches the function on

*RST: 0

Example: `SENS:BAND:RES:AUTO ON`

Manual operation: See ["Resolution Bandwidth \(RBW\)"](#) on page 69

[SENSe:]CONFigure:CORRection

Configures the software to perform calibration measurements.

Using `INITiate<n>[:IMMediate]` then initiates a calibration instead of the actual measurement, until you deliberately select one of the normal measurements again with one of the following commands.

- `[SENSe:]CONFigure:FREQuency:CONTInuous`
- `[SENSe:]CONFigure:FREQuency:SINGLE`
- `[SENSe:]CONFigure:LIST:CONTInuous`
- `[SENSe:]CONFigure:LIST:SINGLE`

Note that calibration data is used only when the second stage correction mode has been turned on with `[SENSe:]CORRection[:STATe]`.

Example:

```
//Turn on second stage correction
CORR ON
//Configure application to run calibration measurement
CONF:CORR
//Initiate calibration with synchronization to end of measurement
INIT;*OPC
//Return to normal measurement (single sweep list mode)
CONF:LIST:SING
//Initiate a calibrated measurement with synchronization to end
of measurement
INIT;*OPC
```

Example: See [Chapter 7.22, "Programming example: measuring a noise figure"](#), on page 234

Usage: Event

Manual operation: See ["2nd Stage Correction"](#) on page 69
See ["Calibrate"](#) on page 85

[SENSe:]CORRection[:STATe] <State>

Includes or excludes calibration data in the actual measurement (see ["2nd Stage Correction"](#) on page 69 for more information).

Parameters:

<State> ON | OFF | 1 | 0
*RST: 0

Example: CORR ON
Includes calibration data in the measurement.

Example: See [Chapter 7.22, "Programming example: measuring a noise figure"](#), on page 234

Manual operation: See ["2nd Stage Correction"](#) on page 69

[SENSe:]CORRection:RECall <recallfilepath>

Sets the calibration results recall filepath and recalls the calibration results.

Setting parameters:

<recallfilepath>

Example: SENS:CORR:REC 'filepath'
This command will recall the calibration results from a selected file with extension .df1.

Usage: Setting only

Manual operation: See ["Calibration Recall"](#) on page 40

[SENSe:]CORRection:SAVE <savefilepath>

Queries and sets the calibration results save filepath and if set saves the calibration results.

Parameters:

<savefilepath>

Example: SENS:CORR:SAVE?
This will report an error -221 if calibration results are not available for saving. If calibration results are available the command will report a suggested filepath which includes the calibration results timestamp.
SENS:CORR:SAVE 'filepath'
This will report an error if calibration results are not available for saving. The command will save the calibration results to a filename with extension .df1.

Manual operation: See ["Calibration Save"](#) on page 39

[SENSe:]SWEep:COUNT <Averages>

Defines the number of measurements that are used to average the results.

Parameters:

<Averages> Number of measurements that are performed at a single frequency before average results are displayed.
If you set an average of 0 or 1, the application performs a single measurement at each frequency.

Range: 0 to 32767

*RST: 1

Example:

SWE:COUN 10

The application averages 10 measurements before it displays the results.

Manual operation: See "[Average](#)" on page 70

[SENSe:]SWEep:TIME <Time>

Defines the measurement time. It automatically decouples the time from any other settings.

Parameters:

<Time> refer to specifications document

*RST: depends on current settings (determined automatically)

Default unit: S

Manual operation: See "[Sweep Time](#)" on page 69

[SENSe:]SWEep:TIME:AUTO <State>

If enabled, the sweep time is automatically selected, depending on the current frequency of the sweep point, as defined in the frequency table (see [Chapter 5.2.3, "Using a frequency table"](#), on page 51).

If disabled, the value defined by `[SENSe:]SWEep:TIME` is used.

Parameters:

<State> ON | OFF | 0 | 1

OFF | 0

Switches the function off

ON | 1

Switches the function on

*RST: 0

Manual operation: See "[Sweep Time](#)" on page 69

DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel <ReferenceLevel>

Defines the reference level (for all traces in all windows).

Suffix:

<n>	irrelevant
<t>	irrelevant

Parameters:

<ReferenceLevel>	Range:	see datasheet
	*RST:	-30 dBm
	Default unit:	DBM

Example: `DISP:TRAC:Y:RLEV -60dBm`**Manual operation:** See "[Ref Level](#)" on page 70

DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:AUTO <State>

Turns automatic determination of the reference level on and off.

Suffix:

<n>	1..n
<t>	1..n irrelevant

Parameters:

<State>	ON OFF 1 0
---------	------------------

Example: `DISP:TRAC:Y:RLEV:AUTO ON`
Turns on automatic level detection.**Manual operation:** See "[Ref Level](#)" on page 70

INPut:ATTenuation <Attenuation>

Defines the total attenuation for RF input.

If you set the attenuation manually, it is no longer coupled to the reference level, but the reference level is coupled to the attenuation. Thus, if the current reference level is not compatible with an attenuation that has been set manually, the command also adjusts the reference level.

Parameters:

<Attenuation>	Range:	see specifications document
	Increment:	5 dB (with optional electr. attenuator: 1 dB)
	*RST:	10 dB (AUTO is set to ON)
	Default unit:	DB

Example: `INP:ATT 30dB`
Defines a 30 dB attenuation and decouples the attenuation from the reference level.**Manual operation:** See "[RF Attenuation](#)" on page 71

INPut:SElect <Source>

Selects the signal source for measurements, i.e. it defines which connector is used to input data to the R&S FSWP.

Parameters:

<Source> **RF**
Radio Frequency ("RF INPUT" connector)
*RST: RF

INPut:TYPE <Input>

The command selects the input path.

Parameters:

<Input> **INPUT1**
Selects RF input 1.
INPUT2
Selects RF input 2.
*RST: INPUT1

Example:

```
//Select input path
INP:TYPE INPUT1
```

INPut:GAIN:STATe <State>

Turns the internal preamplifier on and off. It requires the optional preamplifier hardware.

The preamplification value is defined using the [INPut:GAIN\[:VALue\]](#) on page 157.

Parameters:

<State> ON | OFF | 0 | 1
OFF | 0
Switches the function off
ON | 1
Switches the function on
*RST: 0

Example:

```
INP:GAIN:STAT ON
INP:GAIN:VAL 15
Switches on 15 dB preamplification.
```

Manual operation: See "[Preamplifier](#)" on page 71

INPut:GAIN[:VALue] <Gain>

Selects the "gain" if the preamplifier is activated (`INP:GAIN:STAT ON`, see [INPut:GAIN:STATe](#) on page 157).

The command requires the additional preamplifier hardware option.

Parameters:

<Gain> For R&S FSWP models 1322.8003K08, 1322.8003K09, 1322.8003K27 and 1322.8003K51, the following settings are available:
15 dB and 30 dB
All other values are rounded to the nearest of these two.
For R&S FSWP models 1322.8003K26 and 1322.8003K50:
30 dB
Default unit: DB

Example:

```
INP:GAIN:STAT ON
INP:GAIN:VAL 30
```

Switches on 30 dB preamplification.

Manual operation: See "[Preamplifier](#)" on page 71

SYSTem:CONFigure:DUT:GAIN <Gain>

Defines the expected "gain" of the DUT.

The application uses the "gain" for automatic reference level detection.

Parameters:

<Gain> Range: 10 to 1000
*RST: 30
Default unit: DB

Example:

```
SYST:CONF:DUT:GAIN 25
```

Defines "gain" of 25 dB.

Manual operation: See "[Auto Level Range](#)" on page 71

SYSTem:CONFigure:DUT:STIME <SettlingTime>

Defines the settling time of the noise source.

Parameters:

<SettlingTime> Range: 0 s to 20 s
*RST: 50 ms
Default unit: S

Example:

```
SYST:CONF:DUT:STIM 1 s
```

Defines a settling time of 1 second.

Manual operation: See "[Settling Time](#)" on page 70

7.12 Configuring triggered and gated measurements

The commands required to configure a triggered or gated measurement in a remote environment are described here.

The commands required for trigger input or output are described in [Chapter 7.12.3, "Configuring the trigger output"](#), on page 165.



*OPC should be used after requesting data. This will hold off any subsequent changes to the selected trigger source, until after the sweep is completed and the data is returned.

- [Configuring the triggering conditions](#)..... 159
- [Configuring gated measurements](#)..... 162
- [Configuring the trigger output](#)..... 165

7.12.1 Configuring the triggering conditions

The following commands are required to configure a triggered measurement.

TRIGger[:SEquence]:DTIME	159
TRIGger[:SEquence]:HOLDoff[:TIME]	159
TRIGger[:SEquence]:IFPower:HOLDoff	160
TRIGger[:SEquence]:IFPower:HYSteresis	160
TRIGger[:SEquence]:LEVel[:EXternal<port>]	160
TRIGger[:SEquence]:LEVel:IFPower	161
TRIGger[:SEquence]:LEVel:RFPower	161
TRIGger[:SEquence]:SLOPe	161
TRIGger[:SEquence]:SOURce	161

TRIGger[:SEquence]:DTIME <DropoutTime>

Defines the time the input signal must stay below the trigger level before a trigger is detected again.

Parameters:

<DropoutTime> Dropout time of the trigger.
 Range: 0 s to 10.0 s
 *RST: 0 s
 Default unit: S

Manual operation: See ["Drop-Out Time"](#) on page 81

TRIGger[:SEquence]:HOLDoff[:TIME] <Offset>

Defines the time offset between the trigger event and the start of the measurement.

Parameters:

<Offset> *RST: 0 s
 Default unit: S

Example: TRIG:HOLD 500us

Manual operation: See ["Trigger Offset"](#) on page 81

TRIGger[:SEQuence]:IFPower:HOLDoff <Period>

Defines the holding time before the next trigger event.

Note that this command can be used for **any trigger source**, not just IF Power (despite the legacy keyword).

Parameters:

<Period> Range: 0 s to 10 s
 *RST: 0 s
 Default unit: S

Example:

```
TRIG:SOUR EXT
Sets an external trigger source.
TRIG:IFP:HOLD 200 ns
Sets the holding time to 200 ns.
```

Manual operation: See "[Trigger Holdoff](#)" on page 81

TRIGger[:SEQuence]:IFPower:HYSTeresis <Hysteresis>

Defines the trigger hysteresis, which is only available for "IF Power" trigger sources.

Parameters:

<Hysteresis> Range: 3 dB to 50 dB
 *RST: 3 dB
 Default unit: DB

Example:

```
TRIG:SOUR IFP
Sets the IF power trigger source.
TRIG:IFP:HYST 10DB
Sets the hysteresis limit value.
```

Manual operation: See "[Hysteresis](#)" on page 81

TRIGger[:SEQuence]:LEVel[:EXTernal<port>] <TriggerLevel>

Defines the level the external signal must exceed to cause a trigger event.

Suffix:

<port> Selects the trigger port.
 1 = trigger port 1 (TRIGGER INPUT connector on front panel)
 2 = trigger port 2 (TRIGGER INPUT/OUTPUT connector on rear panel)

Parameters:

<TriggerLevel> Range: 0.5 V to 3.5 V
 *RST: 1.4 V
 Default unit: V

Example:

```
TRIG:LEV 2V
```

Manual operation: See "[Trigger Level](#)" on page 81

TRIGger[:SEQuence]:LEVel:IFPower <TriggerLevel>

Defines the power level at the third intermediate frequency that must be exceeded to cause a trigger event.

Note that any RF attenuation or preamplification is considered when the trigger level is analyzed. If defined, a reference level offset is also considered.

Parameters:

<TriggerLevel> For details on available trigger levels and trigger bandwidths, see the specifications document.

*RST: -20 dBm

Default unit: DBM

Example:

TRIG:LEV:IFP -30DBM

TRIGger[:SEQuence]:LEVel:RFPower <TriggerLevel>

Defines the power level the RF input must exceed to cause a trigger event. Note that any RF attenuation or preamplification is considered when the trigger level is analyzed. If defined, a reference level offset is also considered.

The input signal must be between 500 MHz and 8 GHz.

Parameters:

<TriggerLevel> For details on available trigger levels and trigger bandwidths, see the specifications document.

*RST: -20 dBm

Default unit: DBM

Example:

TRIG:LEV:RFP -30dBm

TRIGger[:SEQuence]:SLOPe <Type>

Selects the trigger slope.

Parameters:

<Type> POSitive | NEGative

POSitive

Triggers when the signal rises to the trigger level (rising edge).

NEGative

Triggers when the signal drops to the trigger level (falling edge).

*RST: POSitive

Example:

TRIG:SLOP NEG

Manual operation: See "[Slope](#)" on page 82

TRIGger[:SEQuence]:SOURce <Source>

Selects the trigger source.

Note on external triggers:

If a measurement is configured to wait for an external trigger signal in a remote control program, remote control is blocked until the trigger is received and the program can continue. Make sure that this situation is avoided in your remote control programs.

Parameters:

<Source> **IMMediate**
 Free Run
EXT | EXT2
 Trigger signal from one of the "Trigger Input/Output" connectors.
 Note: Connector must be configured for "Input".
 *RST: IMMediate

Example:

TRIG:SOUR EXT
 Selects the external trigger input as source of the trigger signal

Manual operation:

See "[Trigger Source](#)" on page 80
 See "[Free Run](#)" on page 80
 See "[Ext. Trigger 1/2](#)" on page 80

7.12.2 Configuring gated measurements

[SENSe:]SWEep:EGATe.....	162
[SENSe:]SWEep:EGATe:CONTInuous:PCOunt.....	163
[SENSe:]SWEep:EGATe:CONTInuous:PLENgtH.....	163
[SENSe:]SWEep:EGATe:CONTInuous[:STATe].....	163
[SENSe:]SWEep:EGATe:HOLDoff.....	164
[SENSe:]SWEep:EGATe:LENGth.....	164
[SENSe:]SWEep:EGATe:POLarity.....	164
[SENSe:]SWEep:EGATe:SOURce.....	165
[SENSe:]SWEep:EGATe:TYPE.....	165

[SENSe:]SWEep:EGATe <State>

Turns gated measurements on and off.

See "[\(Measurement\) Points](#)" on page 49.

Parameters:

<State> ON | OFF | 0 | 1
OFF | 0
 Switches the function off
ON | 1
 Switches the function on

Example:

```
SWE:EGAT ON
Switches on the gate mode.
SWE:EGAT:TYPE EDGE
Switches on the edge-triggered mode.
SWE:EGAT:HOLD 100US
Sets the gate delay to 100 µs.
SWE:EGAT:LEN 500US
Sets the gate opening time to 500 µs.
INIT;*WAI
Starts a sweep and waits for its end.
```

Manual operation: See "[Gated Trigger](#)" on page 82

[SENSe:]SWEep:EGATe:CONTInuous:PCOunt <Amount>

Defines the number of gate periods to be measured after a single trigger event.

Parameters:

<Amount> integer
 Range: 1 to 65535
 Increment: 1
 *RST: 100

Example: SWE:EGAT:CONT:PCO 50

Manual operation: See "[Gate Period Count](#)" on page 84

[SENSe:]SWEep:EGATe:CONTInuous:PLENght <Time>

Defines the length in seconds of a single gate period in continuous gating. The length is determined from the beginning of one gate measurement to the beginning of the next one.

Parameters:

<Time> Range: 125 ns to 30 s
 *RST: 5 ms
 Default unit: S

Example: SWE:EGAT:CONT:PLEN 10

Manual operation: See "[Gate Period Length](#)" on page 84

[SENSe:]SWEep:EGATe:CONTInuous[:STATe] <State>

Activates or deactivates continuous gating.

This setting is only available if [SENSe:]SWEep:EGATe is "On".

Parameters:

<State> ON | OFF | 0 | 1
OFF | 0
 Switches the function off

ON | 1

Switches the function on

*RST: 0

Example:

SWE:EGAT ON

Activate gating

SWE:EGAT:CONT:STAT ON

Activate continuous gating

Manual operation: See "[Continuous Gate](#)" on page 84**[SENSe:]SWEep:EGATe:HOLDoff <DelayTime>**

Defines the delay time between the gate signal and the continuation of the measurement.

Parameters:

<DelayTime> Range: 0 s to 30 s
 *RST: 0 s
 Default unit: S

Example:

SWE:EGAT:HOLD 100us

Manual operation: See "[Gate Delay](#)" on page 83**[SENSe:]SWEep:EGATe:LENGth <GateLength>**

Defines the gate length.

Parameters:

<GateLength> Range: 125 ns to 30 s
 *RST: 400µs
 Default unit: S

Example:

SWE:EGAT:LENG 10ms

Manual operation: See "[Gate Length](#)" on page 83**[SENSe:]SWEep:EGATe:POLarity <Polarity>**

Selects the polarity of an external gate signal.

The setting applies both to the edge of an edge-triggered signal and the level of a level-triggered signal.

Parameters:

<Polarity> POSitive | NEGative
 *RST: POSitive

Example:

SWE:EGAT:POL POS

[SENSe:]SWEep:EGATe:SOURce <Source>

Selects the signal source for gated measurements.

If an IF power signal is used, the gate is opened as soon as a signal at > -20 dBm is detected within the IF path bandwidth (10 MHz).

For more information see "[Trigger Source](#)" on page 80.

Parameters:

<Source> EXTernal | EXT2 | EXT3 | IFPower | IQPower | VIDEo |
 RFPower | PSEN
 *RST: IFPower

Example:

SWE:EGAT:SOUR IFP
 Switches the gate source to IF power.

[SENSe:]SWEep:EGATe:TYPE <Type>

Selects the way gated measurements are triggered.

Parameters:

<Type> **LEVEL**
 The trigger event for the gate to open is a particular power level.
 After the gate signal has been detected, the gate remains open
 until the signal disappears.
EDGE
 The trigger event for the gate to open is the detection of the sig-
 nal edge.
 After the gate signal has been detected, the gate remains open
 until the gate length is over.
 *RST: EDGE

Example:

SWE:EGAT:TYPE EDGE

Manual operation: See "[Gate Mode](#)" on page 83

7.12.3 Configuring the trigger output

The following commands are required to send the trigger signal to one of the variable "TRIGGER INPUT/OUTPUT" connectors on the R&S FSWP.

OUTPut:TRIGger<tp>:DIRection	165
OUTPut:TRIGger<tp>:LEVel	166
OUTPut:TRIGger<tp>:OTYPe	166
OUTPut:TRIGger<tp>:PULSe:IMMediate	167
OUTPut:TRIGger<tp>:PULSe:LENGth	167

OUTPut:TRIGger<tp>:DIRection <Direction>

Selects the trigger direction for trigger ports that serve as an input as well as an output.

Suffix:

<tp> Selects the used trigger port.
 <2>: selects trigger port 2 (on the rear panel).

Parameters:

<Direction> INPut | OUTPut
INPut
 Port works as an input.
OUTPut
 Port works as an output.
 *RST: INPut

OUTPut:TRIGger<tp>:LEVel <Level>

Defines the level of the (TTL compatible) signal generated at the trigger output.

Works only if you have selected a user-defined output with `OUTPut:TRIGger<tp>:OTYPe`.

Suffix:

<tp> 1..n
 Selects the trigger port to which the output is sent.
 2 = trigger port 2 (rear)

Parameters:

<Level> **HIGH**
 5 V
LOW
 0 V
 *RST: LOW

Example: `OUTP:TRIG2:LEV HIGH`

OUTPut:TRIGger<tp>:OTYPe <OutputType>

Selects the type of signal generated at the trigger output.

Suffix:

<tp> 1..n
 Selects the trigger port to which the output is sent.
 2 = trigger port 2 (rear)

Parameters:

<OutputType> **DEVice**
 Sends a trigger signal when the R&S FSWP has triggered internally.
TARMed
 Sends a trigger signal when the trigger is armed and ready for an external trigger event.

UDEFined

Sends a user-defined trigger signal. For more information, see [OUTPut:TRIGger<tp>:LEVel](#).

*RST: DEVIce

OUTPut:TRIGger<tp>:PULSe:IMMediate

Generates a pulse at the trigger output.

Suffix:

<tp> 1..n
Selects the trigger port to which the output is sent.
2 = trigger port 2 (rear)

OUTPut:TRIGger<tp>:PULSe:LENGth <Length>

Defines the length of the pulse generated at the trigger output.

Suffix:

<tp> Selects the trigger port to which the output is sent.
2 = trigger port 2 (rear)

Parameters:

<Length> Pulse length in seconds.
Default unit: S

Example: `OUTP:TRIG2:PULS:LENG 0.02`

7.13 Using the uncertainty calculator

The following commands are necessary to work with the measurement uncertainty calculator.

CALCulate<n>:UNCertainty:COMMon	168
CALCulate<n>:UNCertainty:DATA:FREQuency	168
CALCulate<n>:UNCertainty:DATA:GAIN	169
CALCulate<n>:UNCertainty:DATA:NOISe	169
CALCulate<n>:UNCertainty:DATA:RESults	169
CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty	170
CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty:COLD	170
CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty:HOT	170
CALCulate<n>:UNCertainty:ENR:UNCertainty	171
CALCulate<n>:UNCertainty:ENR:UNCertainty:COLD	171
CALCulate<n>:UNCertainty:ENR:UNCertainty:HOT	172
CALCulate<n>:UNCertainty:MATCH:DUT:IN:RL	172
CALCulate<n>:UNCertainty:MATCH:DUT:IN[:VSWR]	172
CALCulate<n>:UNCertainty:MATCH:DUT:OUT:RL	173
CALCulate<n>:UNCertainty:MATCH:DUT:OUT[:VSWR]	173
CALCulate<n>:UNCertainty:MATCH:PREamp:RL	173

CALCulate<n>:UNCertainty:MATCh:PREamp[:VSWR].....	173
CALCulate<n>:UNCertainty:MATCh:SOURce:CALibration[:VSWR].....	174
CALCulate<n>:UNCertainty:MATCh:SOURce:CALibration:RL.....	174
CALCulate<n>:UNCertainty:MATCh:SOURce:RL.....	174
CALCulate<n>:UNCertainty:MATCh:SOURce[:VSWR].....	175
CALCulate<n>:UNCertainty:PREamp:GAIN.....	175
CALCulate<n>:UNCertainty:PREamp:NOISe.....	175
CALCulate<n>:UNCertainty:PREamp:STATe.....	176
CALCulate<n>:UNCertainty[:RESult]?.....	176
CALCulate<n>:UNCertainty:SANalyzer:GAIN:UNCertainty?.....	176
CALCulate<n>:UNCertainty:SANalyzer:NOISe:UNCertainty?.....	177

CALCulate<n>:UNCertainty:COMMON <State>

Turns matching of the noise source characteristics used during calibration and measurement on and off.

Is available when you use different noise sources for calibration and measurement ([SENSE:]CORRection:ENR:COMMON OFF).

Suffix:

<n> 1..n

Parameters:

<State> ON | OFF | 1 | 0
*RST: unavailable

Example:

CALC:UNC:COMM ON

Applies the values of the calibration noise source to those of the measurement noise source.

Manual operation: See "[Common Source for Meas and Cal](#)" on page 74

CALCulate<n>:UNCertainty:DATA:FREQUENCY <Frequency>

Defines the frequency for which the uncertainty should be calculated.

Is available if you have turned automatic determination of the DUT characteristics off with CALCulate<n>:UNCertainty:DATA:FREQUENCY .

Suffix:

<n> 1..n

Parameters:

<Frequency> Frequency of the DUT.
*RST: 1 GHz
Default unit: HZ

Example:

CALC:UNC:DATA:FREQ 100MHZ

Defines a frequency of 100 MHz.

Manual operation: See "[Use Measurement Values](#)" on page 75

CALCulate<n>:UNCertainty:DATA:GAIN <Gain>

Defines the "gain" of the DUT.

Is available if you have turned automatic determination of the DUT characteristics off with `CALCulate<n>:UNCertainty:DATA:GAIN`.

Suffix:

<n> 1..n

Parameters:

<Gain> "Gain" of the DUT.
*RST: 0 dB
Default unit: DB

Example: `CALC:UNC:DATA:GAIN -5DB`
Defines a DUT "gain" of -5 dB.

Manual operation: See ["Use Measurement Values"](#) on page 75

CALCulate<n>:UNCertainty:DATA:NOISE <NoiseLevel>

Defines the noise level of the DUT.

Is available if you have turned automatic determination of the DUT characteristics off with `CALCulate<n>:UNCertainty:DATA:RESults`.

Suffix:

<n> 1..n

Parameters:

<NoiseLevel> Noise level of the DUT.
*RST: 0 dB
Default unit: DB

Example: `CALC:UNC:DATA:NOIS 10DB`
Defines a DUT noise level of 10 dB.

Manual operation: See ["Use Measurement Values"](#) on page 75

CALCulate<n>:UNCertainty:DATA:RESults <State>

Turns automatic determination of the DUT characteristics for the calculation of the uncertainty on and off.

Suffix:

<n> 1..n

Parameters:

<State> **ON | 1**
The application calculates the uncertainty with the DUT characteristics ("noise figure", "gain" and frequency) resulting from the "noise figure" measurement.

OFF | 0

The application calculates the uncertainty with the DUT characteristics ("noise figure", "gain" and frequency) based on the values you have defined manually.

Example:

```
CALC:UNC:DATA:RES ON
```

Includes the uncertainty in the results displays.

CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty <Uncertainty>

Defines the uncertainty of a calibration noise source.

Is available when `[SENSe:]CORRection:ENR:COMMon` and `[SENSe:]CORRection:ENR:COMMon` are off.

If a smart noise source is used for calibration, the uncertainty values defined in the SNS table are used.

Suffix:

<n> 1..n

Parameters:

<Uncertainty> Uncertainty value of the noise source.
Refer to the specifications document of the noise source to determine its uncertainty.

*RST: 0.1 dB

Default unit: DB

Example:

```
CALC:UNC:ENR:CAL:UNC 0.05
```

Defines an uncertainty of 0.05 dB.

Manual operation: See "[ENR Uncert\(ainty\)](#)" on page 74

CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty:COLD <Uncertainty>**Suffix:**

<n> 1..n

Parameters:

<Uncertainty>

Manual operation: See "[Temperature Uncert\(ainty\)](#)" on page 74

CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty:HOT <Uncertainty>

Defines the uncertainty of a calibration noise source.

Is available when `[SENSe:]CORRection:ENR:COMMon` and `CALCulate<n>:UNCertainty:COMMon` are off.

Suffix:

<n> 1..n

Parameters:

<Uncertainty> Hot temperature uncertainty value of the noise source.
Refer to the specifications document of the noise source to determine its uncertainty.

*RST: 0 K

Example:

CALC:UNC:ENR:CAL:UNC:COLD 5 K
Defines a high temperature uncertainty of 5 K.

Manual operation: See "[Temperature Uncert\(ainty\)](#)" on page 74

CALCulate<n>:UNCertainty:ENR:UNCertainty <Uncertainty>

Defines the uncertainty of a noise source.

If the noise sources during calibration and measurement are different, the command defines the uncertainty of the measurement noise source.

If a smart noise source is used, the uncertainty values defined in the SNS table are used.

Suffix:

<n> 1..n

Parameters:

<Uncertainty> Uncertainty value of the noise source.
Refer to the specifications document of the noise source to determine its uncertainty.

*RST: 0.1 dB
Default unit: DB

Example:

CALC:UNC:ENR:UNC 0.05
Defines an uncertainty of 0.05 dB.

Manual operation: See "[ENR Uncert\(ainty\)](#)" on page 74

CALCulate<n>:UNCertainty:ENR:UNCertainty:COLD <Uncertainty>

Defines the uncertainty of a resistor.

If the noise sources during calibration and measurement are different, the command defines the uncertainty of the measurement noise source.

Suffix:

<n> 1..n

Parameters:

<Uncertainty> Cold temperature uncertainty value of the noise source.
Refer to the specifications document of the noise source to determine its uncertainty.

*RST: 0 K

Example:

CALC:UNC:ENR:UNC:COLD 10
Defines an low temperature uncertainty of 10 K.

Manual operation: See ["Temperature Uncert\(ainty\)"](#) on page 74

CALCulate<n>:UNCertainty:ENR:UNCertainty:HOT <Uncertainty>

Defines the uncertainty of a resistor.

If the noise sources during calibration and measurement are different, the command defines the uncertainty of the measurement noise source.

Suffix:

<n> 1..n

Parameters:

<Uncertainty> Hot temperature uncertainty value of the noise source.
Refer to the specifications document of the noise source to determine its uncertainty.

*RST: 0 K

Example:

CALC:UNC:ENR:UNC:HOT 10

Defines an high temperature uncertainty of 10 K.

CALCulate<n>:UNCertainty:MATCh:DUT:IN:RL <ReturnLoss>

Defines the return loss at the DUT input.

Suffix:

<n> 1..n

Parameters:

<ReturnLoss> *RST: 50.0 dB
Default unit: DB

Example:

CALC:UNC:MATC:DUT:IN:RL 25DB

Defines a return loss of 25 dB.

Manual operation: See ["Input / Output Match"](#) on page 75

CALCulate<n>:UNCertainty:MATCh:DUT:IN[:VSWR] <VSWR>

Defines the VSWR at the DUT input.

Suffix:

<n> 1..n

Parameters:

<VSWR> *RST: 1.0

Example:

CALC:UNC:MATC:DUT:IN 1.1

Defines a VSWR of 1.1 at the DUT input.

Manual operation: See ["Input / Output Match"](#) on page 75

CALCulate<n>:UNCertainty:MATCh:DUT:OUT:RL <ReturnLoss>

Defines the returns loss at the DUT output.

Suffix:

<n> 1..n

Parameters:

<ReturnLoss> *RST: 50.0 dB
Default unit: DB

Example:

CALC:UNC:MATC:DUT:OUT:RL 40DB
Defines a return loss of 40 dB at the DUT output.

Manual operation: See ["Input / Output Match"](#) on page 75

CALCulate<n>:UNCertainty:MATCh:DUT:OUT[:VSWR] <VSWR>

Defines the VSWR at the DUT output.

Suffix:

<n> 1..n

Parameters:

<VSWR> *RST: 1.0

Example:

CALC:UNC:MATC:DUT:OUT 2.0
Defines a VSWR of 2.0 at the DUT output.

Manual operation: See ["Input / Output Match"](#) on page 75

CALCulate<n>:UNCertainty:MATCh:PREamp:RL <ReturnLoss>

Defines the return loss at the input of the preamplifier.

Suffix:

<n> 1..n

Parameters:

<ReturnLoss> *RST: 13.98 dB
Default unit: DB

Example:

CALC:UNC:MATC:PRE:RL 14.5DB
Defines a return loss of 14.5 dB.

CALCulate<n>:UNCertainty:MATCh:PREamp[:VSWR] <VSWR>

Defines the VSWR at the input of the preamplifier.

The command is available if you have turned on the preamplifier with [CALCulate<n>:UNCertainty:PREamp:STAtE](#) on page 176.

Suffix:

<n> 1..n

Parameters:

<VSWR> *RST: 1.5

Example:

CALC:UNC:MATC:PRE 1.8
Defines a VSWR of 1.8.

CALCulate<n>:UNCertainty:MATCh:SOURce:CALibration[:VSWR] <VSWR>

Defines the VSWR at the calibration noise source output.

Is available when [SENSe:]CORRection:ENR:COMMon and CALCulate<n>:UNCertainty:COMMon are off.

If a smart noise source is used, the VSWR values defined in the SNS table are used.

Suffix:

<n> 1..n

Parameters:

<VSWR> *RST: 1.15

Example:

CALC:UNC:MATC:SOUR:CAL 1.4
Defines a VSWR of 1.4.

Manual operation: See "Output Match" on page 74

CALCulate<n>:UNCertainty:MATCh:SOURce:CALibration:RL <ReturnLoss>

Defines the return loss at the calibration noise source output.

Is available when [SENSe:]CORRection:ENR:COMMon and CALCulate<n>:UNCertainty:COMMon are off.

If a smart noise source is used, the return loss values defined in the SNS table are used.

Suffix:

<n> 1..n

Parameters:

<ReturnLoss> *RST: 23.13 dB
Default unit: DB

Example:

CALC:UNC:MATC:SOUR:CAL:RL 20DB
Defines a return loss of 20 dB.

Manual operation: See "Output Match" on page 74

CALCulate<n>:UNCertainty:MATCh:SOURce:RL <ReturnLoss>

Defines the return loss at the noise source output.

If the noise sources during calibration and measurement are different, the command defines the uncertainty of the measurement noise source.

Suffix:

<n> 1..n

Parameters:<ReturnLoss> *RST: 23.13 dB
Default unit: DB**Example:**CALC:UNC:MATC:SOUR:RL 20DB
Defines a return loss of 20 dB.**Manual operation:** See "[Output Match](#)" on page 74**CALCulate<n>:UNCertainty:MATCh:SOURce[:VSWR] <VSWR>**

Defines the VSWR at the noise source output.

If the noise sources during calibration and measurement are different, the command defines the uncertainty of the measurement noise source.

If a smart noise source is used, the VSWR values defined in the SNS table are used.

Suffix:

<n> 1..n

Parameters:

<VSWR> *RST: 1.15

Example:CALC:UNC:MATC:SOUR 1.4
Defines a VSWR of 1.4.**CALCulate<n>:UNCertainty:PREamp:GAIN <Gain>**

Define the "gain" of an external preamplifier that may be part of the test setup.

Suffix:

<n> 1..n

Parameters:

<Gain>

Gain of the preamplifier.

Refer to the specifications document of the preamplifier to determine its "gain".

*RST: 20 dB
Default unit: DB**Example:**CALC:UNC:PRE:GAIN 15DB
Defines a gain of 15 dB.**Manual operation:** See "[Preamplifier Gain \(PA Gain\)](#)" on page 77**CALCulate<n>:UNCertainty:PREamp:NOISe <NoiseLevel>**

Defines the noise level of an external preamplifier that may be part of the test setup.

Suffix:

<n> 1..n

Parameters:

<NoiseLevel>

Noise level of the preamplifier.

Refer to the specifications document of the preamplifier to determine its noise level.

*RST: 5 dB

Default unit: DB

Example:

CALC:UNC:PRE:NOIS 10DB

Defines a noise level of 10 dB.

Manual operation: See "[Preamplifier noise figure \(PA NF\)](#)" on page 76**CALCulate<n>:UNCertainty:PREamp:STATE <State>**

Includes or excludes an external preamplifier from the uncertainty calculation.

If the test setup uses an external preamplifier, you also have to define its "noise figure" and "gain" values.

Suffix:

<n> 1..n

Parameters:

<State> ON | OFF | 1 | 0

*RST: 0

Example:

CALC:UNC:PRE:STAT ON

Turns the preamplifier on.

Manual operation: See "[External Preamplifier \(Ext PA\)](#)" on page 76**CALCulate<n>:UNCertainty[:RESult]?**

Queries the uncertainty of "noise figure" results.

Suffix:

<n> 1..n

Return values:

<Uncertainty> Measurement uncertainty in dB.

Example:

CALC:UNC?

Queries the uncertainty.

Usage:

Query only

Manual operation: See "[Use Measurement Values](#)" on page 75**CALCulate<n>:UNCertainty:SANalyzer:GAIN:UNCertainty? <Uncertainty>**

Queries the uncertainty value of the spectrum analyzer's internal "gain".

Suffix:

<n> 1..n

Query parameters:

<Uncertainty> "Gain" uncertainty of the spectrum analyzer in dB.
Default unit: DB

Example:

CALC:UNC:SAN:GAIN:UNC?
Queries the "gain" uncertainty.

CALCulate<n>:UNCertainty:SANalyzer:NOISe:UNCertainty? <Uncertainty>

Queries the uncertainty value of the spectrum analyzer's internal noise.

Suffix:

<n> 1..n

Query parameters:

<Uncertainty> "Noise figure" uncertainty of the spectrum analyzer in dB.
Default unit: DB

Example:

CALC:UNC:SAN:NOIS:UNC?
Queries the "noise figure" uncertainty.

7.14 Performing measurements

The following commands are necessary to perform "noise figure" measurements.

Example: perform calibration and subsequent single sweep measurement

```
//Perform calibration:
CONF:CORR
INIT;*OPC?
//Perform single sweep measurement and use 2nd stage correction:
CORR:STAT ON
CONF:LIST:SING
INIT
```



You can also perform a sequence of measurements using the Sequencer (see "[Multiple Channels and Sequencer Function](#)" on page 14).

ABORT.....	178
INITiate<n>:CONTinuous.....	178
INITiate<n>[:IMMEDIATE].....	179
INITiate:SEQuencer:ABORT.....	179
INITiate:SEQuencer:IMMEDIATE.....	179
INITiate:SEQuencer:MODE.....	180
[SENSe:]CONFigure:CONTRol.....	180
[SENSe:]CONFigure:MEASurement.....	181
SYSTem:SEQuencer.....	181

ABORt

Aborts the measurement in the current channel and resets the trigger system.

To prevent overlapping execution of the subsequent command before the measurement has been aborted successfully, use the `*OPC?` or `*WAI` command after `ABOR` and before the next command.

For details on overlapping execution see [Remote control via SCPI](#).

Note on blocked remote control programs:

If a sequential command cannot be completed, for example because a triggered sweep never receives a trigger, the remote control program will never finish and the remote channel to the R&S FSWP is blocked for further commands. In this case, you must interrupt processing on the remote channel first in order to abort the measurement.

To do so, send a "Device Clear" command from the control instrument to the R&S FSWP on a parallel channel to clear all currently active remote channels. Depending on the used interface and protocol, send the following commands:

- **Visa:** `viClear()`
- **GPIB:** `ibclr()`
- **RSIB:** `RSDLLibclr()`

Now you can send the `ABORt` command on the remote channel performing the measurement.

Example: `ABOR; :INIT:IMM`
Aborts the current measurement and immediately starts a new one.

Example: `ABOR; *WAI`
`INIT:IMM`
Aborts the current measurement and starts a new one once abortion has been completed.

Usage: Event

INITiate<n>:CONTInuous <State>

Controls the measurement mode for an individual channel.

Note that in single measurement mode, you can synchronize to the end of the measurement with `*OPC`, `*OPC?` or `*WAI`. In continuous measurement mode, synchronization to the end of the measurement is not possible. Thus, it is not recommended that you use continuous measurement mode in remote control, as results like trace data or markers are only valid after a single measurement end synchronization.

For details on synchronization see [Remote control via SCPI](#).

If the measurement mode is changed for a channel while the Sequencer is active, the mode is only considered the next time the measurement in that channel is activated by the Sequencer.

Suffix:

<n> irrelevant

Parameters:

<State> ON | OFF | 0 | 1

ON | 1

Continuous measurement

OFF | 0

Single measurement

*RST: 1 (some applications can differ)

Example:

```
INIT:CONT OFF
```

Switches the measurement mode to single measurement.

```
INIT:CONT ON
```

Switches the measurement mode to continuous measurement.

Manual operation: See "[Continuous Sweep / Run Cont](#)" on page 85

INITiate<n>[:IMMEDIATE]

Starts a (single) new measurement.

You can synchronize to the end of the measurement with *OPC, *OPC? or *WAI.

For details on synchronization see [Remote control via SCPI](#).

Suffix:

<n> irrelevant

Usage:

Asynchronous command

Manual operation:

See "[Tuning Mode](#)" on page 48

See "[Single Sweep / Run Single](#)" on page 85

See "[Calibrate](#)" on page 85

INITiate:SEQuencer:ABORt

Stops the currently active sequence of measurements.

You can start a new sequence any time using [INITiate:SEQuencer:IMMEDIATE](#) on page 179.

Usage:

Event

INITiate:SEQuencer:IMMEDIATE

Starts a new sequence of measurements by the Sequencer.

Its effect is similar to the [INITiate<n>\[:IMMEDIATE\]](#) command used for a single measurement.

Before this command can be executed, the Sequencer must be activated (see [SYSTem:SEQuencer](#) on page 181).

Example:

```

SYST:SEQ ON
Activates the Sequencer.
INIT:SEQ:MODE SING
Sets single sequence mode so each active measurement is performed once.
INIT:SEQ:IMM
Starts the sequential measurements.

```

INITiate:SEQuencer:MODE <Mode>

Defines the capture mode for the entire measurement sequence and all measurement groups and channels it contains.

Note: To synchronize to the end of a measurement sequence using *OPC, *OPC? or *WAI, use SINGle Sequencer mode.

Parameters:

<Mode>

SINGle

Each measurement group is started one after the other in the order of definition. All measurement channels in a group are started simultaneously and performed once. After *all* measurements are completed, the next group is started. After the last group, the measurement sequence is finished.

CONTInuous

Each measurement group is started one after the other in the order of definition. All measurement channels in a group are started simultaneously and performed once. After *all* measurements are completed, the next group is started. After the last group, the measurement sequence restarts with the first one and continues until it is stopped explicitly.

*RST: CONTInuous

[SENSe:]CONFigure:CONTRol <Mode>

Selects the measurement mode for the "Level (Hot)" and "Level (Cold)" measurements.

Note that selecting a noise source with resistor characteristics with [SENSe:]CORRection:ENR:CALibration:TYPE or [SENSe:]CORRection:ENR[:MEASurement]:TYPE automatically selects manual measurement mode.

Parameters:

<Mode>

AUTO | MANual

AUTO

Performs the "Level (Hot)" and "Level (Cold)" measurement in one step.

MANual

Performs the "Level (Hot)" and "Level (Cold)" measurement in two separate steps.

Example: `CONF:CONT AUTO`
Selects the automatic measurement mode.

Manual operation: See "[Meas Mode \(Auto Manual\)](#)" on page 86

[SENSe:]CONFigure:MEASurement <Measurement>

Selects the type of power measurement to perform next.

The command is available for manual measurements (see [\[SENSe:\]CONFigure:CONTRol](#)).

Parameters:

<Measurement> `HOT | COLD`

COLD

Performs the "Level (Cold)" measurement next.

HOT

Performs the "Level (Hot)" measurement next.

Example: `CONF:CONT MAN`
 `CONF:MEAS HOT`
Performs the "Level (Hot)" measurement.

Manual operation: See "[Meas Mode \(Auto Manual\)](#)" on page 86

SYSTem:SEQuencer <State>

Turns the Sequencer on and off. The Sequencer must be active before any other Sequencer commands (`INIT:SEQ. . .`) are executed, otherwise an error occurs.

A detailed programming example is provided in the "Operating Modes" chapter in the R&S FSWP User Manual.

Parameters:

<State> `ON | OFF | 0 | 1`

ON | 1

The Sequencer is activated and a sequential measurement is started immediately.

OFF | 0

The Sequencer is deactivated. Any running sequential measurements are stopped. Further Sequencer commands (`INIT:SEQ. . .`) are not available.

*RST: `0`

Example:

```

SYST:SEQ ON
Activates the Sequencer.
INIT:SEQ:MODE SING
Sets single Sequencer mode so each active measurement is
performed once.
INIT:SEQ:IMM
Starts the sequential measurements.
SYST:SEQ OFF

```

7.15 Configuring the inputs and outputs

- [Radio frequency \(RF\) input](#)..... 182
- [External mixer](#)..... 183
- [External generator](#)..... 194

7.15.1 Radio frequency (RF) input

INPut:COUPling	182
INPut:IMPedance	182
INPut:FILTer:HPASs[:STATe]	183
INPut:FILTer:YIG[:STATe]	183

INPut:COUPling <CouplingType>

Selects the coupling type of the RF input.

Parameters:

<CouplingType> AC | DC

AC
AC coupling

DC
DC coupling

*RST: AC

Example: INP:COUP DC

Manual operation: See "[Input Coupling](#)" on page 87

INPut:IMPedance <Impedance>

Selects the nominal input impedance of the RF input. In some applications, only 50 Ω are supported.

Parameters:

<Impedance> 50 | 75

*RST: 50 Ω

Default unit: OHM

Example: INP:IMP 75

Manual operation: See "[Impedance](#)" on page 87

INPut:FILTer:HPASs[:STATe] <State>

Activates an additional internal high-pass filter for RF input signals from 1 GHz to 3 GHz. This filter is used to remove the harmonics of the R&S FSWP to measure the harmonics for a DUT, for example.

Requires an additional high-pass filter hardware option.

(Note: for RF input signals outside the specified range, the high-pass filter has no effect. For signals with a frequency of approximately 4 GHz upwards, the harmonics are suppressed sufficiently by the YIG-preselector, if available.)

Parameters:

<State> ON | OFF | 0 | 1
OFF | 0
 Switches the function off
ON | 1
 Switches the function on
 *RST: 0

Example: INP:FILT:HPAS ON
 Turns on the filter.

Manual operation: See "[High Pass Filter 1 to 3 GHz](#)" on page 87

INPut:FILTer:YIG[:STATe] <State>

Enables or disables the YIG filter.

Parameters:

<State> ON | OFF | 0 | 1
 *RST: 0

Example: INP:FILT:YIG OFF
 Deactivates the YIG-preselector.

Manual operation: See "[YIG-Preselector](#)" on page 87

7.15.2 External mixer

[SENSe:]CORRection:CVL:BAND.....	184
[SENSe:]CORRection:CVL:BIAS.....	184
[SENSe:]CORRection:CVL:CATalog?.....	185
[SENSe:]CORRection:CVL:CLEar.....	185
[SENSe:]CORRection:CVL:COMMent.....	185
[SENSe:]CORRection:CVL:DATA.....	186
[SENSe:]CORRection:CVL:HARMonic.....	186

[SENSe:]CORRection:CVL:MIXer.....	186
[SENSe:]CORRection:CVL:PORTs.....	187
[SENSe:]CORRection:CVL:SElect.....	187
[SENSe:]CORRection:CVL:SNUMber.....	187
[SENSe:]MIXer<x>:BIAS:HIGH.....	188
[SENSe:]MIXer<x>:BIAS[:LOW].....	188
[SENSe:]MIXer<x>:FREQUency:HANDover.....	188
[SENSe:]MIXer<x>:FREQUency:STARt.....	189
[SENSe:]MIXer<x>:FREQUency:STOP.....	189
[SENSe:]MIXer<x>:HARMonic:BAND:PRESet.....	189
[SENSe:]MIXer<x>:HARMonic:BAND.....	189
[SENSe:]MIXer<x>:HARMonic:HIGH[:VALue].....	190
[SENSe:]MIXer<x>:HARMonic:TYPE.....	190
[SENSe:]MIXer<x>:HARMonic[:LOW].....	191
[SENSe:]MIXer<x>:LOPower.....	191
[SENSe:]MIXer<x>:SIGNal.....	191
[SENSe:]MIXer<x>:LOSS:HIGH.....	192
[SENSe:]MIXer<x>:LOSS:TABLE:HIGH.....	192
[SENSe:]MIXer<x>:LOSS:TABLE[:LOW].....	192
[SENSe:]MIXer<x>:LOSS[:LOW].....	193
[SENSe:]MIXer<x>:PORTs.....	193
[SENSe:]MIXer<x>:RFOVerrange[:STATe].....	193
[SENSe:]MIXer<x>:THReshold.....	194
[SENSe:]MIXer<x>[:STATe].....	194

[SENSe:]CORRection:CVL:BAND <Band>

Defines the waveguide band for which the conversion loss table is to be used. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SElect on page 187).

Is only available with option B21 (External Mixer) installed.

Parameters:

<Band> K | KA | Q | U | V | E | W | F | D | G | Y | J | USER
 Standard waveguide band or user-defined band.
 For a definition of the frequency range for the pre-defined bands, see Table 7-4).
 *RST: F (90 GHz - 140 GHz)

Example:

```
CORR:CVL:SEL 'LOSS_TAB_4'
Selects the conversion loss table.
CORR:CVL:BAND KA
Sets the band to KA (26.5 GHz - 40 GHz).
```

[SENSe:]CORRection:CVL:BIAS <BiasSetting>

Defines the bias setting to be used with the conversion loss table.

Example:

```
CORR:CVL:SEL 'LOSS_TAB_4'
Selects the conversion loss table.
CORR:CVL:COMM 'Conversion loss table for
FS_Z60'
```

[SENSe:]CORRection:CVL:DATA {<Freq>, <Level>}...

Defines the reference values of the selected conversion loss tables. The values are entered as a set of frequency/level pairs. You can define a maximum of 500 frequency/level pairs. Before this command can be performed, you must select the conversion loss table (see [SENSe:]CORRection:CVL:SELEct on page 187).

Is only available with option B21 (External Mixer) installed.

Parameters:

<Freq> The frequencies have to be sent in ascending order.
 Default unit: HZ

<Level> Default unit: DB

Example:

```
CORR:CVL:SEL 'LOSS_TAB_4'
Selects the conversion loss table.
CORR:CVL:DATA 1MHZ,-30DB,2MHZ,-40DB
```

[SENSe:]CORRection:CVL:HARMonic <HarmOrder>

Defines the harmonic order for which the conversion loss table is to be used. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELEct on page 187).

Is only available with option B21 (External Mixer) installed.

Parameters:

<HarmOrder> Range: 2 to 65

Example:

```
CORR:CVL:SEL 'LOSS_TAB_4'
Selects the conversion loss table.
CORR:CVL:HARM 3
```

[SENSe:]CORRection:CVL:MIXer <Type>

Defines the mixer name in the conversion loss table. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELEct on page 187).

Is only available with option B21 (External Mixer) installed.

Parameters:

<Type> string
Name of mixer with a maximum of 16 characters

Example:

```
CORR:CVL:SEL 'LOSS_TAB_4'
Selects the conversion loss table.
CORR:CVL:MIX 'FS_Z60'
```

[SENSe:]CORRection:CVL:PORTs <PortType>

Defines the mixer type in the conversion loss table. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [\[SENSe:\]CORRection:CVL:SElect](#) on page 187).

Is only available with option B21 (External Mixer) installed.

Parameters:

<PortType> 2 | 3
*RST: 2

Example:

```
CORR:CVL:SEL 'LOSS_TAB_4'
Selects the conversion loss table.
CORR:CVL:PORT 3
```

[SENSe:]CORRection:CVL:SElect <FileName>

Selects the conversion loss table with the specified file name. If <file_name> is not available, a new conversion loss table is created.

Is only available with option B21 (External Mixer) installed.

Parameters:

<FileName> String containing the path and name of the file.

Example:

```
CORR:CVL:SEL 'LOSS_TAB_4'
```

[SENSe:]CORRection:CVL:SNUMber <SerialNo>

Defines the serial number of the mixer for which the conversion loss table is to be used. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [\[SENSe:\]CORRection:CVL:SElect](#) on page 187).

Is only available with option B21 (External Mixer) installed.

Parameters:

<SerialNo> Serial number with a maximum of 16 characters

Example: CORR:CVL:SEL 'LOSS_TAB_4'
 Selects the conversion loss table.
 CORR:CVL:MIX '123.4567'

[SENSe:]MIXer<x>:BIAS:HIGH <BiasSetting>

Defines the bias current for the high (last) range.

Is only available if the external mixer is active (see [SENSe:]MIXer<x>[:STATe] on page 194).

Suffix:

<x> 1..n
 irrelevant

Parameters:

<BiasSetting> *RST: 0.0 A
 Default unit: A

[SENSe:]MIXer<x>:BIAS[:LOW] <BiasSetting>

Defines the bias current for the low (first) range.

Is only available if the external mixer is active (see [SENSe:]MIXer<x>[:STATe] on page 194).

Suffix:

<x> 1..n
 irrelevant

Parameters:

<BiasSetting> *RST: 0.0 A
 Default unit: A

[SENSe:]MIXer<x>:FREQuency:HANdOver <Frequency>

Defines the frequency at which the mixer switches from one range to the next (if two different ranges are selected). The handover frequency for each band can be selected freely within the overlapping frequency range.

Is only available if the external mixer is active (see [SENSe:]MIXer<x>[:STATe] on page 194).

Suffix:

<x> 1..n
 irrelevant

Parameters:

<Frequency> Default unit: HZ

Example: MIX ON
 Activates the external mixer.
 MIX:FREQ:HAND 78.0299GHz
 Sets the handover frequency to 78.0299 GHz.

[SENSe:]MIXer<x>:FREQuency:STARt

Sets or queries the frequency at which the external mixer band starts.

Suffix:

<x> 1..n
 irrelevant

Example: MIX:FREQ:STAR?
 Queries the start frequency of the band.

[SENSe:]MIXer<x>:FREQuency:STOP

Sets or queries the frequency at which the external mixer band stops.

Suffix:

<x> 1..n
 irrelevant

Example: MIX:FREQ:STOP?
 Queries the stop frequency of the band.

[SENSe:]MIXer<x>:HARMonic:BAND:PRESet

Restores the preset frequency ranges for the selected standard waveguide band.

Note: Changes to the band and mixer settings are maintained even after using the [PRESET] function. Use this command to restore the predefined band ranges.

Suffix:

<x> 1..n
 irrelevant

Example: MIX:HARM:BAND:PRES
 Presets the selected waveguide band.

[SENSe:]MIXer<x>:HARMonic:BAND <Band>

Selects the external mixer band. The query returns the currently selected band.

Is only available if the external mixer is active (see [SENSe:]MIXer<x>[:STATe] on page 194).

Suffix:

<x> 1..n
 irrelevant

Parameters:

<Band> KA | Q | U | V | E | W | F | D | G | Y | J | USER
 Standard waveguide band or user-defined band.

Table 7-4: Frequency ranges for pre-defined bands

Band	Frequency start [GHz]	Frequency stop [GHz]
KA (A) *)	26.5	40.0
Q	33.0	50.0
U	40.0	60.0
V	50.0	75.0
E	60.0	90.0
W	75.0	110.0
F	90.0	140.0
D	110.0	170.0
G	140.0	220.0
J	220.0	325.0
Y	325.0	500.0
USER	32.18 (default)	68.22 (default)

*) The band formerly referred to as "A" is now named "KA".

[SENSe:]MIXer<x>:HARMonic:HIGH[:VALue] <HarmOrder>

Specifies the harmonic order to be used for the high (second) range.

Suffix:

<x> 1..n
 irrelevant

Parameters:

<HarmOrder> Range: 2 to 61 (USER band); for other bands: see band definition

Example:

```
MIX:HARM:HIGH:STAT ON
MIX:HARM:HIGH 3
```

[SENSe:]MIXer<x>:HARMonic:TYPE <OddEven>

Specifies whether the harmonic order to be used should be odd, even, or both.

Which harmonics are supported depends on the mixer type.

Suffix:

<x> 1..n
 irrelevant

OFF

No automatic signal detection is active.

ON

Automatic signal detection (Signal ID) is active.

AUTO

Automatic signal detection (Auto ID) is active.

ALL

Both automatic signal detection functions (Signal ID+Auto ID) are active.

*RST: OFF

[SENSe:]MIXer<x>:LOSS:HIGH <Average>

Defines the average conversion loss to be used for the entire high (second) range.

Suffix:

<x> 1..n
Mixer

Parameters:

<Average> Range: 0 to 100
*RST: 24.0 dB
Default unit: dB

Example: MIX:LOSS:HIGH 20dB

[SENSe:]MIXer<x>:LOSS:TABLE:HIGH <FileName>

Defines the conversion loss table to be used for the high (second) range.

Suffix:

<x> 1..n
Mixer

Parameters:

<FileName> String containing the path and name of the file, or the serial number of the external mixer whose file is required. The R&S FSWP automatically selects the correct cvl file for the current IF. As an alternative, you can also select a user-defined conversion loss table (.acl file).

[SENSe:]MIXer<x>:LOSS:TABLE[:LOW] <FileName>

Defines the file name of the conversion loss table to be used for the low (first) range.

Suffix:

<x> 1..n
Mixer

Parameters:

<FileName> String containing the path and name of the file, or the serial number of the external mixer whose file is required. The R&S FSWP automatically selects the correct cvl file for the current IF. As an alternative, you can also select a user-defined conversion loss table (.ac1 file).

Example:

```
MIX:LOSS:TABL '101567'
MIX:LOSS:TABL?
//Result:
'101567_MAG_6_B5000_3G5.B5G'
```

[SENSe:]MIXer<x>:LOSS[:LOW] <Average>

Defines the average conversion loss to be used for the entire low (first) range.

Suffix:

<x> 1..n
Mixer

Parameters:

<Average> Range: 0 to 100
*RST: 24.0 dB
Default unit: dB

Example:

```
MIX:LOSS 20dB
```

[SENSe:]MIXer<x>:PORTs <PortType>

Selects the mixer type.

Suffix:

<x> 1..n
irrelevant

Parameters:

<PortType> **2 | 3**
2
Two-port mixer.
3
Three-port mixer.
*RST: 2

Example:

```
MIX:PORT 3
```

[SENSe:]MIXer<x>:RFOVerrange[:STATe] <State>

If enabled, the band limits are extended beyond "RF Start" and "RF Stop" due to the capabilities of the used harmonics.

Suffix:

<x> 1..n
irrelevant

Parameters:

<State> ON | OFF | 1 | 0
*RST: 0

[SENSe:]MIXer<x>:THReshold <Value>

Defines the maximum permissible level difference between test sweep and reference sweep to be corrected during automatic comparison (see [\[SENSe:\]MIXer<x>:SIGNal](#) on page 191).

Suffix:

<x> 1..n
irrelevant

Parameters:

<Value> <numeric value>
Range: 0.1 dB to 100 dB
*RST: 10 dB
Default unit: DB

Example: MIX:PORT 3

[SENSe:]MIXer<x>[:STATe] <State>

Activates or deactivates the use of a connected external mixer as input for the measurement. This command is only available if the optional External Mixer is installed and an external mixer is connected.

Suffix:

<x> 1..n
irrelevant

Parameters:

<State> ON | OFF | 1 | 0
*RST: 0

Example: MIX ON

7.15.3 External generator

SOURce:EXTernal:FREQUency[:FACTor]:DENominator	195
SOURce:EXTernal:FREQUency[:FACTor]:NUMerator	195
SOURce:EXTernal:FREQUency:OFFSet<of>	195
SOURce<si>:EXTernal<gen>:POWER[:LEVel]	195
SOURce<si>:EXTernal<gen>:ROSCillator[:SOURce]	195
SYSTem:COMMunicate:RDEVice:GENerator<gen>:INTerface	196
SYSTem:COMMunicate:GPIB:RDEVice:GENerator<gen>:ADDRes	196

SYSTem:COMMunicate:RDEvice:GENerator<gen>:TYPE.....	196
SYSTem:COMMunicate:TCPip:RDEvice:GENerator<gen>:ADDRess.....	197
SYSTem:CONFigure:GENerator:CONTRol:STATe.....	197
SYSTem:CONFigure:GENerator:INITialise:AUTO.....	197
SYSTem:CONFigure:GENerator:INITialise[:IMMediate].....	198
SYSTem:CONFigure:GENerator:SWITCh:AUTO.....	198

SOURce:EXTernal:FREQUENCY[:FACTor]:DENominator <Denominator>

SOURce:EXTernal:FREQUENCY[:FACTor]:NUMerator <Numerator>

SOURce:EXTernal:FREQUENCY:OFFSet<of> <Denominator>

Suffix:

<of> 1..n

Parameters:

<Denominator> Default unit: HZ

Manual operation: See "[Frequency Coupling](#)" on page 91

SOURce<si>:EXTernal<gen>:POWER[:LEVel] <Level>

Sets the output power of the selected generator.

Suffix:

<si> irrelevant

<gen>

Parameters:

<Level> <numeric value>
 *RST: -20 dBm
 Default unit: DBM

Example: //Define generator output level
 SOUR:EXT:POW -30dBm

Manual operation: See "[Source Power](#)" on page 91

SOURce<si>:EXTernal<gen>:ROSCillator[:SOURce] <Source>

Controls selection of the reference oscillator for the external generator.

If the external reference oscillator is selected, the reference signal must be connected to the rear panel of the instrument.

Suffix:

<si> irrelevant

<gen> irrelevant

Parameters:

<Source> **INTERNAL**
 Uses the internal reference.

EXTernal

Uses the external reference; if none is available, an error flag is displayed in the status bar.

*RST: INT

Example: //Select an external reference oscillator
SOUR:EXT:ROSC EXT

Manual operation: See ["Reference"](#) on page 89

SYSTem:COMMunicate:RDEvice:GENerator<gen>:INTerface <Type>

Defines the interface used for the connection to the external generator.

Suffix:

<gen>

Parameters:

<Type> **GPIB**
TCPIP

Example: SYST:COMM:RDEV:GEN:INT TCP

Manual operation: See ["Interface"](#) on page 89

SYSTem:COMMunicate:GPIB:RDEvice:GENerator<gen>:ADDRess <Number>

Changes the IEC/IEEE-bus address of the external generator.

Suffix:

<gen> 1..n

Parameters:

<Number> Range: 0 to 30
*RST: 28

Example: SYST:COMM:GPIB:RDEV:GEN:ADDR 15

Manual operation: See ["GPIB Address/TCPIP Address / Computer Name"](#) on page 89

SYSTem:COMMunicate:RDEvice:GENerator<gen>:TYPE <Type>

Selects the type of external generator.

For a list of the available generator types, see the specifications document.

Suffix:

<gen>

Parameters:

<Name> <Generator name as string value>
*RST: SMU02

Example: //Select an external generator
 SYST:COMM:RDEV:GEN:TYPE 'SMW06'

Manual operation: See ["Generator Type"](#) on page 88

SYSTem:COMMunicate:TCPIp:RDEvice:GENerator<gen>:ADDRess <Address>

Configures the TCP/IP address for the external generator.

Suffix:
 <gen>

Parameters:
 <Address> TCP/IP address between 0.0.0.0 and 0.255.255.255
 *RST: 0.0.0.0

Example: SYST:COMM:TCP:RDEV:GEN:ADDR 130.094.122.195

Manual operation: See ["GPIB Address/TCP/IP Address / Computer Name"](#) on page 89

SYSTem:CONFigure:GENerator:CONTRol:STATe <State>

Turns automatic control of an external generator on and off.

The command is available with option R&S FSWP-B10.

Parameters:
 <State> ON | OFF | 1 | 0
 *RST: 0

Example: SYST:CONF:GEN:CONT:STAT ON
 Turns on automatic generator control.

Manual operation: See ["Automatic Control"](#) on page 90

SYSTem:CONFigure:GENerator:INITialise:AUTO <State>

Turns automatic connection to the generator on and off.

If on, the application automatically configures the generator before each measurement and turns on its RF output. Note that you have to establish a connection to the generator before you can perform the measurement.

The command is available with option R&S FSWP-B10.

Parameters:
 <State> ON | OFF | 1 | 0
 *RST: 0

Example: SYST:CONF:GEN:INIT:AUTO ON
 Turns automatic generator configuration on.

Manual operation: See ["Init Before Meas"](#) on page 90

SYSTem:CONFIgure:GENerator:INITialise[:IMMEdiate]

Establishes a connection to the external generator.

When you send the command, the application configures the generator once and turns on its RF output. Note that you have to establish a connection to the generator before you can perform the measurement.

The command is available with option R&S FSWP-B10.

Usage: Event

Manual operation: See ["Init External Generator"](#) on page 92

SYSTem:CONFIgure:GENerator:SWITCh:AUTO <State>

Parameters:
<State>

Manual operation: See ["Auto Switch Off"](#) on page 91

7.16 Configuring the display

The following commands are necessary to configure and scale the result displays.

DISPlay[:WINDow<n>]:TABLe:ITEM	198
DISPlay[:WINDow<n>]:TRACe<t>:SYMBols	199
DISPlay[:WINDow<n>]:TRACe<t>:UNCertainty	199
DISPlay[:WINDow<n>]:TRACe<t>:X[:SCALe]	199
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:BOTTom	200
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO	200
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:TOP	201

DISPlay[:WINDow<n>]:TABLe:ITEM <Items>, <State>

Selects the items displayed in the Result Table.

Suffix:

<n> 1..n
[Window](#)

Parameters:

<Items> NOISe | GAIN | TEMPerature | YFACTOR | ENR | PHOT |
PCOLd | CYFactor | CPHot | CPCold | DPHot | DPCold |
NUNCertainty
For a list of possible parameter values (table items) see the
parameter description of the [TRACe<n> \[:DATA\] ?](#) command.

<State> ON | OFF | 1 | 0

Example:

DISP:WIND2:TABL:ITEM NOIS,OFF
Removes the "Noise" result from the "Result Table".

Manual operation: See ["Result Table"](#) on page 26

DISPlay[:WINDow<n>]:TRACe<t>:SYMBOLs <State>

Turns symbols that represent the measurement points on a trace on and off.

Suffix:

<n> 1..n
[Window](#)

<t> 1..n

Parameters:

<State> ON | OFF | 1 | 0
*RST: 0

Example: DISP:WIND2:TRAC:SYMB ON
Switches on the display of symbols in window 2..

Manual operation: See ["Symbols"](#) on page 95

DISPlay[:WINDow<n>]:TRACe<t>:UNCertainty <State>

If enabled, an additional trace is displayed indicating the measured trace values \pm the uncertainty values determined by the uncertainty calculator. This result is only useful for "noise figure" measurements.

Suffix:

<n> 1..n
[Window](#)

<t> 1..n
[Trace](#)

Parameters:

<State> ON | OFF | 0 | 1
OFF | 0
Switches the function off
ON | 1
Switches the function on
*RST: 0

Example: DISP:WIND:TRAC:UNC ON

Manual operation: See ["Uncertainty"](#) on page 95

DISPlay[:WINDow<n>]:TRACe<t>:X[:SCALE] <Frequency>

Selects the type of frequency displayed on the x-axis.

Suffix:

<n> 1..n
[Window](#)

<t> 1..n

Parameters:

<Frequency>

RF | IF | LO

IF

Intermediary frequency, e.g. for measurements on frequency converting DUTs.

RF

Radio frequency.

*RST: RF

Example:

CONF:MODE:DUT DOWN

The DUT converts the input frequency to a lower output frequency.

DISP:TRAC:X RF

Shows the RF frequency on the x-axis.

Manual operation: See "[X-Axis](#)" on page 95

DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:BOTTom <Level>

Defines the bottom value of the y-axis.

Suffix:

<n> 1..n
[Window](#)

<t> 1..n
[Trace](#)

Parameters:

<Level>

The value ranges depend on the result display.

Noise figure, Gain

-75 dB to 75 dB

Temperature

-999990000 K to 999990000 K

all others

-200 dB to 200 dB

Default unit: DB

Example:

DISP:WIND2:TRAC:Y:SCAL:AUTO OFF

DISP:WIND2:TRAC:Y:BOT

Manual operation: See "[Auto Scale / Min / Max](#)" on page 94

DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO <State>

Turns automatic scaling of the y-axis on and off.

Suffix:

<n> 1..n
[Window](#)

<t> 1..n

Parameters:

<State> ON | OFF | 1 | 0
*RST: 1

Example: DISP:WIND2:TRAC:Y:AUTO ON
Turns on automatic scaling for measurement window 2.

Manual operation: See "Auto Scale / Min / Max" on page 94

DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:TOP <Level>

Defines the top value of the y-axis.

Suffix:

<n> 1..n
Window

<t> 1..n
Trace

Parameters:

<Level> The value ranges depend on the result display.

Noise figure, Gain

-75 dB to 75 dB

Temperature

-999990000 K to 999990000 K

all others

-200 dB to 200 dB

Default unit: DB

Example: DISP:WIND2:TRAC:Y:SCAL:AUTO OFF
DISP:WIND2:TRAC:Y:TOP

Manual operation: See "Auto Scale / Min / Max" on page 94

7.17 Working with traces

The following commands are necessary to define trace characteristics.

DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:MODE.....	202
DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>[:STATe].....	202
DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:SMOothing:APERture.....	203
DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:SMOothing[:STATe].....	203
FORMat[:DATA].....	203
FORMat:DEXPort:DSEParator.....	204
FORMat:DEXPort:FORMat.....	205
FORMat:DEXPort:HEADer.....	205

FORMat:DEXPort:TRACes.....	205
MMEMory:STORe<n>:TRACe.....	205
TRACe<n>:COPY.....	206

DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:MODE <Mode>

Selects the trace mode. If necessary, the selected trace is also activated.

Suffix:

<n>	Window
<w>	subwindow Not supported by all applications
<t>	Trace

Parameters:

<Mode>	BLANK VIEW WRITe *RST: Trace 1: WRITe, Trace 2-4: BLANK
--------	--

Example:

```
INIT:CONT OFF
Switching to single sweep mode.
SWE:COUN 16
Sets the number of measurements to 16.
DISP:TRAC3:MODE WRIT
Selects clear/write mode for trace 3.
INIT;*WAI
Starts the measurement and waits for the end of the measurement.
```

Manual operation: See "Traces" on page 97

DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>[:STATe] <State>

Turns a trace on and off.

The measurement continues in the background.

Suffix:

<n>	Window
<w>	subwindow Not supported by all applications
<t>	Trace

Parameters:

<State>	ON OFF 0 1 OFF 0 Switches the function off ON 1 Switches the function on
---------	--

Example:

```
DISP:TRAC3 ON
```

DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:SMOothing:APERture
 <Aperture>

Defines the degree (aperture) of the trace smoothing, if [DISPlay\[:WINDow<n>\]\[:SUBWindow<w>\]:TRACe<t>:SMOothing\[:STATe\] TRUE](#).

Suffix:

<n> [Window](#)
 <w> subwindow
 <t> [Trace](#)

Parameters:

<Aperture> Range: 1 to 50
 *RST: 2
 Default unit: PCT

Example:

DISP3:TRAC2:SMO:APER 5
 Defines an aperture of 5% for trace 2 in window 3

Manual operation: See "[Smoothing](#)" on page 97

DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:SMOothing[:STATe] <State>

Turns trace smoothing for a particular trace on and off.

If enabled, the trace is smoothed by the value specified using [DISPlay\[:WINDow<n>\]\[:SUBWindow<w>\]:TRACe<t>:SMOothing:APERture](#) on page 203.

Suffix:

<n> [Window](#)
 <w> subwindow
 <t> [Trace](#)

Parameters:

<State> ON | OFF | 0 | 1
 OFF | 0
 Switches the function off
 ON | 1
 Switches the function on

Example:

DISP3:TRAC2:SMO ON
 Turns on trace smoothing for trace 2 in window 3

Manual operation: See "[Smoothing](#)" on page 97

FORMat[:DATA] <Format>[, <BitLength>]

Selects the data format that is used for transmission of trace data from the R&S FSWP to the controlling computer.

Note that the command has no effect for data that you send to the R&S FSWP. The R&S FSWP automatically recognizes the data it receives, regardless of the format.

Parameters:

<Format>

ASCIi

ASCIi format, separated by commas.

This format is almost always suitable, regardless of the actual data format. However, the data is not as compact as other formats can be.

REAL

Floating-point numbers (according to IEEE 754) in the "definite length block format".

The format setting `REAL` is used for the binary transmission of trace data.

<BitLength>

Length in bits for floating-point results

16

16-bit floating-point numbers.

Compared to `REAL, 32` format, half as many numbers are returned.

32

32-bit floating-point numbers

For I/Q data, 8 bytes per sample are returned for this format setting.

64

64-bit floating-point numbers

Compared to `REAL, 32` format, twice as many numbers are returned.

Example:

```
FORM REAL, 32
```

FORMat:DEXPort:DSEParator <Separator>

Selects the decimal separator for data exported in ASCII format.

Parameters:

<Separator>

POINT | COMMa

COMMa

Uses a comma as decimal separator, e.g. *4,05*.

POINT

Uses a point as decimal separator, e.g. *4.05*.

*RST: *RST has no effect on the decimal separator.
Default is POINT.

Example:

```
FORM:DEXP:DSEP POIN
```

Sets the decimal point as separator.

Manual operation:

See "[Decimal Separator](#)" on page 99

FORMat:DEXPort:FORMat <FileFormat>

Determines the format of the ASCII file to be imported or exported. Depending on the external program that creates the data file or evaluates it, a comma-separated list (CSV) or a plain data format (DAT) file is required.

Parameters:

<FileFormat> CSV | DAT
 *RST: DAT

Example: FORM:DEXP:FORM CSV

Manual operation: See ["File Type"](#) on page 100

FORMat:DEXPort:HEADer <State>

If enabled, additional instrument and measurement settings are included in the header of the export file for result data. If disabled, only the pure result data from the selected traces and tables is exported.

Parameters:

<State> ON | OFF | 0 | 1
 *RST: 1

Manual operation: See ["Include Instrument & Measurement Settings"](#) on page 99

FORMat:DEXPort:TRACes <Selection>

Selects the data to be included in a data export file (see [MMEMory:STORe<n>:TRACe](#) on page 205).

Parameters:

<Selection> SINGle | ALL

SINGle

Only a single trace is selected for export, namely the one specified by the [MMEMory:STORe<n>:TRACe](#) command.

ALL

Selects all active traces and result tables (e.g. "Result Summary", marker peak list etc.) in the current application for export to an ASCII file.

The <trace> parameter for the [MMEMory:STORe<n>:TRACe](#) command is ignored.

*RST: SINGle

Manual operation: See ["Export all Traces and all Table Results"](#) on page 99

MMEMory:STORe<n>:TRACe <Trace>, <FileName>

Exports trace data from the specified window to an ASCII file.

Secure User Mode

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see "Protecting Data Using the Secure User Mode" in the "Data Management" section of the R&S FSWP base unit user manual.

Suffix:

<n> [Window](#)

Parameters:

<Trace> Number of the trace to be stored

<FileName> String containing the path and name of the target file.

Example:

```
MMEM:STOR1:TRAC 1, 'C:\TEST.ASC'
```

Stores trace 1 from window 1 in the file TEST.ASC.

Manual operation: See ["Export Trace to ASCII File"](#) on page 99
See ["Export Trace to ASCII File"](#) on page 101

TRACe<n>:COPY <TraceNumber>, <TraceNumber>

Copies data from one trace to another.

Suffix:

<n> [Window](#)

Parameters:

<TraceNumber> **TRACE1 | TRACE2 | TRACE3 | TRACE4**
The first parameter is the destination trace, the second parameter is the source.
(Note the 'e' in the parameter is required!)

Example:

```
TRAC:COPY TRACE1, TRACE2
```

Copies the data from trace 2 to trace 1.

Manual operation: See ["Copy Trace"](#) on page 98

7.18 Working with limit lines

The following commands are necessary to set up limit lines and checks.

When configuring limit lines for the "noise figure" application via remote control, you have to send some commands in a defined order.

1. Select the limit line you want to configure by name or create a new limit line name.
2. Select the result type you want to apply the limit line to.

The application automatically selects the unit and scale to make the line compatible to the result type.

3. Define the horizontal data points of the limit line.
4. Define the vertical data points of the limit line. Depending on the command syntax you are using, the shape also defines if the limit line is an upper or lower limit line (CALCulate:LIMit:UPPer:... or CALCulate:LIMit:LOWer:...).

Example: Configure an upper limit line for the Noise Figure result type

```
//Select or create the limit line by name.
CALC:LIM:NAME 'NoiseFigure'
//Comment on the limit line.
CALC:LIM:COMM 'Limit line to test noise figure results'
//Select the result type (here: Noise Figure) to apply the limit line to.
CALC:LIM:TYPE NOIS
//Define the horizontal data points of the limit line.
CALC:LIM:CONT 100MHZ,850MHZ
//Shift the limit line 50 MHz to the left.
CALC:LIM:CONT:SHIF -50MHZ
//Define the vertical data points of an (upper) limit line.
//The unit is fix according to the result type you have selected.
CALC:LIM:UPP 10,10
//Shift the limit line 5 dB down.
CALC:LIM:UPP:SHIF -5
//Turn the limit line on.
CALC:LIM:UPP:STAT ON
//Select the trace to check.
CALC:LIM:TRAC 1
//Turn on the limit check.
CALC:LIM:STAT ON
//Query the limit check results.
CALC:LIM:FAIL?
```

- [Defining general characteristics of a limit line](#).....207
- [Defining horizontal data points](#).....209
- [Controlling lower limit lines](#).....210
- [Controlling upper limit lines](#).....211
- [Managing limit lines](#).....212
- [Controlling limit checks](#).....213

7.18.1 Defining general characteristics of a limit line

CALCulate<n>:LIMit:COMMENT	208
CALCulate<n>:LIMit:NAME	208
CALCulate<n>:LIMit:TYPE	208

CALCulate<n>:LIMit:COMMeNt <Comment>

Defines a comment for a limit line.

Suffix:

<n> irrelevant

 [Limit line](#)

Parameters:

<Comment> String containing the description of the limit line.

Manual operation: See "[Comment](#)" on page 109

CALCulate<n>:LIMit:NAME <Name>

Selects a limit line that already exists or defines a name for a new limit line.

Suffix:

<n> [Window](#)

 [Limit line](#)

Parameters:

<Name> String containing the limit line name.

*RST: REM1 to REM8 for lines 1 to 8

Manual operation: See "[Name](#)" on page 109

CALCulate<n>:LIMit:TYPE <Result>

Configures a limit line for a particular result type.

Suffix:

<n> 1..n

 1..n
[Limit line](#)

Parameters:

<Result> NOISe | GAIN | TEMPerature | YFACTOR | ENR | PHOT | PCOLd

GAIN

Assigns the limit line to "Gain" results.

NOISe

Assigns the limit line to "Noise Figure" results.

PCOLd

Assigns the limit line to "Level (cold)" results.

PHOT

Assigns the limit line to "Level (hot)" results.

TEMPerature

Assigns the limit line to "Temperature" results.

YFACTOR

Assigns the limit line to "Y-Factor" results.

Example: `CALC:LIM2:TYPE GAIN`
 Assigns limit line 2 to the "gain" result display.

7.18.2 Defining horizontal data points

Note that the number of data points on the horizontal axis should be the same as the number of data points on the vertical axis. Otherwise the limit line may take on an unintended shape.

Example: Number of vertical data points < number of horizontal data points

```
CALC:LIM:CONT 100MHZ,200MHZ,300MHZ,400MHZ,500MHZ
```

```
CALC:LIM:UPP 0,5,0
```

⇒ the application dumps 400 and 500 MHz.

Example: Number of vertical data points > number of horizontal data points

```
CALC:LIM:CONT 100MHZ,200MHZ,300MHZ,400MHZ,500MHZ
```

```
CALC:LIM:UPP 0,5,0,5,0,5,0
```

⇒ the application adds new horizontal data points (500.00000100 MHz and 500.00000200 MHz).

[CALCulate<n>:LIMit:CONTrol\[:DATA\]](#)..... 209

[CALCulate<n>:LIMit:CONTrol:SHIFt](#)..... 209

CALCulate<n>:LIMit:CONTrol[:DATA] <LimitLinePoints>...

Defines the horizontal definition points of a limit line.

Suffix:

<n> irrelevant

 [Limit line](#)

Parameters:

<LimitLinePoints> Variable number of x-axis values.

Note that the number of horizontal values has to be the same as the number of vertical values set with [CALCulate<n>:](#)

[LIMit:LOWer\[:DATA\]](#) or [CALCulate<n>:LIMit:UPPPer\[:DATA\]](#). If not, the R&S FSWP either adds missing values or ignores surplus values.

*RST: -

Default unit: HZ

Manual operation: See "[Data Points](#)" on page 110

CALCulate<n>:LIMit:CONTrol:SHIFt <Distance>

Moves a complete limit line horizontally.

Compared to defining an offset, this command actually changes the limit line definition points by the value you define.

Suffix:

<n> irrelevant

 [Limit line](#)

Parameters:

<Distance> Numeric value.
The unit depends on the scale of the x-axis.
Default unit: HZ

Manual operation: See "[Shift x](#)" on page 110

7.18.3 Controlling lower limit lines

CALCulate<n>:LIMit:LOWer[:DATA]	210
CALCulate<n>:LIMit:LOWer:SHIFt	210
CALCulate<n>:LIMit:LOWer:STATe	211

CALCulate<n>:LIMit:LOWer[:DATA] <LimitLinePoints>...

Defines the vertical definition points of a lower limit line.

Suffix:

<n> irrelevant

 [Limit line](#)

Parameters:

<LimitLinePoints> Variable number of level values.
Note that the number of vertical values has to be the same as the number of horizontal values set with [CALCulate<n>:LIMit:CONTRol\[:DATA\]](#). If not, the R&S FSWP either adds missing values or ignores surplus values.
*RST: Limit line state is OFF
Default unit: DBM

Manual operation: See "[Data Points](#)" on page 110

CALCulate<n>:LIMit:LOWer:SHIFt <Distance>

Moves a complete lower limit line vertically.

Compared to defining an offset, this command actually changes the limit line definition points by the value you define.

Suffix:

<n> [Window](#)

 [Limit line](#)

Parameters:

<Distance> Defines the distance that the limit line moves.
Default unit: DB

Manual operation: See "Shift y" on page 110

CALCulate<n>:LIMit:LOWer:STATe <State>

Turns a lower limit line on and off.

Before you can use the command, you have to select a limit line with [CALCulate<n>:LIMit:NAME](#) on page 208.

Suffix:

<n> irrelevant
 [Limit line](#)

Parameters:

<State> ON | OFF | 0 | 1
OFF | 0
Switches the function off
ON | 1
Switches the function on

Manual operation: See "Visibility" on page 107

7.18.4 Controlling upper limit lines

CALCulate<n>:LIMit:UPPer[:DATA]	211
CALCulate<n>:LIMit:UPPer:SHIFt	212
CALCulate<n>:LIMit:UPPer:STATe	212

CALCulate<n>:LIMit:UPPer[:DATA] <LimitLinePoints>...

Defines the vertical definition points of an upper limit line.

Suffix:

<n> irrelevant
 [Limit line](#)

Parameters:

<LimitLinePoints> Variable number of level values.
Note that the number of vertical values has to be the same as the number of horizontal values set with [CALCulate<n>:LIMit:CONTRol\[:DATA\]](#). If not, the R&S FSWP either adds missing values or ignores surplus values.
*RST: Limit line state is OFF
Default unit: DBM

Manual operation: See "Data Points" on page 110

CALCulate<n>:LIMit:UPPer:SHIFt <Distance>

Moves a complete upper limit line vertically.

Compared to defining an offset, this command actually changes the limit line definition points by the value you define.

Suffix:

<n> irrelevant

 [Limit line](#)

Parameters:

<Distance> Defines the distance that the limit line moves.

Manual operation: See "[Shift y](#)" on page 110

CALCulate<n>:LIMit:UPPer:STATe <State>

Turns an upper limit line on and off.

Before you can use the command, you have to select a limit line with [CALCulate<n>:LIMit:NAME](#) on page 208.

Suffix:

<n> irrelevant

 [Limit line](#)

Parameters:

<State> ON | OFF | 0 | 1

OFF | 0

Switches the function off

ON | 1

Switches the function on

Manual operation: See "[Visibility](#)" on page 107

7.18.5 Managing limit lines

CALCulate<n>:LIMit:ACTive?	212
CALCulate<n>:LIMit:COPY	213
CALCulate<n>:LIMit:DELeTe	213

CALCulate<n>:LIMit:ACTive?

Queries the names of *all* active limit lines.

Suffix:

<n> irrelevant

 irrelevant

Return values:

<LimitLines> String containing the names of all active limit lines in alphabetical order.

Example:

CALC:LIM:ACT?

Queries the names of all active limit lines.

Usage:

Query only

Manual operation: See "[Visibility](#)" on page 107

CALCulate<n>:LIMit:COPY <Line>

Copies a limit line.

Suffix:

<n> [Window](#)

 [Limit line](#)

Parameters:

<Line> **1 to 8**
number of the new limit line

<name>

String containing the name of the limit line.

Example:

CALC:LIM1:COPY 2

Copies limit line 1 to line 2.

CALC:LIM1:COPY 'FM2'

Copies limit line 1 to a new line named FM2.

Manual operation: See "[Copy Line](#)" on page 108

CALCulate<n>:LIMit:DELeTe

Deletes a limit line.

Suffix:

<n> [Window](#)

 [Limit line](#)

Manual operation: See "[Delete Line](#)" on page 108

7.18.6 Controlling limit checks

CALCulate<n>:LIMit:CLEar[:IMMEDIATE]	214
CALCulate<n>:LIMit:FAIL?	214
CALCulate<n>:LIMit:STATe	214
CALCulate<n>:LIMit:TRACe<t>	215
CALCulate<n>:LIMit:TRACe<t>:CHECK	215

CALCulate<n>:LIMit:CLEar[:IMMEDIATE]

Deletes the result of the current limit check.

The command works on *all* limit lines in *all* measurement windows at the same time.

Suffix:

<n> [Window](#)

 irrelevant

Example:

`CALC:LIM:CLE`

Deletes the result of the limit check.

CALCulate<n>:LIMit:FAIL?

Queries the result of a limit check in the specified window.

To get a valid result, you have to perform a complete measurement with synchronization to the end of the measurement before reading out the result. This is only possible for single measurement mode.

Suffix:

<n> [Window](#)

 [Limit line](#)

Return values:

<Result> **0**
 PASS
 1
 FAIL

Example:

`INIT;*WAI`

Starts a new sweep and waits for its end.

`CALC2:LIM3:FAIL?`

Queries the result of the check for limit line 3 in window 2.

Usage:

Query only

CALCulate<n>:LIMit:STAtE <State>

Turns the limit check for a specific limit line on and off.

To query the limit check result, use [CALCulate<n>:LIMit:FAIL?](#).

Note that a new command exists to activate the limit check and define the trace to be checked in one step (see [CALCulate<n>:LIMit:TRACe<t>:CHECK](#) on page 215).

Suffix:

<n> irrelevant

 [Limit line](#)

Parameters:

<State> ON | OFF | 0 | 1
OFF | 0
 Switches the function off
ON | 1
 Switches the function on

Example: CALC:LIM:STAT ON
 Switches on the limit check for limit line 1.

Manual operation: See "[Disable All Lines](#)" on page 108

CALCulate<n>:LIMit:TRACe<t> <TraceNumber>

Links a limit line to one or more traces.

Note that this command is maintained for compatibility reasons only. Limit lines no longer need to be assigned to a trace explicitly. The trace to be checked can be defined directly (as a suffix) in the new command to activate the limit check (see [CALCulate<n>:LIMit:TRACe<t>:CHECK](#) on page 215).

Suffix:

<n> [Window](#)
 [Limit line](#)
 <t> irrelevant

Parameters:

<TraceNumber> 1 to 4
 *RST: 1

Example: CALC:LIM2:TRAC 3
 Assigns limit line 2 to trace 3.

CALCulate<n>:LIMit:TRACe<t>:CHECK <State>

Turns the limit check for a specific trace on and off.

To query the limit check result, use [CALCulate<n>:LIMit:FAIL?](#).

Note that this command replaces the two commands from previous signal and spectrum analyzers (which are still supported, however):

- [CALCulate<n>:LIMit:TRACe<t>](#) on page 215
- [CALCulate<n>:LIMit:STATe](#) on page 214

Suffix:

<n> [Window](#)
 [Limit line](#)

<t>	Trace
Parameters:	
<State>	ON OFF 0 1 OFF 0 Switches the function off ON 1 Switches the function on
Example:	CALC:LIM3:TRAC2:CHEC ON Switches on the limit check for limit line 3 on trace 2.
Manual operation:	See "Traces to be Checked" on page 107

7.19 Working with markers

The following commands are necessary to work with markers.

- [Using markers](#).....216
- [Using delta markers](#).....219
- [Configuring markers](#).....222
- [Positioning markers](#).....223
- [Positioning delta markers](#).....225

7.19.1 Using markers

Note that the suffix at CALCulate has an effect only if you query the characteristics of a marker. If you set a marker, you can ignore the suffix because the markers are linked to each other over all measurement windows and will always be on the same frequency.

CALCulate<n>:MARKer<m>:AOFF.....	216
CALCulate<n>:MARKer<m>[:STATE].....	217
CALCulate<n>:MARKer<m>:TRACe.....	217
CALCulate<n>:MARKer<m>:X.....	217
CALCulate<n>:MARKer<m>:Y?.....	218

CALCulate<n>:MARKer<m>:AOFF

Turns off all markers.

Suffix:

<n>	Window
<m>	Marker

Example: CALC:MARK:AOFF
Switches off all markers.

Manual operation: See "All Markers Off" on page 103

CALCulate<n>:MARKer<m>[:STATe] <State>

Turns markers on and off. If the corresponding marker number is currently active as a delta marker, it is turned into a normal marker.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Parameters:

<State> ON | OFF | 0 | 1
OFF | 0
 Switches the function off
ON | 1
 Switches the function on

Example: `CALC:MARK3 ON`
 Switches on marker 3.

Manual operation: See "[Marker Type](#)" on page 103

CALCulate<n>:MARKer<m>:TRACe <Trace>

Selects the trace the marker is positioned on.

Note that the corresponding trace must have a trace mode other than "Blank".

If necessary, the command activates the marker first.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Parameters:

<Trace> **1 to 4**
 Trace number the marker is assigned to.

Example: `//Assign marker to trace 1`
`CALC:MARK3:TRAC 2`

CALCulate<n>:MARKer<m>:X <Position>

Moves a marker to a specific coordinate on the x-axis.

If necessary, the command activates the marker.

If the marker has been used as a delta marker, the command turns it into a normal marker.

Note that markers have to be positioned on a discrete frequency that is part of the frequency list. If you set the marker on a frequency not included in the frequency list, the application positions the marker to the nearest frequency in the list (rounding up or down).

Suffix:<n> [Window](#)<m> [Marker](#)**Parameters:**<Position> Numeric value that defines the marker position on the x-axis.
The unit depends on the result display.Range: The range depends on the current x-axis range.
Default unit: Hz**Example:**

CALC:MARK2:X 1.7MHz

Positions marker 2 to frequency 1.7 MHz.

CALCulate<n>:MARKer<m>:Y? <Result>

Queries the result at the position of the specified marker.

Suffix:

<n> 1..n

<m> 1..n

Query parameters:

<Result> Selects the result.

CPCold

Queries "Cal level (cold)" results.

CPHot

Queries "Cal level (hot)" results.

CYFactor

Queries calibration "Y-Factor" results.

DPCold

Queries "P Cold" results.

DPHot

Queries "P Hot" results.

GAIN

Queries "Gain" results.

NOISe

Queries "Noise Figure" results.

NUNCertainty

Queries the "Noise Figure" uncertainty results.

PCOLd

Queries "Level (cold)" results.

PHOT

Queries "Level (hot)" results.

TEMPerature

Queries "Temperature" results.

YFACtor

Queries "Y-Factor" results.

Return values:

<Result> Default unit: DBM

Usage: Query only

Manual operation: See "[Marker Table](#)" on page 26

7.19.2 Using delta markers

Note that the suffix at `CALCulate` has an effect only if you query the characteristics of a marker. If you set a marker, you can ignore the suffix because the markers are linked to each other over all measurement windows and will always be on the same frequency.

<code>CALCulate<n>:DELTamarker<m>:AOFF</code>	219
<code>CALCulate<n>:DELTamarker<m>:MREFerence</code>	219
<code>CALCulate<n>:DELTamarker<m>[:STATe]</code>	220
<code>CALCulate<n>:DELTamarker<m>:TRACe</code>	220
<code>CALCulate<n>:DELTamarker<m>:X</code>	220
<code>CALCulate<n>:DELTamarker<m>:Y?</code>	221

`CALCulate<n>:DELTamarker<m>:AOFF`

Turns off *all* delta markers.

Suffix:

<n> [Window](#)

<m> irrelevant

Example:

`CALC:DELT:AOFF`

Turns off all delta markers.

`CALCulate<n>:DELTamarker<m>:MREFerence <Reference>`

Selects a reference marker for a delta marker other than marker 1.

The reference may be another marker or the fixed reference.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Parameters:

<Reference> **1 to 16**

Selects markers 1 to 16 as the reference.

FIXed

Selects the fixed reference as the reference.

Example:

`CALC:DELT3:MREF 2`

Specifies that the values of delta marker 3 are relative to marker 2.

CALCulate<n>:DELTamarker<m>[:STATE] <State>

Turns delta markers on and off.

If necessary, the command activates the delta marker first.

No suffix at DELTmarker turns on delta marker 1.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Parameters:

<State> ON | OFF | 0 | 1

OFF | 0

Switches the function off

ON | 1

Switches the function on

Example:

CALC:DELT2 ON

Turns on delta marker 2.

Manual operation: See "[Marker Type](#)" on page 103

CALCulate<n>:DELTamarker<m>:TRACe <Trace>

Selects the trace a delta marker is positioned on.

Note that the corresponding trace must have a trace mode other than "Blank".

If necessary, the command activates the marker first.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Parameters:

<Trace> Trace number the marker is assigned to.

Example:

CALC:DELT2:TRAC 2

Positions delta marker 2 on trace 2.

CALCulate<n>:DELTamarker<m>:X <Position>

Moves a delta marker to a particular coordinate on the x-axis.

If necessary, the command activates the delta marker and positions a reference marker to the peak power.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Parameters:

<Position> Numeric value that defines the marker position on the x-axis.
 Range: The value range and unit depend on the measurement and scale of the x-axis.

Example:

CALC:DELT:X?
 Outputs the absolute x-value of delta marker 1.

CALCulate<n>:DELTamarker<m>:Y? <Trace>

Queries the result at the position of the specified delta marker.

Suffix:

<n> 1..n

<m> 1..n

Parameters:

<Trace>

CPCold

Queries "Cal level (cold)" results.

CPHot

Queries "Cal level (hot)" results.

CYFactor

Queries calibration "Y-Factor" results.

DPCold

Queries "P Cold" results.

DPHot

Queries "P Hot" results.

GAIN

Queries "Gain" results.

NOISe

Queries "Noise Figure" results.

NUNCertainty

Queries the "Noise Figure" uncertainty results.

PCOLd

Queries "Level (cold)" results.

PHOT

Queries "Level (hot)" results.

TEMPerature

Queries "Temperature" results.

YFACTOR

Queries "Y-Factor" results.

Return values:

<Result> Result at the position of the delta marker.
 The unit is variable and depends on the one you have currently set.
 Default unit: DBM

Usage: Query only
Manual operation: See "[Marker Table](#)" on page 26

7.19.3 Configuring markers

DISPlay[:WINDow<n>]:MINFo[:STATe]	222
DISPlay[:WINDow<n>]:MTABLE	222

DISPlay[:WINDow<n>]:MINFo[:STATe] <State>

Turns the marker information in all diagrams on and off.

Suffix:

<n> irrelevant

Parameters:

<State> **ON | 1**
 Displays the marker information in the diagrams.
OFF | 0
 Hides the marker information in the diagrams.
 *RST: 1

Example: DISP:MINF OFF
 Hides the marker information.

Manual operation: See "[Marker Info](#)" on page 104

DISPlay[:WINDow<n>]:MTABLE <DisplayMode>

Turns the marker table on and off.

Suffix:

<n> irrelevant

Parameters:

<DisplayMode> **ON | 1**
 Turns on the marker table.
OFF | 0
 Turns off the marker table.
AUTO
 Turns on the marker table if 3 or more markers are active.
 *RST: AUTO

Example: DISP:MTAB ON
 Activates the marker table.

Manual operation: See "[Marker Table Display](#)" on page 104

7.19.4 Positioning markers

If you are using more than one window, the application performs the peak search in the window that you have selected with the suffix at `CALCulate` only. Because the markers are linked, the frequency position of the marker in the other windows is adjusted accordingly, even if it means that the marker is on a peak in the selected window only.

<code>CALCulate<n>:MARKer<m>:MAXimum:LEFT</code>	223
<code>CALCulate<n>:MARKer<m>:MAXimum:NEXT</code>	223
<code>CALCulate<n>:MARKer<m>:MAXimum[:PEAK]</code>	223
<code>CALCulate<n>:MARKer<m>:MAXimum:RIGHT</code>	224
<code>CALCulate<n>:MARKer<m>:MINimum:NEXT</code>	224
<code>CALCulate<n>:MARKer<m>:MINimum:LEFT</code>	224
<code>CALCulate<n>:MARKer<m>:MINimum[:PEAK]</code>	224
<code>CALCulate<n>:MARKer<m>:MINimum:RIGHT</code>	224

`CALCulate<n>:MARKer<m>:MAXimum:LEFT`

Moves a marker to the next positive peak.

The search includes only measurement values to the left of the current marker position.

Suffix:

<n> Window

<m> Marker

Manual operation: See "[Search Next Peak](#)" on page 105

`CALCulate<n>:MARKer<m>:MAXimum:NEXT`

Moves a marker to the next positive peak.

Suffix:

<n> Window

<m> Marker

Manual operation: See "[Search Next Peak](#)" on page 105

`CALCulate<n>:MARKer<m>:MAXimum[:PEAK]`

Moves a marker to the highest level.

If the marker is not yet active, the command first activates the marker.

Suffix:

<n> Window

<m> Marker

Manual operation: See "[Peak Search](#)" on page 105

CALCulate<n>:MARKer<m>:MAXimum:RIGHT

Moves a marker to the next positive peak.

The search includes only measurement values to the right of the current marker position.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Search Next Peak"](#) on page 105

CALCulate<n>:MARKer<m>:MINimum:NEXT

Moves a marker to the next minimum peak value.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Search Next Minimum"](#) on page 106

CALCulate<n>:MARKer<m>:MINimum:LEFT

Moves a marker to the next minimum peak value.

The search includes only measurement values to the right of the current marker position.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Search Next Minimum"](#) on page 106

CALCulate<n>:MARKer<m>:MINimum[:PEAK]

Moves a marker to the minimum level.

If the marker is not yet active, the command first activates the marker.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Search Minimum"](#) on page 105

CALCulate<n>:MARKer<m>:MINimum:RIGHT

Moves a marker to the next minimum peak value.

The search includes only measurement values to the right of the current marker position.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Search Next Minimum"](#) on page 106

7.19.5 Positioning delta markers

If you are using more than one window, the application performs the peak search in the window that you have selected with the suffix at `CALCulate` only. Because the markers are linked, the frequency position of the marker in the other windows is adjusted accordingly, even if it means that the marker is on a peak in the selected window only.

CALCulate<n>:DELTamarker<m>:MAXimum:LEFT	225
CALCulate<n>:DELTamarker<m>:MAXimum:NEXT	225
CALCulate<n>:DELTamarker<m>:MAXimum[:PEAK]	226
CALCulate<n>:DELTamarker<m>:MAXimum:RIGHT	226
CALCulate<n>:DELTamarker<m>:MINimum:LEFT	226
CALCulate<n>:DELTamarker<m>:MINimum:NEXT	226
CALCulate<n>:DELTamarker<m>:MINimum[:PEAK]	226
CALCulate<n>:DELTamarker<m>:MINimum:RIGHT	227

CALCulate<n>:DELTamarker<m>:MAXimum:LEFT

Moves a delta marker to the next positive peak value.

The search includes only measurement values to the left of the current marker position.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Search Next Peak"](#) on page 105

CALCulate<n>:DELTamarker<m>:MAXimum:NEXT

Moves a marker to the next positive peak value.

Suffix:

<n> 1..n
[Window](#)

<m> 1..n
[Marker](#)

Manual operation: See ["Search Next Peak"](#) on page 105

CALCulate<n>:DELTaMarker<m>:MAXimum[:PEAK]

Moves a delta marker to the highest level.

If the marker is not yet active, the command first activates the marker.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Peak Search"](#) on page 105

CALCulate<n>:DELTaMarker<m>:MAXimum:RIGHT

Moves a delta marker to the next positive peak value on the trace.

The search includes only measurement values to the right of the current marker position.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Search Next Peak"](#) on page 105

CALCulate<n>:DELTaMarker<m>:MINimum:LEFT

Moves a delta marker to the next minimum peak value.

The search includes only measurement values to the right of the current marker position.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Search Next Minimum"](#) on page 106

CALCulate<n>:DELTaMarker<m>:MINimum:NEXT

Moves a marker to the next minimum peak value.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See ["Search Next Minimum"](#) on page 106

CALCulate<n>:DELTaMarker<m>:MINimum[:PEAK]

Moves a delta marker to the minimum level.

If the marker is not yet active, the command first activates the marker.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See "[Search Minimum](#)" on page 105

CALCulate<n>:DELTAmarker<m>:MINimum:RIGHT

Moves a delta marker to the next minimum peak value.

The search includes only measurement values to the right of the current marker position.

Suffix:

<n> [Window](#)

<m> [Marker](#)

Manual operation: See "[Search Next Minimum](#)" on page 106

7.20 Using the status register

The status reporting system stores information about the current state of the R&S FSWP. This includes, for example, information about errors during operation or information about limit checks. The R&S FSWP stores this information in the status registers and in the error queue. You can query the status register and error queue via IEC bus.

The R&S FSWP-K30 features several status registers that are specific to "noise figure" measurements. This chapter describes the application-specific registers, including the corresponding remote commands.

- [Status registers for noise figure measurements](#).....227

7.20.1 Status registers for noise figure measurements

The figure below shows the status registers of the "noise figure" application.




Figure 7-2: Status registers for noise figure measurements

The R&S FSWP structures the information hierarchically, with the Status Byte register (STB) and the Service Request Enable mask register (SRE) being on the highest level. The STB gets its information from the standard Event Status Register (ESR) and the Event Status Enable mask register (ESE). The STB and ESR are both defined by IEEE 488.2. In addition to the ESR, the STB also gets information from the STATUS:OPERation and STATUS:QUESTIONable registers. These registers are the link to the lower lev-

els of the status register and are defined by SCPI. They contain information about the state of the instrument.

For a more comprehensive description of the status registers not mentioned here, and status register functionality in general, see the manual of the base unit.

7.20.1.1 STATus:OPERation register

The STATus:OPERation register contains information on current activities of the R&S FSWP. It also contains information on activities that have been executed since the last read out.

Bit no	Meaning
0 to 3	Unavailable for "noise figure" measurements.
4	MEASuring This bit is set if a measurement is in progress.
5 to 6	Unavailable for "noise figure" measurements.
7	CORRecting This bit is set if a 2nd stage correction is in progress.
8	HCOPy This bit is set if a hardcopy is created.
9 - 14	Unavailable for "noise figure" measurements.
15	This bit is always 0.

7.20.1.2 STATus:QUEStionable register

The STATus:QUEStionable register contains information about indefinite states which can occur if the unit is operated without meeting the specifications.

Bit no	Meaning
0 to 7	Unavailable for "noise figure" measurements.
8	CALibration This bit is set if the R&S FSWP is not calibrated.
9	LIMit This bit is set if a limit line is violated.
10	Unavailable for "noise figure" measurements.
11	CORRection This bit is set if the "noise figure" calibration is questionable.
14	Unavailable for "noise figure" measurements.
15	This bit is always 0.

7.20.1.3 STATUS:QUESTIONABLE:LIMIT register

The STATUS:QUESTIONABLE:LIMIT register contains information about limit lines and the results of a limit checks.

The number of LIMIT registers depends on the number of measurement windows available in any application.

Bit no	Meaning
0	LIMIT 1 FAIL This bit is set if limit line 1 is violated.
1	LIMIT 2 FAIL This bit is set if limit line 2 is violated.
2	LIMIT 3 FAIL This bit is set if limit line 3 is violated.
3	LIMIT 4 FAIL This bit is set if limit line 4 is violated.
4	LIMIT 5 FAIL This bit is set if limit line 5 is violated.
5	LIMIT 6 FAIL This bit is set if limit line 6 is violated.
6	LIMIT 7 FAIL This bit is set if limit line 7 is violated.
7	LIMIT 8 FAIL This bit is set if limit line 8 is violated.
8 to 14	Unavailable for "noise figure" measurements.
15	This bit is always 0.

7.20.1.4 STATUS:QUESTIONABLE:CORRECTION register

The STATUS:QUESTIONABLE:CORRECTION register contains information about the calibration status of "noise figure" measurements.

Bit no	Meaning
0	NO CORRECTION This bit is set if calibration is required.
1 to 2	Unavailable for "noise figure" measurements.
3	Missing Loss or ENR values This bit is set if loss or ENR values are missing for one or more measurement frequencies.

Bit no	Meaning
4 to 14	Unavailable for "noise figure" measurements.
15	This bit is always 0.

7.20.1.5 Status register remote commands

STATus:OPERation[:EVENT]?.....	231
STATus:QUESTionable[:EVENT]?.....	231
STATus:QUESTionable:CORRection[:EVENT]?.....	231
STATus:QUESTionable:LIMit[:EVENT]?.....	231
STATus:OPERation:CONDition?.....	231
STATus:QUESTionable:CONDition?.....	231
STATus:QUESTionable:CORRection:CONDition?.....	231
STATus:QUESTionable:LIMit:CONDition?.....	231
STATus:OPERation:ENABle.....	232
STATus:QUESTionable:ENABle.....	232
STATus:QUESTionable:CORRection:ENABle.....	232
STATus:QUESTionable:LIMit:ENABle.....	232
STATus:OPERation:NTRansition.....	232
STATus:QUESTionable:NTRansition.....	232
STATus:QUESTionable:CORRection:NTRansition.....	232
STATus:QUESTionable:LIMit:NTRansition.....	232
STATus:OPERation:PTRansition.....	232
STATus:QUESTionable:PTRansition.....	232
STATus:QUESTionable:CORRection:PTRansition.....	232
STATus:QUESTionable:LIMit:PTRansition.....	232

STATus:OPERation[:EVENT]?

STATus:QUESTionable[:EVENT]?

STATus:QUESTionable:CORRection[:EVENT]? <ChannelName>

STATus:QUESTionable:LIMit[:EVENT]? <ChannelName>

These commands read out the EVENT section of the status register.

The commands at the same time delete the contents of the EVENT section.

Query parameters:

<ChannelName> String containing the name of the channel.
The parameter is optional. If you omit it, the command works for the currently active channel.

Usage: Query only

STATus:OPERation:CONDition?

STATus:QUESTionable:CONDition?

STATus:QUESTionable:CORRection:CONDition? <ChannelName>

STATus:QUESTionable:LIMit:CONDition? <ChannelName>

These commands read out the CONDition section of the status register.

The commands do not delete the contents of the EVENT section.

Query parameters:

<ChannelName> String containing the name of the channel.
The parameter is optional. If you omit it, the command works for the currently active channel.

Usage: Query only

STATus:OPERation:ENABLE <SumBit>,<ChannelName>

STATus:QUESTionable:ENABLE <SumBit>,<ChannelName>

STATus:QUESTionable:CORRection:ENABLE <SumBit>,<ChannelName>

STATus:QUESTionable:LIMit:ENABLE <SumBit>,<ChannelName>

These commands control the ENABLE part of a register.

The ENABLE part allows true conditions in the EVENT part of the status register to be reported in the summary bit. If a bit is 1 in the enable register and its associated event bit transitions to true, a positive transition occurs in the summary bit reported to the next higher level.

Parameters:

<SumBit> Range: 0 to 65535

<ChannelName> String containing the name of the channel.
The parameter is optional. If you omit it, the command works for the currently active channel.

STATus:OPERation:NTRansition <SumBit>,<ChannelName>

STATus:QUESTionable:NTRansition <SumBit>,<ChannelName>

STATus:QUESTionable:CORRection:NTRansition <SumBit>,<ChannelName>

STATus:QUESTionable:LIMit:NTRansition <SumBit>,<ChannelName>

These commands control the Negative TRansition part of a register.

Setting a bit causes a 1 to 0 transition in the corresponding bit of the associated register. The transition also writes a 1 into the associated bit of the corresponding EVENT register.

Parameters:

<SumBit> Range: 0 to 65535

<ChannelName> String containing the name of the channel.
The parameter is optional. If you omit it, the command works for the currently active channel.

STATus:OPERation:PTRansition <SumBit>,<ChannelName>

STATus:QUESTionable:PTRansition <SumBit>,<ChannelName>

STATus:QUESTionable:CORRection:PTRansition <SumBit>,<ChannelName>

STATus:QUESTionable:LIMit:PTRansition <SumBit>,<ChannelName>

These commands control the Positive TRansition part of a register.

Deprecated remote commands for noise figure measurements

Setting a bit causes a 0 to 1 transition in the corresponding bit of the associated register. The transition also writes a 1 into the associated bit of the corresponding EVENT register.

Parameters:

<SumBit> Range: 0 to 65535

<ChannelName> String containing the name of the channel.
The parameter is optional. If you omit it, the command works for the currently active channel.

7.21 Deprecated remote commands for noise figure measurements

Following is a list of deprecated remote commands. The remote commands are still supported to maintain compatibility to previous versions of "noise figure" measurements (like the R&S FSV-K30), but it is strongly recommended to use the command system in the way it is meant to be used in the R&S FSWP-K30.

Legacy command	Replaced by	Comment
CALCulate:LIMit:TRACe	CALCulate:LIMit:TYPE	Parameters NFIGure, TEFFective and GAIN were supported to assign a limit line to a result and thus the trace because trace and result type were fix. CALCulate:LIMit:TRACe now assigns the limit line to a trace (1 to 4).
CALCulate:MARKer:TRACe CALCulate:DELTaMarker:TRACe		The parameters NOISe, GAIN, NMEM1-3 and GMEM1-3 have been replaced by 1 2 3 4 because no distinction is made between memory and live trace.
CONFigure:ARRay:MEMory	TRACe:COpy	No more distinction between memory and live traces.
CONFigure:SINGle	CONFigure:FREQuency:SINGle	
DISPlay:ARRay:MEMory:STATe DISPlay:CURRent:DATA:STATe	DISPlay:WINDow:TRACe:STATe	No more distinction between memory and live traces.
DISPlay:DATA:TRACe	LAYout system	
DISPlay:FORMat	---	Functionality not supported any more.
DISPlay:WINDow:TABLe	LAYout:WINDow:REPLace / LAYout:REPLace:WINDow	
FETCH: command system	TRACe:DATA	
SENSe:SWEp:POINTs	SENSe:FREQuency:POINTs	
SENSe:FREQuency:CW:FIXed	SENSe:FREQuency:SINGle	
SENSe:FREQuency:LIST:DATA	SENSe:FREQuency:TABLe:DATA	Frequency table only requires RF frequencies on R&S FSWP.

Legacy command	Replaced by	Comment
SENSe:CONFigure:MODE:SYSTem: LOSCillator	SENSe:CONFigure:MODE: SYSTem:LO	
SENSe:CONFigure:MODE:SYSTem: LOSCillator:FREQuency	SENSe:CONFigure:MODE: SYSTem:LO:FREQuency	

7.22 Programming example: measuring a noise figure

```

// Preset and start option K30
*RST
INSTRument:SElect NOISE

// Set frequencies
SENSe:FREQuency:START 100000
SENSe:FREQuency:STOP 3000000000
SENSe:FREQuency:POINts 201

// ENR settings
SENSe:CORRection:ENR:MODE TABLE
// Set the ENR values of your noise source here
SENSe:CORRection:ENR:MEASurement:TABLE:DATA 100e3, 15.77, 10e6, 15.77, 100e6, 15.35,
1e9, 15.12, 2e9, 14.70, 3e9, 14.57

// Set meas time
SENSe:SWEep:TIME 300ms

// Configure and start calibration
SENSe:CONFigure:CORRection
INITiate:IMMEDIATE
*OPC
SENSe:CORRection:STATe ON

// Configure and start measurement
// --> don't forget to add the DUT to the signal path here
// Configure a frequency list measurement with the settings above in single sweep
SENSe:CONFigure:LIST:SINGLE
INITiate:IMMEDIATE
*OPC

```

Annex

A Reference: frequency table file format

Frequency tables can be exported to a file in xml format for further evaluation in other applications. Transducer factors stored in the specified xml format can also be imported to the R&S FSWP for other measurements (see ["Import / Export"](#) on page 53). This reference describes in detail the format of the export/import files for frequency tables.

```
<?xml version="1.0" encoding="UTF-8"?>
<TableAttributes>
  <Header comment=""/>
  <Data freq="" value=""/>
  ...
</TableAttributes>
```

Example: Import file for a frequency table

```
<?xml version="1.0" encoding="UTF-8"?>
<TableAttributes>
  <Header comment="Frequency values for NC364B (example)"/>
  <Data freq="100000000" value="13.14"/>
  <Data freq="1000000000" value="13.21"/>
  <Data freq="10000000000" value="13.22"/>
  <Data freq="20000000000" value="13.17"/>
  <Data freq="30000000000" value="13.26"/>
  <Data freq="40000000000" value="13.38"/>
  <Data freq="50000000000" value="13.53"/>
  <Data freq="60000000000" value="13.63"/>
  <Data freq="70000000000" value="13.81"/>
</TableAttributes>
```

List of Remote Commands (Noise Figure)

[SENSe:]BANDwidth:LIST:DATA.....	133
[SENSe:]BANDwidth:RESolution:AUTO.....	153
[SENSe:]BANDwidth[:RESolution].....	152
[SENSe:]BWIDth:RESolution:AUTO.....	153
[SENSe:]BWIDth[:RESolution].....	152
[SENSe:]CONFigure:CONTRol.....	180
[SENSe:]CONFigure:CORRection.....	153
[SENSe:]CONFigure:FREQuency:CONTInuous.....	131
[SENSe:]CONFigure:FREQuency:SINGLE.....	131
[SENSe:]CONFigure:LIST:CONTInuous.....	131
[SENSe:]CONFigure:LIST:SINGLE.....	131
[SENSe:]CONFigure:MEASurement.....	181
[SENSe:]CONFigure:MODE:DUT.....	137
[SENSe:]CONFigure:MODE:SYSTem:IF:FREQuency.....	135
[SENSe:]CONFigure:MODE:SYSTem:LO.....	136
[SENSe:]CONFigure:MODE:SYSTem:LO:FREQuency.....	136
[SENSe:]CORRection:CVL:BAND.....	184
[SENSe:]CORRection:CVL:BIAS.....	184
[SENSe:]CORRection:CVL:CATalog?.....	185
[SENSe:]CORRection:CVL:CLEar.....	185
[SENSe:]CORRection:CVL:COMMeNt.....	185
[SENSe:]CORRection:CVL:DATA.....	186
[SENSe:]CORRection:CVL:HARMonic.....	186
[SENSe:]CORRection:CVL:MIXer.....	186
[SENSe:]CORRection:CVL:PORTs.....	187
[SENSe:]CORRection:CVL:SELect.....	187
[SENSe:]CORRection:CVL:SNUMber.....	187
[SENSe:]CORRection:ENR:CALibration:MODE.....	139
[SENSe:]CORRection:ENR:CALibration:SNS:SRNumber.....	145
[SENSe:]CORRection:ENR:CALibration:SPOT.....	139
[SENSe:]CORRection:ENR:CALibration:SPOT:COLD.....	138
[SENSe:]CORRection:ENR:CALibration:SPOT:HOT.....	138
[SENSe:]CORRection:ENR:CALibration:TABLE:SELect.....	139
[SENSe:]CORRection:ENR:CALibration:TYPE.....	140
[SENSe:]CORRection:ENR:COMMon.....	140
[SENSe:]CORRection:ENR[:MEASurement]:MODE.....	143
[SENSe:]CORRection:ENR[:MEASurement]:SNS:SRNumber.....	145
[SENSe:]CORRection:ENR[:MEASurement]:SPOT.....	143
[SENSe:]CORRection:ENR[:MEASurement]:SPOT:COLD.....	144
[SENSe:]CORRection:ENR[:MEASurement]:SPOT:HOT.....	144
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:DELeTe.....	141
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:LIST?.....	141
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:SELect.....	141
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature:DELeTe.....	142
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature:LIST?.....	142
[SENSe:]CORRection:ENR[:MEASurement]:TABLE:TEMPerature[:DATA].....	142
[SENSe:]CORRection:ENR[:MEASurement]:TABLE[:DATA].....	140

[SENSe:]CORRection:ENR[:MEASurement]:TYPE.....	143
[SENSe:]CORRection:IREJection.....	137
[SENSe:]CORRection:LOSS:CALibration:MODE.....	146
[SENSe:]CORRection:LOSS:CALibration:SPOT.....	146
[SENSe:]CORRection:LOSS:CALibration:TABLE:DELeTe.....	146
[SENSe:]CORRection:LOSS:CALibration:TABLE:LIST?.....	147
[SENSe:]CORRection:LOSS:CALibration:TABLE:SELeCt.....	147
[SENSe:]CORRection:LOSS:CALibration:TABLE[:DATA].....	147
[SENSe:]CORRection:LOSS:CALibration:TEMPerature.....	147
[SENSe:]CORRection:LOSS:INPut:MODE.....	148
[SENSe:]CORRection:LOSS:INPut:SPOT.....	148
[SENSe:]CORRection:LOSS:INPut:TABLE:DELeTe.....	149
[SENSe:]CORRection:LOSS:INPut:TABLE:LIST?.....	149
[SENSe:]CORRection:LOSS:INPut:TABLE:SELeCt.....	149
[SENSe:]CORRection:LOSS:INPut:TABLE[:DATA].....	148
[SENSe:]CORRection:LOSS:INPut:TEMPerature.....	150
[SENSe:]CORRection:LOSS:OUTPut:MODE.....	150
[SENSe:]CORRection:LOSS:OUTPut:SPOT.....	150
[SENSe:]CORRection:LOSS:OUTPut:TABLE:DELeTe.....	151
[SENSe:]CORRection:LOSS:OUTPut:TABLE:LIST?.....	151
[SENSe:]CORRection:LOSS:OUTPut:TABLE:SELeCt.....	151
[SENSe:]CORRection:LOSS:OUTPut:TABLE[:DATA].....	150
[SENSe:]CORRection:LOSS:OUTPut:TEMPerature.....	151
[SENSe:]CORRection:RECall.....	154
[SENSe:]CORRection:SAVE.....	154
[SENSe:]CORRection:TEMPerature.....	144
[SENSe:]CORRection[:STATe].....	154
[SENSe:]FREQuency:CENTer.....	132
[SENSe:]FREQuency:LIST:DATA.....	132
[SENSe:]FREQuency:POINts.....	133
[SENSe:]FREQuency:SINGle.....	133
[SENSe:]FREQuency:SINGle:COUPLed.....	134
[SENSe:]FREQuency:SPAN.....	134
[SENSe:]FREQuency:STARt.....	134
[SENSe:]FREQuency:STEP.....	135
[SENSe:]FREQuency:STOP.....	135
[SENSe:]FREQuency:TABLE:DATA.....	132
[SENSe:]MIXer<x>:BIAS:HIGH.....	188
[SENSe:]MIXer<x>:BIAS[:LOW].....	188
[SENSe:]MIXer<x>:FREQuency:HANdOver.....	188
[SENSe:]MIXer<x>:FREQuency:STARt.....	189
[SENSe:]MIXer<x>:FREQuency:STOP.....	189
[SENSe:]MIXer<x>:HARMonic:BAND.....	189
[SENSe:]MIXer<x>:HARMonic:BAND:PRESet.....	189
[SENSe:]MIXer<x>:HARMonic:HIGH[:VALue].....	190
[SENSe:]MIXer<x>:HARMonic:TYPE.....	190
[SENSe:]MIXer<x>:HARMonic[:LOW].....	191
[SENSe:]MIXer<x>:LOPower.....	191
[SENSe:]MIXer<x>:LOSS:HIGH.....	192
[SENSe:]MIXer<x>:LOSS:TABLE:HIGH.....	192

[SENSe:]MIXer<x>:LOSS:TABLE[:LOW].....	192
[SENSe:]MIXer<x>:LOSS[:LOW].....	193
[SENSe:]MIXer<x>:PORTs.....	193
[SENSe:]MIXer<x>:RFOVerrange[:STATe].....	193
[SENSe:]MIXer<x>:SIGNal.....	191
[SENSe:]MIXer<x>:THReshold.....	194
[SENSe:]MIXer<x>[:STATe].....	194
[SENSe:]SWEep:COUNT.....	155
[SENSe:]SWEep:EGATe.....	162
[SENSe:]SWEep:EGATe:CONTInuous:PCOunt.....	163
[SENSe:]SWEep:EGATe:CONTInuous:PLENght.....	163
[SENSe:]SWEep:EGATe:CONTInuous[:STATe].....	163
[SENSe:]SWEep:EGATe:HOLDoff.....	164
[SENSe:]SWEep:EGATe:LENGth.....	164
[SENSe:]SWEep:EGATe:POLarity.....	164
[SENSe:]SWEep:EGATe:SOURce.....	165
[SENSe:]SWEep:EGATe:TYPE.....	165
[SENSe:]SWEep:TIME.....	155
[SENSe:]SWEep:TIME:AUTO.....	155
ABORT.....	178
CALCulate<n>:DELTAmarker<m>:AOFF.....	219
CALCulate<n>:DELTAmarker<m>:MAXimum:LEFT.....	225
CALCulate<n>:DELTAmarker<m>:MAXimum:NEXT.....	225
CALCulate<n>:DELTAmarker<m>:MAXimum:RIGHT.....	226
CALCulate<n>:DELTAmarker<m>:MAXimum[:PEAK].....	226
CALCulate<n>:DELTAmarker<m>:MINimum:LEFT.....	226
CALCulate<n>:DELTAmarker<m>:MINimum:NEXT.....	226
CALCulate<n>:DELTAmarker<m>:MINimum:RIGHT.....	227
CALCulate<n>:DELTAmarker<m>:MINimum[:PEAK].....	226
CALCulate<n>:DELTAmarker<m>:MREFerence.....	219
CALCulate<n>:DELTAmarker<m>:TRACe.....	220
CALCulate<n>:DELTAmarker<m>:X.....	220
CALCulate<n>:DELTAmarker<m>:Y?.....	221
CALCulate<n>:DELTAmarker<m>[:STATe].....	220
CALCulate<n>:LIMit:ACTive?.....	212
CALCulate<n>:LIMit:CLEar[:IMMediate].....	214
CALCulate<n>:LIMit:COMMeNt.....	208
CALCulate<n>:LIMit:CONTRol:SHIFt.....	209
CALCulate<n>:LIMit:CONTRol[:DATA].....	209
CALCulate<n>:LIMit:COPY.....	213
CALCulate<n>:LIMit:DELeTe.....	213
CALCulate<n>:LIMit:FAIL?.....	214
CALCulate<n>:LIMit:LOWer:SHIFt.....	210
CALCulate<n>:LIMit:LOWer:STATe.....	211
CALCulate<n>:LIMit:LOWer[:DATA].....	210
CALCulate<n>:LIMit:NAME.....	208
CALCulate<n>:LIMit:STATe.....	214
CALCulate<n>:LIMit:TRACe<t>.....	215
CALCulate<n>:LIMit:TRACe<t>:CHECK.....	215
CALCulate<n>:LIMit:TYPE.....	208

CALCulate<n>:LIMit:UPPer:SHIFt.....	212
CALCulate<n>:LIMit:UPPer:STATe.....	212
CALCulate<n>:LIMit:UPPer[:DATA].....	211
CALCulate<n>:MARKer<m>:AOFF.....	216
CALCulate<n>:MARKer<m>:MAXimum:LEFT.....	223
CALCulate<n>:MARKer<m>:MAXimum:NEXT.....	223
CALCulate<n>:MARKer<m>:MAXimum:RIGHT.....	224
CALCulate<n>:MARKer<m>:MAXimum[:PEAK].....	223
CALCulate<n>:MARKer<m>:MINimum:LEFT.....	224
CALCulate<n>:MARKer<m>:MINimum:NEXT.....	224
CALCulate<n>:MARKer<m>:MINimum:RIGHT.....	224
CALCulate<n>:MARKer<m>:MINimum[:PEAK].....	224
CALCulate<n>:MARKer<m>:TRACe.....	217
CALCulate<n>:MARKer<m>:X.....	217
CALCulate<n>:MARKer<m>:Y?.....	218
CALCulate<n>:MARKer<m>[:STATe].....	217
CALCulate<n>:UNCertainty:COMMon.....	168
CALCulate<n>:UNCertainty:DATA:FREQuency.....	168
CALCulate<n>:UNCertainty:DATA:GAIN.....	169
CALCulate<n>:UNCertainty:DATA:NOISe.....	169
CALCulate<n>:UNCertainty:DATA:RESults.....	169
CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty.....	170
CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty:COLD.....	170
CALCulate<n>:UNCertainty:ENR:CALibration:UNCertainty:HOT.....	170
CALCulate<n>:UNCertainty:ENR:UNCertainty.....	171
CALCulate<n>:UNCertainty:ENR:UNCertainty:COLD.....	171
CALCulate<n>:UNCertainty:ENR:UNCertainty:HOT.....	172
CALCulate<n>:UNCertainty:MATCH:DUT:IN:RL.....	172
CALCulate<n>:UNCertainty:MATCH:DUT:IN[:VSWR].....	172
CALCulate<n>:UNCertainty:MATCH:DUT:OUT:RL.....	173
CALCulate<n>:UNCertainty:MATCH:DUT:OUT[:VSWR].....	173
CALCulate<n>:UNCertainty:MATCH:PREamp:RL.....	173
CALCulate<n>:UNCertainty:MATCH:PREamp[:VSWR].....	173
CALCulate<n>:UNCertainty:MATCH:SOURce:CALibration:RL.....	174
CALCulate<n>:UNCertainty:MATCH:SOURce:CALibration[:VSWR].....	174
CALCulate<n>:UNCertainty:MATCH:SOURce:RL.....	174
CALCulate<n>:UNCertainty:MATCH:SOURce[:VSWR].....	175
CALCulate<n>:UNCertainty:PREamp:GAIN.....	175
CALCulate<n>:UNCertainty:PREamp:NOISe.....	175
CALCulate<n>:UNCertainty:PREamp:STATe.....	176
CALCulate<n>:UNCertainty:SANalyzer:GAIN:UNCertainty?.....	176
CALCulate<n>:UNCertainty:SANalyzer:NOISe:UNCertainty?.....	177
CALCulate<n>:UNCertainty[:RESult]?.....	176
DISPlay:FORMat.....	128
DISPlay[:WINDow<n>]:MINFo[:STATe].....	222
DISPlay[:WINDow<n>]:MTABLE.....	222
DISPlay[:WINDow<n>]:SIZE.....	128
DISPlay[:WINDow<n>]:TABLE:ITEM.....	198
DISPlay[:WINDow<n>]:TRACe<t>:SYMBOLs.....	199
DISPlay[:WINDow<n>]:TRACe<t>:UNCertainty.....	199

DISPlay[:WINDow<n>]:TRACe<t>:X[:SCALe].....	199
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO.....	200
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:BOTTom.....	200
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel.....	156
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:AUTO.....	156
DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:TOP.....	201
DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:MODE.....	202
DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:SMOothing:APERture.....	203
DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>:SMOothing[:STATe].....	203
DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>[:STATe].....	202
FORMat:DEXPort:DSEParator.....	204
FORMat:DEXPort:FORMat.....	205
FORMat:DEXPort:HEADer.....	205
FORMat:DEXPort:TRACes.....	205
FORMat[:DATA].....	203
INITiate:SEQuencer:ABORT.....	179
INITiate:SEQuencer:IMMediate.....	179
INITiate:SEQuencer:MODE.....	180
INITiate<n>:CONTinuous.....	178
INITiate<n>[:IMMediate].....	179
INPut:ATTenuation.....	156
INPut:COUPLing.....	182
INPut:FILTer:HPASs[:STATe].....	183
INPut:FILTer:YIG[:STATe].....	183
INPut:GAIN:STATe.....	157
INPut:GAIN[:VALue].....	157
INPut:IMPedance.....	182
INPut:SElect.....	157
INPut:TYPE.....	157
INSTRument:CREate:DUPLicate.....	117
INSTRument:CREate:REPLace.....	118
INSTRument:CREate[:NEW].....	118
INSTRument:DELeTe.....	118
INSTRument:LIST?.....	119
INSTRument:REName.....	119
INSTRument[:SElect].....	120
LAYout:ADD[:WINDow]?.....	121
LAYout:CATalog[:WINDow]?.....	123
LAYout:IDENtify[:WINDow]?.....	123
LAYout:MOVE[:WINDow].....	123
LAYout:REMOve[:WINDow].....	124
LAYout:REPLace[:WINDow].....	124
LAYout:SPLitter.....	125
LAYout:WINDow<n>:ADD?.....	126
LAYout:WINDow<n>:IDENtify?.....	126
LAYout:WINDow<n>:REMOve.....	127
LAYout:WINDow<n>:REPLace.....	127
MMEMory:STORe<n>:TRACe.....	205
OUTPut:TRIGger<tp>:DIRection.....	165
OUTPut:TRIGger<tp>:LEVel.....	166

OUTPut:TRIGger<tp>:OTYPE.....	166
OUTPut:TRIGger<tp>:PULSe:IMMEDIATE.....	167
OUTPut:TRIGger<tp>:PULSe:LENGth.....	167
SOURce:EXTErnal:FREQUency:OFFSet<of>.....	195
SOURce:EXTErnal:FREQUency[:FACTor]:DENominator.....	195
SOURce:EXTErnal:FREQUency[:FACTor]:NUMerator.....	195
SOURce<si>:EXTErnal<gen>:POWer[:LEVel].....	195
SOURce<si>:EXTErnal<gen>:ROSCillator[:SOURce].....	195
STATus:OPERation:CONDition?.....	231
STATus:OPERation:ENABle.....	232
STATus:OPERation:NTRansition.....	232
STATus:OPERation:PTRansition.....	232
STATus:OPERation[:EVENT]?.....	231
STATus:QUEStionable:CONDition?.....	231
STATus:QUEStionable:CORRection:CONDition?.....	231
STATus:QUEStionable:CORRection:ENABle.....	232
STATus:QUEStionable:CORRection:NTRansition.....	232
STATus:QUEStionable:CORRection:PTRansition.....	232
STATus:QUEStionable:CORRection[:EVENT]?.....	231
STATus:QUEStionable:ENABle.....	232
STATus:QUEStionable:LIMit:CONDition?.....	231
STATus:QUEStionable:LIMit:ENABle.....	232
STATus:QUEStionable:LIMit:NTRansition.....	232
STATus:QUEStionable:LIMit:PTRansition.....	232
STATus:QUEStionable:LIMit[:EVENT]?.....	231
STATus:QUEStionable:NTRansition.....	232
STATus:QUEStionable:PTRansition.....	232
STATus:QUEStionable[:EVENT]?.....	231
SYSTem:COMMunicate:GPIB:RDEvice:GENerator<gen>:ADDReSS.....	196
SYSTem:COMMunicate:RDEvice:GENerator<gen>:INTerface.....	196
SYSTem:COMMunicate:RDEvice:GENerator<gen>:TYPE.....	196
SYSTem:COMMunicate:TCPip:RDEvice:GENerator<gen>:ADDReSS.....	197
SYSTem:CONFIgure:DUT:GAIN.....	158
SYSTem:CONFIgure:DUT:STIME.....	158
SYSTem:CONFIgure:GENerator:CONTRol:STATe.....	197
SYSTem:CONFIgure:GENerator:INITialise:AUTO.....	197
SYSTem:CONFIgure:GENerator:INITialise[:IMMEDIATE].....	198
SYSTem:CONFIgure:GENerator:SWITCh:AUTO.....	198
SYSTem:PRESet:CHANnel[:EXEC].....	120
SYSTem:SEQuencer.....	181
TRACe<n>:COPY.....	206
TRACe<n>[:DATA]?.....	129
TRIGger[:SEQuence]:DTIME.....	159
TRIGger[:SEQuence]:HOLDoff[:TIME].....	159
TRIGger[:SEQuence]:IFPower:HOLDoff.....	160
TRIGger[:SEQuence]:IFPower:HYSTeresis.....	160
TRIGger[:SEQuence]:LEVel:IFPower.....	161
TRIGger[:SEQuence]:LEVel:RFPower.....	161
TRIGger[:SEQuence]:LEVel[:EXTErnal<port>].....	160
TRIGger[:SEQuence]:SLOPe.....	161

TRIGger[:SEQuence]:SOURce.....161

Index

Symbols

2nd stage correction 37, 69

A

Aborting
 Sweep 85
 AC/DC coupling 87
 Application cards 11
 Application notes 11
 Attenuation 71
 Auto ID
 External Mixer (remote) 191
 Threshold (External Mixer, remote control) 194
 Auto level range 71
 Averaging 70

B

Band
 External Mixer (remote) 189
 Bandwidth
 Resolution 40, 69
 Bias
 External Mixer (remote) 188
 Brochures 11

C

Calibration 37, 69, 85
 Recall 40
 Save 39
 Capture time
 see also Measurement time 155
 Center frequency 49
 Channel
 Creating (remote) 118, 120
 Deleting (remote) 118
 Duplicating (remote) 117
 Querying (remote) 119
 Renaming (remote) 119
 Replacing (remote) 118
 Selecting (remote) 120
 Clear 53
 Closing
 Channels (remote) 118
 Windows (remote) 127
 Comment
 Limit lines 109
 Compatibility
 Limit lines 107
 Continuous sweep
 Softkey 85
 Conventions
 SCPI commands 113
 Conversion loss
 External Mixer (remote) 192, 193
 Conversion loss tables
 Available (remote) 185
 Band (remote) 184
 Bias (remote) 184
 Deleting (remote) 185
 External Mixer (remote) 192

Harmonic order (remote) 186
 Mixer type (remote) 187
 Selecting (remote) 187

Copying

Channel (remote) 117
 Traces 98

D

Data format
 Remote 205
 Data sheets 11
 Decimal separator
 Trace export 99, 101
 Deleting
 Limit line values 110
 Delta markers
 Defining 103
 Direct measurement 54
 Direct measurements 32
 Drop-out time
 Trigger 81
 Duplicating
 Channel (remote) 117
 DUT characteristics 54

E

ENR 55
 ENR source 57
 ENR table 59
 Delete 61
 Edit 60, 61
 Evaluation methods
 Remote 121
 Excess noise ratio (ENR) 55
 Exporting
 Measurement settings 99
 Traces 98, 99, 101
 External generator
 Interface 89
 Interface settings 88
 External Mixer
 Activating (remote) 194
 Band 189
 RF overrange 193
 Type 193
 External reference
 External generator control 89
 External trigger 80
 Level (remote) 160

F

Filters
 High-pass (RF input) 87
 RBW 40
 YIG (remote) 183
 Fixed LO 55
 Format
 Data (remote) 205
 Free Run
 Trigger 80

Frequency	
Center	49
Span	49
Start	49
Stepsize	50
Stop	49
Frequency conversion	54
Frequency conversion measurements	32
Frequency list	29, 52
Frequency set	47
Frequency table	52, 53

G

Gate	
Delay	83
Length	83
Mode	83
Settings	82
Gated trigger	
Activating	82
Delay	83
Length	83
Mode	83
Gating	
Source	80
Generator type	
External generator	88
Generators	
Frequency range, external generator	89
Power range, external generator	89
Setup files, external generator	88, 89
Getting started	10
GPIO	
Address, External generator	89
External generator	89
TTL synchronization, External generator	89
Group delay	
Smoothing	97

H

Handover frequency	
External Mixer (remote)	188
Hardware settings	
Displayed	15
Harmonics	
External Mixer (remote)	190, 191
High-pass filter	
RF input	87
Hysteresis	
Trigger	81

I

IF Power	
Trigger level (remote)	161
Image rejection	55
Impedance	
Setting	87
Input	
Coupling	87
Input loss	63
Inserting	
Limit line values	110
Installation	13
Instrument security procedures	10

K

Keys	
Peak Search	105
RUN CONT	85
RUN SINGLE	85

L

Limit lines	106
Activating/Deactivating	107
Comment	109
Compatibility	107
Copying	108
Creating	108
Data points	110
Deactivating	108
Deleting	108
Deleting values	110
Details	108
Editing	108
Inserting values	110
Managing	106
Name	109
Saving	110
Selecting	108
Shifting	110
Traces	107
View filter	107
Visibility	107
Y-axis	109
Lines	
Configuration	106
Limit, see Limit lines	106
LO	
Level (External Mixer, remote control)	191
Loss	
Input	63
Output	63
Loss table	66
Delete	67
Edit	67
Losses	63

M

Marker	42
Markers	
Deactivating	103
Delta markers	103
Minimum	105
Next minimum	106
Next peak	105
Peak	105
Table	104
Type	103
Maximizing	
Windows (remote)	128
Measurement	
Frequency list	29
Performing	84
Measurement point	
Delete	53
Insert	53
Measurement points	49
Measurement time	
Remote	155

- Minimum 105
 - Marker positioning 105
 - Next 106
- Multiple
 - Measurement channels 14
- N**
- Name
 - Limit lines 109
- Next Minimum 106
 - Marker positioning 106
- Next Peak 105
 - Marker positioning 105
- Noise source 37
- Noise source characteristics 55
- O**
- Options
 - High-pass filter 87
 - Preamplifier 71
- Output loss 63
- Overview
 - Configuration 45
- P**
- Peak search
 - Key 105
- Peaks
 - Marker positioning 105
 - Next 105
 - Softkey 105
- Populate 53
- Ports
 - External Mixer (remote) 193
- Position
 - Limit line values 110
- Preamplifier
 - Setting 71
 - Softkey 71
- Preset
 - Bands (External Mixer, remote) 189
- Presetting
 - Channels 47
- Pretrigger 81
- Preview
 - Trigger/Gate settings 79
- R**
- RBW 69
 - see Resolution Bandwidth 40
- Reference frequency
 - External generator 89
- Reference level 70
- Release notes 11
- Remote commands
 - Basics on syntax 112
 - Boolean values 116
 - Capitalization 113
 - Character data 116
 - Data blocks 117
 - Numeric values 115
 - Optional keywords 114
 - Parameters 115
 - Strings 117
 - Suffixes 114
- Resolution bandwidth 69
 - Impact 40
- Restoring
 - Channel settings 47
- Results
 - Data format (remote) 205
 - Exporting 99
- RF attenuation 71
- RF overrange
 - External Mixer 193
- RF Power
 - Trigger level (remote) 161
- Room temperature 59
- RUN CONT
 - Key 85
- RUN SINGLE
 - Key 85
- S**
- Safety instructions 11
- Saving
 - Limit lines 110
- Security procedures 10
- Sensitivity
 - RBW 40
- Sequencer 14
 - Activating (remote) 179
 - Remote 178
- Sequences
 - Aborting (remote) 179
 - Mode (remote) 180
- Service manual 10
- Settling time 70
- Setup files
 - External generator 88, 89
- Shift x
 - Limit lines 110
- Shift y
 - Limit lines 110
- Signal capturing
 - Duration (remote) 155
- Signal ID
 - External Mixer (remote) 191
- Single sweep
 - Softkey 85
- Slope
 - Trigger 82, 161
- Smoothing
 - Traces (group delay) 97
- Softkeys
 - Continuous Sweep 85
 - External 80
 - Free Run 80
 - Line Config 106
 - Min 105
 - Next Min 106
 - Next Peak 105
 - Norm/Delta 103
 - Peak 105
 - Preamp 71
 - Single Sweep 85
 - Trigger Offset 81
 - Trigger/Gate Config 78
- Span 49

- Specifics for
 - Configuration 47
- Start frequency 49
- Step(size) 50
- Stop frequency 49
- Suffixes
 - Common 112
 - Remote commands 114
- Sweep
 - Aborting 85
 - Time (remote) 155
- Sweep time 69
- T**
- TCP/IP
 - Address, External generator 89
 - External generator 89
- Temperature 59
- Trace 96
 - Mode 41
 - Preset 98
 - Selection 97
- Traces
 - Copying 98
 - Copying (remote control) 206
 - Export format 99, 101
 - Exporting 98, 99, 101
 - Mode (remote) 202
- Traces to be Checked
 - Limit lines 107
- Trigger
 - Configuration preview 79
 - Drop-out time 81
 - External (remote) 161
 - Holdoff 81
 - Hysteresis 81
 - Offset 81
 - Slope 82, 161
- Trigger level 81
 - External trigger (remote) 160
 - IF Power (remote) 161
 - RF Power (remote) 161
- Trigger source 80
 - External 80
 - Free Run 80
- Trigger/Gate
 - Configuration (Softkey) 78
- TTL handshake
 - see TTL synchronization 89
- TTL synchronization
 - External generator 89
- Tuning mode 28, 48
- V**
- Videos 11
- View filter
 - Limit lines 107
- Visible
 - Limit lines 107
- W**
- White papers 11
- Window title bar information 15
- Windows
 - Adding (remote) 121
 - Closing (remote) 127
 - Configuring 47
 - Layout (remote) 125
 - Maximizing (remote) 128
 - Querying (remote) 123
 - Replacing (remote) 124
 - Splitting (remote) 128
 - Types (remote) 121
- Y**
- Y-axis
 - Limit lines 109
- YIG-preselector
 - Activating/Deactivating 87
 - Activating/Deactivating (remote) 183