# R&S®TA-TRS RF Performance Testing User Manual



1528936102 Version 05



Make ideas real



This manual applies to the following options:

- R&S QuickStep Sequencer (1528.9049.02)
- R&S QS-ETM (1528.9110.02)
- R&S QS-ETMU (1529.9126.02)

The contents of this manual correspond to R&S QuickStep Sequencer version 4.60 or higher.

The firmware of the instrument uses several valuable open source software packages. For information, see the "Open Source Acknowledgment" document, which is available for download from the customer web section on GLORIS, the global Rohde & Schwarz information system: https://extranet.rohde-schwarz.com.

Rohde & Schwarz would like to thank the open source community for their valuable contribution to embedded computing.

© 2021 Rohde & Schwarz GmbH & Co. KG Mühldorfstr. 15, 81671 München, Germany Phone: +49 89 41 29 - 0 Email: info@rohde-schwarz.com Internet: www.rohde-schwarz.com Subject to change – data without tolerance limits is not binding. R&S<sup>®</sup> is a registered trademark of Rohde & Schwarz GmbH & Co. KG. Trade names are trademarks of the owners.

1528.9361.02 | Version 05 | R&S®TA-TRS

The following abbreviations are used throughout this manual: R&S<sup>®</sup> is abbreviated as R&S ; e.g. R&S<sup>®</sup>TA-TRS is abbreviated as R&S TA-TRS.

## Contents

1	R&S TA-TRS Overview	5
2	Prerequisites	6
2.1	EN303340	6
2.1.1	One Box Setup	6
2.1.2	Multi Box Setup	7
2.2	EN303345	8
2.2.1	One Box Setup	8
2.2.2	Multi Box Setup	9
2.3	EN303372-2	11
2.3.1	One Box Setup	11
2.3.2	Multi Box Setup	12
3	Starting TA-TRS	14
3.1	Quickstep Setup	14
3.2	Instrument Setup Menu	15
3.2.1	QS-ETM	15
4	Test Setup	18
<b>4</b> 4.1	Test Setup EN303340 & EN303372 Automated Test Setup	
<b>4</b> 4.1 4.2	Test Setup EN303340 & EN303372 Automated Test Setup EN303340 & EN303372 Automated Test Setup with Camera	18 
4 4.1 4.2 4.3	Test Setup EN303340 & EN303372 Automated Test Setup EN303340 & EN303372 Automated Test Setup with Camera EN303345 Automated Test Setup	
4 4.1 4.2 4.3 5	Test Setup EN303340 & EN303372 Automated Test Setup EN303340 & EN303372 Automated Test Setup with Camera EN303345 Automated Test Setup Test Configuration	
4 4.1 4.2 4.3 5 5.1	Test Setup         EN303340 & EN303372 Automated Test Setup         EN303340 & EN303372 Automated Test Setup with Camera         EN303345 Automated Test Setup         Test Configuration         Test Properties	
4 4.1 4.2 4.3 5 5.1 5.1.1	Test Setup.         EN303340 & EN303372 Automated Test Setup.         EN303340 & EN303372 Automated Test Setup with Camera.         EN303345 Automated Test Setup.         Test Configuration.         Test Properties.         File Settings.	
4 4.1 4.2 4.3 5 5.1.1 5.1.1 5.1.2	Test Setup.         EN303340 & EN303372 Automated Test Setup.         EN303340 & EN303372 Automated Test Setup with Camera.         EN303345 Automated Test Setup.         Test Configuration.         Test Properties.         File Settings.         ReRun Settings.	
4 4.1 4.2 4.3 5 5.1.1 5.1.1 5.1.2 5.1.3	Test Setup.         EN303340 & EN303372 Automated Test Setup.         EN303340 & EN303372 Automated Test Setup with Camera.         EN303345 Automated Test Setup.         Test Configuration.         Test Properties.         File Settings.         ReRun Settings.         General Dialog.	
4 4.1 4.2 4.3 5 5.1.1 5.1.1 5.1.2 5.1.3 5.1.3	Test Setup.         EN303340 & EN303372 Automated Test Setup.         EN303340 & EN303372 Automated Test Setup with Camera.         EN303345 Automated Test Setup.         Test Configuration.         Test Properties.         File Settings.         ReRun Settings.         General Dialog.         Compensation Dialog.	
<ul> <li>4</li> <li>4.1</li> <li>4.2</li> <li>4.3</li> <li>5</li> <li>5.1.1</li> <li>5.1.2</li> <li>5.1.3</li> <li>5.1.4</li> <li>5.1.5</li> </ul>	Test Setup.         EN303340 & EN303372 Automated Test Setup.         EN303340 & EN303372 Automated Test Setup with Camera.         EN303345 Automated Test Setup.         Test Configuration.         Test Properties.         File Settings.         ReRun Settings.         General Dialog.         Compensation Dialog.         Remote Control DUT Dialog.	18 19 21 24 24 24 24 24 24 24 24 
<ul> <li>4</li> <li>4.1</li> <li>4.2</li> <li>4.3</li> <li>5</li> <li>5.1.1</li> <li>5.1.2</li> <li>5.1.3</li> <li>5.1.4</li> <li>5.1.5</li> <li>5.1.6</li> </ul>	Test Setup.         EN303340 & EN303372 Automated Test Setup.         EN303340 & EN303372 Automated Test Setup with Camera.         EN303345 Automated Test Setup.         Test Configuration.         Test Properties.         File Settings.         ReRun Settings.         General Dialog.         Compensation Dialog.         Remote Control DUT Dialog.         Signal Mode List Dialog.	18 19 21 24 24 24 24 24 24 24 23 
<ul> <li>4</li> <li>4.1</li> <li>4.2</li> <li>4.3</li> <li>5</li> <li>5.1.1</li> <li>5.1.2</li> <li>5.1.3</li> <li>5.1.4</li> <li>5.1.5</li> <li>5.1.6</li> <li>5.2</li> </ul>	Test Setup         EN303340 & EN303372 Automated Test Setup         EN303340 & EN303372 Automated Test Setup with Camera         EN303345 Automated Test Setup         Test Configuration         Test Properties         File Settings         ReRun Settings         General Dialog         Compensation Dialog.         Remote Control DUT Dialog.         Signal Mode List Dialog.         Test Cases.	18 19 21 24 24 24 24 25 25 32 33 33
<ul> <li>4.1</li> <li>4.2</li> <li>4.3</li> <li>5</li> <li>5.1.1</li> <li>5.1.2</li> <li>5.1.3</li> <li>5.1.4</li> <li>5.1.5</li> <li>5.1.6</li> <li>5.2.1</li> </ul>	Test Setup.         EN303340 & EN303372 Automated Test Setup.         EN303340 & EN303372 Automated Test Setup with Camera.         EN303345 Automated Test Setup.         Test Configuration.         Test Properties.         File Settings.         ReRun Settings.         General Dialog.         Compensation Dialog.         Signal Mode List Dialog.         EN303340.	18 19 21 24 24 24 24 24 24 25 32 33 35 35

5.2.3	EN303372-2 Test Case	44
6	Test Preparation	46
6.1	Compensating Losses	46
6.1.1	Compensation Setup	48
6.1.2	Instrument Configuration	49
6.1.3	Status	51
6.1.4	Result and Normalization Tab	51
6.1.5	Compensation File Save / Open	52
6.2	Learning DUT IR Commands	52
6.2.1	RedRat Prerequisites	52
6.2.2	Start RedRat	54
6.2.3	Teaching RedRat	56
6.2.4	Constructing Sequences	58
6.3	AVB Camera Setup	60
6.3.1	AVB Camera Prerequisites	61
6.3.2	AVB Camera Connection Test with Pylon Software	61
6.3.3	AVB Camera Test Setup	63
7	Test Status and Results	71
7.1	Test with Auto Mode	71
7.2	Test with Full Manual Mode	72
7.3	Test with Semi Manual Mode	73
7.4	Test with Simple Manual Mode	74
7.5	Test Result	75
	Index	77

## 1 R&S TA-TRS Overview

R&S TA-TRS is a sequencer software tool that is used together with R&S BTC and certain accessories to provide the user with test automation and test reporting capabilities. The software features a user-friendly interface and unique test configurations such as compensation loss, multiple interfering signals and smart learning of DUT control via infrared remote control.

Used together with the R&S Broadcast Instruments, it offers users easy execution and management of test cases for product validation and production testing. Offers an automated test platform to perform RF and interoperability tests. In these tests, you verify your product in accordance to the ETSI standards.

The test suite is designed to optimize the testing time. The versatile configuration allows you to tailor the tests according to your different requirements, for example you can perform the tests only on a subset of test signals.

The key facts are as followed:

- Supports all test cases for EN 303340, EN 303345 and EN 303372-2
- Automated detection of picture failure point for video and audio
- Optional camera solution for automated error detection on TV screens
- Intuitive state-of-the-art GUI with signal path loss compensation
- Reproducible and consistent test results
- Future-proof solution since more standards can easily be integrated into the software solution

## 2 Prerequisites

These required equipment need to be installed before using R&S TA-TRS:

- Required hardware and operating system
  - Standard PC
  - Windows 7 as 64 bit version, including service pack 1 and universal C runtime update (KB2999226) or Windows 8.1, Windows 10 (capped by Windows 7 only if uses with AVBCAM)
- R&S QuickStep sequencer software tool V4.60
- Broadcast Test Center (R&S BTC) firmware version 02.32 or higher.

### 2.1 EN303340

The following provides information for one or multiple box setup requirements.

### 2.1.1 One Box Setup

R&S BTC test instrument with the following options:

BTC - Main Signal

- Broadcast Test Center (R&S BTC)
- Baseband Generator first channel (R&S BTC-B1)
- Baseband Generator second channel (R&S BTC-B2)
- Baseband Main Module, two I/Q paths to RF (R&S BTC-B12)
- RF Path A, 100 kHz to 3 GHz (R&S BTC-B3103)
- RF Path B, 100 kHz to 3 GHz (R&S BTC-B3203)
- Extended Baseband Routing (R&S BTC-K8)
- Multimedia Generator Suite (R&S BTC-K20 Included in base unit)
- Arbitrary Waveform Generator (R&S BTC-K35)
- Basic Stream library (R&S LIB-K70)
- DVB-T/DVB-H Coder (R&S BTC-K501)
- DVB-T2 Coder (R&S BTC-K516)
- DTV Interferers (R&S WV-K1114)
- AV Distortion Analysis (R&S VT-K2111)
- HDMI RX 300 MHz (R&S VT-B2361)
- Power Measurement (R&S BTC-K2055)
- Power Sensor that BTC supports
- RedRat IR Remote Controller (R&S BTC-Z)

Camera option for DUT with screen like TV

• AVB Camera Software (R&S BTC-KT3329)

• Camera accessories (R&S BTC-Z3329)

Required files in R&S BTC

- Stream files: After installing TA-TRS in the PC, TimeCodeTRP.zip file is saved under
  - C:\Users\Public\Documents\Rohde-Schwarz\QuickStep\Projects\
- TimeCodeTRP.zip: Unzip and copy them into D:\TSGEN\AVBrun\
  - Grouper\_576i\_50.trp
  - Grouper\_720p\_50.trp
  - Grouper\_720p\_50\_Camera.trp
  - Colorbar\_720p\_50.trp
- Interferer signals: After installing TA-TRS in the PC, EN303340\_interferer\_files\_V2.zip file is saved under C:\Users\Public\Documents\Rohde-Schwarz\QuickStep\Projects\
- EN303340\_interferer\_files\_V2.zip: Unzip and copy them into D:\ARB\DTV\_INTERFERERS\
  - LTE\_BS-idle\_V3\_synth.wv
  - LTE\_BS-100PC\_synth.wv
  - Short\_UE-Video-Stream\_V2.wv
  - DVB-T\_8MHz.wv (SFU-K354)

### 2.1.2 Multi Box Setup

R&S BTC (1path) and R&S SFE instruments with the following options:

BTC - Main Signal

- Broadcast Test Center (R&S BTC)
- Baseband Generator first channel (R&S BTC-B1)
- Baseband Generator second channel (R&S BTC-B2)
- Baseband Main Module, one I/Q path to RF (R&S BTC-B11)
- RF Path A, 100 kHz to 3 GHz (R&S BTC-B3103)
- Multimedia Generator Suite (R&S BTC-K20 Included in base unit)
- Basic stream library (R&S LIB-K70)
- DVB-T/DVB-H Coder (R&S BTC-K501)
- DVB-T2 Coder (R&S BTC-K516)
- AV Distortion Analysis (R&S VT-K2111)
- HDMI RX 300 MHz (R&S VT-B2361)
- Power Measurement (R&S BTC-K2055)
- Power Sensor that BTC supports
- RedRat IR Remote Controller (R&S BTC-Z)

SFE - Interferer Signal

Broadcast Tester (R&S SFE)

- Memory Expansion (R&S SFE-B3)
- ARB Waveform Generator (R&S SFE-K35)
- DTV Interferers (R&S SFU-K354)

Camera option for DUT with screen like TV

- AVB Camera Software (R&S BTC-KT3329)
- Camera accessories (R&S BTC-Z3329)

Required files in R&S BTC

• Stream files: After installing TA-TRS in the PC, TimeCodeTRP.zip file is saved under

C:\Users\Public\Documents\Rohde-Schwarz\QuickStep\Projects\

- TimeCodeTRP.zip: Unzip and copy them into D:\TSGEN\AVBrun\
  - Grouper\_576i\_50.trp
  - Grouper\_720p\_50.trp
  - Grouper\_720p\_50\_Camera.trp
  - Colorbar\_720p\_50.trp

Required files in R&S SFE

- Interferer signals: After installing TA-TRS in the PC, EN303340\_interferer\_files\_V2.zip file is saved under C:\Users\Public\Documents\Rohde-Schwarz\QuickStep\Projects\
- EN303340\_interferer\_files\_V2.zip: Unzip and copy them into D:\ARB\DTV INTERFERERS\
  - LTE\_BS-idle\_V3\_synth.wv
  - LTE\_BS-100PC\_synth.wv
  - Short\_UE-Video-Stream\_V2.wv
  - DVB-T\_8MHz.wv (SFU-K354)

### 2.2 EN303345

The following provides information for one or multiple box setup requirements.

### 2.2.1 One Box Setup

R&S BTC test instrument with the following options:

BTC - Main Signal

- Broadcast Test Center (R&S BTC)
- Baseband Generator first channel (R&S BTC-B1)
- Baseband Generator second channel (R&S BTC-B2)
- Baseband Main Module, two I/Q paths to RF (R&S BTC-B12)
- RF Path A, 100 kHz to 3 GHz (R&S BTC-B3103)

- RF Path B, 100 kHz to 3 GHz (R&S BTC-B3203)
- Extended Baseband Routing (R&S BTC-K8)
- Multimedia Generator Suite (R&S BTC-K20 Included in base unit)
- AM/FM RDS RDBS Coder (R&S BTC-PK570)
- DAB/DAB+/T-DMB Coder (R&S BTC-PK511)
- T-DMB/DAB Streams (R&S LIB-K51)
- DRM/DRM+ Coder (R&S BTC-PK519)
- DRM/DRM+ MDI Stream Library (R&S LIB-K60)
- Analog A/V RX (R&S VT-B2370)
- Audio Analysis (R&S VT-K2150)
- Power Measurement (R&S BTC-K2055)
- Power Sensor that BTC supports
- RedRat IR Remote Controller (R&S BTC-Z)

Required files in R&S BTC

- FM and AM noise source. Above BTC2.30, It is default files under D:\AUDIOPLAYER\CCIR559\
  - AWGN\_CCIR559\_4500Hz\_120s\_V3.wav
  - AWGN\_CCIR559\_15kHz\_120s\_V3.wav
- DAB stream(LIB-K51 option): Copy them into D:\TSGEN\TDMB\_DAB\DAB\
  - RED\_Sine+\_120s\_eti\_ni\_file.dab\_c
  - PRODUCT-STREAM-01\_V1.0.eti
  - PRODUCT-STREAM-02\_V1.0.eti
- DRM stream(LIB-K60 option): Copy them into D:\TSGEN\DRM\
  - HF.DCP\_C
  - LFMF.DCP\_C
  - VHF.DCP\_C
  - HF\_wanted.DCP\_C
  - HF\_unwanted.DCP\_C
  - LFMF\_wanted.DCP\_C
  - LFMF\_unwanted.DCP\_C
  - VHF\_wanted.DCP\_C
  - VHF\_unwanted.DCP\_C

### 2.2.2 Multi Box Setup

R&S BTC(1path) and R&S SFE instruments with the following options:

- SFE Main Signal
- Broadcast Tester (R&S SFE)
- Memory Expansion (R&S SFE-B3)
- AM/FM/RDS Coder (R&S SFE-K170)

- TRP Player (R&S SFE-K22)
- T-DMB/DAB Coder (R&S SFE-K11)
- T-DMB/DAB Streams (R&S SFU-K221)
- DRM/DRM+ Coder (R&S BTC-PK519)
- DRM/DRM+ MDI Stream Library (R&S LIB-K60)

BTC - Interferer Signal

- Broadcast Test Center (R&S BTC)
- Baseband Generator first channel (R&S BTC-B1)
- Baseband Generator second channel (R&S BTC-B2)
- Baseband Main Module, one I/Q path to RF (R&S BTC-B11)
- RF Path A, 100 kHz to 3 GHz (R&S BTC-B3103)
- Multimedia Generator Suite (R&S BTC-K20 Included in base unit)
- AM/FM RDS RDBS Coder (R&S BTC-K570)
- DAB/DAB+/T-DMB Coder (R&S BTC-K511)
- T-DMB/DAB Streams (R&S LIB-K51)
- DRM/DRM+ Coder (R&S BTC-PK519)
- DRM/DRM+ MDI Stream Library(R&S LIB-K60)
- Analog A/V RX (R&S VT-B2370)
- Audio Analysis (R&S VT-K2150)
- Power Measurement (R&S BTC-K2055)
- Power Sensor that BTC supports
- RedRat IR Remote Controller (R&S BTC-Z)

Required files in R&S SFE

- DAB stream(SFU-K221option): Copy them into D:\TSGEN\TDMB DAB\DAB\
  - RED\_Sine+\_120s\_eti\_ni\_file.dab\_c
  - PRODUCT-STREAM-01\_V1.0.eti
  - PRODUCT-STREAM-02\_V1.0.eti
- DRM stream(LIB-K60 option): Copy them into D:\TSGEN\DRM\
  - HF.DCP\_C
  - LFMF.DCP\_C
  - VHF.DCP\_C
  - HF\_wanted.DCP\_C
  - HF\_unwanted.DCP\_C
  - LFMF\_wanted.DCP\_C
  - LFMF\_unwanted.DCP\_C
  - VHF\_wanted.DCP\_C
  - VHF\_unwanted.DCP\_C

### Required files in R&S BTC

- FM and AM noise source: Above BTC2.30, It is default files under D:\AUDIOPLAYER\CCIR559\
  - AWGN\_CCIR559\_4500Hz\_120s\_V3.wav
  - AWGN\_CCIR559\_15kHz\_120s\_V3.wav

DAB stream(LIB-K51 option): Copy them into D:\TSGEN\TDMB\_DAB\DAB\

- RED\_Sine+\_120s\_eti\_ni\_file.dab\_c
- PRODUCT-STREAM-01\_V1.0.eti
- PRODUCT-STREAM-02\_V1.0.eti
- DRM stream(LIB-K60 option): Copy them into D:\TSGEN\DRM\
  - HF.DCP\_C
  - LFMF.DCP\_C
  - VHF.DCP\_C
  - HF\_wanted.DCP\_C
  - HF\_unwanted.DCP\_C
  - LFMF\_wanted.DCP\_C
  - LFMF\_unwanted.DCP\_C
  - VHF\_wanted.DCP\_C
  - VHF\_unwanted.DCP\_C

### 2.3 EN303372-2

The following provides information for one or multiple box setup requirements.

### 2.3.1 One Box Setup

R&S BTC test instrument with the following options:

BTC - Main Signal

- Broadcast Test Center (R&S BTC)
- Baseband Generator first channel (R&S BTC-B1)
- Baseband Generator second channel (R&S BTC-B2)
- Baseband Main Module, two I/Q paths to RF (R&S BTC-B12)
- RF Path A, 100 kHz to 3 GHz (R&S BTC-B3103)
- RF Path B, 100 kHz to 3 GHz (R&S BTC-B3203)
- Extended Baseband Routing (R&S BTC-K8)
- Multimedia Generator Suite (R&S BTC-K20 Included in base unit)
- Basic stream library (R&S LIB-K70)
- DVB-S/DVB-S2, DSNG Coder (R&S BTC-PK508)
- Additive White Gaussian Noise (AWGN) (R&S BTC-K1040)

- AV Distortion Analysis (R&S VT-K2111)
- HDMI RX 300 MHz (R&S VT-B2361)
- Power Measurement (R&S BTC-K2055)
- Power Sensor that BTC supports
- RedRat IR Remote Controller (R&S BTC-Z)

Camera Option for DUT with screen like TV

- AVB Camera Software (R&S BTC-KT3329)
- Camera accessories (R&S BTC-Z3329)

Required files in R&S BTC

• Stream files: After installing TA-TRS in the PC, TimeCodeTRP.zip file is saved under

C:\Users\Public\Documents\Rohde-Schwarz\QuickStep\Projects\

- TimeCodeTRP.zip: Unzip and copy them into D:\TSGEN\AVBrun\
  - Grouper\_576i\_50.trp
  - Grouper\_720p\_50.trp
  - Grouper\_720p\_50\_Camera.trp
  - Colorbar\_720p\_50.trp

### 2.3.2 Multi Box Setup

R&S BTC(1path) and R&S SFE instruments with the following options:

BTC - Main Signal

- Broadcast Test Center (R&S BTC)
- Baseband Generator first channel (R&S BTC-B1)
- Baseband Main Module, one I/Q path to RF (R&S BTC-B11)
- RF Path A, 100 kHz to 3 GHz (R&S BTC-B3103)
- Multimedia Generator Suite (R&S BTC-K20 Included in base unit)
- Basic Stream Library (R&S LIB-K70)
- DVB-S/DVB-S2, DSNG Coder (R&S BTC-K508)
- Additive White Gaussian Noise (AWGN) (R&S BTC-K1040)
- AV Distortion Analysis (R&S VT-K2111)
- HDMI RX 300 MHz (R&S VT-B2361)
- Power Measurement (R&S BTC-K2055)
- Power Sensor that BTC supports
- RedRat IR Remote Controller (R&S BTC-Z)

SFE - Interferer Signal

- Broadcast Tester (R&S SFE)
- Memory Expansion (R&S SFE-B3)
- DVB-S/DVB-DSNG Coder (R&S SFE-K3)
- DVB-S2 Coder (R&S SFE-K8)

• TRP Player(R&S SFE-K22)

Camera Option for DUT with screen like TV

- AVB Camera Software (R&S BTC-KT3329)
- Camera accessories (R&S BTC-Z3329)

Required files in R&S BTC

• Stream files: After installing TA-TRS in the PC, TimeCodeTRP.zip file is saved under

C:\Users\Public\Documents\Rohde-Schwarz\QuickStep\Projects\

- TimeCodeTRP.zip: unzip and copy them into D:\TSGEN\AVBrun\
  - Grouper\_576i\_50.trp
  - Grouper\_720p\_50.trp
  - Grouper\_720p\_50\_Camera.trp
  - Colorbar\_720p\_50.trp

Required files in R&S SFE

• Stream files: After installing TA-TRS in the PC, TimeCodeTRP.zip file is saved under

C:\Users\Public\Documents\Rohde-Schwarz\QuickStep\Projects\

- TimeCodeTRP.zip: unzip and copy them into D:\TSGEN\AVBrun\
  - Grouper\_576i\_50.trp
  - Grouper\_720p\_50.trp
  - Grouper\_720p\_50\_Camera.trp
  - Colorbar\_720p\_50.trp

## 3 Starting TA-TRS

To start using TA-TRS:

- Install R&S Quickstep
- Insert the Quickstep Dongle and connect with the instrument.
- Start the R&S Quickstep from the Windows "Start" menu

### 3.1 Quickstep Setup

The following descries the steps need to be setup and configure in Quickstep to run TA-TRS:

- 1. Open QuickStep.
- 2. Select Test Project (.tpl file) for file with \_Simulation naming convention runs without instruments for demo purpose.

Use	ers	Public > Public Documents > Rohde-Schw	varz 🕨 QuickStep 🕨 Pro	ojects ► QS-ETM ►
Inc	lud	e in library 🔻 Share with 👻 New folder		
	٠	Name	Туре	Size
		퉬 ActiveReports	File folder	
		🌗 Results	File folder	
		🔲 🔄 CalibrationETM.tpl	R&S QuickStep te	56 KB
<b>.</b>		EN303340ETM.tpl	R&S QuickStep te	99 KB
200		EN303340ETM_Simulation.tpl	R&S QuickStep te	99 KB
nts		EN303345ETM.tpl	R&S QuickStep te	93 KB
as		EN303345ETM_Simulation.tpl	R&S QuickStep te	93 KB
	=	EN303372-2ETM.tpl	R&S QuickStep te	91 KB
		EN303372-2ETM_Simulation.tpl	R&S QuickStep te	97 KB

Figure 3-1: Test project files for ETM

a) Under

```
\label{eq:C:UsersPublicDocumentsRohde-SchwarzQuickStepProjects, The folder (QS-ETM) and files are created by installer automati-
```

- cally.
- b) QS-ETM: Test projects files for multi legacy instrument solution
- 3. Over at the "Test Steps" under "Test Project Browser", check that the test plan is loaded correctly.



Figure 3-2: Test plan name check

- 4. Set report name, type, path
  - a) Click "Test Cases" under "Test Procedure Before/After"
  - b) Set "Report Name"

Default name is "R&S EN303340 Test Report" for EN303340

- c) Set "Report Type"
  - Default Report type is DOC (Word file)
  - Available format: HTML, PDF, PDF + HTML, DOC
- d) Set "Report Path"

Default Report path is "C:\QuickStep\_Report\EN303340\" for EN303340

Test Project Browser 🔹 🎙		Test	Step	p Setti	ngs		-	RS_Report	t		
Group 🛅 Sequence 📋 Remove		Id	Er	nable	Breakpoint	Test Procedure	2	ReportNan	ne		
(w) Control Statements	1		0	4		Test Procedure	Before	R&S	_		
Control statements		Test	Step	p Setti	ngs			RS_Report	t\Sa	weReport	
Test Project Parameters		Id	Er	nable	Breakpoint	Test Procedure	3	ReportTyp	•	ReportPath	4
Image: A start steps	2		0			Test Procedure	After	DOC	F	C:\QuickStep_I	
🗆 📝 🛅 ETSI EN303340 Test Plan [1]								HTML	٦		
🖌 👜 Test Procedures Before/After								PDF + HT			
1 Test Cases [2]								DOC	nr.		
Testrun After [1]											

Figure 3-3: Report name, type, and path setting

### 3.2 Instrument Setup Menu

### 3.2.1 QS-ETM

1. Over at the "Test Steps" under "Test Project Browser", select the Test Plan

#### Instrument Setup Menu

Testplan Editor 🖁 Testprocedure Editor	∝ુ Sy	stem Co	nfigurator	🖄 Results Viewer	Test Execution
🕂 Add Test Step 🛛 🗙 Remove Test Step	Test Sys	tem: Sy	/stem 1	•	Single Run
Test Project Browser	- d	ep Setti	ings	-	AVBRun_Block_sv
🗁 Group 🛅 Sequence 🗴 Remove		Enable	Breakpoint	Test Procedure 📿	Instrument B
Control Statements				Test Cases	BTC 2 Path BTC 2 Path BTC + SFx BTC + SFx + VTx SFU + SFx + VTx

Figure 3-4: Instrument setup menu

- 2. In the"Instrument" combo box, select setup
- 3. EN303340 / EN303372-2 setup list
  - BTC 2 Path
  - BTC + SFx
  - BTC + SFx +VTx
  - SFU + SFx +VTx
- 4. EN303345 setup list
  - BTC 2 Path
  - BTC 2 Path + UPx
  - SFx + BTC
  - SFx + BTC + UPx



Figure 3-5: Configure VISA resource

Click "VISA"

6. Enter correct information Visa Resource

i

VBRun_Block_sw\Init_EN303340_EN303372_MIS								
Inst	rument Setup	BTC 2	Path	•				
BTC/SFU Vis	a Resource	TCPIP::19	92.168.1.1::HISLIP/2000	0 🕶 🗱				
SFx	Interfac	се Туре	HISLIP -					
VTx	Во	ard No.						
	Hostna	me / IP	192.168.1.1					
	I	nstance	/20000					
	Т	ïmeout	20000	ms				
		8	Check Connection					

User can input any Visa Resource information or make it blank for instruments that are not used. For empty information, there is warning message. However, user can ignore it

AVBRun_Block_sw\Init_EN303340_EN303372_MIS	Test Step Parameters 🔹 🖡
Instrument BTC/SFU Visa SFx Visa VTx Visa	Step No 1 Step Enabled 🗷
BTC 2 Path TCPIP::192.16	Step Id 3 Breakpoint 🗔
	Test Procedure Test Cases
	Test Step\Description
	Test Step Parameters
	AVBRun_Block_sw\Init_EN303340_EN303372_MIS
	Instrument Setup BTC 2 Path
	BTC/SFU Visa Resource TCPIP::192.168.1.1::HISLIP/20000 Visa
	SFx Visa Resource Visa
	VTx Visa Resource
	IP, GPIB or USB Address expected. e.g. TCPIP::192.168.2.1

## 4 Test Setup

There are different test setups for different standard manually and automatically. All the different test setups describes in following sub section.

### 4.1 EN303340 & EN303372 Automated Test Setup

The following setups are for EN303340/EN303372 automated testing for DUT without screen like set-top box. Based on K8 (Baseband routing) option, additional coupler or combiner is required. Legacy instrument option allows using SFU and SFE as an interferer signal with 1 path BTC.



Figure 4-1: Instrument setup without K8 option for DUT without screen



Figure 4-2: Instrument setup with K8 option for DUT without screen

EN303340 & EN303372 Automated Test Setup with Camera



Figure 4-3: Instrument setup with legacy instrument for DUT without screen (Optional)

There is a limitation when you use K8 option. Dynamic range between two signals like wanted signal and unwanted signal is 56 dB. So, result is more than 56 dB, report shows >56 dB.

The above setup consists of the following:

- Computer: TA-TRS installed connected to BTC via LAN or GPIB
- BTC: Proper options that mentioned in Chapter 2, "Prerequisites", on page 6
- Matching pad: DUT input is 75 ohm and BTC output is 50 ohm
- RedRat/RedRatX: DUT control for channel searching using IR (infrared) signal, which connected to computer. You need to run learning process to create control sequence before testing
- Coupler or Combiner: without K8 option, it is required to combine two signals
- Cables: RF cables, HDMI cable, LAN cables

### 4.2 EN303340 & EN303372 Automated Test Setup with Camera



Please do not use router to connect camera and BTC with PC. It drops transmission data rate from camera and cause missing frame.

The following setup is for EN303340/EN303372 automated testing with AVB Camera for DUT with screen like TV.

### EN303340 & EN303372 Automated Test Setup with Camera



Figure 4-4: Instrument setup without K8 option for DUT with screen



Figure 4-5: Instrument setup with K8 option for DUT with screen



Figure 4-6: Instrument setup with legacy instrument for DUT with screen (Optional)

The above setup consists of the following:

- Computer: TA-TRS installed connected to BTC via LAN. HDMI port is required with camera setup
- BTC: Proper options that mentioned in Chapter 2, "Prerequisites", on page 6
- Matching pad: DUT input is 75 ohm and BTC output is 50 ohm
- RedRat/RedRatX: DUT control for channel searching using IR (infrared) signal, which connected to computer. You need to run learning process to create control sequence before testing
- Coupler or Combiner: Without K8 option, it is required to combine two signals
- Cables: RF cables, HDMI cable, LAN cables
- AVB Camera software and camera: Camera capture TV screen and stream to PC via LAN. AVB camera software in PC detects correct video and output it to BTC via HDMI
- USB to LAN adapter: Main LAN port in PC is for camera. The adapter is for BTC control

### 4.3 EN303345 Automated Test Setup

The following setups are for EN303345 automated testing for Radio receiver DUT like analog or digital radio. Based on K8 (Baseband routing) option, additional coupler or combiner is required. Legacy instrument option allows using SFU and SFE as a main signal only because SFx does not have audio player which requires to play CCIR noise source for interferer signal.

EN303345 Automated Test Setup



Figure 4-7: Instrument setup without K8 option for Radio receiver



Figure 4-8: Instrument setup with K8 option for Radio receiver



Figure 4-9: Instrument setup with legacy instrument for Radio receiver (Optional)

There is a limitation when you use K8 option. Dynamic range between two signals like wanted signal and unwanted signal is 56 dB. So, result is more than 56 dB, report shows >56 dB.

The above setup consists of the following:

- Computer: TA-TRS installed connected to BTC via LAN or GPIB
- BTC: Proper options that mentioned in Chapter 2, "Prerequisites", on page 6
- UPL/UPV: Audio quality measurement
- Matching pad: DUT input is 75 ohm and BTC output is 50 ohm
- RedRat/RedRatX: DUT control for channel searching using IR (infrared) signal, which connected to computer. You need to run learning process to create control sequence before testing
- Coupler or Combiner: without K8 option, it is required to combine two signals
- Cables: RF cables, HDMI cable, LAN cables

## 5 Test Configuration

### 5.1 Test Properties

Several dialogs are provided for further test case configuration. The parameters in these dialogs apply to all test cases in the test suite.

V1.1.2				
File	ReRun			
	General	Compensation Setting	Remote Control DUT	Signal Mode List

Figure 5-1: Test configuration menu

### 5.1.1 File Settings

For the File Section, there are three functions as follows:

- Open Test Setting: Load existing test setting.
- Open Default Setting: Reset all settings back to default.
- Save Test Setting: Save the setting for the test for loading in future.

V1.1.2	
File	ReRun
F	Open Test Settting
	Open Default Setting
	Save Test Setting

Figure 5-2: File settings menu

### 5.1.2 ReRun Settings

ReRun features provide convenient test plan and report file generation. Whenever test is done, TA-TRS generates report file (PDF, HTML, WORD) based on you setting. In addition, the log file, which contains all test result information, is automatically generated in the same location with the same filename. Using the log file, you can use below menus.

V1	.1.2		
	File	ReRun	
F		Rel	Run Failed TestCase
		Res	sume TestCase

Figure 5-3: ReRun Settings menu

For the ReRun Section, there are two functions as follows:

- ReRun Failed TC
  - It works for the test result that is finished
  - TA-TRS only run the test cases that have "FAIL" result
  - Other "PASS" results are copied to the report without testing
- Resume Failed TC
  - It works for the test result that is stopped or canceled during the test
  - TA-TRS find final test position and resume the test
  - All results before final test position are copied to the report without testing

### 5.1.3 General Dialog

General

In the "Test Properties", select "General" tab.

### 5.1.3.1 EN303340 and EN303372-2

#### **Test condition**

Fest Conditions	Picture Failure Report
Test Setup & Me	thod
2RF Paths	✓ Detailed Method ▼
Picture Degrada	tion Judgement
	Auto
A/V Interface	
	HDMI 👻
-	
Test Video Strea	im
EDID Loading	Grouper_720p_50.trp
EDID Loading	Grouper_720p_50.trp  Stream Path - D:\TSGEN\AVBrun\

Figure 5-4: Video test conditions in General dialog

The Test Conditions tab under "General" dialog consists of the followings:

Test Setup

Set the test setup. Two setups are available based on BTC-K8 (Baseband routing):

- "2RF Paths"
  - It uses 2 RF path BTC with combiner or coupler

2 Path Compensation file (\*.2comp) is only available for "Compensation Setting"

- "1RF Path (K8)"

It uses 1 RF path BTC with baseband routing option (BTC-K8)

1 Path Compensation file (\*.1comp) is only available for "Compensation Setting"

• Method

Set the test method. Two approaches are available:

- "Detailed Method"
   Iterates through a range of levels to find out the exact level where the picture failure happens in the DUT
- "Quick Method"
   Directly tests the DUT with the limit requirement. At the end of the test, a Passed/failed verdict is given
- "Picture Degradation Judgement"

Select the mode of the picture failure point measurement.

– "Auto"

Measures the picture failure using the AV distortion analyzer application. Requires AV distortion analysis (R&S VT-K2111) with HDMI hardware. If this option is not installed, you can perform the measurement manually.

- "Manual"

Measures the picture failure using the human eyes. Watch the TV screen to judge the picture failure point. For manual mode, it is classified to "Full Manual", "Semi Manual" and simple manual. It is describes in detail in the Chapter 7, "Test Status and Results", on page 71 section. Alarm can be sounded during either start or finish by checking on the "Start" and "Finish" checkbox.

Picture Degradation Judgement

	Semi Ma	nual	•
Sour	nd Alarm	Start	Finish

Figure 5-5: Manual mode with sound alarm selection

A/V Interface

Select the input signal for measurement. The available signals depend on the installed options and modules

– "HDMI"

HDMI input of the HDMI RX module (R&S VT-B2361)

- "Composite" Composite input of the A/V RX module (R&S VT-B2370)
- "Camera"
   Comera input module (B&S BTC KT2220 & BTC 72220

Camera input module (R&S BTC-KT3329 & BTC-Z3329)

Test Video Stream

Select the video stream for the test.

The stream location is D:\TSGEN\AVBrun\ on the R&S BTC. Default steam is Grouper\_720p\_50.trp. You can also load your own stream after changing filename to User.trp and save it to the stream location.

To change video output format for DUT using EDID, check on the "EDID Loading" checkbox.

#### Picture failure

Visible Error Definition Threshold SSIM -	0.97	
Threshold SSIM -	0.07	
Manager	0.37	
Measurement Duration	200	ms
Reference Video Quality		
Threshold SSIM ~	1	
Onset of Picture Degradation		
Time	10	s
	Defau	lt
Measurement Delay Time after RF s	setting	
Time	1000	ms

Figure 5-6: Picture Failure in General dialog

The Picture Failure tab under "General" dialog consists of the followings:

• Visible Error Definition

To define the quality parameters used for A/V analysis to reliably assess video quality and detect any deviation from a reference signal. PSNR and SSIM are the objective metric and most commonly used for quality measurements of compressed images.

- "SSIM"

Define structural similarity index to be used for the threshold limit setting for picture failure point measurement. The value range is 0 dB to 1 dB and value of 1 is achieved if there is two similar sets of data. Recommended is 0.97

- "PSNR"

Define peak signal to noise ratio to be used for the threshold limit setting for picture failure point measurement. The value range is 0 dB to 100 dB. The higher the value, the better the quality. Recommended are 35 dB.

- "Measurement Duration"
   Define measurement period. The value range is 20 ms to 999 ms. Recommended is 200 ms.
- Reference Video Quality

Define the reference video quality for Auto test. Auto test is required to make reference video file. After making it, TA-TRS will check whether the quality is good enough. If the result is lower than threshold, the test stops and issues a warning message

"Threshold"

Defines SSIM or PSNR value for threshold. Recommended are 100 dB for PSNR and 1 for SSIM with HDMI input video.

Note: Using camera for A/V interface, Threshold value is changed automatically because the setup has more noise and uncertainty. Recommended are 37 dB for PSNR and 0.98 for SSIM

Onset of Picture Degradation

To determine the picture failure, the signal quality is evaluated. The evaluation is determined by degradation criteria specified in the test standard.

– "Time"

Defines how many seconds a period should last. Recommended default is 15 s.

- Measurement Delay Time after RF setting After changing RF parameter especially level, it needs some time for error-free from instrument effect.
  - "Time"

Defines the delay time after setting the RF. Recommended is 1000 ms.

#### 5.1.3.2 EN303345

#### **Test condition**

est Conditions	Audio Failure	Report
Test Setup & Me	thod	
2RF Paths	Detailed Me	ethod 🔹
Audio Degradati	on Judgement	
	Auto	•
Audio Interface	Composite	•
Measurement Se	etup	
	Conducted	•
Measurement Ch	annel	
	Left(Ch1)	•

Figure 5-7: Audio test conditions in General dialog

The Test Conditions tab under General dialog consists of the followings:

- Test Setup
  - Set the test setup. Two setups are available based on BTC-K8 (Baseband routing):
  - "2RF Paths"
     It uses 2 RF path BTC with combiner or coupler 2 Path Compensation file (\*.2comp) is only available for "Compensation Setting".
  - "1RF Path (K8)"

It uses 1 RF path BTC with baseband routing option (BTC-K8) 1 Path Compensation file (\*.1comp) is only available for "Compensation Setting".

"Audio Degradation Judgement"

Select the mode of the audio failure point measurement.

"Auto"

Measures the audio failure using Audio analyzer. Requires additional instrument UPL or UPV. If Audio analyzer is not available, you can perform the measurement manually.

"Manual"

Measures the audio failure using the human ears. Listen audio signal to judge the audio failure point. For manual mode, it is classified to Full manual, Semi manual and simple manual. It is describes in detail in the Chapter 7, "Test Status and Results", on page 71 section. Alarm can be sounded during either start or finish by checking on the Start and Finish checkbox.

"Audio Interface"

Select the input signal for measurement.

"Composite"

Composite input of the A/V RX module (R&S VT-B2370).

"Measurement Setup"

Select type of setup for measurement. Two approaches are available:

"Conducted"

Measurement setup will be done in conducted mode.

- "Radiated"

Measurement setup will be done in radiated mode.

Note: For "Radiated", limit line and level unit are changed based on standard. You need to apply TEM-cell factor into compensation file during Compensating Losses.

Measurement Channel

Set the measurement channel. Two channels are available:

- "Left (Ch1)"

Ch1 is selected as the measurement channel.

"Right (Ch2)"
 Ch2 is selected as the measurement channel.

#### Audio failure

est Condit	ions Auc	lio Failure	Report	
Impairment	t Criteria			
AM SN	R	<ul> <li>SNR &gt;</li> </ul>	28	dB
FM	R	<ul> <li>SNR &gt;</li> </ul>	40	dB
DAB TH	DN(Optiona	• THDN <	= 5	%
DRM TH	DN(Optiona	THDN <	- 5	%
SuncientA	UUIO LEVEI	Nalige		
Level	0.3	v -	0.8	v
Level Clean audi	0.3	V -	0.8	v
Level Clean audi Time	0.3	V -	0.8 s Def	V

Figure 5-8: Audio Failure in General dialog

The "Audio Failure" tab under "General" dialog consists of the followings:

- "Impairment Criteria"
  - Judgment parameters for analog radio.
  - SNR: Standard mentioned threshold (28dB for AM, 40dB for FM).
  - - Audio: Manual listening test

Judgment parameters for digital radio

- Audio: Manual listening test
- THDN (Optional): Standard does not mentions parameter for measurement. Result with THDN is closed to manual listening. TA-TRS uses it as optional method
- "Sufficient Audio Level Range" Define the sufficient audio level range. By default the range is set to 0.3 V to 0.8 V.
- "Clean Audio"
   Define the time for clean audio. By default the time is set to 10 s.
- "Measurement Delay Time after RF Setting" Only available if "Auto" test method is used. Define the delay time before any automated measurement to allow the DUT to settle down/pick-up the signal. By default the time is set to 1000 ms.

### 5.1.3.3 Report for All Test Cases

Test Conditions Audio Failure Report
Basic Additional
Title1
Trite2
Title3
Environment Information
Temperature ("C)
Humidity (%)
Uncertainty (dB)

#### Figure 5-9: Report information in General dialog

The "Report" tab under "General" dialog consists of the followings:

This information is shown on the first page of the report.

- "Basic" Tab Enter the DUT information (Model, Serial Number, Operator and Description) in the test report.
- "Additional" Tab Enter additional information (Up to 3 titles and descriptions) in the test report.
- "Environment Information" Enter the environment information (Temperature, Humidity, and Uncertainty) in the test report.

### 5.1.4 Compensation Dialog

**Compensation Setting** 

To ensure a precise result for the testing, loss incurred by external parts should not be neglected. TA-TRS provides auto-compensation methods that use compensation files. Select the file you want to use as compensation file in the test and load it. Further details see Chapter 6.1, "Compensating Losses", on page 46 to create a new compensation file using power sensor.

Compensation Setting	
File Location	
O:\R & S Stuffs\My Project\ETSI Development\R	Load
ок	Cancel

Figure 5-10: Compensation loading dialog

### 5.1.5 Remote Control DUT Dialog

Remote Control DUT

To allow full automation, TA-TRS controls the DUT using IR signals (IR remote control).

- "Load" button Select the sequence file you want to use in the test.
- "Make New Sequence" button Create a new sequence file using the RedRat 3-II or RedRat-X IR remote control. Further details see Chapter 6.2, "Learning DUT IR Commands", on page 52.

Remote Control DUT	-	
File Location		
O:\R & S Stuffs\My Project	ct\ETSI Development\R	Load
Make New Sequence	ОК	Cancel

Figure 5-11: Remote control making or loading dialog

### 5.1.6 Signal Mode List Dialog

The following illustrates the different signal model list dialog.

#### 5.1.6.1 EN303340

TA-TRS specifies the signal information for EN30340 based on standard for DVB-T and DVB-T2. Default values are from the standard.

Table 2: DVB-T configura	Son	Value for SMM VM non
Bandwidth	6.66 MHz +	7.61 MHz *
FFT	BK *	ax -
Modulation	64QAM •	64QAM -
Heady	Non-Herarchical +	Non Herarchical +
Guard interval	14 •	14 .
Code rate	2/3 *	2/3 •
Channel Bandwidth	7 MHz +	8 3042 **

Figure 5-12: EN303340 signal parameters

#### 5.1.6.2 EN303345

TA-TRS specifies the signal information for EN30345 based on standard for AM, FM, DAB, DRM. Default values are from the standard.

	FM.	DAB	DRM		
Te	able 1: A	M config	uration		
			Wanted	Unwanted	Blocking
^	udio modi	Attion	Frequency 1 kHz	Weighted noise Recommendation (TU-R 85.559-2 [5]	Frequency 1 kHz
			Band-limited to 4.5 kHz	Band-Imbed to 4.5 kHz	
•	Xher Mod.	Aation	Mod. Depth 40 %	Mod. Depth 50% quasipeak	Nod. Depth 80 %

Figure 5-13: EN303345 signal parameters

### 5.1.6.3 EN303372-2

TA-TRS specifies the signal information for EN30372-2 based on standard for DVB-S, DVB-S2. Default values are from the standard. It also contains menu for Adjacent Signal stream selection and transponder frequency setting for remote control.

DVB-S	DVB-S2	Adjacent Signal	Transponde	r Freq.(Ren	note Control)
Co	nfiguration				
	irequency		1500	) M	łz
	evel		-65	68	-
1	lymbol Rate		27.5	MS	i/s
0	Constellation		QPSK		•
0	Code Rate		3/4		•
1	Roll off		0.35		•
_					

### 5.2 Test Cases

### 5.2.1 EN303340

To select a test case for individual configuration.

Under "Test Case", click the test case name.

The selected test case name is highlighted in blue color. For example above, "4.2.3 Sensitivity" is selected. You can also select all test cases by checking the "Select All" checkbox. Each individual configuration is applied to the selected test case

### **Test Cases**

	4.2.3 Sensitivity			
Test Case	Test Arrangement			
Select Al	Definition			
<ul> <li>✓ 4.2.3 Sensitivity</li> <li>✓ 4.2.4 Adjacent channel selectivity</li> <li>✓ 4.2.5 Blocking</li> </ul>	The maximum us signal level or fiel (BER), or other s	able sensitivity is o id strength able to pecified output pe	defined as the minimum produce a specified ar fromance which depe	receiver Radio Frequency (RF) input nalogue SINAD ratio or Bit Error Ratio nds on this input signal level.
✓ 4.2.6 Overloading	Parameters and L	mos	1	
	Test description	C wanted signal Center	Require config.	d sensitivity limit for DTT ration in tables 2 and 3
		(MHz)	DVB-T	VB-T2
	VHF Sensitivity	198.5	-77	-75
	UHF Sensitivity	666.0	-77	-75
Test Method - Detailed Metho Compensation Setting - No Ca	d 🔳	Video Quality J	Judgement - Auto	Input Type - HDMI
Remote Control DUT - No Rer	note Controller File			OK Cancel

Figure 5-14: Test case selection and details for EN303340

### 5.2.1.1 4.2.3 Sensitivity

For Sensitivity test arrangement, 1

- 1. Band selection and frequency.
- 2. Signal mode selection for DVB-T and DVB-T2 .
- 3. Limit value (level) for each signal mode and frequency.
#### 4.2.3 Sensitivity

arameters and L	imits	_	
Test description	C wanted signal Center	Requin config	ed sensitivity limit for DTT juration in tables 2 and 3
(MHz)		VB-T	VB-T2
VHF Sensitivity	198.5	-77	-75
UHF Sensitivity	666.0	-77	-75

Figure 5-15: 4.2.3 Sensitivity arrangement for EN303340

#### 5.2.1.2 4.2.4 Adjacent Channel Selectivity

Definition						
Adjacent chann receive a wante	el selectivity	(I/C) is define signal without	d as the meas	ure of the capabi given degradation	lity of the re	ceiver to
Parameters and	Limits	agria maroa	a choosing a	gronogadaa		
Measurement	Algorism S	art from Limit	I/C (Default)	•		
Interferer (I) type	C wanted signal Center	l centre frequency	Minimum required I/C limit (where I = lic) for DTT configurations (dB)		Minimum required I/C limit (where I = Ilic) DTT configurations (dB) UC (d	
	frequency (MHz)	(MHz)	VB-T	DVB-T2	DVB-T	DVB-T2
LTE 800 BS light	786.0	796.0	35	36	35	36
LTE 700 BS light	690.0	763.0	43	43	43	43
UE Video	690.0	708.0	33	38	33	38
N-1 UHF	482.0	474.0	25	25	25	25
N+1 UHF	482.0	490.0	25	25	25	25

#### 4.2.4 Adjacent channel selectivity

Figure 5-16: 4.2.4 Adjacent channel selectivity for EN303340

For Adjacent Channel Selectivity test arrangement:

- 1. Band selection with interferer signal.
- 2. Wanted signal and unwanted signal frequencies.
- 3. Signal mode selection for DVB-T and DVB-T2.
- 4. Limit value (I/C) for each signal mode and frequency.
- 5. Measurement Algorithm
  - Start from Limit I/C (Default): Test starts from limit I/C to find picture failure error

Measurement	Algorism St	art from Limit	I/C (Default)	•		
Interferer (I) type	C wanted signal Center	l centre frequency	Minimum r limit (who for DTT conf	equired I/C ere I = Ilic) igurations (dB)	User d star I/C	lefined ting (dB)
	frequency (MHz)	(MHz)	VB-T	VB-T2	DVB-T	DVB-T2
LTE 800 BS light	786.0	796.0	35	36	35	36
LTE 700 BS light	690.0	763.0	43	43	43	43
UE Video	690.0	708.0	33	38	33	38
N-1 UHF	482.0	474.0	25	25	25	25
V+1 UHF	482.0	490.0	25	25	25	25

Figure 5-17: 4.2.4 Algorithm - Start from Limit I/C

 Test Range Margin: Test starts from limit I/C to find picture failure error. If testing I/C is more/less than margin value (below screen example is 10dB) from limit line. It stops test and show results like > 45 dB or < 25 dB when limit I/C is 35. It helps you to check certain performance instead of finding picture failure error.

Measurement	Algorism Te	est Range M	argin	▼ 10	dB	
Interferer (I) type	C wanted signal Center	l centre frequency	Minimum r limit (wh for DTT conf	required I/C ere I = Ilic) figurations (dB)	User o star I/C	lefined ting (dB)
	frequency (MHz)	(MHz)	DVB-T	VB-T2	DVB-T	DVB-T2
LTE 800 BS light	786.0	796.0	35	36	42	43
LTE 700 BS light	690.0	763.0	43	43	55	56
UE Video	690.0	708.0	33	38	40	41
N-1 UHF	482.0	474.0	25	25	55	55
V+1 UHF	482.0	490.0	25	25	56	56

Figure 5-18: 4.2.4 Algorithm - Test Range Margin

For Adjacent Channel Selectivity test arrangement, select the sensitivity that is need band selection and wanted signal center frequency, the required sensitivity limit for DTT configuration for DVB-T and DVB-T2. You can also select to perform either DVB-T or DVB-T2 or both.

#### 5.2.1.3 4.2.5 Blocking

For Blocking test arrangement:

- 1. Band selection with interferer signal.
- 2. Wanted signal and unwanted signal frequencies.
- 3. Signal mode selection for DVB-T and DVB-T2.
- 4. Limit value (Interferer level) for each signal mode and frequency.

#### 4.2.5 Blocking

rameters and Limi	ts			
Interferer (I) si type Ce freq (N	C wanted signal Center	I Required blocking centre configurations in t		ting level Imax for DTT in tables 2 and 3 (dBm)
	frequency (MHz)	(MHz)	DVB-T	DVB-T2
LTE 700 BS Fully	690.0	763.0	-25	N/A
LTE 700 BS Fully	690.0	763.0	N/A	-25

Figure 5-19: 4.2.5 Blocking for EN303340

#### 5.2.1.4 4.2.6 Overloading

For Overloading test arrangement:

- 1. Preamplifier conditions (With Preamp (On/Off) or Without Preamp).
- 2. Wanted signal and unwanted signal frequencies.
- 3. Signal mode selection for DVB-T and DVB-T2.
- 4. Limit value (Interferer level) for each signal mode and preamplifier conditions.

#### 4.2.6 Overloading

b lose its ability to one wanted signal d	discriminate ag lue to the onse	ainst interferi t of strong no	ng signals at frequen xn-linear behaviour.	cies differing from that of
arameters and Lim	ts			
Test	C wanted signal Center	l centre frequency	Required overl configurations	oad level Imax for DTT in tables 2 and 3 (dBm)
	frequency (MHz)	(MHz)	VB-T	VB-T2
Preamplifier on	690.0	763.0	-12	-12
Preamplifier off	690.0	763.0	-4	-4
Without Preamplifier	690.0	763.0	-4	-4

Figure 5-20: Overloading for EN303340

# 5.2.2 EN303345 Test Case

It supports three standard versions with latest version EN303 345 -2 to -5 included as V1.1.1 (2020).

- V1.1.1
- V1.1.1 (2020)
- V1.1.7

Version	V1.1.1 •	
Test	Case	
	SelectAl	
₹ 4.2	Sensitivity	
4.2.5	Adjacent channel selectivity and Blocking	1

Figure 5-21: Version selection menu for EN303345



From TA-TRS software V2 onwards, test case number will be removed from the GUI for EN303345 testing.

#### 5.2.2.1 4.2.4 Sensitivity

ameters and	Limits		
Al Analog	🗸 Al Digtal		
Analog Digital			
De- modulation	Tuned frequency band	Wanted signal Centre frequency (MHz)	Required sensitivity limit (dBm)
	🗵 LF	0.216	-65
AM	🗵 MF	0.999	-65
	🗵 HF	9.9	-65
FM	VHF II	98	-90

Figure 5-22: 4.2.4 Sensitivity - Conducted for EN303345

# 4.2.4 Sensitivity Test Arrangement Definition The receiver sensitivity is the mining

og Digts			
De- rodulation	Tuned frequency band	Wanted signal Centre frequency (MHz)	Required sensitivity limit (dBuV/m)
	V LF	0.216	74
AM	MF	0.999	66
	🗵 HF	9.9	60
EM	VHF II	98	50

Figure 5-23: 4.2.4 Sensitivity - Radiated for EN303345

For Sensitivity test arrangement, you can change test environment - Radiated or Conducted in "Test condition" on page 26.

- 1. Band selection for analog and digital.
- 2. Wanted signal frequency.
- 3. Limit value (level) for each frequency.

#### 5.2.2.2 4.2.5 Adjacent Channel Selectivity and Blocking

est Arrangemen Setting	t						
Wanted si During Uni During Uni	gnal ON wanted signal	set Meas	urement Ag	orism Sta	t from Limit	I/C (Defaul	t) -
Parametens an Al Analog Analog Digt	d Limits V Al Dig	tal					
De-	Tuned	C Wanted	C Wanted		Requi (see no	red I/C ratio stes 1 and 2	2)
modulation	band fre	frequency (MHz)	ay (dBm)	N=1 (dB)			Blocking (dB)
414	🗹 LF	0.216	-59.0	-5	25	35	40
(external	🗷 MF	0.999	-59.0	-5	25	35	40
antenna)	🗷 HF	9.9	-59.0	-5	25	35	40
FM (external anterna)	🗵 VHF II	98	-89.0	-23	3	17	30

Figure 5-24: Adjacent Channel Selectivity and Blocking - Conducted for EN303345

4.2.5 Adjacent channel selectivity and Blocking

Analog Digit	a						
De-	Tuned	C Wanted	C Wanted		Requir (see no	red L/C ratio tes 1 and 2	5
modulation	band	band frequency (MHz)	(dBuV/m)			N=3 (dB)	Blocking (dB)
	🗷 LF	0.216	80	-30	10	20	20
(integral	🗷 MF	0.999	72	-30	10	20	20
antenna)	🗵 HF	9.9	66	-30	10	20	20
FM (integral antenna)	VHF II	98	51	-23	-3	17	30

Figure 5-25: Adjacent channel selectivity and Blocking - Radiated for EN303345

For Adjacent Channel Selectivity and Blocking test arrangement, you can change test environment - Radiated or Conducted in "Test condition" on page 26.

- 1. Band selection for analog and digital.
- 2. Wanted signal frequency and level.
- 3. Limit value (I/C) for each offset of frequencies.

- 4. "Wanted signal ON During Unwanted signal set": It helps to hold wanted signal during unwanted signal is set.
- 5. Measurement Algorism
  - Start from Limit I/C (Default): Test starts from limit I/C to find audio failure error

De-	Tuned	C Warted	C Wanted		Requir (see no	red L/C ratio ites 1 and 2	0
nodulation	band	frequency (MHz)	(dBm)	N=1     (d8)	N+2 (d8)	N=3     (d8)	Blocking (dB)
414	🗵 LF	0.216	-59.0	-5	25	35	40
(external	🗷 MF	0.999	-59.0	-5	25	35	40
antenna)	🗵 HF	9.9	-59.0	-5	25	35	40
FM (external anterna)	VHF II	98	-89.0	-23	3	17	30

Figure 5-26: 4.2.5 Algorism - Start from Limit I/C (Default)

 Test Range Margin: Test starts from limit I/C to find picture failure error. If testing I/C is more/less than margin value (below screen example is 10dB) from limit line. It stops test and show results like > 45 dB or < 25 dB when limit I/C is 35. It helps you to check certain performance instead of finding picture failure error.

De- modulation	Tuned	C Warted	C Warted	Required L/C ratio (see notes 1 and 2)			
	band	frequency (MHz)	(dBm)	N+1 (d8)	N+2 (dB)	₩ <sup>N+3</sup> (d8)	Blocking (dB)
	🗷 LF	0.216	-59.0	-5	25	35	40
(external	MF	0.999	-59.0	-5	25	35	40
antenna)	🗷 HF	9.9	-59.0	-5	25	35	40
FM (external anterna)	🗷 VHF II	98	-89.0	-23	3	17	30

Figure 5-27: 4.2.5 Algorism - Test Range Margin

# 5.2.3 EN303372-2 Test Case

#### 5.2.3.1 4.3.1 Adjacent Signal Selectivity

#### 4.3.1 Adjacent signal selectivity

aused by the ad with regard to the occupied bandwi	lacent signal wantes sign dth	Frequency offset a al shall take the va	and power level o slues given below	ffset of the a F is the idea	djacent signa I signal	al .
atelite mode			Freq & level	offset from w	anted signal	
VB-S	6	DVB-S2	Frequency		1500 M	
ymbol rate	stellation for l	.ow & High SR	Frequency wanted s	y offset from ignal (MHz)	Power leve from wante	el offset d signal
Symbol Rate (MS/s)	DVB-S	DV8-S2	📝 -F - 4	👽 F+4	10	)
Low End	10	7.5	🔽 -F - 2	👽 F + 2	4	
Hgh End	30	45	💽 -F	📝 F	0	

Figure 5-28: 4.3.1 Adjacent Signal Selectivity for EN303372-2

For Adjacent Signal Selectivity test arrangement:

- 1. Signal mode selection for DVB-S and DVB-S2.
- 2. Wanted signal frequency.
- 3. Low and high symbol rate for DVB-S and DVB-S2.
- 4. Frequency offset selection and power level offset for interferer signal.
- 5. Limit value (Result difference between with noise and without noise).
- 6. Different Constellation for Low & High SR: You can set different constellation for low & high symbol rate in "Test condition" on page 26.

#### 5.2.3.2 4.3.2 Dynamic Range

efinition				
ynamic range iameter. The l ange of at leas	is measured to allow a IDU shall be able to pro st 40 dB.	a wide range od satel ocess without degrad	te EIRP and of ODI ation input signals at	J antenna any level in a
stellite mode				
VB-S	V DVE	-52		
equency & Le	rvel			-
Band	Frequency (MHz)	Lowest Level (dBm)	Centre Level (dBm)	I Highest Level (dBm)
Lowest	950	-65	-45	-25
Centre	1500	-65	-45	-25
Highest	2150	-65	-45	-25

Figure 5-29: 4.3.2 Dynamic Range for EN303372-2

For Dynamic Range test arrangement:

- 1. Signal mode selection for DVB-S and DVB-S2.
- 2. Band selection.
- 3. Wanted signal frequencies and levels.
- 4. Limit value (Dynamic range).

# 6 Test Preparation

In order to run the different test cases, you need to provide the following files:

- Compensation setting file
- Remote control command sequence file
- Setting up of AVBCamera for EN303340 and EN303372 automated test with camera setup

A new file should be created if there is no existing compensation setting file or remote control command sequence file.

# 6.1 Compensating Losses

TA-TRS provides auto-compensation methods to compensate the loss that occurs in external parts connected to the R&S BTC and DUT, such as cables and impedance matching pad.



User need to check frequency range based on standard The supported power sensors are as follows: R&S NRP-Z11 R&S NRP-Z21, R&S NRP-Z22, R&S NRP-Z23, R&S NRP-Z24 R&S NRP-Z31 R&S NRP-Z51, R&S NRP-Z52, R&S NRP-Z55, R&S NRP-Z56 R&S NRP-18T R&S NRP-6A

To create a new compensation file

Select and open the calibration test plan

QS-ETM

#### **Compensating Losses**

Rohde-	Schwarz + QuickStep + Projects + QS-ETM	► <b>-</b>
New fol	der	
*	Name	Date modified
	🐌 ActiveReports	4/25/2018 4:32 PM
-0	🐌 Results	4/26/2018 1:21 PM
<sup>its</sup> ≡	CalibrationETM.tpl	4/25/2018 4:18 PM
as	EN303340ETM.tpl	4/25/2018 4:14 PM
	EN303340ETM_Simulation.tpl	4/26/2018 1:21 PM
	EN303345ETM.tpl	4/25/2018 4:15 PM
	EN303345ETM_Simulation.tpl	4/26/2018 11:05 AM
	EN303372-2ETM.tpl	4/25/2018 4:16 PM
jk)	EN303372-2ETM_Simulation.tpl	4/25/2018 4:16 PM
+		
File	name: CalibrationETM.tpl	

Figure 6-1: QS-ETM Calibration test project

QS-ETM support multi instrument with Power sensor and R&S spectrum analyzer. User need to set Visa Resource following to QS-ETM

Test	Step	o Setti	ngs			PathLoss_(	Cor	npensation\Co
Id	E	nable	Breakpoint	Test Proced	lure	Instrument	Set	BTC Visa
	1	✓		Path Loss C	ompensatio	m Analyzer	~	TCPIP::192.168.
				BTC+Powe		er Sensor		
					BTC+Spect	trum Analyz	er	
					Sfx+Spect	rum Analyze	er	

#### Figure 6-2: QS-ETM instrument setup

The "Compensation" dialog is displayed.

**Compensating Losses** 

Compensation - Demo mode	
Compensation - Demo mode Compensation Setup BTC Setup 2 RF Paths  Type Atten. Absolute Instrument Configuration Power Level 0 dBm Frequency User Define Stat 474 Stop 850 Step 8 MHz Matching Pad loss Constant 5.72 d8	Status Instrument connected  Result(RF Path1) Result(RF Path2) Curret Value Frequency MHz Loss dB No Freq Loss BTC I I I I I I I I I I I I I I I I I I I
Additional loss	Compensation File Save / Open
	File Location Open

Figure 6-3: Compensation form

# 6.1.1 Compensation Setup

Compensation Setup						
BTC Setup	2 RF Paths					
Туре	Atten. Relative					

Figure 6-4: Compensation setup menu

- 1. "BTC Setup"
  - 2 RF Paths: You need combiner or coupler to add two signals. There are two steps measurements for path 1 and path 2. Compensation file extension is \*.2comp.

1 RF Path: BTC need K8 (Baseband routing) option. Compensation file extension is \*.1comp.

2. "Type"

Select the type of compensation method.

• "Atten. Absolute": Directly measure the setup loss without reference cable.

• "Atten. Relative": Measure the loss for reference cable and measure the setup loss with reference cable. Normalization tab appears for reference cable measurement.

Result(RF Path1)	Result(RF Path2)	Normalization				
Current Value		Summary				
Frequency	MHz dB	Fr Max Min	equecy 0 0	Lo: 0 0	dB dB	Start
No Freq	Loss		STC			1st RF

Figure 6-5: Atten. Relative type with Normalization tab

# 6.1.2 Instrument Configuration

BTC setup for compensation.

Instru	ument C	onfiguratio	n
	Power		
	Level	0	dBm
	Frequer	cy	
	User [	)efine	•
	Start	474	]
	Stop	850	
	Step	8	MHz
	Matchin	g Pad loss	
	Cor	nstant 5	. <b>72</b> dB
	Additio	nal loss	
		Loss Ta	able

- 1. Power
  - Level: Compensation power from BTC. Default is 0 dBm.

Power		
Level	0	dBm

Figure 6-6: Power menu

2. Frequency

It has a predefine frequency list based on standard.

Frequency	
User Define	-
EN 303 340 EN 303 345	
EN 303 372	
User Define	

Figure 6-7: Frequency list selection menu

Below menus are only available when "User Define" is selected. You can change parameters on their own.

- "Start": Start frequency. Default is 474 MHz
- "Stop": Stop frequency. Default is 850 MHz
- "Step": Step frequency. Default is 8 MHz
- 3. "Matching Pad loss"

Matching pad is necessary to match the impedance between BTC and DUT. However, power sensor cannot compensate the matching pad because of different impedance. It is added manually into measured setup loss.

• Constant: Constant value applies to all frequency range. Default is 5.72 dB.



Figure 6-8: Matching pad loss menu

4. "Additional loss"

You can apply additional loss based on frequency. It can be used to add TEM-cell factor or matching pad loss when loss is different over the frequency.

Addi	tional loss	
	Loss Table	

Figure 6-9: Additional loss menu

Loss Table: You can create loss table over frequency and save/open it.



Figure 6-10: Additional loss table

# 6.1.3 Status

It shows the status messages and progress information.

Status		
	Instrument connected	

Figure 6-11: Status menu

# 6.1.4 Result and Normalization Tab

When "Atten. Relative" type is selected, You need to compensate reference cable first in "Normalization" tab before measure setup loss.

Number of tabs are changed based on "Compensation Setup".

Each tab has a "Start" button that runs individually.

Result(RF Path1)	Result(RF Path2)	Normalization			
Current Value		Summary			
Frequency	MHz dB	Fre Max Min	Quecy 0 0	Loss 0 dB 0 dB	Start
No Freq	Loss	B	TC NR	P-Zxx Ref	

Figure 6-12: Result tab

### 6.1.5 Compensation File Save / Open

When compensation is finished, "Save" button is enabled automatically. Compensation file is used for "Compensation Setting " in Chapter 5.1.4, "Compensation Dialog", on page 32.

"Open" button is used for checking the compensation file.

Compensation File Save / Open		
File Location	Save	Open

Figure 6-13: Compensation save / open menu

# 6.2 Learning DUT IR Commands

#### 6.2.1 RedRat Prerequisites

Driver needs to be installed before using RedRat. Install correct driver for your Redrat type - RedRat 3-II or RedRat-X.

#### 6.2.1.1 RedRat 3-II

1. Download driver - Link: https://www.redrat.co.uk/support/firmware-drivers/.

#### RedRat 3-II Windows Device Driver

Windows XP 32-bit	Version 3.4.4
Windows XP 64-bit	Version 3.4.4
Vista, Windows 7, 8 & 10 32-bit	Version 3.4.4
Vista, Windows 7, 8 & 10 6+bit	Version 3.4.4

#### Figure 6-14: RedRat 3-II driver download menu

- 2. Extract zip file. It contains system file.
- 3. Go to "Device Manager" and find "Infrared Remote Control IO".
- 4. "Update Driver Software" using system file.



Figure 6-15: RedRat driver update in Device manager

#### 6.2.1.2 RedRat-X

1. Download driver - Link: https://www.redrat.co.uk/support/firmware-drivers/

RedRat-X Driver

Download the Windows driver installer for the RedRat-X,	RR.X Driver	
and the moving on a fitter and their in advantage for one the annual to		

#### Figure 6-16: Redrat-X driver download menu

- 2. Extract zip file. It contains exe file.
- 3. **Execute** InstallRedRatDriver.exe.

### 6.2.2 Start RedRat

To allow full automation, TA-TRS is using the RedRat 3-II or RedRat-X IR remote control to establish an intelligent learning system. Firstly, you teach the RedRat 3-II or RedRat-X the IR signals of the original DUT remote control. Then you construct the sequences to remotely control the DUT using the RedRat 3-II or RedRat-X.

The RedRat 3-II or RedRat-X IR remote control consists of a hardware and software component. The hardware component sends and receives IR signals. The software component controls the hardware component and is integrated into the TA-TRS.

To display the "Infrared Remote Control" dialog and connect the RedRat 3-II or RedRat-X.

pensation Setting	Remote Control DUT	Signal Mode List
Remote Control DUT		
File Location		
O:∖R & S Stuffs\/	/ly Project\ETSI Development\l	R Load
Make New Sequence	ОК	Cancel

Open the "Remote Control DUT dialog" and click "Make New Sequence".

Figure 6-17: Make new sequence menu

The "Infrared Remote Control" dialog is displayed.

#### Learning DUT IR Commands

iction.		Heb
Step 1: Learn Functionality of Re	mote Control   Close<<	<ul> <li>1. Press button of software remote control.</li> </ul>
unctionality Save./Open	Sequence Save Open	
Save Open	Save Open	2. Press button of remote control.
Alow Two Sgnais Per Button Software Remote Control	Mode Select *	
		3. After all buttons are learned: Save functionality
4 5 6	Number Button	Save
MENU Ø EXT		
User Dered		
	Mouse Right Click : Edit Mode	

Figure 6-18: Infrared remote control menu

It consists of four steps to create remote control file and Instrument need to generate correct signal for scanning channels.

Action		
	Step 1: Learn Functionality of Remote Control	
	Step 1: Learn Functionality of Remote Control	
	Step 2: Test Functionality of Software Remote Control	
_	Step 3: Learn Sequences	
ľ	Step 4:Test Sequences	

Figure 6-19: Step selection menu

- "Learn Functionality of Remote Control" Mapping IR signal into button in "Software Remote Control".
- "Test Functionality of Remote Control" Testing mapped IR signal is generated correctly using button in "Software Remote Control".
- "Learn Sequences" Making the sequence for auto scan or manual scan using button in "Software Remote Control".
- "Test Sequences" Testing the sequence is generated correctly.

If the RedRat 3-II or RedRat-X is not connected, the error message appears.



Figure 6-20: Missing Redrat error message

# 6.2.3 Teaching RedRat

Use the original remote control of the DUT to teach the RedRat 3-II or RedRat-X the IR signal for each button.

- To create a new functionality file: Under "Action", select "Step 1: Learning Functionality of Remote Control".
- To save an IR signal for necessary buttons, repeat the following steps for each button:
  - Under "Software Remote Control", an image of the DUT remote control is provided. Click a button on the remote control image.





Figure 6-21: RedRat signal input dialog

- While the "Signal Input" dialog is being displayed, press the corresponding button on the original remote control to generate an IR signal. This information is saved and assigned to the button on the remote control image.
- If the IR signal is successfully learned, the "Signal Input" dialog is closed.
- In the "Remote Control DUT" dialog under "Remote Control", the font color of the button changes form black to white.



Figure 6-22: Functionality recording procedure

3. After all buttons have been successfully assigned, the remote control image looks as follows:

Functionality
Save/Open
Save Open
Allow Two Signals Per Button
Software Demote Control
Sonware Remote Control
Power
1 2 3
7 8 9
MENU 0 EXIT
< ок 🕨
User-Defined
User1 User2

Figure 6-23: Necessary buttons mapping

- 4. To save functionality into the file:
  - Under "Functionality", click "Save".

The saved functionality file is used to create new sequence file.

Save/Open	
Save	Open

Figure 6-24: Functionality save / open menu

- 5. To generate and verify an IR signal of the RedRat 3-II or RedRat-X IR remote control:
  - Under "Action", select "Step 2: Test Functionality of Software Remote Control".
- 6. Under "Software Remote Control", click the button on the remote control image to check whether IR signal operates correctly.

#### 6.2.4 Constructing Sequences

Construct the sequences to remotely control the DUT after learning all buttons.

It is used for channel or frequency scan for DUT during the test. Before constructing the sequence, BTC needs to generate proper signal to DUT to work with DUT.

- 1. Under "Action", select "Step 3: Learn Sequences" to create a new sequence file.
- Under "Mode", select "Channel/Frequency switching" which is only selection at this moment.
- 3. Under "Type of scanning", select one of four options.

Type of scanning



#### Figure 6-25: Type of scanning menu

- "Full Scan no channel/Frequency"
   It is known as auto scan without any additional frequency input during scan procedure. This mode can cover most of applications.
- "Scan entering Frequency [MHz]"

It is known as manual scan with frequency(MHz) input during scan procedure. This frequency keeps changing during the actual test. It needs to give timing information to generate proper frequency (MHz). "Insert Freq.[MHz]" button works for it. Put "Insert Freq.[MHz]" into sequence when manual frequency is required during scan procedure.

Type of scanning	
Scan entering Frequency [MHz]	-
Insert Freq.[MHz]	

Figure 6-26: Manual scan with frequency menu

- "Scan entering Frequency [kHz]" Same with "Scan entering Frequency [MHz]" procedure. Frequency is kHz unit instead of MHz.
- "Scan Freq.[MHz] & SR[KS/s]"

It is only for DVB-S/S2. Same with "Scan entering Frequency [MHz]" procedure. It has one more parameter, which is symbol rate.

Type of scanning		
Scan Freq.[MHz] & SR[KS/s]		
Insert Freq.[MHz]	Insert SR[KS/s]	

Figure 6-27: Manual scan with frequency and symbol rate menu

 Uses the IR signals assigned to the buttons on the "Software Remote Control", as learned earlier. Click the buttons on the remote control image to create the sequence list.

Note: During clicking the buttons, RedRat 3-II or RedRat-X must direct to DUT to control. You can see what is the next step. Between clicking the buttons, delay time is recorded and saved in the list.

Adde Channel/Frequency switching ▼ ype of scanning full Scan - no Channel/Frequency ▼ Number Button 2 Delay : 3 Sec 3 OK 4 Delay : 2 Sec 5 ► 6 Delay : 3 Sec 7 OK 8 Delay : 3 Sec 9 ▼ 10 Delay : 2 Sec 11 ▼ 12 Delay : 2 Sec	•	requency switching anning - no Channel/Frequency -	Node Channel/Fr Type of sca full Scan -
Shannel/Frequency switching       ype of scanning       full Scan - no Channel/Frequency       Ymmber       Button       2     Delay : 3 Sec       3     OK       4     Delay : 2 Sec       5     ►       6     Delay : 3 Sec       7     OK       8     Delay : 3 Sec       9     ▼       10     Delay : 2 Sec       11     ▼       12     Delay : 2 Sec	•	requency switching	hannel/Fr ype of sca 'ull Scan -
ype of scanning ull Scan - no Channel/Frequency ▼ Number Button 2 Delay : 3 Sec 3 OK 4 Delay : 2 Sec 5 ► 6 Delay : 3 Sec 7 OK 8 Delay : 3 Sec 9 ▼ 10 Delay : 2 Sec 11 ▼ 12 Delay : 2 Sec	•	anning - no Channel/Frequency	ype of sca full Scan -
Number     Button       2     Delay : 3 Sec       3     OK       4     Delay : 2 Sec       5     ►       6     Delay : 3 Sec       7     OK       8     Delay : 3 Sec       9     ▼       10     Delay : 2 Sec       11     ▼       12     Delay : 2 Sec	•	- no Channel/Frequency	ull Scan -
Number     Button       2     Delay : 3 Sec       3     OK       4     Delay : 2 Sec       5     ►       6     Delay : 3 Sec       7     OK       8     Delay : 3 Sec       9     ▼       10     Delay : 2 Sec       11     ▼       12     Delay : 2 Sec	•	Button	ull Scan -
Number     Button       2     Delay : 3 Sec       3     OK       4     Delay : 2 Sec       5     ►       6     Delay : 3 Sec       7     OK       8     Delay : 3 Sec       9     ▼       10     Delay : 2 Sec       11     ▼       12     Delay : 2 Sec		Button	Number
Number         Button           2         Delay : 3 Sec           3         OK           4         Delay : 2 Sec           5         ►           6         Delay : 3 Sec           7         OK           8         Delay : 3 Sec           9         ▼           10         Delay : 2 Sec           11         ▼           12         Delay : 2 Sec		Button	Number
Number         Button           2         Delay : 3 Sec           3         OK           4         Delay : 2 Sec           5         ►           6         Delay : 3 Sec           7         OK           8         Delay : 3 Sec           9         ▼           10         Delay : 2 Sec           11         ▼           12         Delay : 2 Sec		Button	Number
2 Delay: 3 Sec 3 OK 4 Delay: 2 Sec 5 ► 6 Delay: 3 Sec 7 OK 8 Delay: 3 Sec 9 ▼ 10 Delay: 2 Sec 11 ▼ 12 Delay: 2 Sec			Number
3 OK 4 Delay: 2 Sec 5 ► 6 Delay: 3 Sec 7 OK 8 Delay: 3 Sec 9 ▼ 10 Delay: 2 Sec 11 ▼ 12 Delay: 2 Sec	- 6	Delay: 3 Sec	2
4 Delay: 2 Sec 5 ► 6 Delay: 3 Sec 7 OK 8 Delay: 3 Sec 9 ▼ 10 Delay: 2 Sec 11 ▼ 12 Delay: 2 Sec	- 1	OK	3
5 ► 6 Delay: 3 Sec 7 OK 8 Delay: 3 Sec 9 ▼ 10 Delay: 2 Sec 11 ▼ 12 Delay: 2 Sec	- 1	Delay: 2 Sec	4
6 Delay: 3 Sec 7 OK 8 Delay: 3 Sec 9 ▼ 10 Delay: 2 Sec 11 ▼ 12 Delay: 2 Sec	- 1	•	5
7 OK 8 Delay:3 Sec 9 ▼ 10 Delay:2 Sec 11 ▼ 12 Delay:2 Sec		Delay: 3 Sec	6
8 Delay: 3 Sec 9 ▼ 10 Delay: 2 Sec 11 ▼ 12 Delay: 2 Sec	- I.	OK	7
9 ▼ 10 Delay:2Sec 11 ▼ 12 Delay:2Sec	1	Delay: 3 Sec	8
10 Delay:2 Sec 11 ▼ 12 Delay:2 Sec		•	9
11 ▼ 12 Delay:2Sec		Delay: 2 Sec	10
12 Delay : 2 Sec		<b>T</b>	11
,		Delay: 2 Sec	12
13 OK	Ļ	ок	13
14 Delay: 61 Sec		Delay: 61 Sec	14

Figure 6-28: Sequence recording example

- 5. If you want to modify the sequence list:
  - In the sequence list table, right-click a row.
  - Select either "Insert Line", "Insert Delay", "Delete Line" or "Delete All".

0	Delay. 3	Sec	
7	ОК	Incert Line	-
8	Delay	Insert Line	- 1
9	•	Insert Delay	
10	Delay	Delete Line	
11	•	Delete All	
12	Delay z	380	1
13	OK		ш
14	Delay: 61	1 Sec	÷
•		•	
Mouse F	Right Click : Edit	Mode	

#### Figure 6-29: Sequence modification menu

 Under "Sequence", click "Save" to save sequence into the file. The saved sequence file contains not only the sequence list, but also the functionality information. The saved sequence file can be selected in Chapter 5.1.5, "Remote Control DUT Dialog", on page 33 for controlling the DUT during the test.

Sequence Save/Open	
Save	Open

Figure 6-30: Sequence save / open menu

- To generate and verify an IR signal sequence of the RedRat 3-II or RedRat-X IR remote control:
  - Under "Action", select "Step 4:Test Sequences".
  - Under "Sequence", select" Channel/Frequency switching" in the "Mode" to play the sequence list.

# 6.3 AVB Camera Setup

R&S AVB Camera consists of both the software and hardware required to perform the video quality measurement. It includes the controlling software for the processing of the video output from the camera and transmits it to AV Distortion Analyzer. The Hardware consists of the camera, power adaptor and tripod.

The following features shall be provided:

- Get frames from camera output
- Crop frame to get the TV screen only
- Detect time code of each frame
- Filter out all the disturbed frames
- Select the best frame
- Output frame through HDMI port to BTC

# 6.3.1 AVB Camera Prerequisites

These required equipment need to be installed before using AVB Camera on which the following lists are required:

- PC
  - Windows7 OS
  - HDMI output port
- Installed software
  - Pylon 4 Camera Software Suite 4.1.0.3660
  - AVB Camera software
- Accessories USB to LAN adapter for controlling instruments
  - HDMI cable
  - 2 x Category 6 shielded GigE cable
  - Power over Ethernet device (Optional) It gives power over Ethernet to camera instead of using power adapter.
- 4. BTC
  - AVB Camera software (R&S BTC-KT3329)
  - AV distortion analysis (R&S VT-K2111)
  - HDMI RX 300 MHz (R&S VT-B2361)
  - Other options in Chapter 2, "Prerequisites", on page 6

#### 6.3.2 AVB Camera Connection Test with Pylon Software

To help and check whether camera is working correctly:

- 1. Connect power adapter to camera.
- Connect LAN cable between camera and PC main LAN port. Note: You should use PC main LAN port to connect PC because of high-speed data rate from camera. Additional USB to LAN port is needed to connect BTC.
- 3. Set DHCP for IP address of PC.

nternet Protocol Version 4 (TCP/SPv4)	Properties			9 <mark>- 8</mark>
General Alternate Configuration				
You can get IP settings assigned auton this capability. Otherwise, you need to for the appropriate IP settings.	atically if y ask your r	your n	etxork kadnin	supports istrator
Obtain an IP address automatical	Y			
Use the following IP address:				
IP address:				
Subret marks				
Default gateway:				
Chine Diff server address autom	atesty			
O Use the following DNS server add	10040			
Preferred DNS server:				
Alternate DNS server:				
Validate settings upon exit			Adv	anced
		ox		Cancel
	_		_	

Figure 6-31: DHCP setting for PC

4. Run the "pylon IP Configurator".



Figure 6-32: Program in start menu

- 5. Run pylon IP Configurator.
  - Set DHCP for camera.
  - Click "Refresh" button.
  - Check "Status" is "OK". IP address may be different.

#### AVB Camera Setup

📝 pylon IP Configurator v4.1							- 8 <mark>- X</mark>
File View ?							
Name	Device User ID	Serial Numb	er MAC Address	Status	P Configuration	IP Address	Subnet Mask
Local Area Connection							
acA2000-50gm				ОК	DHCP	169.254.209.10	255.255.0.0
State P     P Address:     Subnet Mask:	Bask Ver No Der	er acA2000-5 dor: del Name: vice User ID: sel Namber: III	50gm (21575632) Basler acA2000-50gm				Refesh
Gateway:	MA P P	C Address: Configuration: Address:	DHCP 169.254.209.10				
Device User ID:	Gar	bnet Mask: Seway:	255.255.0.0				
5	ave .						

Figure 6-33: Pylon IP configurator status

# 6.3.3 AVB Camera Test Setup

The following shows the AVB camera test setup.



Figure 6-34: AVB camera test setup

#### 6.3.3.1 AVB Camera Hardware Setup

The following describes the procedure for AVB camera test setup:

- 1. Connect BTC RF port to TV antenna input by RF cable and matching pad.
  - Depend on K8 (Baseband routing) option, you may need coupler or combiner.
  - It transmits terrestrial or satellite standard signal.
- 2. Connect camera to PC main LAN port by a LAN cable.

- Check connection in Chapter 6.3.2, "AVB Camera Connection Test with Pylon Software", on page 61.
- It transmits video signal to AVB camera software.
- 3. Connect BTC to PC USB to LAN adapter by a LAN cable. Recommend to use static IP (ex. 192.168.1.100).
- 4. Connect PC HDMI output to BTC HDMI (B2361) module input by HDMI cable. It transmits video signal after processing by AVB camera software.
- 5. Connect RedRat 3-II or RedRat-X to PC USB port.

#### 6.3.3.2 AVB Camera Graphical User Interface

Upon analysis, the selected frame is shown on the left window area. On the right hand side is the analyzer log and camera exposure setting. It indicates the time, frame time code, for each time code, how many frames have been captured by the camera and which frame is selected. At the bottom green color area is the "Status" log. It indicates what operation has been performed.



Figure 6-35: AVB camera GUI

#### **Control Buttons**

There are total 12 control buttons. Upon start-up, only "Unlock", "About" and "Exit" button are enabled.

When option key is verified, the control buttons are enabled and allowed to use.



Figure 6-36: AVB Camera menu icons

The functionality of each button is listed as follows:

"Unlock"

Pop up unlock dialog and connect to BTC to verify option key. Upon success, the rest of the buttons are enabled.

"Crop Display"

Pop up cropping dialog and allow you to select the cropping area. Upon finish, the analysis of the frame is only done on the cropping area. You are able to press and drag to select the cropping area.

The recommended area is within upon and bottom blue line and outside the middle rectangle. This window is auto exit after you finish the cropping. The cropping area's information is then saved in a file. So that next time if you need to run the application, it reads back the information from the file and auto set accordingly as the cropping area.



Figure 6-37: AVB camera cropping window

- "Calibration"
  - Currently is not supported.
- "Start Analysis" Start analyzing on the cropping area, detect time code, discard disturbed frames, select the frame and display on the left display window.
- "Stop" Stop analysis.
- "Camera" Connect or disconnect camera.
- HDMI Out"

Output selected frame on the second monitor through HDMI. This is a toggle button, press one more time the application stops outputting frame on the second monitor.

"AutoScroll"

The status log is auto scrolled to the last line.

"About"

Pop up about dialog to show software version.

"Exit"

Close window and exit from the application.

#### Capture Frame Window

This is the displayed video after cropping process. It shows timecode at the bottom. If timecode is not displayed, the window shows black screen when the timecode is not detected during analysis.

#### Analyzer Log Area

It shows current frame number and number of captured pictures. Selected frame is transmitted to BTC. It only works when timecode in the bottom is detected during analysis.

#### **Camera Properties**

- "Camera Settings"
  - Exposure value helps to solve flickering issue and brightness from TV. Default value is 10000 us.
  - Other solution is to change lens setting manually.
- "Frame Selection Settings"

It decides which picture is transmitted to BTC among captured pictures. First and last pictures are not counted because it has a chance to be overlapped with other frame picture.

- "Max Brightness": The most brightest picture is selected
- "2nd Frame": First valid captured picture is selected
- "3rd Frame": Second valid captured picture is selected
- "4th Frame": Third valid captured picture is selected



Figure 6-38: Frame selection example

TV backlight cannot be turned on always for power consumption issue. It is the reason why user need to set backlight setting to max to minimize off time. Even though, each picture from capturing by camera has different brightness, which can affect AV distortion measurement algorism. AVBCamera helps to send consistent brightness picture using Frame Selection Settings.

#### 6.3.3.3 AVB Camera Test Sequence

The following are settings required before running TA-TRS.

- Set the position for TV and camera. Camera needs to face the center of TV screen to get correct video.
- Connect all required cables and accessories explained in Chapter 6.3.3, "AVB Camera Test Setup", on page 63.
- 3. PC: Set screen resolution of HDMI output which appears as a second monitor.

Screen properties

- Display: 2. R&S HDMI RX
- Resolution: 1920 x 1080 (recommended)
- Orientation: Landscape
- Multiple displays: Extend these displays

C	hange t	the appearance of	f your displays
---	---------	-------------------	-----------------

	1 2	Detect Identify
Display:	2. R&S HDMI Rx 🔹	
Resolution:	[1920 × 1080 (recommended) ▼	
Orientation:	Landscape 💌	
Multiple displays:	Extend these displays	
Make this my m	ain display	Advanced settings

#### Figure 6-39: PC screen setting

4. TV: Turns off all enhanced functions for display and set back light illumination to maximum to avoid flickering issue.

Note: AV distortion analyzer compares between reference video and incoming video for picture failure. The latest TV has many enhanced functions like auto brightness control. It may affect test results because screen keep changing even human eyes cannot detect. You should turn off all enhanced functions.

5. BTC

- Generate DVB-T/T2 or DVB-S/S2 signal depends on DUT support. Use Grouper\_720p\_50\_Camera.trp under D:\TSGEN\AVBrun folder.
- 6. DUT: Scan channel to show video.
- 7. PC: Run AVB Camera software.

Image: Second	> 68	2												enera	AVE (
Selected     Properties       Capture     Time     Frame     Captures     Selected     Convers     Selected     Default       Default     Prime     Selected     Prime     Selected     Prime     Selected     Prime       Selected     Selected     Prime     Selected     Prime     Selected     Prime       Selected     Selected     Selected     Prime     Selected     Prime       Selected     Selected     Selected     Selected     Prime       Date     Time     Category     Event / Message				Ext .	About	C) Help	Auto Scoal	HEME OUR		0	Carl Analysis	Calibration 51	Anto Crop (	Crop Display	(D) United
Capture Frame     Analyzer Log     Properties       Capture     Time     Frame     Captures     Selected     Camera Settings       Default     Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected     Image: Selected     Image: Selected     Image: Selected     Image: Selected       Image: Selected														rta	ph/re (
Capture Time Prame Captures Selected Camera Settings Exposure: 1000 µs Definit Frame Selection Settings Prame Selection Settings Prame Selection Settings Prame Selection Settings 2 nd Prame 3 nd Prame 4 th Prame Date Time Category Event / Message		Properties	Log	Analyzer Log	/					e	ure Frame	Capts			
As Log Dute Time Category Event / Message		Camera Settings	ures Selected	Captures	Frame	Time					apture	G			
Antage Date Time Category Event / Message		Exposure: 10000 µs													
As Log Dute Time Category Event / Message		Default													
Aucling Date Time Category Event / Hessage		Frame Selection Settings Max Brightness 2nd Frame 3nd Frame 4th Frame													
Date Time Category Event / Message															itus Lo
			ssage	nt / Messa	Eve						Y	Category	Time	Date	
Wed Feb 14 20 08:05:50 Info Application started successful Wed Feb 14 20 08:05:51 Warning Camera is not ready, please wat								isful ise wait	ed succe eady, ple	ation start ra is not r	Applica Camer	D Info Warning	08:05:50	Feb 14 20. Feb 14 20.	We

Figure 6-40: AVB camera starting window

- 8. AVB Camera: Option detection.
  - Click "Unlock" button.
  - Type BTC IP address and click "Connect" button to detect R&S®BTC-KT3329.

<b>I C</b>	onnect B	TC to	unlock			6	×
	BTC IP /	\ddre	155				
	192		168	1		100	
				Connec	:t	Clos	e

Figure 6-41: BTC connection menu for option detection

onnect B1	TC to	unlock					×
BTC IP A	ddre	155					
192		168		1		90	
Unable t	0 CO	nnect to	o 192	.168.1	.90.		
				Connec	t	Clos	e

Figure 6-42: Option detection error message

- 9. AVB Camera: Crop display.
  - Click "Crop Display" button.
  - Press left mouse button and drag to select the cropping area. It should contain timecode correctly. The recommend area is within upon and bottom blue line and outside the middle rectangle. The window is auto exit after you finish the cropping. The cropping area's information is saved in a file. So that next time if you need to run the application, it reads back the information from the file and auto set accordingly as the cropping area.



Figure 6-43: AVB camera cropping window

- 10. AVB Camera: Video out to BTC.
  - Click "HDMI Out" button
  - It transmits cropped video to BTC
- 11. AVB Camera: Analysis
  - Click "Start Analysis" button
  - AVB camera can captures 4~7 same picture per frame. You can see number of pictures in below "Captures" column.
  - AVB camera selects only one picture to send to BTC by "Frame Selection Settings", which is mentioned in "Camera Properties" on page 66.

Note: It is recommended capturing at least five pictures for accurate processing. Depend on crop size, capture speed is changed and it affects number of captured pictures. If AVB camera cannot detect time code, screen is black and log information update is stopped. Try to change brightness setting in lens and camera tilt position.

Capture Frame			Analy	zer Log		
A STATE AND A STAT		Time	Frame	Captures	Selected	*
各人主人の一人が開催生産ン	41	10:10:00	158	0	1	
	42	16:16:00	159	7	1	
	43	16:16:00	160	6	2	
	44	16:16:00	161	6	2	
Real I	45	16:16:00	162	6	4	
	46	16:16:01	163	6	3	
	47	16:16:01	164	6	2	
A Part of the second	48	16:16:01	165	7	5	
A the statement in a second second second second	49	16:16:01	166	6	2	ļ

Figure 6-44: AVB camera processing window

#### 12. PC: Run TA-TRS

- Select "Camera" for "A/V Interface " in "General" menu.
- Before running test cases, it makes reference video and test quality. If quality checking is failed, change "Frame Selection Settings" in "AVB Camera".

Test Conditions	Picture Failure Report	
Test Setup & Me	thod	
2RF Paths	Detailed Method	٠
Picture Degrada	tion Judgement	
	Auto	•
A/V Interface		
	Camera	•
-		
Test Video Stel	am	_
	Grouper_720p_50_Camera.b	•
	Stream Path - DI/TSGENAVBr	uni
		-

Figure 6-45: Camera selection in General menu

# 7 Test Status and Results

While running the TA-TRS, a "Status Information" window showing the overall and current test status and the signal information uses for the test cases.

# 7.1 Test with Auto Mode

When choose "Auto" mode in the picture degradation judgment, the test is auto run by itself. You can abort the test by clicking the "Abort" button. You can switch between "Current Test" mode and "Overall Result" mode.

EN303340 - Limit: 35 d8		
	Result View	Current Test 🔹
Current Test Status		
Creating reference Running test case	I/C setting	
Task 4.2.4	DVB-T	Log L/C(dB)
Adj. channel selectiv	ity: 1.LTE800 BS light	38.2
Infomation	Picture Falure	
Bandwidth 8MHz	No. of Error	
Frequency 786 MHz	Test Time	
VC 38.2 dB	0 min 0 s	
Overal Test Status		auri

Figure 7-1: Current test mode

2.3 Sensitivity	3 Senativity   42.6 All Channel Selectivity   42.5 Blocking   42.6 Overloading							
interferer (i) type	C wanted signal Center frequency	I centre frequency (MHz)	Minimum limit (wh for DTT cont	required I/C ere I = IIc) figurations (d8)	Measured L/C for DTT configurations in tables 2 and 3 (dB)			
LTE 800 BS light	(MHz) 786.0	796.0	35	36	37.5	38.5		
E LTE 700 BS light	690.0	763.0	43	43	47.7			
UE Video	690.0	708.0	33	38	Testing			
😨 N-1 UHF	482.0	474.0	25	25				
🔄 N+1 UHF	482.0	474.0	25	25				

Figure 7-2: Overall result mode

# 7.2 Test with Full Manual Mode

When "Full Manual" mode in the picture degradation judgment, there is a manual operation column for you to enter the level and set it using the "Set" button and click "Final Level" button if the level is the final level. Start the test by clocking on the "Start" button.

During the test, when an error is observed, click the "Error" button, if there is no error, click the "No Error" button. You can also retest the test again by clicking the "Retest" button. You can abort the test by clicking the "Abort" button. There also shortcut keys for some of the button, which stated beside the name of the button.
#### Test with Semi Manual Mode



Figure 7-3: Full manual mode

It is possible for keyboard control using shortcut key.

- Arrow up: Level or CI value increase
- Arrow down: Level or CI value decrease

For alternate control, you only need to press ALT+ any below key first time. After activate it, you can press alphabet only without ALT key.

- ALT + A: Level or CI set
- ALT + F: Final Level
- ALT + S: Start test
- ALT + E: Error
- ALT + D: No Error
- ALT + R: Retest

# 7.3 Test with Semi Manual Mode

When "Semi Manual" mode in the picture degradation judgment, there is a manual operation column for you to start the test by clocking on the "Start" button. During the test, when an error is observed, click the "Error" button, if there is no error, click the "No Error" button. You can also retest the test again by clicking the "Retest" button.

You can abort the test by clicking the "Abort" button. The level and final level is done automatically. There also shortcut keys for some of the button, which stated beside the name of the button.

#### Test with Simple Manual Mode



Figure 7-4: Semi manual mode

It is possible for keyboard control using shortcut key.

- Arrow up: Level or CI value increase
- Arrow down: Level or CI value decrease

For alternate control, you only need to press ALT+ any below key first time. After activate it, you can press alphabet only without ALT key.

- ALT + A: Level or CI set
- ALT + F: Final Level
- ALT + S: Start test
- ALT + E: Error
- ALT + D: No Error
- ALT + R: Retest

# 7.4 Test with Simple Manual Mode

When Simple Manual mode is selected in the picture degradation judgment, there is a "Start (Enter)" button to start the test. When the picture failure will analyze for 15s, if there is any error observed, click the "Start (Enter)" button and it will auto set to the next level. You can abort the test by clicking the "Abort" button.



Figure 7-5: Simple manual mode

# 7.5 Test Result

After the test had completed or aborted, a test report and log file will be auto generated. The following shows a sample of test report information, test configurations and test results of the report.

#### ETSI EN303 340 RFTest

Operator:

DUT Model:

DUT Serial Number:

Description:

#### Instrument: SFU 02.80.00.08

Instrument Options:

SFU-K1,SFU-K3,SFU-K6,SFU-K8,SFU-K11,SFU-K12,SFU-K16,SFU-K20,SFU-K40,SFU-K55,SFU-K60,SFU-K221,SFU-K223,SFU-K224,SFU-K227,SFU-K-B30,SFU-B15,SFU-B3,SFU-B4,SFU-B6,SFU-B30

Dll version: 1.0.0.9

Figure 7-6: Test report information

#### EN303340 TestPlan

Version	Version 1.1.2
Compensation	Not Used
IR remote control	Not Used

#### Picture Failure

Input	HDMI
Length of Period	10 sec
SSIM Value:	0.97
Measurement Duration:	200 ms

#### Environment Information

Temperature	
Humidity	
Uncertainty	

#### Reference Video Information

Video Resolution (H x V)	1280x720	
Number of Frames	1152	
File Size	684MB	
Reference Name D:\VTE\UserData\RefVideo.avr in BTC		

#### Figure 7-7: Test configuration

#### 4.2.4 Adjacent channel selectivity

#### Table: Measurement record for adjacent channel selectivity tests

Test	l type	C Signal center frequency (MHz)	l Signal center frequency (MHz)	Min. requir for DTT cor in tables (d	ed I/C limit figurations s 2 and 3 B)	Measured i configu in tables (d	I/C for DTT rations 2 and 3 B)
				DVB-T	DVB-T2	DVB-T	DVB-T2
1	LTE 800BS	786	796	35	36	56.5 (PASS)	52.6 (PASS)
2	LTE 700BS	690.0	763.0	43	43	57.3 (PASS)	53.4 (PASS)
3	LTE 700BS	690.0	708.0	33	38	47.8 (PASS)	43.9 (PASS)
4	N-1 UHF	482.0	474.0	25	25	42.2 (PASS)	38.4 (PASS)
5	N+1 UHF	482.0	490.0	25	25	42.2 (PASS)	38.4 (PASS)

Figure 7-8: Test result

# Index

# A

AVB Camera Graphical User Interface	
Analyzer Log Area	64
Camera Properties	64
Capture Frame Window	64
Control Buttons	64
AVB Camera Setup	
AVB Camera Connection Test with Pylon Software .	60
AVB Camera Prerequisites	60
AVB Camera Test Setup	60
AVB Camera Test Setup	
AVB Camera Graphical User Interface	63
AVB Camera Hardware Setup	63
AVB Camera Test Sequence	63

### С

Compensating Losses	
Compensation File Save / Open	46
Compensation Setup	46
Instrument Configuration	46
Result and Normalization Tab	46
Status	46

# Е

EN303340	
4.2.3 Sensitivity	35
4.2.4 Adjacent Channel Selectivity	35
4.2.5 Blocking	35
4.2.6 Overloading	35
Picture Failure	25
Test Condition	25
EN303340 & EN303372 Automated Test Setup	18
EN303340 & EN303372 Automated Test Setup with C	Camera
	18
EN303345	
4.2.4 Sensitivity	40
4.2.5 Adjacent channel selectivity and Blocking	40
4.3.1 Adjacent signal selectivity	44
4.3.2 Dynamic range	44
Audio Failure	25
Multi Box Setup	8
One Box Setup	8
Test Condition	25
EN303345 Automated Test Setup	18
EN303372-2	
Multi Box Setup	6, 11
One Box Setup	6, 11
Picture Failure	25
Test Condition	25

### L

Learning DUT IR Commands	
Constructing Sequences	52
RedRat Prerequisites	52
Start RedRat	52
Teaching RedRat	52

# Ρ

Prerequisites	
EN303340	6
EN303345	6
EN303372-2	6

### Q

QuickStep	
Setup	 14

# R

R&S TA-TRS Overview	
RedRat Prerequisites	
RedRat 3-II	
RedRat-X	

# S

33

### Т

Test Cases	35
Test Configuration	24
Compensation Dialog 2	24
File Settings	24
General Dialog2	24
Remote Control DUT Dialog 2	24
ReRun Settings2	24
Signal Mode List Dialog 2	24
Test Preparation	16
AVB Camera Setup4	16
AVB Camera Test Sequence 4	16
Compensating Losses 4	16
Learning DUT IR Commands 4	16
Test Results7	′5
Test Setup 1	8
Test Status and Results 7	1
Test with Auto Mode7	1
Test with Full Manual Mode7	1
Test with Semi Manual Mode7	1
Test with Simple Manual Mode7	1