

Satellite Navigation Digital Standards for R&S®SMBV100A Supplement

The following description includes additions to the Satellite Navigation - Digital Standards for R&S®SMBV100A user manual. It informs you about new features coming with the R&S SMBV FW 4.15.125.49 and higher.

- **Related manuals**

For comprehensive documentation, refer to the following operating manuals:

- Satellite Navigation - Digital Standards for R&S®SMBV100A
- R&S®SMBV-P101 GNSS Production Tester

See the R&S SMBV product page: www.rohde-schwarz.com/manual/smbv100a

- **Additional features**

Support of R&S SMBV-P101 remote commands:

- R&S SMBV-P101 remote commands are supported, if the R&S SMBV is fully equipped with the basic GNSS system options: R&S SMBV-K44/-K66/-K94/-K107.

Installing the option R&S SMBV-P101 is not required.

- Remote command subset extension to the placeholder `<Subsystem>`:

The `<Subsystem>` remote command placeholder replacing the GNSS subsystems

`SOURCE:BB:GPS|GALileo|GLONass|BEIDou` is extended by the R&S SMBV-P101 remote command subset `SOURCE:BB:GNPR`.

For a comprehensive list of R&S SMBV-P101 remote commands, see the R&S SMBV-P101 user manual.



1178916102