

R&S®FSW, R&S®FPS, R&S®FSWP R&S®ESW, R&S®FSWT External Touch Monitor Update

Release Notes

These Release Notes are for following models of the R&S®FSW Signal and Spectrum Analyzer:

R&S® FSW8, order no. 1312.8000K08, R&S® FSW13, order no. 1312.8000K13,
R&S® FSW26, order no. 1312.8000K26, R&S® FSW43, order no. 1312.8000K43,
R&S® FSW50, order no. 1312.8000K50, R&S® FSW67, order no. 1312.8000K67,
R&S® FSW85, order no. 1312.8000K85

These Release Notes are for following models of the R&S®FPS Signal and Spectrum Analyzer:

R&S® FPS4, order no. 1319.2008K04, R&S® FPS7, order no. 1319.2008K07,
R&S® FPS13, order no. 1319.2008K13, R&S® FPS30, order no. 1319.2008K30
R&S® FPS40, order no. 1319.2008K40

These Release Notes are for following models of the R&S®FSWP Phase Noise Analyzer:

R&S® FSWP8, order no. 1322.8003.08, R&S® FSWP26, order no. 1322.8003.26,
R&S® FSWP50, order no. 1322.8003.50,

These Release Notes are for following models of the R&S®ESW EMI Test Receiver:

R&S® ESW8, order no. 1328.4100.08, R&S®ESW26, order no. 1328.4100.26
R&S® ESW44, order no. 1328.4100.44

These Release Notes are for following models of the R&S®FSWT Test Receiver:

R&S® FSWT26, order no. 1313.7008.26

© 2016 Rohde & Schwarz GmbH & Co. KG

Muehldorfstr. 15, 81671 Munich, Germany

Phone: +49 89 41 29 - 0

Fax: +49 89 41 29 12 164

E-mail: <mailto:info@rohde-schwarz.com>

Internet: <http://www.rohde-schwarz.com>

Subject to change.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

Trade names are trademarks of the owners.

1 Installation Package for External Touch Monitor Update

External touch monitors are not supported by default. User action is required. This document describes the update procedure:

To activate the support of an external touch display, you need to execute the installation package "TouchMonitorUpdate-W7_64Bitxyz.msi". The file can be placed on any disk drive, network drive or USB storage device attached to the instrument.

Prerequisite: Operating system Windows Embedded Standard 7 64 Bit

1. Do not connect the external touch monitor via USB before the installation is completed.
2. Start the instrument with an account with administrator rights (e.g. the user "Instrument")
3. Open Windows Explorer and navigate to the folder containing the installation package.
4. Start the installation by double clicking the File "TouchMonitorUpdate-W7_64Bitxyz.msi"
5. Press "Next".
The installation procedure starts and may take up to five minutes. A black console window will show up. Please be patient until the process is complete
6. Press "Exit".
The instrument will perform several reboots.
7. Connect the external display to the instrument using a DVI or DisplayPort cable as well as an USB cable.

2 Customer Support

Technical support – where and when you need it

For quick, expert help with any Rohde & Schwarz equipment, contact one of our Customer Support Centers. A team of highly qualified engineers provides telephone support and will work with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz equipment.

Up-to-date information and upgrades

To keep your instrument up-to-date and to be informed about new application notes related to your instrument, please send an e-mail to the Customer Support Center stating your instrument and your wish. We will take care that you will get the right information.

Europe, Africa, Middle East

Phone +49 89 4129 12345

customersupport@rohde-schwarz.com

North America

Phone 1-888-TEST-RSA (1-888-837-8772)

customer.support@rsa.rohde-schwarz.com

Latin America

Phone +1-410-910-7988

customersupport.la@rohde-schwarz.com

Asia/Pacific

Phone +65 65 13 04 88

customersupport.asia@rohde-schwarz.com

China

Phone +86-800-810-8828 / +86-400-650-5896

customersupport.china@rohde-schwarz.com