# R&S<sup>®</sup>ScopeSuite Release Notes

Software Version 5.35.1

© 2023 Rohde & Schwarz GmbH & Co. KG Muehldorfstr. 15, 81671 Munich, Germany Phone: +49 89 41 29 - 0 E-mail: info@rohde-schwarz.com Internet: http://www.rohde-schwarz.com

 $\label{eq:subject} \begin{array}{l} \text{Subject to change} - \text{Data without tolerance limits is not binding.} \\ \text{R\&S}^{\circledast} \text{ is a registered trademark of Rohde & Schwarz GmbH & Co. KG.} \\ \text{Trade names are trademarks of the owners.} \end{array}$ 

1317.4549.02 | Version 37 | R&S®ScopeSuite |

The software makes use of several valuable open source software packages. For information, see the "Open Source Acknowledgment" provided with the product.

The following abbreviations are used throughout this document: R&S<sup>®</sup>ScopeSuite is abbreviated as R&SScopeSuite.



**ROHDE&SCHWARZ** 

Make ideas real

## Contents

1	Information on the current version and history	3
1.1	Version 5.35.1	3
1.2	Version 5.30.1	4
1.3	Version 5.20.1	6
1.4	Version 5.0.1	8
1.5	Version 4.80.1	10
2	Modifications to the documentation	14
3	Software update	15
3.1	Update information	15
3.2	Updating the firmware	15
3.2.1	Uninstall old versions	15
3.2.2	Install R&S ScopeSuite	
3.2.3	Log files	18
3.2.4	Error recovery	18
4	Customer support	19

## 1 Information on the current version and history

## 1.1 Version 5.35.1

#### New functionality

Option/Topic	Functions
DisplayPort	Support only for R&S RTP, RTP-B • DP 1.4a (RTP-K114) • Main-Link Tests • Eye Diagram Tests • Jitter Measurement Tests • HBR/RBR Level Verification and Peak to Peak Differential Voltage Tests • HBR3/HBR2 Level Verification Test • HBR3/HBR2 Peak to Peak Differential Test • Main-Link Frequency Compliance Test • SSC Tests • Intra-pair Skew Test • AC Common Mode Noise Test • Inter-Pair Skew Test • AC Common Mode Noise Test • Inter-Pair Skew Test • AC Common Mode Noise Test • Inter-Pair Skew Test • AUX CH Tests • EYE Tests • AUX_CH (Manchester-II) Sensitivity Test • Termination DC Tests • DP_PWR Tests • Inrush (Normative) and Outrush (Informative) Test • DP_PWR Tests • Linter Tests • Eye Diagram Test • Jitter Tests • Differential Voltage Test • Jitter Tests • Differential Voltage Test • Main-Link Frequency Compliance Test • SSC Tests • Intra-Pair Tests • Intra-Pair Tests • Intra-Pair Tests • Intra-Pair Skew Test • AUX CH Tests • O AUX CH Tests • Differential Voltage Test • Main-Link Frequency Compliance Test • SSC Tests • Intra-Pair T

Option/Topic	Improvements	
USB2.0	<ul> <li>the GUI text "Receiver Sensitivity Offset" has been changed to "AWG Rx Sensitivity Offset" to clarify the settings is related to AWG setting.</li> </ul>	
C-PHY	• Eye Test now uses Advanced Eye Diagram Analysis (K136/K137)	
D-PHY	<ul><li>Eye Test now uses Advanced Eye Diagram Analysis (K136/K137).</li><li>Changed minimum bandwidth to 4GHz.</li></ul>	

	<ul> <li>VOD(0), VOD(1), VOD Mismatch, Risetime(Tr) and Falltime(Tf) tests are now reported.</li> </ul>
Ethernet	<ul> <li>Improved guided steps image for 2.5G Base-T transmitter non-linear distortion test with disturber. The test setup diagram has been revised to represent the test more accurately.</li> <li>For 100BASE-T1, the common mode emission test will use log scale as default for the frequency axis.</li> </ul>
DDR4/LPDDR4 /LPDDR4X	<ul> <li>Input receiver compliance mask for voltage and timing: change acquisition length for eye from ms to UI for better usability.</li> <li>Single ended probe support for CK and DQS.</li> <li>Support for scope internal clearance button to reset the scope when required.</li> </ul>
DDR3	• Two channel support for data and strobe timing test case.
USB3.2-RX	<ul> <li>Tested against Anritsu Software MX190000A V10.00.01</li> <li>Tested against Anritsu Software MX183000A V10.00.01</li> </ul>

#### **Tested firmware**

Version	Functions
Firmware 5.35.1	This ScopeSuite version is tested against the RTx firmware version 5.35.1

#### **Known issues**

issue	Known Issues	
Common	Upgrading Firmware and ScopeSuite procedure: To prevent conflicting of License Server, the step to follow is to upgrade Firmware first, next uninstall ScopeSuite from control panel then install the latest version of ScopeSuite.	

## 1.2 Version 5.30.1

Option/Topic	Functions
	Support for only R&S RTP, RTP-B Calibration
USB3.2-RX (K102)	<ul> <li>USB3.2 Gen1 5GT/s         <ul> <li>TD.1.8.1/TD.1.9.1 Amplitude and De-emphasis Calibration</li> <li>TD.1.8.20/TD1.9.21 Short Channel Calibration</li> <li>Connection Std-A, Std-B, microB                 <ul></ul></li></ul></li></ul>

- o TD.1.10.2...3Rj and Sj Calibration
- Connection: Std-A, microB, Type-C
  - Upstream Facing Port
    - TD.1.10.4...9 CLB Analysis
      - TD.1.10.10...11 Eye Width and Eye Height Calibration
  - Downstream Facing Port
    - o TD.1.10.4...9 CLB Analysis
    - o TD.1.10.10...11 Eye Width and Eye Height Calibration

#### Device

- USB3.2 Gen1 5GT/s
  - TD.1.8.3...19/TD1.9.3...20 Receiver Jitter Tolerance Test Long channel
  - TD1.8.21...22/TD1.9.22...23 Receiver Jitter Tolerance Test Short channel
- USB3.2 Gen2 10GT/s
  - o TD.1.10.12...29 Receiver Jitter Tolerance Test Long channel
  - o TD.1.10.31...32 Receiver Jitter Tolerance Test Short channel

## Hub

- USB3.2 Gen1 5GT/s
  - TD.1.8.3...19/TD1.9.3...20 Receiver Jitter Tolerance Test Long channel
  - TD1.8.21...22/TD1.9.22...23 Receiver Jitter Tolerance Test Short channel
- USB3.2 Gen2 10GT/s
  - $\circ \qquad \text{TD.1.10.12...29 Receiver Jitter Tolerance Test-Long channel}$
  - o TD.1.10.31...32 Receiver Jitter Tolerance Test Short channel

#### Host

- USB3.2 Gen1 5GT/s
  - TD.1.8.3...19/TD1.9.3...20 Receiver Jitter Tolerance Test Long channel
  - TD1.8.21...22/TD1.9.22...23 Receiver Jitter Tolerance Test Short channel
  - USB3.2 Gen2 10GT/s
    - TD.1.10.12...29 Receiver Jitter Tolerance Test Long channel
    - o TD.1.10.31...32 Receiver Jitter Tolerance Test Short channel

Option/Topic	Improvements	
Common	<ul> <li>After creating new session and checked on "Test Checked", skew values is not updated to GUI. Update scope skew values to properties files so that ScopeSuite will update to GUI on starting of new session.</li> </ul>	
MGBase-T1	<ul> <li>Added informative values of signa_n, sigma_e, and P_max in reports for 149.5.2.2 Transmitter linearity test case</li> </ul>	
1000Base-T1	<ul> <li>Added digital filter property setting for RTP 8 GHz and above for transmitter distortion test</li> </ul>	
D-PHY	<ul><li>Improved LP to HS separation algorithm.</li><li>Fixed channel skew not applied in LP Tests.</li></ul>	
Ethernet	<ul> <li>Support ZNL model vector network analyzer</li> <li>Improved guided steps for test setups using Link Partner</li> <li>Support 2-channel oscilloscopes</li> </ul>	

HDMI	Added advanced eye for clock and data test
DDR4/LPDDR4 /LPDDR4X	<ul> <li>New test case: Input receiver compliance mask for voltage and timing. (DQ Eye mask tests). User able to configure the mask parameters and its jump step length in the GUI.</li> <li>Configurable time out length in the GUI for strobe timing test case in case DUT has very less transitions.</li> <li>Custom speed selection in the GUI if DUT do not belong to any of the nominal speeds.</li> <li>Support for various preamble types. User is able to select 1TCK, 2TCK for preamble types shown in JEDEC. For preamble types not defined in specs, user may choose 'auto' to process.</li> </ul>
DDR3	Read Write parameters configurable in GUI.

#### **Tested firmware**

Version	Functions
Firmware	This ScopeSuite version is tested against the RTx firmware version 5.30.1 on RTP-B,
5.30.1	RTP & RTO6 & RTO2000 series.

#### **Known issues**

issue	Known Issues
Common	Upgrading Firmware and ScopeSuite procedure: To prevent conflicting of License Server, the step to follow is to upgrade Firmware first, next uninstall ScopeSuite from control panel then install the latest version of ScopeSuite.

### 1.3 Version 5.20.1

Option/Topic	Functions
	Support for only R&S RTP, RTP-B 1.2
С-РНҮ (К28)	<ul> <li>LP-TX Signaling Requirements (Group1)         <ul> <li>1.1.1 ~1.1.7</li> </ul> </li> <li>HS-TX Signaling Requirements (Group2)         <ul> <li>1.2.1 ~ 1.2.6, 1.2.10 ~1.2.20</li> </ul> </li> <li>HS-TX Signaling Requirements for Eye Measurements (Group2)         <ul> <li>1.2.7 ~1.2.9, 1.2.21</li> </ul> </li> </ul>
	<ul> <li>LP-TX Signaling Requirements (Group1)         <ul> <li>1.1.1 ~1.1.8</li> </ul> </li> <li>HS-TX Signaling Requirements (Group2)         <ul> <li>1.2.1 ~ 1.2.6, 1.2.10 ~1.2.13, 1.2.16~1.2.19</li> </ul> </li> <li>HS-TX Signaling Requirements for Eye Measurements (Group2)         <ul> <li>1.2.7 ~1.2.9, 1.2 21 ~1.2.22</li> </ul> </li> </ul>

D-PHY (K27)	Support for RTP, RTP-B, RTO6, RTO2000 2.0/2.1/2.5 • Clock Lane HS-TX Signaling Requirements (Group4) ○ 1.4.18 ~ 1.4.20 • HS Clock-To-Data Lane Timing Requirements (Group5) ○ 1.5.8 ~ 1.5.10 • Eye Test ○ 1.4.18, 1.4.20, 1.5 7
Automation K99	<ul><li>Coverage of all eMMC test cases</li><li>Supports Python Client</li></ul>

Option/Topic	Improvements
Common	<ul> <li>Guided steps: automatic update of the channel configuration images in the guided steps, according to the user configuration.</li> <li>Guided steps: automatic update of the oscilloscope's images in the guided steps, according to the detected instrument.</li> <li>Test case error handling enhancement for 10BASE-T1, 100BASE-T1, 100BASE-T1 and MGBASE-T1</li> <li>Support German numbering system (e.g. 0,25E-3).</li> <li>Enhance Auto Y-axis scaling function</li> </ul>
	•
MGBase-T1	<ul> <li>Updated skew settings and support 'Retrieve Skew' button</li> <li>"149.5.2.2 Transmitter linearity" test case: supported for 5G and 10G</li> <li>Added hardware digital filter property to 10GBASE-T1 linearity test</li> </ul>
PCle	<ul> <li>New select type "Reference Clock".</li> <li>"Reference Clock" test cases are moved out of "System Board".</li> </ul>
100Base-T1	<ul> <li>"SLAVE transmitter timing jitter (96.5.4.3)" test case: "Edge Selection" (either, rising and falling)</li> <li>"Common mode emission" test case: it is only using log scale if K18 is present</li> <li>Add edge selection for rising, falling and both for jitter measurements</li> </ul>
1000Base-T1	• Add edge selection for rising, falling and both for jitter measurements
Ethernet	<ul> <li>1000BASE-T         <ul> <li>Peak Output Voltage (40.6.1.2.1): Measurement method is split:                 <ul> <li>Amplitude /Min and Max</li> <li>Transmitter distortion (40.6.1.2.4): Distortion plot is added</li> </ul> </li> </ul> </li> </ul>
USB/USB3.2	<ul> <li>USB2.0 "High speed Signal quality" tests: support 4 margins for the report</li> <li>Hub &gt; Downstream SuperSpeed Transmitted Eye test cases: the test has the wrong picture for the test fixture. The picture mentions 11" Device Test Fixture 2, but it should be 5" Host Test Fixture 2. (USB3.2) This applies to the corresponding test on the Host (DFP) as well.</li> <li>SuperSpeed Transmitted Eye test case: in the guided step CP1 or CP0 are used instead of CP10</li> </ul>

HDMI	• The unit of channel skew is now displayed as "ps".
Ethernet 2.5/5/10G	<ul> <li>The legacy K25 license is also working with Version 5.20.1</li> <li>2.5GBaseT "MDI Return Loss test case": The stop frequency is changed from 250MHz to 125MHz based on the latest specification (IEEE 802.3 clause 126.8.2.1).</li> </ul>
DDR4/LPDDR4 /LPDDR4X	<ul> <li>Support of width trigger and up to three zone trigger to capture bursts of strobe signal.</li> <li>Support configurable DQ threshold and hysteresis</li> </ul>

#### **Tested firmware**

Version	Functions
Firmware	This ScopeSuite version is tested against the RTx firmware version 5.20.1 on RTP-B,
5.20.1	RTP & RTO6 & RTO2000 series.

#### Known issues

issue	Known Issues
Common	After installation ScopeSuite could fail on the first run of any test case. Restart the ScopeSuite and try again.

### 1.4 Version 5.0.1

Option/Topic	Functions
Common	Support RTO 6
Common	eMMC support for RTP
Common	Merge k22 and k86 (eliminate k86)
Common	Merge k23 and k25 (eliminate k25)
HDMI	<ul> <li>2.1 TMDS</li> <li>All Clock Tests</li> <li>Single-Ended Tests</li> <li>Differential Timing Tests</li> <li>Differential Voltage Mask Tests</li> <li>Jitter Mask Tests</li> <li>Inter-Pair Skew (HF 1-3)</li> <li>1.4b</li> </ul>

	<ul> <li>All Clock Tests</li> <li>Voltage Off Tests</li> <li>Single-Ended Tests</li> <li>Voltage Off Tests</li> <li>Differential Timing Tests</li> <li>Jitter Mask Tests</li> <li>Inter-Pair Skew (7-6)</li> </ul>
MGBase-T1	<ul> <li>149.5.2.3 Transmitter timing jitter master</li> <li>149.5.2.3 Transmitter timing jitter slave</li> <li>149.5.2.3.1 Transmit MDI random jitter in master mode</li> <li>149.5.2.3.2 Transmit MDI deterministic jitter in master mode</li> <li>149.5.2.2 Transmitter linearity (only 2.5G)</li> <li>149.5.2.6 Transmitter clock frequency</li> <li>149.5.2.3 Transmitter power spectral density (PSD) and power level</li> <li>149.5.2.5 Transmitter peak differential output</li> <li>149.5.2.1 Maximum output droop</li> <li>149.8.2.1 MDI return loss</li> </ul>
DDR3/DDR3L/ LPDDR3, DDR4/LPDDR4	<ul> <li>Support configurable scaling modes (Auto/Reference)</li> <li>Support write triggering method (Edge/ABR/Width)</li> <li>Support CLK Off selection for DDR4 both online and offline execution.</li> <li>Configurable hysteresis of address signals</li> </ul>
Automation K99	<ul><li>Support Sub-Test selections and its run API.</li><li>Support two channel mode for DDR4.</li></ul>

#### Improvements

Option/Topic	Improvements
Common	<ul> <li>ScopeSuite errors handling enhancement.</li> <li>ScopeSuite log file enhancement</li> <li>Communication protocol enhancement between ScopeSuite, Scope and VNA.</li> <li>Enhancement of keeping ScopeSuite in front of firmware when running on scope.</li> </ul>
DDR3/DDR3L/ LPDDR3, DDR4/LPDDR4 /LPDDR4X	<ul> <li>Error handling enhancement</li> <li>Timing &amp; electrical test cases enhancement</li> <li>Re-design tDIPW measurement on CMD/ADD/CS</li> <li>Smarter execution for Data Timing and Strobe Timing Tests</li> </ul>
USB/USB3.2	<ul><li>Property view enhancement.</li><li>Error message handling enhancement.</li></ul>
PCle	• Test cases re-arrangement in different test subtypes.
Ethernet 1000Base- T/100Base-Tx	<ul> <li>Support calculation of 85 Ohm &amp; 115 Ohm reference impedance in MDI return loss measurement.</li> </ul>

#### **Tested Firmware**

Version	Functions
Firmware 4.80.1/5.0.1	This ScopeSuite Version is tested against the RTX Firmware Version 4.80.1 & 5.0.1 on RTP & RTO2000 series, 5.0.1 on RTO6.

#### Known issues

issue	Known Issues
<b>Opening</b> session	With US windows OS and German ("," as a decimal point) numbering format, entering sessions in ScopeSuite will give error.         Image: Control of Cont
MGBASE-T1	<ul> <li>For 2.5G and 5G speed variants, the test case '149.5.2.2 Transmitter linearity (test mode 4)' has not been implemented. This is due to the standard and the official test methodology not being finalized and still worked on.</li> <li>For the test case '149.5.2.3.2 Transmit MDI deterministic jitter in master mode', it can yield negative jitter results. As above, standard and test methodology not finalized.</li> <li>For very long acquisitions it can happen that ScopeSuite is running out of memory. Please close other applications and restart ScopeSuite.</li> </ul>
HDMI 1.4	Voltage Off Tests fails with firmware 4.80.1

### 1.5 Version 4.80.1

Option/Topic	Functions
USB 3.2 Gen 1	Official SigTest version 3.2.11.4 (see installation instructions 3.2.2.1)
(5 GT/s)	(NOTE: SSC Profile Test will need higher version of SigTest)
	Device - Low Frequency Periodic Signaling Tx (TD.1.1)

- Device Short Channel Transmitted Eye (TD.1.3) •
- Device Long Channel Transmitted Eye (TD.1.3)
- Device SSC Profile (TD.1.6)
- Host Low Frequency Periodic Signaling Tx (TD.1.1) •
- Host Short Channel Transmitted Eye (TD.1.3) ٠
- Host Long Channel Transmitted Eye (TD.1.3) •
- Host SSC Profile (TD.1.6) •
- Hub Upstream Low Frequency Periodic Signaling Tx (TD.1.1) .
- Hub Upstream Short Channel Transmitted Eye (TD.1.3) •
- Hub Upstream Long Channel Transmitted Eye (TD.1.3) •
- Hub Upstream SSC Profile (TD.1.6)
- Hub Downstream Low Frequency Periodic Signaling Tx (TD.1.1)
- Hub Downstream Short Channel Transmitted Eye (TD.1.3)
- Hub Downstream Long Channel Transmitted Eye (TD.1.3)
- Hub Downstream SSC Profile (TD.1.6) •

	Official SigTest version 4.0.23.2 (see installation instructions 3.2.2.1)
	Device – Short Channel Transmitted Eye (TD.1.4)
	Device – Long Channel Transmitted Eye (TD.1.4)
	Device – SSC Profile (TD.1.7)
	Device – Transmit Equalization Test (TD.1.5)
	Host – Short Channel Transmitted Eye (TD.1.4)
	Host – Long Channel Transmitted Eye (TD.1.4)
	Host – SSC Profile (TD.1.7)
USB 3.2 Gen 2	Host – Transmit Equalization Test (TD.1.5)
(10 GT/s)	Hub – Upstream Short Channel Transmitted Eye (TD.1.4)
	Hub – Upstream Long Channel Transmitted Eye (TD.1.4)
	Hub – Upstream SSC Profile (TD.1.7)
	Hub – Upstream Transmit Equalization Test (TD.1.5)
	Hub – Downstream Short Channel Transmitted Eye (TD.1.4)
	Hub – Downstream Long Channel Transmitted Eye (TD.1.4)
	Hub – Downstream SSC Profile (TD.1.7)
	Hub – Downstream Transmit Equalization Test (TD.1.5)
	Official SigTest version 3.2.0 (pre-installed)

Add-In card - Signal Quality •

PCle 3.0

Add-In card - Tx Equalization System Board - Signal Quality

٠

- ٠ System Board - Tx Equalization •
- System Board Reference Clock ٠

10BASE-T1L	<ul> <li>146.5.4.1 Transmitter output voltage</li> <li>146.5.4.2 Transmitter output droop</li> <li>146.5.4.3 Transmitter timing jitter</li> <li>146.5.4.4 Transmitter power spectral density (PSD) and power level</li> <li>146.5.4.5 Transmit clock frequency</li> <li>146.8.3 MDI return loss</li> <li>146.8.4 MDI mode conversion loss</li> </ul>
1000BASE-T1	Test Head verification
DPHY	<ul> <li>1.2</li> <li>1.5.5 Initial HS Skew Calibration Burst T_SKEWCAL-SYNC and T_SKEWCAL</li> <li>1.5.6 Periodic HS Skew Calibration Burst T_SKEWCAL-SYNC and T_SKEWCAL</li> </ul>
DDR3/DDR3L/ LPDDR3, DDR4/LPDDR4	Support Expert Mode
LPDDR4X	<ul> <li>Clock Timing (13.3)</li> <li>Data Timing (4.24.1.2, 4.24.1.3)</li> <li>Strobe Timing (8.3.1, 4.24.1, 4.25.1)</li> <li>Command Timing (13.7)</li> <li>Address Timing (13.7)</li> <li>AC &amp; DC Input Levels for ADD and CMD (8.1)</li> <li>AC &amp; DC Input Levels for ADD and CMD (8.1)</li> <li>AC Input Levels for CK (8.3.3)</li> <li>AC Overshoot &amp; Undershoot for ADD and CMD and CTRL (8.3.4)</li> <li>AC Overshoot &amp; Undershoot for DQ,DQS and DM (8.3.6)</li> <li>Input Slew Rate for ADD and CMD (8.4.2)</li> <li>AC &amp; DC Output Levels for CK (8.3.2)</li> <li>Output Slew Rate for DQ (9.4)</li> <li>AC &amp; DC Input Levels for CK (8.3.2)</li> <li>Input Slew Rate for CK (8.4.1)</li> <li>Differential Cross Point Voltage for CK (8.5)</li> <li>AC Input Levels for DQS (8.7.2)</li> <li>AC Differential Cross Point Voltage for DQS (8.7.4)</li> <li>Input Slew Rate for DQS (8.7.5)</li> <li>Differential AC Output Levels for DQS (9.3)</li> <li>Differential Output Slew Rate for DQS (9.5)</li> </ul>
Automation K99	<ul> <li>Coverage of all 10BASE-T1L test cases</li> <li>Coverage of all DDR3, DDR3L, DDR4, LPDDR4, LPDDR4X</li> </ul>

Option/To	opic	Improve	ements
Common		•	RSScopesuite log file enhancement Add build number and build type for beta installer Communication protocol enhancement

Support High Definition as standard feature on new serial number scopes

10BASE-T1S	Removed common mode conversion loss test case and updated return loss limits
100BASE-T1	<ul><li>CommonModeEmission is issuing a warning above 70MHz</li><li>Improved reporting</li></ul>
1000BASE-T1	Changed filter for jitter test cases from 2 MHz to 5 MHz
100BASE-TX	AOI Template Test changed from mandatory to informative
DDR3/DDR3L/ LPDDR3, DDR4/LPDDR4	<ul><li>Error handling enhancement</li><li>Electrical test cases enhancement</li></ul>

#### **Tested Firmware**

•

Version	Functions
Firmware 4.80.1	This Scope Suite Version is tested against the RTX Firmware Version 4.80.1

#### **Known issues**

issue	Known Issues
PCle	In older Windows 10 versions, PCIe3 test cases may prompt crash message as SigTest exits.

## **2** Modifications to the documentation

The current documentation is up-to-date.

## **3** Software update

### 3.1 Update information

R&S ScopeSuite can be installed on Windows 7,8 and 10 systems.

You need a VISA installed. The system is tested against R&S VISA 5.8.5 and we recommend to use this or a higher version.


www.rohde-schwarz.com/rsvisa

### 3.2 Updating the firmware

#### 3.2.1 Uninstall old versions

It is recommended to remove older versions manually before starting installation:

1. Search for "Add or remove programs"



2. In Apps & features uninstall ScopeSuite

Setti	ngs				
ŵ	Home	Арр	os & features		
Fi	nd a setting $ ho$	Ļ.	Microsoft Corp.		9/3/2022
App	05	<b>?</b>	R&S Effective Rights (Shell Exter	nsion) (8196E39E-7	6/2/2020
	Apps & features	<b>?</b>	R&S Endpoint Management Ser	vice (RSEMS) (66C	6/2/2020
≣t	Default apps		R&S ScopeSuite		0.99 GB 8/30/2022
町	Offline maps		5.20.1.6038		
Ţ.	Apps for websites			Modify	Uninstall
<b>□</b> 1	Video playback	<b>?</b>	R&S Setup - Net (00000000-000	0-000-0000-000	6/2/2020
Ť	Startup		R&S Visa		37.4 MB 6/2/2020
		<b>?</b>	Remote Help Assistant (2B0D81,	A6-06F0-4DCB-B4	6/2/2020

#### 3.2.2 Install R&S ScopeSuite

You can install the R&S ScopeSuite on Windows 7,8,10 and 11.

When you install the R&S ScopeSuite on a R&S RTO/RTP please reboot the R&S RTO/RTP after the installation.

To install the R&S ScopeSuite:

1. Start the "RSScopeSuiteSetup.exe".

An Installation wizard opens:

R&S ScopeSuite Setup		<u>a 186</u> 8)		×
R&S Sco	peSuite			
Terms and Con Products	ditions for roya	alty-free	9	^
September 2021				~
	I agree to the lice	ense <mark>te</mark> rms and	l conditio	ns
		Install	Clo	se

2. Follow the instructions to complete the installation.

#### 3.2.2.1 SigTest Installation for USB 3.2

In order to perform the USB 3.2 tests, the SigTest versions 3.2.11.4 (Gen1) and 4.0.23.2 (Gen2) have to be installed from the Intel website:

https://www.intel.de/content/www/de/de/design/technology/high-speedio/tools.html?grouping=EMT\_Content%20Type&sort=title:asc

Follow the individual installation instructions.

#### 3.2.3 Log files

In case you encounter problems, it is helpful to supply us log files and send along a waveform from the scope when the problem occurred.

The log files can be found here:

<My Documents folder>\Rohde-Schwarz\RSScopeSuite\<VersionNumber>\Logs

#### 3.2.4 Error recovery

- Check the oscilloscope firmware version. Confirm that it is the same as the version stated in "Tested Firmware".
- Check for loose connections. Make sure the probe is connected to the test point firmly.
- Check if the DUT is in the correct test mode.
- If the problem persists, soft reboot the instrument.
   Select "Power" button (bottom right) followed by "Exit". Launch the application from the desktop ("RTx" for oscilloscope and "Vector Network Analyzer" for VNA).
- If the problem still persists, hard reboot the instrument by switching it off and on again.

## 4 Customer support

#### Technical support - where and when you need it

For quick, expert help with any Rohde & Schwarz product, contact our customer support center. A team of highly qualified engineers provides support and works with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz products.

#### **Contact information**

Contact our customer support center at www.rohde-schwarz.com/support or follow this QR code:



Figure 4-1: QR code to the Rohde & Schwarz support page