

Products: R&S<sup>®</sup>DVM50, R&S<sup>®</sup>DVM100, R&S<sup>®</sup>DVM120, R&S<sup>®</sup>DVM400

# DVB-H Measurements with the R&S®DVM Basics and Application

Additional chapter covering IEC 62002 (MBRAI)

## **Application Note**

The DVB-H standard is a specification for bringing television broadcast services to handheld receivers. In order to save battery power, data for a specific service is transmitted in short bursts. This type of transmission utilizes special techniques within the transport stream.

The R&S®DVM offers a wide range of functions to analyze the characteristics of the DVB-H transport stream. This document describes the characteristics of the DVB-H transport stream and shows how the R&S®DVM can be used for efficient analysis in research and development, production, and broadcasting.



1	Overview	3
2	Requirements	3
3	Introduction	
4	DVB-H (ETSI EN 302 304) – General Overview	
	RF characteristics (improved mobile reception)	
	Time slicing at the transport stream level (power save function)	4
5	The DVB-H Transport Stream (ETSI EN 301 192, ISO/IEC 13818-6)	6
	Multiprotocol encapsulation (MPE)	
	Multiprotocol encapsulation - forward error correction (MPE-FEC)	8
	MPE signaling	8
6	R&S®DVM Analysis of DVB-H Signaling	10
	Displaying DVB-H contents	10
	Interpretation of the PMT table	11
	Interpretation of the INT table	12
	Interpretation of the NIT table	13
7	Time-Slicing - R&S®DVM DVB-H Time Slice Analyzer	14
	Measurement parameters	
	Burst Timing	15
	MPE-FEC analysis	15
8	Multiprotocol Encapsulation (MPE) – R&S®DVM Data Broadcast Analysis	20
	Data broadcast analysis – GUI	20
	Protocol (0)	21
	Content (2)	21
	Content Details (8)	
	Data broadcast analysis features	21
	Overview	
	Interpreter	22
	Raw data	
9	Conformance Testing according to IEC 62002 (MBRAI) [6]	
	The DVB-H error criterion	24
10	Abbreviations	26
11	Bibliography	
12	Additional Information	27
13	Ordering Information	28

#### 1 Overview

The DVB-H standard is a specification for bringing television broadcast services to handheld receivers. In order to save battery power, data for a specific service is transmitted in short bursts. This type of transmission utilizes special techniques within the transport stream.

The R&S®DVM offers a wide range of functions to analyze the characteristics of the DVB-H transport stream. This document describes the characteristics of the DVB-H transport stream and shows how the R&S®DVM can be used for efficient analysis in research and development, production, and broadcasting.

## 2 Requirements

To access the DVB-H analysis functionality, your R&S®DVM device must have the data broadcast analysis functionality (R&S®DVM400: DVM-B1, R&S®DVM50/100/120: DVM-K11) installed.

#### 3 Introduction

For more than 100 years (since the advent of the automobile), the concept of "mobility" has been synonymous with individual independence.

The onset of the Internet era in the late 20th century and the global spread of the mobile telephone have also helped to shape expectations, which, for today's consumers, are reachability, information, and individuality – anywhere, anytime. In the early days, mobile phones were "only" expected to ensure that the user could always be reached by telephone, but expectations are now trending more and more toward multimedia content.

Over the course of the past decade, broadcasting responded to the demand for more information and entertainment by introducing digital standards which allow several broadcasts/services to be carried in one frequency channel. However, these technologies pertain primarily to an extension of conventional stationary reception. See [2] for more information.

DVB for mobile devices was hampered by a lack of absolutely essential power saving features, as well as by a lack of practicable implementations for mobile reception. To meet those challenges, the European Telecommunication Standardization Union developed the DVB-H standard (where H stands for handheld).

## 4 DVB-H (ETSI EN 302 304) – General Overview

As noted above, this application note will discuss baseband analysis. For the sake of completeness, this section will briefly touch upon the details of the standard's RF component. For further details and procedures for testing the RF component of DVB-H, see [1].

#### RF characteristics (improved mobile reception)

The speed of non-stationary terminals differs from null. This speed component results in the Doppler effect. The Doppler effect describes the fact that movement (of the transmitter or receiver) causes a frequency (f) to shift (?f), so that the resulting frequency on the other side (transmitter or receiver) is f + ?f.

In multicarrier modulations such as DVB-T (coded orthogonal frequency division multiplexing, or COFDM for short), where the standard calls for either 2048 (2k mode) or 8192 (8k mode) carriers, modes with a lower number of carriers are less affected by the Doppler effect because the subcarrier spacing is wider.

Reduced symbol length is a side effect in COFDM with a smaller number of carriers. The reduced symbol length results in a reduction of the guard interval which was introduced for multipath reception, and a higher transmitter density (see single frequency network [2]) is required. That, in turn, results in higher costs to the network operators. However, the 2k mode also allows application of better error protection measures (in-depth interleaving).

For DVB-H, the 4k mode was added to the 2k and 8k modes. The 4k mode is the middle ground between improved mobile reception properties, error protection (in-depth interleaving), and transmitter density.

# Time slicing at the transport stream level (power save function)

As noted above, receivers manufactured to conventional standards (DVB-T) require too much energy to be practical for battery-operated devices. So DVB-H introduced the time slicing approach in order to reduce the power consumption of mobile, handheld devices.

7BM59\_1E 4 Rohde & Schwarz




Fig. 1: Time slicing (schematic)

Time slicing is the transmission of data for a specific service in bursts rather than in a continuous stream (the TS is still continuous). Responding to signals in the transport stream, the receiver switches on only when a data burst is being transmitted. The receiver is then turned off during the OFF time. This results in a considerable reduction of the receiver's power requirements.

The R&S<sup>®</sup>DVM provides efficient and powerful analysis and monitoring functions which allow analysis of time slicing and of the transmitted data.

In order to illustrate the broad range of functions provided by the  $R\&S^{@}DVM,$  the following section will discuss the underlying details of DVB-H baseband.

# 5 The DVB-H Transport Stream (ETSI EN 301 192, ISO/IEC 13818-6)

This standard utilizes the Internet Protocol (IP) in order to flexibly accommodate DVB-H program contents in the different transport layers.

#### **Multiprotocol encapsulation (MPE)**

In DVB-H, multiprotocol encapsulation is used to carry IP packets over the MPEG-2 transport stream.




Fig. 2: Multiprotocol encapsulation (MPE) [1]

Multiprotocol encapsulation is a process in which data is integrated in data packets with different specifications so that it can be transported in different transport systems.

For DVB-H, MPE encapsulation is handled as follows:

- The data to be transmitted is bundled in user datagram protocol (UDP) packets (UDP packets only include the destination port in their header information since the protocol does not return an acknowledgment of receipt).
- The UDP packets are then packed in IP packets which do include the sender's and recipient's IP addresses in their header information.
- In the third and last step, the resulting IP packets are integrated in data storage media command and control (DSM-CC) sections (table id = 0x0E). These sections are defined in ISO/IEC 13818-6.

The header of a DSM-CC packet contains the following information:



Fig. 3: DSM-CC header [1]

The recipient MAC address can be used as a selection criterion for addressing a specific service. However, only the last two bytes (5, 6) are used for this. This type of signaling can be used if different programs are transmitted in packets with the same PID. Bytes 1 to 4 are used to signal time slicing (see the preceding section). In DVB-H, those DSM-CC sections are referred to as MPE sections.




Fig. 4: User data in the application data table (MPE sections) [4]

The application data table (MPE section) consists of 191 columns with a maximum of 1024 rows. The IP datagrams (also called IP packets) constitute the payload of the MPE sections. Starting with the first byte in the upper left-hand corner (first cell), the IP datagrams are inserted column by column. The bytes are strung together as shown in Fig. 4. After all available IP datagrams have been inserted in the MPE section, the remaining cells are filled with zero bytes (which are also called padding bytes).

# Multiprotocol encapsulation – forward error correction (MPE-FEC)

The DVB-H standard defines MPE-FEC sections (multiprotocol encapsulation – forward error correction) so that error-free IP datagrams for clean decoding can be achieved in spite of high packet losses which can occur, for instance, if the receiver moves at too high a speed.

MPE-FEC sections are normal MPE sections with Reed-Solomon encoding which then, by means of the resulting overhead (25% more), permits error correction on the decoder side.




Fig. 5: MPE-FEC frame [4]

After the above-mentioned 191 columns in the application table have been filled, a 64-byte checksum can be calculated for each of the rows and inserted, row by row, into the RS data table. The overhead resulting from the FEC encoding can be reduced by omitting the RS columns. This procedure is called puncturing.

One MPE-FEC frame is transmitted in each time slice burst. The use of MPE-FEC sections is optional for each of the DVB-H services.

#### **MPE** signaling

The following excerpt from the implementation guidelines [5] will show the steps involved in MPE signaling:

"All IP platforms supported on a particular transport stream are announced in NIT (or optionally in BAT, in which case NIT announces the BAT). To access an INT sub\_table on a particular transport stream, the below described procedure may be used:

- Search NIT for linkage\_descriptor with linkage\_type 0x0B.
  - If found, the descriptor announces the service\_id and platform\_id for each available INT sub\_table.
  - If not found, search for linkage\_descriptor with linkage\_type 0x0C.

- If found, the descriptor announces the BAT where linkage\_descriptor with linkage\_type 0x0B is available.
- If not found, INT is not available, and IP services (if any) on the actual DVB network cannot be accessed.
- Search PMT sub\_table using the service\_id from the step 1.
- The PMT announces the elementary stream carrying a particular INT sub table.

Note that selecting one of the INT sub\_tables effectively selects the associated IP platform.

INT announces access parameters for IP streams, and associates each IP stream with an IP datagram stream. The access parameters consist of parameters to identify the DVB network (network\_id), the transport stream (original\_network\_id and transport\_stream\_id), the DVB service (service\_id) and the component (component\_tag).

Selecting IP platform is typically done by the user. To receive an IP service, INT sub\_table of the IP platform supporting the service is checked, to get access parameters for each of the IP datagram streams carrying the elements of the service.

Using the access parameters, receiver searches for the PMT sub\_table (identified by the service\_id), which then announces the elementary stream (identified by the component\_tag) carrying the requested IP stream. On the elementary stream, the receiver typically would filter the IP stream based on IP address."

For a detailed description of the DVB-H transport stream, see [1].

# 6 R&S®DVM Analysis of DVB-H Signaling

The R&S<sup>®</sup>DVM family provides a broad range of functions for comprehensive monitoring and analysis of the above-referenced characteristics of the DVB-H transport stream.

### **Displaying DVB-H contents**




Fig. 6: DVB-H Signaling in the Transport Stream

As can be seen in the above screenshot, in the section marked in red, the contents of the transport stream are listed in a tree structure. In addition to the standard-specific tables (PSI/SI), all available programs are shown as folders.

The example above shows a program with additional data DVB-H content and standard encoded MPEG-2 audio and video.

In accordance with the standard, the IP/MAC notification table is interpreted as a service, which is why the INT is not listed under PSI/SI in the Service folder.

As noted in Section 4, the network information table (NIT), the IP MAC notification table (INT), and the program map table (PMT) have special significance for analyzing the signaling of the multiprotocol encapsulation (MPE) specified in the DVB-H standard.

The following steps will show how the R&S®DVM can be used to ensure correct signaling of the service.

The tables mentioned can be interpreted with the Interpreter application.



Fig. 7: Interpreter area

#### Interpretation of the PMT table

```
3rd Stream
                                                 8 bit 0x05 (5)
Stream type
                                                                       Private Sections
reserved
Elementary PID
                                                3 bit 0x7
13 bit 0x0120 (288)
reserved
ES info length
                                               4 bit 0xF
12 bit 10
Data Broadcast Id Descriptor
                                                 8 bit 0x66 (102)
 Descriptor tag
 Descriptor length
                                               8 bit 8
16 bit 0x000B (11) IP/MAC Notification Table
 Data broadcast id
                                               8 bit 5
24 bit 0x002C02 (11266)
 Platform ID data length
Platform id
                                                 8 bit 0x01 (1)
2 bit 0x3
 Action type
                                                                       location of IP/MAC streams in DVB netw
 reserved
 INT versioning flag
INT version
                                                 1 bit 0
                                                 5 bit 0
4th Stream
                                                 8 bit 0x90 (144) DVB-H MPE and MPE-FEC sections
Stream type
reserved
Elementary PID
                                               3 bit 0x7
13 bit 0x012F (303)
reserved
ES info length
                                               4 bit 0xF
12 bit 7
Data Broadcast Id Descriptor
 Descriptor tag
Descriptor length
                                                 8 bit 0x66 (102)
                                                16 bit 0x0005 (5) Multiprotocol Encapsulation
 Data broadcast id
Stream Identifier Descriptor
                                                 8 bit 0x52 (82)
8 bit 1
8 bit 0x26 (38)
 Descriptor tag
Descriptor length
```

Fig. 8: PMT table

The program map table (PMT) contains references to all elementary streams of the selected service. As shown above, video, audio, and data ES references are listed in the stream loops.

**Stream type**, an 8-bit indicator, signals the contents of the elementary stream. Some examples:

0x01: MPEG-1 video 0x02: MPEG-2 video 0x05: private sections

0x90: DVB-H MPE and MPE-FEC sections

The entries for **Elementary PID** refer to the packet identifiers (PID) of the transport stream packets associated with each of the elementary streams.

For data services, the elementary stream is referenced via **Data Broadcast ID**, for example:

0x005: Multiprotocol encapsulation

0x00B: INT table

#### Interpretation of the INT table




Fig. 9: IP/MAC notification (INT) table

As described under "Multiprotocol encapsulation (MPE)" (Section 4), the elementary streams in DVB-H are integrated into the DSM-CC section of the transport stream via IP packets.

The INT table takes on a kind of signaling function for the transmitted IP packets. Fig. 9 shows the specified destination IP address (1) for the IP contents which are transmitted via the selected service (2).

Network id, Transport stream id and Service ID form a unique triplet, which identifies a service consisting of one or more PIDs.

#### Interpretation of the NIT table

In general, the network information table describes all physical parameters of a DVB transmission channel.




Fig. 10: Network information table (NIT)

In our case, the NIT contains the time\_slice\_fec\_identifier descriptor (green). It provides basic non-dynamic information on, for example maximum burst duration, burst size and FEC in use.

# 7 Time-Slicing - R&S®DVM DVB-H Time Slice Analyzer

The DVB-H time slice analyzer (1) can be selected in the "Streaming" application of the R&S®DVM. When "Start" (2) is pressed, the R&S®DVM DVB-H time slice analyzer (3) opens in a separate window.




Fig. 11: Time slice analyzer

The window consists of two panes:

- Burst Timing measured values and diagrams pertaining to burst timing and data rates
- MPE FEC Analysis measured values such as power savings, burst timing and data rates (includes the values from the Burst Timing pane)

In the following sections, we will discuss the measured values that are displayed in the window panes.

#### **Measurement parameters**

Various DVB-H transmission parameters can be determined under ETSI EN 101 192; these parameters are displayed on the R&S<sup>®</sup>DVM. But the R&S<sup>®</sup>DVM also provides other functionalities.

#### **Burst Timing**




Fig. 12: Burst timing diagram

The above diagram shows the burst structure of the incoming transport stream. Labels for the measured values are shown in red.

The following sections of this document contain a detailed description of the measured burst timing and data rate values which are shown both in the diagram and in the list below. The measured values listed under "Burst Timing" can also be found as a subset under "MPE-FEC analysis."

#### **MPE-FEC** analysis

The parameters displayed are categorized under FEC, power save function, bandwidth, and transmission.

#### FEC:

FEC:	Used	
Number of Rows:	1024	
Number of Padding Columns:	28	
Number of Puncturing Bytes:	0	
Burst FEC Code Rate:	0.718	

FEC Indicates if forward error correction of the MPE

sections is being used.

Number of Rows  $(N_R)$ 

If FEC is activated, the number of rows of the MPE-

FEC frame is shown here.

Number of Padding Columns (N<sub>PC</sub>)

If FEC is activated, the number of padding columns


of the MPE-FEC frame is shown here.

#### Number of Puncturing Bytes (N<sub>PB</sub>)

If FEC is activated, the number of puncturing bytes of the MPE-FEC frame is shown here.

#### Burst FEC Code Rate (C<sub>R</sub>)

If FEC is activated, the burst FEC code rate is shown here.



#### **Power Save Function:**

 Burst Duration:
 642 ms

 Burst Cycle-Time:
 7523 ms

 Receiver On-Time:
 665 ms

 Receiver Off-Time:
 7047 ms

 Power Saving from Start:
 88 % (Synchronization Time = 250 ms)


 Maximum Signalled Delta\_T Margin:
 23.675 ms

 Minimum Signalled Delta\_T Margin:
 12.618 ms

#### **Burst Duration**


 $(T_B)$ 

#### Burst duration in ms



# Burst Cycle-Time (T<sub>CYC</sub>)


Burst cycle time in ms.



The burst cycle time  $(T_{\mbox{\scriptsize CYC}})$  indicates the time interval between the starting points of two bursts.

#### Receiver On-Time (T<sub>ON</sub>)


Receiver on-time in ms.



The receiver on-time  $(T_{ON})$  is derived from the burst duration  $(B_d)$  and the current maximum delta\_T\_margin.

#### Receiver Off-Time (T<sub>OFF</sub>)

Receiver off-time in ms.



The receiver off-time ( $T_{OFF}$ ) is derived from the burst cycle duration ( $T_{CYC}$ ) minus the receiver on-time ( $T_{ON}$ ).


 $T_{OFF} = T_{CYC} - T_{ON}$ 

# Power Saving from Start (Ps)

Power savings in % (synchronization time  $S_t$  = 250 ms), compared to a signal without time slicing.

#### Maximum Signalled Delta\_T Margin

Maximum delta\_T margin in ms.



Delta\_T Margin The delta\_T margin marks the space between the signaled delta\_T instant and the actual start of a burst.

#### Minimum Signalled Delta\_T Margin

Minimum delta\_T margin in ms.


See the above graph.

#### **Bandwidth:**

	Burst Bit Rate:	2995.431 kbit/s
ı	Burst Peak Bit Rate:	3158.400 kbit/s
ı	Constant Bit Rate:	248.686 kbit/s
ı	Burst Total Size:	240264 Bytes
ı	Burst IP Payload:	166408 Bytes
ı	DVB-H Encapsulation Overhead:	31 %


# Burst Bit Rate (B<sub>R</sub>)

Mean burst bit rate (B<sub>R</sub>) in kbit/s



# Burst Peak Bit Rate (P<sub>R</sub>)

Peak bit rate  $(\mathbf{P}_{R})$  in kbit/s. The time required to determine this value is 10 ms.



# Constant Bit Rate (C<sub>B</sub>)

Mean bit rate in kbit/s



The equivalent bit rate  $(C_B)$  for a continuous data stream.

Burst Total Size (B<sub>T</sub>)

Total burst size in bytes.

$$B_T = B_R \times T_B$$

Burst IP Payload (B<sub>IP</sub>)

Size of the burst's IP payload in bytes.


DVB-H Encapsulation Overhead (E<sub>OV</sub>) Overhead in % resulting from DVB-H encapsulation.

$$E_{OV} = \frac{B_T - B_{IP}}{B_T} \times 100\%$$

#### **Transmission:**

Erroneous Rows before FEC decoding:	0
Erroneous Rows after FEC decoding:	0
Frame Error Rate (FER):	0
MPE Frame Error Rate (MFER):	0
Correct IP Packets before FEC:	122
Erroneous IP Packets before FEC:	0
IP Packet error rate before FEC:	0
IP Packet error rate before FEC from start:	0
Correct IP Packets after FEC:	122
Erroneous IP Packets after FEC:	0
IP Packet error rate after FEC:	0
IP Packet error rate after FEC from start:	0

In order to determine the transmission path quality, the R&S<sup>®</sup>DVM provides a function to analyze various data structures for errors and to indicate whether or not an error correction function can remove the errors.



General definition of the error rate:  $e = \frac{IU_{\it erroneous}}{IU_{\it total}}$  ;

where IU = units of information

**Erroneous Rows** Number of erroneous MPE-FEC rows before FEC before FEC decoding decoding **Erroneous Rows** Number of erroneous MPE-FEC rows after FEC after FEC decoding decoding Frame Error Rate Frame error rate from the start of the measurement, from Start before FEC decoding MPE Frame Error Frame error rate from the start of the measurement, Rate from Start after FEC decoding **Correct IP** Number of error-free IP packets before FEC decod-Packets before ing **FEC Erroneous IP** Number of erroneous IP packets before FEC de-Packets before coding **FEC IP Packet Error** IP packet error rate before FEC decoding Rate before FEC **Correct IP** Number of error-free IP packets after FEC decoding Packets after **FEC Erroneous IP** Number of erroneous IP packets after FEC decod-Packets after ing **FEC IP Packet Error** IP packet error rate after FEC decoding Rate after FEC

## 8 Multiprotocol Encapsulation (MPE) – R&S®DVM Data Broadcast Analysis

The data broadcast analysis provides versatile features for the analysis of the data transmitted via MPE; the various steps of analysis correspond to the individual encapsulation steps.



Fig. 13: Data broadcast analysis

When the user clicks a data DVB-H service, various transmission parameters/data are displayed, depending on which area was selected for analysis.

#### Data broadcast analysis - GUI

The Protocol (**1**), Content (**2**), and Content Details (**1**) panes are displayed in all analysis areas, i.e. Overview, Interpreter, Raw Data, and Carousel Timing.




Fig. 14: Data broadcast analysis, GUI

8

#### Protocol (1)

The Protocol pane of the data broadcast analysis shows the data transmission protocol. For DVB-H analysis, a folder structure labeled "DVB-H MAC" is displayed. In the contents of the folder, the DSM-CC sections are grouped into "MPE Section" and "MPE FEC Section".

## Content (2)

The Content pane shows the content of the data transmitted via the DSM-CC sections. DVB-H data is transported via IP packets, and therefore specific packets are displayed here. IP packets are identified by originating and destination IP address (in accordance with Ipv6).

## Content Details (6)

The lower section of the screen shows further details with respect to the transported IP content and correlating, DVB-H-specific information.

The following sections will discuss in detail the various analysis features of the R&S®DVM, which are available in the Overview, Interpreter, and Raw Data views.

#### Data broadcast analysis features

The analysis window, shown in red in the picture on page 21, provides the user with various analysis functions for the DVB-H elementary stream.

#### **Overview**

```
escription from elementary stream loop of PMT
Stream Identifier Descriptor
                                               8 bit 0x52 (82)
 Descriptor tag
 Descriptor length
                                              8 bit 1
8 bit 0x26 (38)
Component tag

Data Broadcast Id Descriptor
                                               8 bit 0x66 (102)
 Descriptor tag
 Descriptor length
 Data broadcast id
                                              16 bit 0x0005 (5) Multiprotocol Encapsulation
escription from service (program) loop of SDT
Data Broadcast Descriptor
                                               8 bit 0x64 (100)
 Descriptor tag
 Descriptor length
Data broadcast id
                                              8 bit 15
16 bit 0x0005 (5) Multiprotocol Encapsulation
 Component tag
Selector length
                                               8 bit 0x26 (38)
8 bit 2
                                               3 bit 0x3 (3)
 MAC address range
MAC_IP mapping flag
                                                                    valid MAC address byte are bytes 6 to 4
                                                                    8 bits alignment
 Alignment indicator
                                               1 bit 0x0 (0)
                                               3 bit 0x7
8 bit 255
 Max sections per datagram
                                              3 char eng
8 bit 5
 ISO 639 language code
 Text length
                                              5 char DVB-H
 Text
```

Fig. 15: Data broadcast analysis, Overview view

The view shows the references within the transport stream which point to the active DVB-H elementary stream. That allows a quick overview of the signaling of the elementary stream.

#### Interpreter

```
Table: datagram_section (MPE) for DVB-H
 table_id
section_syntax_indicator
                                    8 bit 0x3E
                                                       DSM CC sections with private data
                                    1 bit 1
 private_indicator
                                    1 bit
 reserved
                                    2 bit 0x3
 section_length
                                   12 bit 1377
 Section (MPE) for DVB-H
  MAC_address_6
                                    8 bit 0x06
 {\tt MAC\_address\_5}
                                    8 hit 0x05
  reserved
                                    2 bit 0x3
  payload_scrambling_control
                                    2 bit 0
  address_scrambling_control
LLC_SNAP-flag
                                    2 bit 0
                                    1 bit 0
  current_next_indicator
                                    1 bit
  section_number
                                    8 bit 0
  last_section_number
                                    8 bit 0
                                   12 bit 769
                                                       in units of 10 ms
                                   1 bit 0
1 bit 0
  table_boundary
  frame_boundary
                                   18 bit 0x000000
  IP_datagram
                               1364 bytes shown in Raw Data
  CRC_32
                                   32 bit 0xED5601F5 CRC32 ok
```

Fig. 16: Data broadcast analysis, Interpreter view

When the corresponding section (MPE or MPE-FEC) is selected, the DSM-CC header for DVB-H can be displayed. The individual sections can be differentiated as follows:

MPE: table\_id = 0x3E (IP data)

MPE-FEC: table\_id = 0x78 (Reed-Solomon data)

As was described in Section 4, realtime parameters (green) are transmitted in the sections. They tell the receiver when it can go off-line:

- delta\_t: Time to start of next burst from 1<sup>st</sup> byte of this DSM-CC section
- table\_boundary: If FEC in use, this is set to 1 for the last section of MPE data; i.e. all further sections in this burst must be FEC data
- frame\_boundary: If FEC in use, then set to 1 for the last FEC section in this burst
- address: row.column address of the section data in the application data table

#### Raw data

```
0: 0xBC 0x97 0xE7 0x6A 0x26 0x1E 0xAE 0x3B 0x3B 0x06 ...j;.
 10: 0xAA 0x0E 0x4B 0x5F 0xF9 0x41 0x67 0x87 0x5A 0x14 ..K .Ag.Z.
 20: 0xB5 0xE3 0x67 0x0D 0xA3 0x9D 0xA1 0x33 0xED 0xE5 ..g....3..
 30: 0x47 0xCA 0xE0 0x7B 0x32 0xF3 0xB2 0x14 0x39 0x85 G..{2...9.
 40: 0xFF 0xF9 0x7B 0x6D 0xEE 0x41 0x6A 0xB8 0xC7 0x90 ... {m.Aj...
 50: 0x65 0x1E 0xCD 0x5F 0x14 0x13 0x42 0x68 0x71 0xF9 e.._..Bhq.
 60: 0x4F 0x51 0x0B 0xDC 0x1E 0x6F 0xA7 0x4D 0x9D 0xD8 0Q...o.M..
 70: 0x0A 0xB0 0x5E 0xCA 0x0F 0xED 0xA4 0x8C 0xD1 0x59 ..^....Y
 80: 0x26 0x9C 0x6B 0x15 0x19 0xD4 0xFC 0xF1 0x75 0x3B
 90: 0x25 0xEC 0xFl 0x05 0x74 0x54 0x10 0x4A 0xD3 0x63 %...tT.J.c
100: 0x2F 0x0E 0xC6 0x1F 0xE8 0x0E 0xDB 0xDl 0x0B 0x69 /.....i
110: 0xFF 0x01 0xF4 0x97 0x3D 0x85 0xD4 0xC1 0x45 0x10 ....=...E.
120: 0x77 0xCC 0x23 0xE4 0x98 0x25 0x11 0x03 0x3F 0x83 w.#..%...?.
130: 0xD3 0xD0 0xE3 0x28 0xEB 0x16 0x91 0x39 0xD8 0x81 ...(...9..
140: 0xEF 0x40 0xC7 0xCl 0x8A 0x80 0xD5 0xFE 0x83 0x92 .@......
150: 0x66 0xB8 0x46 0x8B 0x72 0x7E 0xAC 0xF8 0x91 0x3F f.F.r~...?
160: 0x17 0x6D 0x41 0x3B 0x57 0x9E 0x4D 0x26 0x3E 0xE7 .mA;W.Ma>.
170: 0xFA 0x12 0x2B 0x7E 0x79 0x53 0xC7 0x2F 0xE1 0x56 ..+~yS./.V
180: 0xE2 0xDF 0x46 0x91 0x46 0xCA 0xF7 0x43 0x49 0x5A ..F.F..CIZ
190: 0x0E 0x59 0x67 0x04 0x28 0x41 0xF6 0x10 0x06 0x74 .Yg.(A...t
200: 0x45 0xE5 0x9B 0xF5 0xC4 0xA6 0x4A 0x8D 0x09 0x5D E....J..]
210: 0xF1 0xF5 0xC3 0xBA 0x6D 0x8C 0x54 0xA9 0xA5 0xD9 ....m.T...
220: 0x74 0xA2 0x57 0x0A 0xA0 0x97 0xAB 0x7C 0xD9 0xDF t.W....|..
230: 0x31 0x89 0xAB 0x2B 0x89 0xAC 0x6A 0x69 0x09 0xBF 1..+..ji..
948. 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 -W
```

Fig. 17: Raw Data view

The Raw Data view shows the payload of the DSM-CC sections in ASCII format.

## 9 Conformance Testing according to IEC 62002 (MBRAI) [6]

The International Electrotechnical Commission (IEC) created the MBRAI specifications, which call for strict conformance tests that ensure the proper functionality of mobile receiver terminals for DVB-T/H transmissions. MBRAI is a common abbreviation of the IEC 62002 standard and stands for "mobile and portable DVB-T/H radio access interface".




Fig. 18: Test setup for conformance tests in accordance with IEC 62002

As shown in the above schematic, a DVB-T/H signal source is affected by various interferences.

The test cases of the MBRAI standard can be divided into seven parts: C/N performance, input signal levels, immunity to analog and/or digital signals in other channels, immunity to co-channel interference, multipath reception within the guard interval, multipath reception outside the guard interval and impulsive noise. For details about the creation of test scenarios according to MBRAI please see [7].

The influence of the interferences on the receiver terminal is determined by means of various degradation criteria.

Depending on the terminal category, one or more of the following criteria are used as reference values: bit error rate (BER), picture failure point (PFP), subjective failure point and the DVB-H error criterion.

#### The DVB-H error criterion

The degradation criterion in case of DVB-H is the MPE-FEC frame error rate (MFER). As shown before, an MPE-FEC frame consists of MPE (IP payload data) and MPE-FEC sections (Reed Solomon data). Due to the Reed Solomon data, a fix of a certain number of errors in the MPE section can be applied.

The MFER is the percentage of erroneous frames after error correction:

$$MFER = \frac{Number\_of\_erroneous\_frames}{Total\_number\_of\_frames} x100 \%$$

The degradation criterion is a 5 % MFER value.

In order to determine the degradation criterion, Rohde & Schwarz offers the R&S®DVM family for in-depth DVB-H analysis on the transport stream layer. See chapter 7 for details.




Fig. 19: Test setup for MBRAI-compliance tests

## 10 Abbreviations

ASCII American Standard Code for Information Interchange

BAT Bouquet Association Table

COFDM Coded Orthogonal Frequency Division Multiplexing

DSM-CC Data Storage Media Command and Control
DVB-H Digital Video Broadcasting for Handhelds

DVB-T Digital Video Broadcasting for Terrestrial Applications

EN European Norm
ES Elementary Stream

ETSI European Telecommunications Standards Institute

FEC Forward Error Correction
GUI Graphical User Interface

IEC International Electrotechnical Commission

INT IP/MAC Notification Table

IP Internet Protocol

ISO International Organization for Standardization

MAC Media Access Control
MPE Multi Protocol Encapsulation
MPEG Moving Pictures Experts Group
NIT Network Information Table

PID Packet Identifier
PMT Program Map Table

PSI Program Specific Information

RF Radio Frequency
RS Reed-Solomon

SFN Single Frequency Network

SI System Information
TS Transport Stream
UDP User Datagram Protocol

## 11 Bibliography

- [1] Fischer, Walter; Dürport, Werner; Kirchhoff, Ralph; Tobergte, Thomas (2005). Application Note 1MA91\_0E. Test of DVB-H-Capable Mobile Phones in Development and Production. Munich: Rohde & Schwarz GmbH & Co. KG website: http://www.rohdeschwarz.com.
- [2] Fischer, Walter (2005). Digital Television. A Practical Guide for Engineers. Berlin: Springer.
- [3] International Organization for Standardization (Ed.) (2005). International Standard ISO/IEC 13181-6: Information technology - Generic coding of moving pictures and associated audio information - Part 6: Extensions for DSM-CC. International Organization for Standardization.
- [4] European Telecommunications Standards Institute (Ed.) (2001). ETSI EN 301 192 Digital Video Broadcasting (DVB); DVB specification for data broadcasting Sophia Antipolis Cedex, France: European Telecommunications Standards Institute.
- [5] European Telecommunications Standards Institute (Ed.) (2005). ETSI TR 102 377. Digital Video Broadcasting (DVB); DVB-H Implementation Guidelines. Sophia Antipolis Cedex, France: European Telecommunications Standards Institute.
- [6] International Electrotechnical Commission (Ed.) (2005). International Standard IEC 62002-1. Mobile and portable DVB-T/H radio access Part 1: Interface specification. International Electrotechnical Commission.
- [7] Gsoedl, Harald (2006). Application Note 7BM61\_0E. Creating Test Scenarios in Accordance with IEC 62002 (MBRAI) Using the R&S®SFU. Munich: Rohde & Schwarz GmbH & Co. KG website: http://www.rohde-schwarz.com

#### **12 Additional Information**

Our application notes are revised and updated from time to time. To check if a new version is available, please visit <a href="http://www.rohde-schwarz.com">http://www.rohde-schwarz.com</a>.

Please direct any comments or suggestions concerning these application notes to  $\underline{\mathsf{Broadcasting}\text{-}\mathsf{TM}\text{-}\mathsf{Applications}}\underline{\mathsf{Qrohde}\text{-}\mathsf{schwarz}.\mathsf{com}}.$ 

© European Telecommunications Standards Institute 2005. © European Broadcasting Union 2005. Further use, modification, redistribution is strictly prohibited. ETSI standards are available from <a href="http://pda.etsi.org/pda/">http://pda.etsi.org/pda/</a> and <a href="http://etsi.org/services-products/freestandard/home.htm">http://etsi.org/services-products/freestandard/home.htm</a>

# **13 Ordering Information**

<b>R&amp;S® DVM50</b> R&S® DVM-K1 R&S® DVM50-K10 R&S® DVM-K11	MPEG-2 Monitoring System Additional TS Input In-Depth Analysis Data Broadcast Analysis	<b>2085.1900.02</b> 2085.5211.02 2085.5434.02 2085.5311.02
<b>R&amp;S® DVM100 R&amp;S® DVM120</b> R&S® DVM-B1 R&S® DVM-K1 R&S® DVM-K10	MPEG-2 Monitoring System MPEG-2 Monitoring System Analyzer Board Additional TS Input In-Depth Analysis	2085.1600.02 2085.1700.02 2085.3283.02 2085.5211.02 2085.5228.02
R&S® DVM400 R&S® DVM400-B1 R&S® DVM-K1 R&S® DVM-K2 R&S® DVM-K11 R&S® DVM400-B2 R&S® DVM400-B3  R&S® DVM400-B4  R&S® DV-ASC R&S® DV-DVBH R&S® DV-HDTV R&S® DV-TCM R&S® DV-TCM	Base Unit Analyzer Additional TS Input TS Capture Data Broadcast Analysis TS Generator Upgrade TS Recorder up to 90 Mbit/s Upgrade TS Recorder up to 214 Mbit/s Advanced Stream Combiner DVB-H Stream Library HDTV Sequences Test Card M Streams Documentation of Calibration Values	2085.1800.02 2085.5505.02 2085.5211.02 2085.5234.02 2085.5311.02 2085.5511.02 2085.5528.02 2085.5534.02 2085.8804.02 2085.8704.01 2085.7650.02 2085.7708.02 2082.0490.29
	Service Manual	2085.1839.02



 $ROHDE \& SCHWARZ GmbH \& Co. KG \cdot M\"uhldorfstraße 15 \cdot D-81671 \, M\"unchen \cdot Postfach 80 \, 14 \, 69 \cdot D-81614 \, M\"unchen \cdot Tel. (+4989) \, 4129 - 0 \cdot Fax \, (+4989) \, 4129 - 13777 \cdot Internet: \\ \frac{http://www.rohde-schwarz.com}{http://www.rohde-schwarz.com}$ 

This application note and the supplied programs may only be used subject to the conditions of use set forth in the download area of the Rohde & Schwarz website.