

R&S®FS-K96/-K96PC/-K196 OFDM Vector Signal Analysis Software Release Notes Software Version 3.6

These Release Notes describe the following options of the R&S®OFDM Vector Signal Analysis Software:

- R&S®OFDM Vector Signal Analysis Software FS-K96, order no. 1310.0202.06
- R&S®OFDM Vector Signal Analysis Software FS-K96PC, order no. 1310.0219.06
- R&S®OFDM Vector Signal Analysis Software FS-K96U, order no. 1310.0225.06
- R&S®5G Air Interface Candidates FS-K196, order no. 1309.9200.06

New Features in V3.6:

- Support of UFMC and GFDM demodulation

© 2015 Rohde & Schwarz GmbH & Co. KG
Muehldorfstr. 15, 81671 Munich, Germany
Phone: +49 89 41 29 - 0
Fax: +49 89 41 29 12 - 164
E-mail: <mailto:info@rohde-schwarz.com>
Internet: <http://www.rohde-schwarz.com>

Subject to change – Data without tolerance limits is not binding.
R&S® is a registered trademark of Rohde & Schwarz GmbH & Co.
KG.
Trade names are trademarks of the owners.

The following abbreviations are used throughout this document:
R&S®FS-K96/-K96PC/-K196 is abbreviated as R&S FS-K96/-
K96PC/-K196.

Contents

1	Installation	3
1.1	Version Minimum System Requirements.....	3
1.2	Software Installation.....	3
1.2.1	Preparing the PC.....	4
1.2.2	Installing the R&S FS-K96/-K196 Software.....	6
1.2.3	Checking for Successful Installation.....	7
1.2.4	Uninstalling the R&S FS-K96/-K196 Software.....	9
1.3	Using the Smartcard Reader.....	10
2	New Functions	11
2.1	Support of UFMC and GFDM demodulation.....	11
2.2	Lists of New Functions.....	11
2.2.1	Current Release V3.6.....	11
2.2.2	Earlier Releases V3.0 to V3.5.....	12
3	Modified Functions	13
4	Improvements	14
5	Modifications to the Documentation	14
6	Customer Support	15

1 Installation

1.1 Version Minimum System Requirements

The following minimum system configuration is recommended for the use of the R&S FS-K96/R&S FS-K96PC/R&S FS-K196 Software:

- Operating System: Microsoft Windows 7
- Free Hard Disk Space: 1 GB
- Free RAM: ≥ 1 GB
- Graphics Resolution: \geq XGA (800x600 pixel)
- USB: one free USB port to connect the smartcard reader (if no PC-built-in smartcard reader is used)
- Measuring instrument connection:
 - Hardware: IEC/IEEE bus or LAN connection
 - Software: VISA driver, National Instruments VISA version ≥ 4.2


1.2 Software Installation

For successful installation of the R&S FS-K96/-K196 Software you need to

1. prepare your PC
2. install the R&S FS-K96/-K196 Software

In order to complete both steps, execute the `AutoStart.exe` file in the main directory of the installation CD. In the case that you have download the installation package from the Rohde&Schwarz homepage, please unzip the directory and go to the main directory.


The following screen will appear and the browser will guide you through the installation process.



1.2.1 Preparing the PC

The R&S FS-K96/-K196 Software needs some additional software components to run properly. All necessary components are delivered with the software itself. You can install them from the CD-ROM (or your downloaded install directory) prior to installing the R&S FS-K96/-K196 Software.

They are located in the category “Installation” and then “Required Components”



Prepare the PC as follows (a detailed explanation follows after the list):

3. Check if Microsoft .NET Framework 2.0 is installed on your computer by clicking on the link “Check for .NET installed”. Start the installation if it is not already installed.
4. Install all required components using the R&S Framework Installer.
5. Install VISA for remote operation of the used instruments.

Installing Microsoft .NET Framework Version 2.0

You need to install Microsoft .NET Framework 2.0 or a later version in order to use the R&S FS-K96/-K196 Software. Therefore, you need to check whether the .NET Framework is already installed.

6. Click on "Check for .NET Installed.exe".
7. A message box tells you, if the .NET Framework is installed or not.
8. If the .NET Framework is not installed on your PC, click on the link to the installer.

Install the required components

A number of software components are required to use the R&S FS-K96/-K196 Software. It is recommended to use the R&S Framework Installer available on the CD-ROM to install all required components.

9. Start the R&S Framework Installer by clicking on the link.

The screenshot shows the 'Required Components' page of the R&S FS-K96/-K196 OFDM Vector Signal Analysis Software. The page lists the following components and their installation instructions:

- Installing Microsoft .NET Framework Version 2.0**
 - Start [Check for .NET Installed \(exe\)](#).
 - A message box tells you if the .NET Framework is installed or not.
 - If .NET is not installed, start the [.NET Framework Installer \(exe\)](#) and follow the instructions.
- Installing required components:**
 - Start the installation of all required components by using the [R&S Framework Installer \(exe\)](#).
 - A dialog box lists all required components. Check the "Installation State" of the components you want to install.
 - If the component is "Ready to install", it can be installed by just selecting the component with the checkbox in the first column and clicking "Install selected components" afterwards.
 - If the component is "Ready to download", the Framework Installer cannot find the installation file on a local hard drive. You need to download the component and install it manually.
 - Install the missing components with the "Install selected components" button.

10. The installer opens the following dialog box:

The screenshot shows the 'Rohde & Schwarz OFDM Vector Signal Analysis Software Framework Installer, Version 2.0' dialog box. It contains a table with the following data:

Install?	Component	Required Version	Installation State	Installation Source Path	Download Path	Detailed Information
<input checked="" type="checkbox"/>	Microsoft Visual C++ Runtime Library	2005 SP1 ATL Security Update x86	Ready to install	C:\Documents a...	http://www.rohde-s...	...
<input checked="" type="checkbox"/>	MATLAB Component Runtime	2009b (Version 7.9, Runtime V7.11)	Ready to install	C:\Documents a...	http://www.rohde-s...	...
<input type="checkbox"/>	MATLAB .NET Interfacing	2009b (Version 7.9, Runtime V7.11)	Installed by FS-K96 installer		Installed by FS-K96 i...	...
<input checked="" type="checkbox"/>	Intel IPP Library	4.1	Ready to install	C:\Documents a...	http://www.rohde-s...	...
<input type="checkbox"/>	VISA	... (ANY)	Not installed		Not available for do...	Click here to get mor...
<input type="checkbox"/>	Port Mapper (for Remote Control)	2.8	Ready to install	C:\Documents a...	http://www.rohde-s...	...

Summary Status: Some mandatory components are not installed and their installation sources are missing. Check the manual on how to obtain these sources.

Buttons: Install selected components, Refresh, Exit

**Mandatory Components**

- Microsoft Visual C++ Runtime Library
- MATLAB Component Runtime
- MATLAB .NET Interfacing
- Intel IPP Library
- VISA

Optional Components

- Port Mapper
(necessary for remote control of the R&S FS-K96/-K196 Software)

11. The mandatory components need to be installed in order to operate the software. Check the "Installation State" of the components you want to install.
 - a) If the component is "Ready to install", it can be installed by just selecting the component with the checkbox in the first column and clicking "Install selected components" afterwards.
 - b) If the component is "Ready to download", the R&S Framework Installer cannot find the installation file on a local hard drive. You need to download the component and install it manually. Afterwards, you can use the R&S Framework Installer to check, whether the installation has been successful.
 - c) If you do not have the VISA component already installed on your PC, it is recommended to install the component from the additional CD that is supplied together with the R&S FS-K96/-K196 Software package.
12. Start the installation by pressing the "Install selected components" button. All selected components will be installed.

Note that the Matlab .NET Interfacing is installed with the Matlab Component Runtime. There is no separate installation routine for it.



You can also install all components manually. All files necessary are on the CD-ROM in the corresponding directories in the `\install\Framework` folder.

Install VISA

It is necessary to install VISA (Virtual Instrument Software Architecture) to access instruments connected to the PC via IEEE or LAN bus.

Please use the National Instruments VISA:

- The National Instrument VISA driver CD is supplied together with the R&S FSPC Software package. You can also visit <http://www.ni.com/visa> to get the latest version for your operating system.

1.2.2 Installing the R&S FS-K96/-K196 Software

After installing all required components, you can install the R&S FS-K96/-K196 Software.

You can start the installer either by using your browser to navigate there or directly from the CD (`\install\OFDM Vector Signal Analysis Software.exe`).



ROHDE & SCHWARZ

Software and User Documentation

R&S FS-K96/-K196 OFDM Vector Signal Analysis Software

Safety Instructions Installation Documentation Contact

Required Components
Installing R&S FS-K96/-K196
Release Notes

Installing R&S FS-K96/-K196 OFDM Vector Signal Analysis Software

After having installed all required components, you can **install the R&S FS-K96/-K196 (File)**.

The installer will do the following:


- Install the R&S FS-K96/-K196 Software including an uninstall tool
- Create a Windows Start Menu entry (Programs → R&S OFDM Vector Analysis Software)
- Create a shortcut on the desktop (optional)

Start the software via the start menu entry or the shortcut on the desktop.

1.2.3 Checking for Successful Installation

After a successful installation, please start the R&S FS-K96/-K196 Software. Run the following sequence in order to check the functionality:

- ▶ If you do not have the license smartcard (cf. [Using the Smartcard Reader](#)) at hand, click “Demo Mode” in the dialog that prompts you to insert your smartcard.
- ▶ The R&S FS-K96/-K196 Software opens. Click on the hardkey <DEMODO SETTINGS> on the right hand side and select the file `WimaxOfdm_DL_G1_16_16QAM.mat` as Configuration File. You can find this file in your install directory in the folder `\CONFIGURATIONS`.



Rohde & Schwarz FS-K96

Demodulation Settings

Signal Description Demodulation Control

System Configuration

Manual Configuration Generate Configuration File **2**

Configuration File

OFDM Symbol Characteristics

FFT Length

Cyclic Prefix Length

Preamble Symbol Characteristics

Block Length

Frame Offset

Frame Characteristics

Frame Length

Please select configuration file

Suchen in: CONFIGURATIONS

DVBT_Mode2k_Ng1_32_QPSK.mat

WimaxOfdm_DL_G1_16_16QAM.mat

WlanA_64QAM.mat

WLANac_20MHz_LongCP.xml

WLANac_40MHz_LongCP.xml

WLANac_40MHz_ShortCP.xml

WLANac_80MHz_LongCP.xml

WLANac_80MHz_ShortCP.xml

WLANac_160MHz_LongCP.xml

WLANac_160MHz_ShortCP.xml

WlanN_64QAM.mat

Dateiname: WimaxOfdm_DL_G1_16_16QAM.mat **3**

Dateityp: Configuration File (*.mat;*.xml)

Öffnen Abbrechen

GENERAL SETTINGS MAIN

DEMODO SETTINGS SETUP

DISPLAY FILE

GRAPH LIST DISP

POWER MKR

EVM OPEN IN SEPARATE WINDOW

CHANNEL


CORSTELL HELP

MISC / STATISTIC


CAPTURE DSP

EXIT FS-K96 RUN SGL RUN CONT REFRESH SCREEN A PRESET

- ▶ Press the hotkey <RUN SGL> and select the file WimaxOfdm_DL_G1_16_16QAM.iq.tar. You can find this file in your install directory in the folder \SIGNALS.



- ▶ You should get a valid measurement as shown in the following screenshot.



1.2.4 Uninstalling the R&S FS-K96/-K196 Software

The OFDM Vector Signal Analysis Software can be uninstalled using the Uninstall tool in "%Program folder%\Rohde-Schwarz\OFDM Vector Signal Analysis Software\Uninstall" or via "Add or Remove Software" in the Windows Control Panel.

The framework components have to be uninstalled manually via "Add or Remove Software" in the Windows Control Panel.



Before uninstalling the components, ensure that no other software uses one of the components.

The following programs have been installed:

- Intel Integrated Performance Primitives RTI4.1 for Windows on Intel Pentium processors
- Matlab Component Runtime 7.11
- Rohde & Schwarz OFDM Vector Analysis Software (FS-K96/-K196)
- Microsoft .NET Framework 2.0 (see following note)
- Microsoft Visual C++ 2005 Redistributable (see following note)
- Rohde & Schwarz Portmap 2.8.3 (optional)



It is not recommended to uninstall the two Microsoft components:

- Microsoft .NET Framework 2.0
- Microsoft Visual C++ 2005 Redistributable
- They are most probably also used by other software components on your PC.

1.3 Using the Smartcard Reader

To enable the FS-K96/-K196 Software via smartcard (dongle), you have to load the FS-K96PC or FS-K96 and optionally FS-K196 license on an existing smartcard or order a new smartcard (FSPC license dongle PC software).

You can use the smartcard together with the USB smartcard reader (for SIM format) supplied with the software or insert the smartcard (full format) in a reader already connected to your PC or built in your PC. Instructions on how to insert the card into the reader is also supplied together with the CD package.

Note that support for problems with the smartcard licensing can only be guaranteed, if the supplied USB smartcard reader (for SIM format) is used.

1. With the delivery of the R&S FSPC you got a smartcard and a USB smartcard reader.



2. Remove the smartcard.



3. Insert the smartcard into the USB smartcard reader.
With the USB smartcard reader such that the LED or "OMNIKEY" label is facing upward, insert the smartcard with the chip facing downward and the angled corner facing away from the USB smartcard reader.



4. After pushing the smartcard completely inside the USB smartcard reader, you can use it together with the software.



You may have problems locking your PC while the card is inserted, as Windows will try to get log-in information from the card immediate after you lock your PC. You can overcome this problem by editing one registry entry. Either execute the registry file `DisableCAD.reg` in the same folder the USB Smartcard reader installation files are located. Or manually change the entry:

- ▶ Open the Windows Start Menu and select the "Run" item.
- ▶ Enter "regedit" in the dialog to open the system registry.
- ▶ Navigate to `HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\Windows\CurrentVersion\policies\system`.
- ▶ Set the value of `DisableCAD` to 0.

Note that security policies may prevent you from editing the value. Contact your IT administration if you have problems with editing the value or installing the drivers.

2 New Functions

This section lists the new functions that were introduced in version 3.6 and the previous versions.

2.1 Support of UFMC and GFDM demodulation

With the new R&S®FS-K196 option, Universal Filtered Multi-Carrier (UFMC) and Generalized Frequency Division Multiplexing (GFDM) can be analyzed.

2.2 Lists of New Functions

2.2.1 Current Release V3.6

Version	Function
V3.6	Support of UFMC and GFDM demodulation

2.2.2 Earlier Releases V3.0 to V3.5

Version	Function
V3.5	Support of the I/Q bandwidth extension FSV-B160
V3.5	Support of the I/Q bandwidth extension FSW-B320
V3.5	Support of digital and analog baseband inputs for the R&S FSW Signal and Spectrum Analyzer
V3.5	Support of the new input parameter "cyclic delay diversity"
V3.5	Speed improvement for automatic synchronization in the R&S FS-K96 Configuration File Wizard
V3.4	Support of the R&S®RTO Oscilloscope
V3.4	Import and export of I/Q data using the iq-tar file format
V3.4	Additional normalization modes for EVM calculation
V3.4	External trigger port selection for the R&S®FSW signal analyzer
V3.3	160 MHz signal bandwidth using the R&S FSW-B160 bandwidth extension
V3.3	Selectable normalization and frame averaging modes for EVM calculation
V3.3	Full demodulation and reference data readout by remote control
V3.3	Marker on peak and minimum traces available
V3.2	Support for the R&S®FSW Signal Analyzer
V3.2	Support for signals with two different cyclic prefix lengths
V3.2	Support for WLAN 802.11ac signals
V3.2	Tutorial videos
V3.2	Generation of example I/Q signals with the FS-K96 Configuration File Wizard
V3.2	New remote control commands
V3.2	Drag & Drop functionality for I/Q data files, configurations files and setting files
V3.1	R&S FS-K96 Configuration File Wizard
V3.1	Demonstration mode that operates without a license
V3.1	Support for the R&S FSVR Real-Time Spectrum Analyzer
V3.1	Support for Windows 7 32-bit and 64-bit
V3.0	Software is licensed with a smartcard / dongle.
V3.0	Support for FSQ, FSG, FSUP, FSV (please refer to the manual for details on the minimum firmware requirement)

Version	Function
V3.0	Matlab Kernel is upgraded to Matlab 2009b.
V3.0	Support for Windows 7 32-bit
V3.0	Possibility to evaluate more than two measurements simultaneously ("OPEN IN SEPARATE WINDOWS" hardkey)
V3.0	Coupled markers for Screen A and Screen B
V3.0	Read-in of an encrypted *.wv file (compatible to R&S WinIQSIM)
V3.0	New measurement results: <ul style="list-style-type: none"> • Allocation Matrix of the configuration file (for debugging). • EVM vs. Symbol for one specific carrier • Power vs. Symbol for one specific carrier • EVM vs. Carrier for one specific symbol • Power vs. Carrier for one specific symbol

3 Modified Functions

The following table lists the modified functions and indicates the version in which the modification was carried out:

Version	Function
V3.5	The default file input format is now the iq-tar file format (instead of the iqw file format).
V3.3	The Save Demod Data key now stores both the received data and the reference data within one MAT-file.
V3.3	The power spectrum result is always available if a valid capture buffer exists, regardless of the demodulation state.
V3.3	The remote control readout of the impulse response trace distinguishes between linear and logarithmic unit, which can be selected in the measurement settings.

4 Improvements

The following table lists the improvements and indicates the version in which the issue was observed for the first time:

Version	Function
V3.5	RTO baseband mode fixed.

Improvements from previous versions:

Version	Function
V3.4	The autoleveling has been improved for wide band signals.
V3.3	The R&S FS-K96 did not accept the R&S FSVR as capture source. This issue is solved. The R&S FS-K96PC was not affected.
V3.2	TRACe[:DATA]? remote control output for EVM vs Carrier and EVM vs Symbol traces were scaled different from the displayed traces. This issue is solved.
V3.2	Auto levelling for wide bandwidth signals with high power on the R&S FSW Signal Analyzer has been improved.
V3.1	Optimization for OFDM signals with high spectral efficiency (few guard carriers) – relevant mainly for FSQs with the B72 option
V1.0	Increased accuracy of the channel estimation. In rare conditions, not all pilot cells were considered for channel estimation.
V1.0	Constellation diagram “pumping” during continuous measurement
V1.0	Out of memory for large constellations (>256 QAM)
V1.0	No frequency error calculation for special configurations
V1.0	EVM vs. Symbol mean trace missing for symbols with Don't Care Cells
V1.0	IF filter bandwidth setting too high if adjustable channel filter is used

5 Modifications to the Documentation

The new and modified functions mentioned in these release notes are already documented. The manual can be downloaded from the internet under:

<http://www.rohde-schwarz.com/product/FSK96.html>.

6 Customer Support

Technical support – where and when you need it

For quick, expert help with any Rohde & Schwarz equipment, contact one of our Customer Support Centers. A team of highly qualified engineers provides telephone support and will work with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz equipment.

Up-to-date information and upgrades

To keep your instrument up-to-date and to be informed about new application notes related to your instrument, please send an e-mail to the Customer Support Center stating your instrument and your wish. We will take care that you will get the right information.

Europe, Africa, Middle East

Phone +49 89 4129 12345

customersupport@rohde-schwarz.com

North America

Phone 1-888-TEST-RSA (1-888-837-8772)

customer.support@rsa.rohde-schwarz.com

Latin America

Phone +1-410-910-7988

customersupport.la@rohde-schwarz.com

Asia/Pacific

Phone +65 65 13 04 88

customersupport.asia@rohde-schwarz.com

China

Phone +86-800-810-8828 / +86-400-650-5896

customersupport.china@rohde-schwarz.com