

History and release notes for the Rohde&Schwarz FSE spectrum analyzers FSEA, FSEB, FSEK, FSEM, FSIQ and for EMI Test Receiver ESIB

Contents

Contents.....	1
History for FSE spectrum analyzers FSEA, FSEB, FSEK, FSEM, FSIQ and for EMI Test Receiver ESIB.....	1
Remote control via LAN.....	3

History for FSE spectrum analyzers FSEA, FSEB, FSEK, FSEM, FSIQ and for EMI Test Receiver ESIB		
Revision	Date	Note
3.8.0	02/2018	- RSFSEx Memory Operations.vi - added Instr File To PC choice - Added example rsfsex_Hardcopy_Example.vi - Added *OPC? query to the RSFSEx Initiate Hardcopy.vi
3.7.1	04/2005	Modifications: Code maintenance: I/O conversion specification fixed:
3.7.0	02/2005	Modifications: - Error Checking and Instrument Version Checking implemented.
3.6.4	01/2004	Modifications: - fixed RSFSEx Adjust Channel Power Settings.vi, missing parameter Adju
3.6.3	06/2003	Modifications: - Documentation improvements
3.6.2	04/2003	Modifications: - Documentation improvements
3.6	01/2003	Modifications: - Included support for RSIB interface - RSFSEx Read Trace IQ Data.vi is improved This driver supports the options: B5 ,B7-B13, B21, K10, K11, K20, K21, K30, K31, FSIQ-K70, FSIQ-K71, FSIQ- K72, FSIQ- K73, ESIB-B
3.5	03/2002	Modifications: Added support for latest versions of firmware and for new options FSE-K30, FSE-K31 and FSIQ-K73. - Changed VIs: RSFSEx Channel Power Standard.vi RSFSEx BTS Power Settings.vi RSFSEx MS Power Settings.vi RSFSEx GSM Spectrum Mod Range.vi RSFSEx Configure WCDPower Measurement.vi RSFSEx WCDP Measurement Mode.vi RSFSEx CDP Set to Standard.vi RSFSEx CDP Inactive Channel Treshold.vi RSFSEx CDP Side Band.vi RSFSEx CDP Fast Mode.vi RSFSEx CDP Spreading Factor.vi RSFSEx CDP Code Number.vi RSFSEx CDP CPICH Slot.vi RSFSEx CDP Scrambling Code.vi RSFSEx CDP Normalize.vi

History for FSE spectrum analyzers FSEA, FSEB, FSEK, FSEM, FSIQ and for EMI Test Receiver ESIB

Revision	Date	Note
		RSFSEx Memory Select Items.vi RSFSEx BTS Set ARFCN.vi RSFSEx MS Set ARFCN.vi RSFSEx BTS Default Settings.vi RSFSEx MS Default Settings.vi RSFSEx Get Burst Limit Check.vi RSFSEx CDP Level Auto Adjust.vi RSFSEx CDP Marker To.vi RSFSEx Get CDP Crest Factor.vi RSFSEx Read WCDMA Trace Data.vi RSFSEx Read ABIT Stream Data.vi RSFSEx Read Burst Power.vi RSFSEx Fetch Burst Power.vi - New VIs: RSFSEx Trace Averaging Method.vi RSFSEx Trace ASCII Comment.vi RSFSEx Modulation Summary Units.vi RSFSEx GSM Burst Phase Freq Condition.vi RSFSEx Configure WCDPower MS Meas.vi RSFSEx CDP Preference.vi RSFSEx CDP Sync Type.vi RSFSEx CDP Signal Mapping.vi RSFSEx CDP Antenna Type.vi RSFSEx WCDP Channel Table Name.vi RSFSEx WCDP Channel Table Copy.vi RSFSEx WCDP Channel Table Delete.vi RSFSEx WCDP Channel Table Restore.vi RSFSEx WCDP Channel Table Comment.vi RSFSEx WCDP Channel Table Data.vi RSFSEx WCDP Channel Table Catalog.vi RSFSEx WCDP MS Channel Table.vi RSFSEx WCDP MS Channel Table File.vi RSFSEx WCDP MS Channel Table Name.vi RSFSEx WCDP MS Channel Table Copy.vi RSFSEx WCDP MS Channel Table Delete.vi RSFSEx WCDP MS Channel Table Comment.vi RSFSEx WCDP MS Channel Table Data.vi RSFSEx WCDP MS Channel Table Catalog.vi RSFSEx Stat Measurement Samples.vi RSFSEx Stat Measurement Scaling.vi RSFSEx Stat Percent Marker.vi RSFSEx SEM Limit Line.vi RSFSEx Get Activated Limit Lines.vi RSFSEx WCDPower MS Mode.vi RSFSEx Get WCDP MS Measurement.vi RSFSEx Read WCDP Trace Data.vi RSFSEx Read Burst Status Values.vi RSFSEx Read Burst Power Individual.vi RSFSEx Fetch Burst Status Values.vi RSFSEx Fetch Burst Power Individual.vi RSFSEx Fetch Spectrum Reference.vi RSFSEx Fetch PTemplate Reference.vi RSFSEx Firmware Update.vi

Remote control via LAN

This driver also supports remote control via LAN. For more information see application note [1EF47](#)