

LabVIEW Driver History for the R&S®CMW Wideband Radio Communication Tester

Products:

| R&S®CMX500



| R&S®CMP200



Driver history for LabVIEW

Table of Contents

1	<i>Installation of the LabVIEW driver</i>	3
1.1	Installation on a Windows machine	3
1.2	Installation on a non-Windows machine	4
2	<i>RsCmxpBase – Base Unit (1.0.0)</i>	5
3	<i>RsCmxpGprf – General Purpose RF (1.0.0)</i>	6
4	<i>RsCmpUwbM – Ultra-Wideband Measurement (1.0.0)</i>	7
5	<i>RsCmwxpNrFr1M – New Radio Frequency Range 1 Measurement (1.0.0)</i> 8	
6	<i>RsCmxpNrFr2M – New Radio Frequency Range 2 Measurement (1.0.0)</i> ...	9
7	<i>RsCmxpLteM – LTE Measurement (1.0.0)</i>	10

1 Installation of the LabVIEW driver

Before you start the installer, please close your LabVIEW application.

1.1 Installation on a Windows machine

The driver is distributed as a WinZip self-extracting executable file. Installer supported operation systems: Win7, Win8, Win10.

Preconditions:

- LabVIEW 2015 or newer installed
- Any VISA installed – R&S VISA 5.12.2 or newer / NI VISA 16.0 or newer

When you start the driver WinZip installer, the following steps are being performed:

1. Unpacking of the driver's **instr.lib** and **user.lib** directories content as well as the **Installer.vi** into a temporary folder: **C:\temp\rscmwXXX-lv2015-x.x.x**
The driver is compiled in **LabVIEW 2015 64-bit**. From there you can copy to another location or run the **Installer.vi** manually later. The content of the temporary folder is not deleted after the installation is finished. Starting the same installation again will overwrite the data in this temporary folder.
2. After unpacking, the **Installer.vi** is automatically started in the last opened version of LabVIEW.
In case you have more than one version of LabVIEW installed on your machine, make sure that the last opened LabVIEW version is the one in which you want to use the driver. If that's not the case, cancel the installation at this point, open and close your desired LabVIEW version and run the installer again. You can have the driver installed parallel for more LabVIEW versions by repeating the installation process for each desired version.
3. On the installer options page you have a choice to uncheck the **Mass-compiling** option (**not recommended, because of the driver's performance penalty as well as VIs opening times**) and also you can change the location of the **instr.lib** part of the driver. **user.lib** part must be placed in the default location, otherwise the Express VI configuration will not function.
On this page you also see the actual LabVIEW version.
Hitting **Next** button will first delete the old driver (if it existed), copy the new driver and mass-compile it.
4. The LabVIEW is closed and after starting it again the driver is ready for use.

1.2 Installation on a non-Windows machine

In case you would like to install the driver on a non-Windows machine, use a Windows machine to start the driver's WinZip self-extracting executable file. **This machine does not need to have LabVIEW installed.**

After the **Step 1** from the previous chapter is finished, copy the content of the temporary folder to your target machine and start the **Installer.vi** manually. From that point onwards, the installation process is the same as described in the previous chapter Steps 2, 3, and 4.

2 RsCmxpBase – Base Unit (1.0.0)

Driver history for LabVIEW driver		
Instruments: CMX500, CMP200		
Revision	Date	Note
1.0.0	08/2020	First released Version

3 RsCmxpGprf – General Purpose RF (1.0.0)

Driver history for LabVIEW driver		
Instruments: CMX500, CMP200		
Revision	Date	Note
1.0.0	08/2020	First released Version

4 RsCmpUwbM – Ultra-Wideband Measurement (1.0.0)

Driver history for LabVIEW driver		
Instruments: CMP200		
Revision	Date	Note
1.0.0	08/2020	First released Version

5 RsCmwxpNrFr1M – New Radio Frequency Range 1 Measurement (1.0.0)

Driver history for LabVIEW driver		
Instruments: CMX500, CMP200, CMW500		
Revision	Date	Note
1.0.0	11/2020	First released Version

6 RsCmxpNrFr2M – New Radio Frequency Range 2 Measurement (1.0.0)

Driver history for LabVIEW driver		
Instruments: CMX500, CMP200		
Revision	Date	Note
1.0.0	08/2020	First released Version

7 RsCmxpLteM – LTE Measurement (1.0.0)

Driver history for LabVIEW driver		
Instruments: CMX500, CMP200		
Revision	Date	Note
1.0.0	10/2020	First released Version

About Rohde & Schwarz

Rohde & Schwarz is an independent group of companies specializing in electronics. It is a leading supplier of solutions in the fields of test and measurement, broadcasting, radiomonitoring and radiolocation, as well as secure communications. Established more than 80 years ago, Rohde & Schwarz has a global presence and a dedicated service network in over 70 countries. Company headquarters are in Munich, Germany.

Regional contact

Europe, Africa, Middle East

+49 1805 12 42 42* or +49 89 4129 137 74

customersupport@rohde-schwarz.com

North America

1-888-TEST-RSA (1-888-837-8772)

customer.support@rsa.rohde-schwarz.com

Latin America

+1-410-910-7988

customersupport.la@rohde-schwarz.com

Asia/Pacific

+65 65 13 04 88

customersupport.asia@rohde-schwarz.com

Certified Quality System
ISO 9001
DQS REG. NO 1954 QM

Rohde & Schwarz GmbH & Co. KG

Mühlendorfstraße 15 | D - 81671 München

Phone + 49 89 4129 - 0 | Fax + 49 89 4129 - 13777

www.rohde-schwarz.com